

User Manual

SV-iV5

AC Drives

5.5–37kW (200V) / 5.5–220kW (400V)



Safety Instructions

- Read this manual carefully before Installing, wiring, operating, servicing or inspecting the drive.
- Keep this manual within easy reach for quick reference.

Thank you for purchasing LS Vector Drives!

SAFETY INSTRUCTIONS

To prevent injury and property damage, follow these instructions. Incorrect operation due to ignoring instructions will cause harm or damage. The seriousness of which is indicated by the following symbols.



DANGER

This symbol indicates the instant death or serious injury if you don't follow instructions



WARNING

This symbol indicates the possibility of death or serious injury



CAUTION

This symbol indicates the possibility of injury or damage to property

■ The meaning of each symbol in this manual and on your equipment is as follows.



This is the safety alert symbol.

Read and follow instructions carefully to avoid dangerous situation.



This symbol alerts the user to the presence of "dangerous voltage" inside the product that might cause harm or electric shock.

■ After reading this manual, keep it in the place that the user always can contact easily.

■ This manual should be given to the person who actually uses the products and is responsible for their maintenance.



WARNING

- **Do not remove the cover while power is applied or the unit is in operation.**
Otherwise, electric shock could occur.
- **Do not run the inverter with the front cover removed.**

Otherwise, you may get an electric shock due to high voltage terminals or charged capacitor exposure.

- **Do not remove the cover except for periodic inspections or wiring, even if the input power is not applied.**
Otherwise, you may access the charged circuits and get an electric shock.
- **Wiring and periodic inspections should be performed at least 10 minutes after disconnecting the input power and after checking the DC link voltage is discharged with a meter (below DC 30V).**
Otherwise, you may get an electric shock.
- **Operate the switches with dry hands.**
Otherwise, you may get an electric shock.
- **Do not use the cable when its insulating tube is damaged.**
Otherwise, you may get an electric shock.
- **Do not subject the cables to scratches, excessive stress, heavy loads or pinching.**
Otherwise, you may get an electric shock.



CAUTION

- **Install the inverter on a non-flammable surface. Do not place flammable material nearby.**
Otherwise, fire could occur.
- **Disconnect the input power if the inverter gets damaged.**
Otherwise, it could result in a secondary accident and fire.
- **After the input power is applied or removed, the inverter will remain hot for a couple of minutes.**
Otherwise, you may get bodily injuries such as skin-burn or damage.
- **Do not apply power to a damaged inverter or to an inverter with parts missing even if the installation is complete.**
Otherwise, electric shock could occur.
- **Do not allow lint, paper, wood chips, dust, metallic chips or**

other foreign matter into the drive.
Otherwise, fire or accident could occur.

OPERATING PRECAUTIONS

1) Transport and Installation

- Be sure to carry inverter in a proper way suitable for its weight, or it may result in damage to inverter.
- Do not pile up inverters above allowable limit.
- Be sure to install the inverter as directed in this instruction manual.
- Do not turn off the power supply to the damaged inverter.
- Do not open the front cover while carrying the inverter.
- Do not place the heavy material on the inverter.
- The direction of installation should be observed properly as criterions specified in this manual show.
- Make sure that you should not put screw, metal material, water, oil and the inflammable something else.
- Keep in mind that inverter is very vulnerable to drop from the mid air and strong shock.
- Be certain to use the inverter under the following conditions.

Environment	Ambient temperature	- 10 ~ 40 °C (Non-frozen)
	Humidity	Below 90% RH (Dewdrop should not be formed)
	Storage temperature	- 20 ~ 65 °C
	Ambient condition	Free of corrosive gas, inflammable gas, oil-waste and dust
	Altitude/vibration	Below 1000m above sea level, Below 5.9m/sec² (=0.6g)

2) Wiring works

- Do not connect phase-leading capacitors, surge filter, radio noise filter to the output of inverter.
- Output terminals (terminals named U, V, W respectively) should be connected in a proper phase sequence.

3) Adjustment before starting trial operation

- Be sure to check relevant parameters for the application before starting trial operation.

4) Directions

- Be sure not to approach the machine when retry function is selected. The machine may start working suddenly.
- Stop key on the keypad should be set to be in use. For safety, additional emergency stop circuit should be required.
- Inverter restarts if alarm condition is cleared while FX/RX signal is on. Therefore, be sure to operate the alarm reset switch after checking if FX/RX signal is off.
- Never modify the inverter for inappropriate use.
- Motor may not be protected by electronic thermal protection.

- Do not start or stop the inverter by the magnetic contactor installed at the input of inverter.
- Noise filter should be used for the minimization of troubles by electro-magnetic noise. Electronic equipments close to the inverter should be protected against the damage caused by troubles.
- Be sure to install the AC reactor at the input of inverter in case of input voltage unbalance. Otherwise, generator or phase-leading capacitors may be destroyed by the harmonic current from inverter.
- If 400V class motor is used with the inverter, insulation-enforced motor should be used or countermeasures against the suppression of micro-surge voltage generated by the inverter should be carried out. Otherwise, micro-surge voltage is generated across input terminal for the motor and this voltage lowers allowable insulation break-down voltage and then, may cause the destruction of the motor.
- Be sure to set the parameters once more, in case of initialization of parameters, all values of parameters is set to values of factory setting.
- High speed operation can be set easily, therefore be sure to check the performance of motor or machine before changing parameter value.
- DC braking function cannot produce a zero-servo torque. If required, additional equipment should be installed.
- When inverter trip or emergency stop (BX) occurs without keypad connected, LED on the control board will blink by the interval of 0.5 sec. But LED will blink by 1 sec when keypad is connected.

5) Countermeasure against malfunction troubles

- If inverter is damaged and then gets into uncontrollable situation, the machine may lead to the dangerous situation, therefore to avoid this situation, be sure to install the additional equipments such as brake.

6) Maintenance, inspection and parts replacement

- Do not perform the megger (insulation resistance check) test on the control board.
- Please refer to Chapter 7 (intervals for parts replacement).

7) Disposal

- Handle the inverter as an industrial waste when disposing of it.

8) General instructions

Many of the diagrams and drawings in this instruction manual show the inverter without a circuit breaker, a cover or partially open. Never run the inverter like this. Always place the cover with circuit breakers and follow this instruction manual when operating the inverter.

Safety Instructions	-----	i
Chapter 1 Introduction		
1.1 Key features	-----	1
1.2 Inverter nameplate and model	-----	2
Chapter 2 Specifications		
2.1 Standard specification	-----	3
2.2 Common specification	-----	4
Chapter 3 Installation and wiring		
3.1 Wiring precaution	-----	5
3.2 Basic wiring	-----	7
3.3 Power circuit terminal	-----	9
3.4 Control circuit terminal	-----	14
3.4.1 Control terminal layout	-----	14
3.4.2 Control terminal description	-----	14
3.4.3 Wiring Control terminal	-----	16
3.4.4 Caution on Encoder wiring	-----	16
3.4.5 Wiring and jumper setting for Complementary or Open Collector	-----	17
3.4.6 Wiring and jumper setting for Line Drive	-----	17
3.4.7 Jumper setting for Analog Input	-----	18
Chapter 4 Trial Operation		
4.1 Keypad description	-----	19
4.2 Keypad display description	-----	20
4.3 Setting of Parameter values	-----	21
4.4 Parameter group	-----	22
4.5 Auto-Tuning	-----	24
4.5.1 Motor and Encoder parameter setting	-----	24
4.5.2 Rotational Auto-tuning	-----	25
4.5.3 Standstill Auto-tuning	-----	27
4.6 Pulse encoder check	-----	28
4.7 Operation by Keypad	-----	29
4.8 Operation by Terminal	-----	30
Chapter 5 Parameter List		
5.1 Display group (DIS_[][])	-----	33
5.2 Input/output group (I/O_[][])	-----	34
5.3 Parameter group (PAR_[][])	-----	37
5.4 Function group (FUN_[][])	-----	38
5.5 Control group (CON_[][])	-----	39
5.6 User group (USR_[][])	-----	40
5.7 2 nd function group (2nd_[][])	-----	41
Chapter 6 Parameter description		
6.1 Display group (DIS_[][])	-----	42
6.1.1 DIS_00(Motor control status monitoring)	-----	42
6.1.2 DIS_01 ~ 03(user display 1, 2, 3)	-----	42
6.1.3 DIS_04(Process PID Controller)	-----	44
6.1.4 DIS_05(Fault display)	-----	44
6.1.5 DIS_06(User group display selection)	-----	45

6.2 Input/output group (I/O_[][])	46
6.2.1 Jump code (I/O_00)	46
6.2.2 Multi-function Input Terminal	46
1) I/O_01 ~ 07(Multi-function input terminal P1 ~ P7 define)	46
2) I/O_08(Reversal of Multi-function input terminal)	57
3) I/O_09(Low Pass Filter Time Constant for the Terminals)	57
4) I/O_10Inversion of Multi-function aux contact output	57
6.2.3 Multi-function analog input	58
1) I/O_11 ~ 25	58
(Definition of Multi-function analog input terminal, Gain, Bias, LPF time constant)	58
2) Adjusting Gain and Bias by Keypad	60
6.2.4 Multi Function Outputs (MFO)	61
1) I/O_41 ~ 43	61
(Multi-function aux contact output (AX1 ~ AX2) and Open collector (OC1) output setting).....	61
2) I/O_46(Fault Output Relay (30A, 30B, 30C))	66
3) I/O_59 ~ 61(Overload trip enable, level, time)	66
6.2.5 Analog output	66
6.3 3 Parameter group (PAR_[][])	68
6.3.1 Jump code (PAR_00)	68
6.3.2 Parameter group function	68
1) PAR_01(Parameter initialize)	68
2) PAR_02 ~ 03(All Parameter Read/Write)	68
3) PAR_04(Parameter Lock)	69
4) PAR_05(Password)	69
6.3.3 Motor parameters setting	70
1) PAR_07(Motor rating setting), PAR_08(Motor cap. Selection of user)	70
2) PAR_09(Motor Cooling method)	70
3) PAR_10 ~ 13(pulse number of Encoder, direction, Error detection, LPF)	70
6.3.4 PAR_14, PAR_15(Encoder error detection time, encoder error reference speed)	71
6.3.5 Auto-tuning	73
1) Motor and Encoder parameters setting for Auto-tuning	73
2) Rotational Auto-tuning	74
3) Standstill Auto-tuning	76
4) Motor parameters	78
5) Auto tuning error message	79
6.4 Function group (FUN_[][])	81
6.4.1 Jump code (FUN_00)	81
6.4.2 Operating method select	81
1) FUN_01(RUN/STOP source select)	81
2) FUN_02(Speed setting method)	82
3) FUN_03(Stop method)	82
6.4.3 FUN_04(Motor Max Speed Reference)	82
6.4.4 Multi-step speed and Dwell Speed setting methods	82
1) FUN_12 ~ 19(Multi-step speed 0 ~ 7)	82
2) FUN_20(JOG speed command)	82
3) FUN_21 ~ FUN_22(Dwell Speed, Time)	83
6.4.5 Accel/Decel pattern and time selection	84
1) FUN_33(Accel/Decel reference speed)	84
2) FUN_40 ~ 47(Accel/Decel time 1 ~ 4)	84
3) FUN_36 ~ 39(S curve ratio during Accel/Decel 1 ~ 2)	85
4) FUN_48(Deceleration time for zero speed selection)	87
5) FUN_49(Zero speed deceleration time)	87
6) FUN_51(Decel time when BX is ON)	88
7) FUN_52(Pre-excitation)	88
8) FUN_53(Hold Time)	88
6.4.6 Electronic Thermal (Motor I^2T) Selection	89

6.4.7 Inverter switching frequency select	90
1) FUN_57(Inverter switching frequency select)	90
2) Setting range and factory setting of switching frequency	90
6.4.8 Power ON Start Selection (FUN_58)	91
6.4.9 Restart after fault reset (FUN_59)	91
6.4.10 Restart After Fault Reset	92
1) FUN_60(Number of auto restart try)	92
2) FUN_61(Delay time before Auto restart)	92
6.4.11 Wait time for restart upon stop	93
6.4.12 Overspeed error detection (FUN_63,FUN_64)	93
6.5 Control group (CON_[][])	94
6.5.1 Jump code (CON_00)	94
6.5.2 Control mode select (CON_01)	94
6.5.3 Application mode (CON_02)	94
6.5.4 Automatic Speed Regulator : ASR	94
1) CON_05(ASR LPF Time Constant 1)	94
2) CON_08(ASR LPF Time Constant 2)	94
3) CON_03 ~ 04(ASR PI Gain 1)	95
4) CON_06 ~ 07(ASR PI Gain 2)	95
5) CON_09(Ramp time for ASR gain Transfer)	95
6) CON_10(Motor Speed at the time of ASR Gain Transfer)	95
6.5.5 Process PID Control	97
6.5.6 Draw Control	99
6.5.7 Droop Control	101
6.5.8 Torque Control	103
1) CON_26(Torque Reference Source Selection)	103
2) CON_32(Torque Bias Source select)	103
3) CON_35(Torque Balance)	104
4) Torque Bias Enable/Disable	104
5) CON_34(Torque Bias F/F)	104
6) CON_28 ~ 31	
(Torque Limit Define, Torque Limit during FWD RUN /REV RUN/Regenerating)	104
7) Torque Current reference	105
6.5.9 Speed Search (CON_49)	106
6.6 User group (USR_[][])	107
6.6.1 Jump code (USR_00)	107
6.6.2 Macro	107
1) USR_01(Macro Init)	107
2) USR_02(User Save)	107
3) USR_03(User Recall)	107
6.6.3 User code define (USR_04 ~ 67)	107
6.7 2nd group (2nd_[][])	109
6.7.1 Jump code (2nd_00)	109
6.7.2 2nd motor control mode selection (2nd_01)	109
6.7.3 2nd motor speed setting	109
6.7.4 2nd motor parameters related to acceleration and deceleration	110
6.7.5 2nd motor parameters related to the pulse encoder	110
6.7.6 2nd motor parameters	110
6.7.7 2nd motor miscellaneous parameters	110

Chapter	Periodic inspection	
7		
	7.1 Precautions -----	111
	7.2 Check points -----	111
	7.3 Parts replacement -----	112
Chapter	Troubleshooting and maintenance	
8		
	8.1 Fault display -----	113
	8.2 Fault status and history -----	114
	8.3 Fault reset -----	114
	8.4 Troubleshooting -----	115
Appendix		
	A Accessories -----	125
	B Dimensions -----	127
	C Encoder division option card -----	132
	D Braking resistor and braking unit -----	134
	E Control block diagram -----	136

Chapter 1 - Introduction

This instruction manual is designed for **LS STARVERT-iV5 series Vector Control Inverters**, which have excellent characteristics in speed and torque control with pulse encoder mounted on the shaft of 3 phase induction motor, and covers installation, maintenance, wiring and operation for these inverters.


1.1 Key Features

- Current Controlled Vector Control Inverter with Speed Sensor using IGBT as Power Semiconductor Device.
- Tension/Torque Control and Wide Variety of Process Control
- Process PI Control, Draw Control, Droop Control etc.
- Auto-tuning of Motor Parameters for Precise Speed/Torque Control: Rotational/Standstill mode
- Encoder error (H/W and S/W) detection function
- Inverter Application


Application	Applicable Machine/System	Features
Process Control	<ul style="list-style-type: none">● Steel Strip● Paper Mill● Textile● Film● Coater● Printing Machine	Tension Control Wide Range of Speed Control
Hoisting Control	<ul style="list-style-type: none">● Lifts (Elevators)● Parking● Stacker Crane● Crane● Hoist	High Speed Operation High Starting Torque Positioning Wide Range of Speed Control
Machine Control	<ul style="list-style-type: none">● Machine Tool● Wire Drawing● Extruder	High Speed Operation High Starting Torque Positioning
Others	<ul style="list-style-type: none">● Conveyor● Industrial Washing Machine	High Speed Operation Positioning

1.2 Inverter Nameplate and Model

1.2.1 Inverter Nameplate (Example)



1.2.2 Inverter Model Name



Chapter 2 - Specification

2.1 Standard Specification

2.1.1 200V Class

SV[] [] [] iV5-2(DB)		022	037	055	075	110	150	185	220	300	370
Max. applicable motor output ⁽¹⁾	[HP]	3	5	7.5	10	15	20	25	30	40	50
	[kW]	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37
Output	Capacity [kVA] ⁽²⁾	4.5	6.1	9.1	12.2	17.5	22.5	28.2	33.1	46	55
	Rated current [A]	12	16	24	32	46	59	74	88	122	146
	Speed	0 ~ 3600rpm (Vector control)									
	Voltage	200 ~ 230V ⁽³⁾									
Input	Voltage	3 ϕ 200 ~ 230V (-10% ~ +10%)									
	Frequency	50 ~ 60Hz (\pm 5%)									
Inverter weight [kg(lbs)]		6(13)	6(13)	14(30)	14(30)	28(61)	28(61)	28(61)	28(61)	42(93)	42(93)

2.1.2 400V Class

SV[] [] [] iV5-4(DB)		022	037	055	075	110	150	185	220	300	370
Max. applicable motor output ⁽¹⁾	[HP]	3	5	7.5	10	15	20	25	30	40	50
	[kW]	2.2	3.7	5.5	7.5	11	15	18.5	22	30	37
Output	Capacity [kVA] ⁽²⁾	4.5	6.1	9.1	12.2	18.3	22.9	29.7	34.3	46	57
	Rated current [A]	6	8	12	16	24	30	39	45	61	75
	Speed	0 ~ 3600rpm (Vector control)									
	Voltage	380 ~ 480V ⁽³⁾									
Inverter weight [kg(lbs)]		6(13)	6(13)	14(30)	14(30)	28(61)	28(61)	28(61)	28(61)	45(99)	45(99)

SV[] [] [] iV5-4(DB)		450	550	750	900	1100	1320	1600	2200
Max. applicable motor output ⁽¹⁾	[HP]	60	75	100	120	150	175	215	300
	[kW]	45	55	75	90	110	132	160	220
Output	Capacity [kVA] ⁽²⁾	70	85	116	140	170	200	250	329
	Rated Current [A]	91	110	152	183	223	264	325	432
	Speed	0 ~ 3600 rpm (Vector control)							
	Voltage	380 ~ 480V ⁽³⁾							
Inverter weight [kg(lbs)]		63(139)	63(139)	68(150)	98(216)	98(216)	122(269)	122(269)	175(386)
Input	Voltage	3 ϕ 380 ~ 460V (-15% ~ +10%) ⁽⁴⁾							
	Frequency	50 ~ 60 Hz (\pm 5%)							

Note)

1. It represents the output capacity of maximum applicable motor in case LG-OTIS 4- pole motor is used.
 2. Rated capacity ($= \sqrt{3} \times V \times I$) is calculated based on 220V for 200V class, 440V for 400V class.
 3. Maximum output voltage cannot be generated above specified input voltage.
 4. Derate the rated current by 10% when the input voltage is in the range of 507 ~ 528V.
- ※ The electrical specifications of the MD type (2.2~22kW Class) are the same as the above.

SV[] [] [] iV5-2/4DB(MD)	055	075	110	150	185	220
Inverter weight [kg(lbs)]	7.7(16.9)	7.7(16.9)	13.7(30.2)	13.7(30.2)	20.3(44.7)	20.3(44.7)

2.2 Common Specification

Items		Detailed Specification
Inverter type		Voltage source inverter using IGBT
Control	Control method	<ul style="list-style-type: none"> Field oriented vector control inverter using Encoder feedback (5.5 ~ 220kW)
	Speed control accuracy	<ul style="list-style-type: none"> Analog setting: $\pm 0.2\%$ ($25 \pm 10^\circ\text{C}$) of max. Speed Digital setting : $\pm 0.01\%$ ($0 \sim 40^\circ\text{C}$) of max. Speed
	Speed setting resolution	<ul style="list-style-type: none"> Analog setting: $\pm 0.005\%$ of maximum Speed Digital setting: 0.01% of maximum Speed
	Cut-off frequency of ASR	50Hz
	Torque control accuracy	3%
	Accel/ Decel	Time setting
		Combination
		Pattern
Braking	Braking method	Dynamic braking using external resistors
	Braking torque	150%
	Braking resistor	External braking resistor should be provided.
Input	Speed settings	<ul style="list-style-type: none"> Digital setting via keypad Multi-step speed setting by input terminal selection Analog input settings of $-10 \sim 10\text{V}$ or $4 \sim 20\text{mA}$ Remote setting by option card
	Analog input	<ul style="list-style-type: none"> 3 channels (AI1, AI2, AI3*) $-10 \sim 10\text{V}$, $0 \sim 10\text{V}$, $10 \sim 0\text{V}$, $40 \sim 20\text{mA}$, $20 \sim 4\text{mA}$, (*AI3: $-10 \sim 10\text{V}$, $0 \sim 10\text{V}$, $10 \sim 0\text{V}$, Motor NTC only) Selectable among 9 different user-defined functions AI3 (Motor NTC): only available with a LG-OTIS motor used.
	Contact input	<ul style="list-style-type: none"> FX, RX, BX, RST, P1 ~ P7 Selectable among 29 different user-defined input functions
Output	Analog output	<ul style="list-style-type: none"> 2 channels (AO1, AO2) $-10\text{V} \sim 10\text{V}$ Voltage output Selectable among 31 different user-defined functions
	Contact output	<ul style="list-style-type: none"> 2 channels (1A-1B, 2A-2B) Fault alarm relay: 1 channel (30A-30C, 30B-30C)
	Open Collector	1 Channel (OC1/EG)
Protection		Overcurrent, Overvoltage, Low voltage, Inverter overheat, Inverter thermal sensor malfunction, Motor overheat, Motor thermal sensor malfunction, Overspeed, Instantaneous IGBT gate block (BX), Fuse blown open, External Trip, Pulse encoder malfunction, Electronic thermal function, Inverter overload, Ground fault current, IGBT short, Communication error
Environment	Installation condition	Indoor, Free of Corrosive gas and Direct sunlight
	Ambient temperature	$-10 \sim 40^\circ\text{C}$ (Non-frozen condition)
	Humidity	Below RH 90% (Dewdrop should not be formed)
	Cooling method	Forced ventilation by cooling fan
	Altitude, Vibration	Below 1000m above sea level, Below 5.9m/s^2 ($=0.6\text{G}$)

Chapter 3 – Installation and wiring

This chapter describes general items for the installation and wiring of an inverter and includes instruction for wiring to power terminal and control one and caution in case of wiring, and also explains the function of each terminal for both power and control.


3.1 Caution on installation

3.1.1 Do not install the inverter in a location where excessive vibration is present.

Be cautious when installing on presses or moving equipment.

3.1.2 Caution on Ambient Temperature

Ambient temperature greatly affects inverter lifetime, therefore be sure to keep the ambient temperature of installation location at -10 to 40°C .




3.1.3 Install the inverter on the unflammable material. The inverter operates at high-temperature.

3.1.4 Avoid a humid and hot location.

3.1.5 Install the inverter in a location free of oil mist and dust.

Totally enclosed panel can be used to protect the inverter against that materials.

3.1.6 Secure the installation space enough to protect the inverter against the overheating.




3.1.7 Special care should be taken in case the inverter is to be installed in the panel.

In case more than 2 inverters are to be installed or ventilation fan is to be installed in the panel, make sure that inverter and ventilation fan is properly installed. If they are poorly installed, it causes the increase of an ambient temperature and less effective ventilation. Therefore, be sure to keep the ambient temperature of inverter below the allowable temperature.

3.1.8 Install the inverter tightly not to get loose using proper sized bolt or screw.

3.2 Basic Wiring

- SV055, 075, 110, 150, 185, 220iV5-2(DB)
- SV055, 075, 110, 150, 185, 220iV5-4(DB)




Note) ● : Main circuit, ○ : Control circuit

3. Installation and wiring

■ SV300, 370iV5-2

SV300, 370, 450, 550, 750, 900, 1100, 1320, 1600, 2200iV5-4




Note) ●: Main circuit, ○: Control circuit

3.3 Power Circuit Terminal


- SV022, 037, 055, 075, 110, 150, 185, 220iV5-2(DB)
SV022, 037, 055, 075, 110, 150, 185, 220iV5-4(DB)



- SV300, 370iV5-2
SV300, 370, 450, 550, 750iV5-4



- SV900, 1100, 1320, 1600, 2200iV5-4




3.3.1 Power Circuit Terminal Description


Name	Function	Description
R, S, T	3 Phase input power supply	Connected to 3 phase input power supply 1) 200V Class : 200 ~ 230V, 50/60Hz 2) 400V Class : 380 ~ 480V, 50/60Hz
U, V, W	Inverter Output	Connected to 3 phase induction motor
G	Grounding	Used for inverter frame earth
B1, B2	Braking Resistor	Connected to braking resistor
P1, P2	DC Reator and DB Unit	Used for DC Reactor, DB Unit and DC link common connection
N	DB Unit	Used for DB Unit and DC link common connection

3.3.2 Cautions to be required for wiring to Power Circuit Terminal

- ① Connect terminals (R, S and T) to 3 phase input power supply after checking inverter nameplate attached on the inverter. Never connect terminals (U, V and W) to 3 phase input power supply. It results in lethal damage to the inverter.



- ② Never connect the phase advancing capacitor to the inverter output. If already installed, remove the phase advancing capacitor clearly.



3. Installation and wiring

- ③ Cable between inverter output and motor should be less than 30m long. If cable gets long, surge voltage appears across motor terminals depending on the cable parameters. Especially, in 400V class motor case, insulation withstanding voltage may be decreased. Use an insulation-enforced motor when 400V class motor is used.
- ④ Crimp terminal with insulation cap should be used for the input power supply and the motor.
- ⑤ After finishing wiring, be certain to remove all the wire or cable scraps inside the inverter.
- ⑥ Use the shield cable or twist-paired wire for control circuit terminal. Do not put them into the same wiring duct for the power terminal.
- ⑦ When wiring is changed after operating the inverter, be sure to check LCD window on the keypad or charge lamp is turned off. Capacitors inside inverter are charged with high voltage and it may result in lethal injury.
- ⑧ Below 22kW inverter, B1 and B2 on the power terminal should not be connected to anything else other than DB resistors.

3.3.3 Main Power Circuit Wire Sizes and Grounding Wire Size

① Main Power Circuit Wire Sizes

If wiring for the main power terminal is not performed properly, it may cause severe damage to inverter or lethal injury to inverter operator. **Be sure to use 600V, 75°C copper wire.**

Inverter Capacity		Terminal screw size	Screw Torque ¹ (Kgf.cm)	Ring Terminals		Wire Size			
						mm ²		AWG	
				R, S, T	U, V, W	R, S, T	U, V, W	R, S, T	U, V, W
200V	2.2kW	M4	15	2-4	2-4	2	2	14	14
	3.7kW	M4	15	2-4	2-4	3.5	3.5	12	12
	5.5 kW	M5	15	5.5-5	5.5-5	5.5	5.5	10	10
	7.5 kW	M5	15	14-5	8-5	8	8	8	8
	11 kW	M6	26	14-5	14-5	14	14	6	6
	15 kW	M6	26	22-6	22-6	22	22	4	4
	18.5 kW	M8	45	38-8	38-8	30	30	2	2
	22 kW	M8	45	38-8	38-8	38	30	2	2
400V	30/37 kW	M8	100	60-8	60-8	60	60	1/0	1/0
	2.2/3.7kW	M4	15	2-4	2-4	2	2	14	14
	5.5 kW	M5	15	5.5-5	5.5-5	3.5	2	12	14
	7.5 kW	M5	15	14-5	8-5	3.5	3.5	12	12
	11 kW	M6	26	14-5	14-5	5.5	5.5	10	10
	15 kW	M6	26	22-6	22-6	14	8	6	8
	18.5 kW	M8	45	38-8	38-8	14	8	6	8
	22 kW	M8	45	38-8	38-8	22	14	4	6
	30/37 kW	M8	100	60-8	60-8	22	22	4	4
	45/55 kW	M8	100	38-8	38-8	38	38	2	2
	75 kW	M8	100	60-8	60-8	60	60	1/0	1/0
	90 kW	M12	300	60-12	60-12	60	60	1/0	1/0
	110 kW	M12	300	80-12	80-12	80	80	3/0	3/0
	132/160 kW	M12	300	100-12	100-12	100	100	4/0	4/0
	220 kW	M12	300	200-12	200-12	2 x 100	2 x 100	2 x 4/0	2 x 4/0

3. Installation and wiring


- 1) Apply the rated torque to terminal screws. Loose screws can cause of short circuit or malfunction.
Tightening the screws too much can damage the terminals and cause a short circuit or malfunction.

② Grounding Wire Size and Caution to be taken


- Be sure to ground the motor and the inverter to prevent electric shock injury. (200V class: ground impedance 100Ω , 400V class: ground impedance 10Ω)
- Connect the inverter ground to the ground terminal exclusively used for the inverter.
- It is strongly recommended that as thick a grounding wire as possible be used and wire be short.

Motor Capacity	Ground wire size(mm ²)	
	200V Class	400V Class
5.5 ~ 7.5 kW	5.5	3.5
11 ~ 15 kW	14	8
18.5 ~ 22 kW	22	14
30 ~ 37 kW	22	14
45 ~ 75 kW	-	22
90 ~ 132 kW	-	38
160 ~ 220 kW	-	60


3.3.4 Wiring DC Reactor (Option) (30kW and higher)



3.3.5 Wiring DB Unit (Option) (30kW and higher)




3.3.6 Wiring guide when using both of DC reactor (Option) and DB Unit(option) (30kW and higher)



3.4 Control Circuit Terminal

3.4.1 Control Terminal Layout



3.4.2 Control Circuit Terminal Function Description


Item	Name	Function	Description
Contact Input	FX	Forward Run Command	<ul style="list-style-type: none"> Forward/Reverse RUN Command is ON when closed to CM separately. Motor stops when FX/RX is ON or Off at the same time.
	RX	Reverse Run Command	
	BX	Emergency Stop	<ul style="list-style-type: none"> ON when closed to CM, FREERUN Stop and Deceleration stop. It does not trigger fault alarm signal.
	RST	Fault Reset	Resets when fault condition is cancelled.
	P1(MM0)	Multi-function input contact	<ul style="list-style-type: none"> 1 function can be selected among 27 different functions shown below. (Multi-step speed 1 / 2 / 3, Jog, MOP Up / Down / Save / Clear, Analog Hold, Main Drive, 2nd function, Accel./Decel. Time selection, 3 Wire RUN, External trip (B contact), Power failure prevention, Reverse rotation prevention, Process PI Disable, Timer input, Soft start cancel, ASR PI Gain switch-over, ASR P/PI switch-over, Flux command value switch-over, Pre-excitation, Speed/Torque control, Torque limit ON/Off, Torque bias ON/Off)
	P2(MM1)		
	P3(AT0)		
	P4(FHM)		
	P5(BAT)		
	P6(BRC)		
	P7(MCC)		
	CM	COMMON	<ul style="list-style-type: none"> On when each contact is tied to CM.
Analog Input	VREF	Power supply for analog setting	<ul style="list-style-type: none"> Reference voltage by variable resistor (+ 10V) : 10kΩ
	A11	Voltage/ Current Signal Input	<ul style="list-style-type: none"> Voltage signal input (-10 ~ 10V), current signal input (4 ~ 20mA), Motor NTC selectable via Multi-function Analog input. Selectable among following 8 different functions; Speed/Torque/Flux command, Torque bias, Torque limit, Process PI controller command, Process PI controller feedback value, Draw command, Motor NTC input) Jumper setting in Voltage Input: Closed (Jumper connected as Default) <ul style="list-style-type: none"> → A11, A12: Open (Jumper disconnected), A13: Switch set on left side Jumper setting in Current Input <ul style="list-style-type: none"> → A11, A12: Short Motor NTC (When using LG-OTIS Motor Only) <ul style="list-style-type: none"> → A13: switch set on right side.
	A12		
	A13	Voltage/Motor NTC Input	
	5G	COMMON	<ul style="list-style-type: none"> COMMON terminal for Analog input

3. Installation and wiring

Item	Name	Function	Description	
Encoder Input	PE	P/S (Power supply) for Pulse Encoder	+5V	
	5G		0V	
	A+	Encoder A-phase signal	<ul style="list-style-type: none">A, B signal for Line Drive Type Encoder. Short P5 pin of JP2 on I/O PCB and set JP1 switch to LD for the use of Line Drive. ※ Jumpered as default	
	A-			
	B+	Encoder B-phase signal		
	B-			
	PE	P/S for Open Collector	+15V	
	5G		0V	
	PA	Encoder A-phase signal	<ul style="list-style-type: none">A, B signal for Complementary or Open Collector Type Encoder.Short P15 pin of JP2 on I/O PCB and set JP1 switch to “OC”.	
	PB	Encoder B-phase signal		
Encoder Output	RA	Encoder signal output : A-phase	Encoder A, B phase signal output – Open Collector Type	
	GE	Output Common		
	RB	Encoder signal output : B-phase		
	GE	Output Common		
Analog Output	AO1	Analog Output 1	<ul style="list-style-type: none">Output range: -10V ~ +10VSelectable among 31 (Motor speed, speed ref. 1~2, Torque command 1~2, torque current, flux ref., flux current, Inverter output current/voltage, Motor Temp, DC link voltage...)	
	AO2	Analog Output 2		
	5G	COMMON	<ul style="list-style-type: none">COMMON terminal for Analog Output	
Relay output	1A	Multi-function relay output 1 (A Contact)	<ul style="list-style-type: none">Selectable among the following 14 functions; Zero speed detect, Speed detect (Bi-directional), Speed detect (Uni-directional), Speed reach, Speed deviation, Torque detect, On Torque limit, Motor overheat, Inverter overheat, on low voltage, Inverter running, Inverter regenerating, Inverter ready, Timer output	
	1B			
	2A	Multi-function relay output 2 (A Contact)		
	2B			
	OC1	Open Collector Ouput		
	EG			
	30A	Fault alarm A contact		<ul style="list-style-type: none">Outputs when fault occurs.Deactivated in BX condition.
	30B	Fault alarm B contact		
	30C	COMMON		<ul style="list-style-type: none">COMMON for 30A, 30B

3.4.3 Wiring the Control Circuit Terminal

- ① Shield wire or vinyl insulated wire are highly recommended to be used for the control circuit terminal.
- ② Be sure to use twisted shield wire if wiring distance gets too long.
- ③ Wire should be at least as thick as $0.2 \sim 0.8 \text{ mm}^2$ (18 ~ 26 AWG).
- ④ Screwing torque limit should be kept under 5.2 lb-in.
- ⑤ Maximum interrupting capacity of auxiliary contact 1, 2 is of AC 250V/1A, DC 30V/1A.
- ⑥ Maximum interrupting capacity of fault alarm relay A, B contact is of AC 250V/1A, DC 30V/1A.
- ⑦ Open collector output 1, 2 and 3 can be used below maximum of 24V/100mA.
- ⑧ Wires for the control circuit terminal should be separated from ones for the power circuit terminal, if possible and in case wires for both control circuit terminal and the power circuit one cross each other, they should be crossed at right angles (90°).



3.4.4 Caution on wiring pulse encoder

1) Check-up of the coupling and alignment of motor and encoder shaft


- ① Be sure to mount the pulse encoder at the location where it rotates at the same speed as the motor does.
- ② In case there is speed slip between the motor shaft and encoder shaft, the motor may not start or it causes mechanical vibration.
- ③ Poor alignment of motor and encoder shaft results in torque ripple and causes mechanical vibration which has the same frequency as the motor speed at the constant speed region.

2) Wiring the pulse encoder


- ① Be sure to **use twist paired shield wire** and **ground shield wire to screw for earth on the I/O PCB**.
- ② Signal wires should be separated from the power lines, if possible. Electromagnetic noise may affect the pulse encoder output signals.

3. Installation and wiring

3.4.5 Wiring and Jumper Setting for +15V Complementary / Open Collector Type Pulse Encoder



3.4.6 Wiring and Jumper Setting for Line Drive Type Pulse Encoder ※ Jumper provided as default




CAUTION

- NEVER change the jumper setting during inverter run. Otherwise, it may cause inverter trip, adversely affecting the entire system.
Therefore, verify the Jumper is correctly set before operation.

3. Installation and wiring

3.4.7 Jumper Setting for Analog Input (Voltage/Current/Motor NTC Input)

※ Jumper setting as default : Voltage Input (OPEN)



CAUTION

- NEVER change the jumper setting during inverter run. Otherwise, it may cause inverter trip, adversely affecting the entire system.
- Motor NTC input for Analog Input 3 is ONLY available when LG-OTIS Motor is connected.
If user use a motor other than LG-OTIS with different NTC specification and use this function, it will lead to motor overheat and damage to the motor.

Chapter 4 - Trial Operation

4.1 Keypad Operation

LCD Keypad can display up to 32 alphanumeric characters and monitor or set parameter values to operate the inverter and the motor properly. As follows are keypad view and explanation on each key/LED on the keypad.


<Keypad View>



Items	Name	Function	Description
Key	MODE	Mode	Enables to move to the other groups (Initial Screen → IO → PAR → FUN...) and go to the first code in the same group.
	PROG	Program	Enables to modify setting values.
	ENT	Enter	Enables to move to the other groups (Initial Screen ← IO ← PAR ← FUN...) and save the changed setting values.
	▲ (Up)	Up	Moves to the next code or increments setting values.
	▼ (Down)	Down	Moves to the next code or decrements setting values.
	SHIFT/ESC	Shift/ESC	Acts as Shift key in a setting mode and as ESC key in other mode.
	REV	Reverse RUN	Reverse RUN command is enabled.
	STOP/RESET	Stop/Reset	Stop key during inverter operation. Resets fault when inverter returns to normal after fault has occurred.
	FWD	Forward RUN	Forward RUN command is enabled.
LED	(REV)	Reverse RUN	Lit when motor is in reverse revolution. Blinks on acceleration/deceleration, lit in a constant speed
	(STOP/RESET)	Stop/Reset	Lit when the motor stops. Blinks when fault has occurred.
	(FWD)	Forward RUN	Lit when motor is in forward revolution. Blinks on acceleration/deceleration, lit in a constant speed


4.2 Keypad LCD Display

4.2.1 LCD Start-up display



No.	Function	Description
1	Motor speed	Real motor speed in RPM (Revolution Per Minute)
2	Motor control Mode	SPD: Speed control mode TRQ: Torque control mode BX: Emergency stop
3	Generating torque	Displays % ratio to the rated torque of a motor.
4	Output current	Inverter output current in RMS

4.4.2 Group display



No.	Function	Description
1	Parameter group	Displays the name of each parameter group. There are DIS, I/O, PAR, FUN, CON, USR and 2 nd group.
2	Code name	Displays a code name to be set.
3	Code Number	Displays a code name to be set.
4	Code data and unit	Displays a code data and a code unit to be set.

4.3 Setting of Parameter Values

In case inverter is to be in use using a keypad, proper parameter values can be set depending on the load and operation condition. For more detailed information, refer to Chapter 6.

First, move on to the code in a group where is intended to change parameter value. cursor (■) blinks by pressing [PROG] key. Parameter value can be set using (SHIFT/ESC)], [▲(Up)] and [▼(Down)] keys and then can be saved by entering [ENT] key.

Note) In some cases, data will not be changed for the following two reasons.

- * Some data cannot be changed during inverter operation.
- * Parameter data lock function is set. (PAR_04 [Parameter Lock] is enabled)

Example) In case the 1st acceleration time is to be changed from 10(sec) to 15(sec), it can be set as shown below.

<div>FUN▶ Acc Time-1 40 10.0 sec</div>	Move on to the code to be changed.
<div>FUN▶ Acc Time-1 40 ■10.0 sec</div>	Press the [PROG] key. Setting mode (Cursor(■) appears and blinks.)
<div>FUN▶ Acc Time-1 40 10.0 sec</div>	Move the Cursor(■) to the position to be changed using [(SHIFT/ESC)] key.
<div>FUN▶ Acc Time-1 40 15.0 sec</div>	Set the data using [▲(Up)], [▼(Down)] key.
<div>FUN▶ Acc Time-1 40 15.0 sec</div>	Save the changed data by pressing [ENT] key. (Cursor disappears.)

4.4 Data Groups


SV-iV5 series inverters use LCD keypad for user's convenience. Data groups are divided into 7 groups for easy access depending on the inverter application.

Name	LCD keypad (on the upper left)	Description
Display group	DIS	Motor speed, Motor control mode, Generating torque, Output current, User selection display, Process PID output/reference/feedback value, Fault display, User group display setting and so on.
I/O group	I/O	Digital input parameters, Digital output parameters, Analog input related parameters, Analog input related parameters and so on.
Parameter group	PAR	Parameter initialization, Parameter read / write / lock /password, Motor related constants, Auto-tuning and so on.
Function group	FUN	Operating frequency, Operation mode, Stop mode, Acceleration /deceleration time and pattern, Carrier frequency, Electronic thermal selection and so on.
Control group	CON	Control mode, ASR PI gain, Process PID gain, Draw control setting, Droop control related constants, Torque control related constants, V/F control related constants and so on.
User group	USR	User macro function, macro function save, macro function recall
2 nd function group	2nd	2 nd motor control mode, 2 nd motor accel./decel.time, 2 nd motor parameters and so on.

Refer to Chapter 6. Function Description for more details.

- **Group transfer in the keypad**

For transfer to another group, [MODE] key is used and ▲(Up), ▼(Down) key is used to move up and down in the same group.



- User group and 2nd group is omitted.

4.5 Auto-Tuning

Parameters such as stator resistance (R_s), stator leakage inductance (sL), flux current (I_f), rotor time constant (τ_r) and stator self-inductance (L_s) are indispensable for obtaining an excellent control performance in the vector control and are automatically measured and set using auto-tuning function.

- SV-IV5 features two types of Auto-tuning: 1) Rotational Auto Tuning
2) Standstill Auto Tuning


4.5.1 Motor & Encoder parameter setting before Auto-Tuning

The parameters on the nameplate of the motor and the pulse number of encoder should be set before operation.

LCD Display	Description
PAR ► Motor select 07 kW	<ul style="list-style-type: none"> Enter the motor capacity.
PAR ► Enc Pulse 10 [][[]]	<ul style="list-style-type: none"> Set the pulse numbers per revolution of pulse encoder coupled to the motor shaft.
PAR ► Base Speed 17 rpm	<ul style="list-style-type: none"> Set the motor base speed.
PAR ► Rated Volt 18 V	<ul style="list-style-type: none"> Set the rated voltage of the motor. (Voltage value on the name plate)
PAR ► Pole number 19 []	<ul style="list-style-type: none"> Set the number of poles of the motor.
PAR ► Efficiency 20 %	<ul style="list-style-type: none"> Set the efficiency of the motor in the case of Standstill auto tuning mode. Automatically set in the case of Rotational mode.
PAR ► Rated-Slip 21 rpm	<ul style="list-style-type: none"> Set the rated slip speed of the motor. Rated slip = synchronous speed – rated speed
PAR ► Rated-Curr 22 A	<ul style="list-style-type: none"> Set the rated current of the motor.

4.5.2 Rotational Auto-tuning

1) Precautions

 <h2 style="display: inline; margin-left: 10px;">CAUTION</h2>
<p>Be sure to remove the load connected to the motor shaft before performing rotational auto-tuning. Otherwise, it may lead to damage to the motor or bodily injury. DB resistor should be installed because the inverter repeats abrupt Accel/Decel many times to find the motor constant (Tr) during tuning.</p>

2) Rotational Auto-tuning procedure

LCD Display	Description	Tuning Time
PAR ▶ AutoTuneType 23 Rotational	Set it to " Rotational ".	-
PAR ▶ Auto tuning 24 ALL1	Auto-tuning starts when it is set to " ALL1 ".	-
PAR ▶ Auto tuning 24 Enc Testing	Checks whether the encoder wiring is properly done and an encoder works well by rotating the motor at 1500 rpm in forward direction.	30 ~ 35(Sec)
PAR ▶ Auto tuning 24 Rs Tuning	Stator resistance (Rs) is measured without rotating the motor.	10 ~ 20(Sec)
PAR ▶ Auto tuning 24 sL Tuning	The leakage inductance (sL) of the motor is measured without rotating the motor.	5 ~ 20(Sec)
PAR ▶ Auto tuning 24 IF Tuning	The flux current (IF) is measured by rotating the motor at 1500 rpm.	30 ~ 60(Sec)
PAR ▶ Auto tuning 24 Ls Tuning	Stator self-inductance (Ls) is measured by rotating the motor at 1500 rpm.	50 ~ 60(Sec)
PAR ▶ Auto tuning 24 Tr Tuning	Accel/Decel is performed repeatedly to find motor constant (Tr) so that DB Resistor should be connected before starting tuning. Otherwise, "Over Voltage " trip will occur.	20 ~ 60(Sec)

4. Trial Operation

<div>PAR ► Auto tuning 24 None</div> <div>PAR ► Auto tuning 24 [] [] Error</div>	<p>When auto-tuning is complete successfully, "None" is displayed. If error occurs during auto-tuning, "[] [] Error" is displayed. In this case, verify motor parameters and encoder setting is done properly and redo the auto-tuning. If the problem persists, contact LS representative.</p>	<p>Total: 3 ~ 5 (Min.)</p>
--	---	--

- FWD/REV LED on keypad will blink during Auto-tuning.
- If setting PAR_24 (Auto tuning) to " ALL2 ", all procedure is same as "ALL1" except Encoder Testing will be skipped.
- Motor constants of each can be selected and separately tuned.
(Encoder Test, Rs Tuning, Lsigma, Flux Curr, Ls Tuning, Tr Tuning)
- If encoder phase (A, B) or inverter output wiring is switched during Auto-tuning, " Enc AB Chgd " message will be displayed. In this case, changing PAR_11 (Enc Dir Set) setting from " A Phase Lead " to " B Phase Lead " (or oppositely) will erase the need for changing the wiring.

4.5.3 Standstill Auto Tuning

1) Precaution

Be sure to lock the motor shaft using magnetic brake.

2) StandStill Type Auto-tuning procedure

LCD Display	Description	Tuning Time
PAR ► AutoTuneType 23 Standstill	Set the auto-tuning type to " Standstill ".	-
PAR ► Auto tuning 24 ALL1	Auto-tuning starts if ALL1 is set.	-
PAR ► Auto tuning 24 Rs Tuning	Stator resistance (R_s) is measured without rotating the motor.	20-30 Sec
PAR ► Auto tuning 24 sL Tuning	The leakage inductance (sL) of the motor is measured without rotating the motor.	90-150 Sec
PAR ► Auto tuning 24 If/Tr/Ls Tuning	Flux current (IF), rotor time constant (τ_r) and stator self-inductance (Ls) is measured simultaneously without rotating the motor.	40-70 Sec
PAR ► Auto tuning 24 None PAR ► Auto tuning 24 [[]] Error	When auto-tuning is complete successfully, "None" is displayed. If error occurs during auto-tuning, "[[]] Error" is displayed. In this case, verify motor parameters and encoder setting is done properly and redo the auto-tuning. If the problem persists, contact LS representative.	Total: 3-5 minutes

- FWD/REV LED on keypad will blink during Auto-tuning.
- Motor constants of each can be selected and separately tuned.
(Rs Tuning, Lsigma, Flux Curr, Ls Tuning, Tr Tuning)

4.6 Pulse Encoder Check

4.6.1 The definition of forward rotation

Forward rotation is of counter-clockwise from the side view of motor shaft.

Motor



4.6.2 Forward rotation check

Be sure to check if positive(+) speed is displayed when inverter power is on and rotates the motor in the forward direction.

+xx.xrpm	SPD
Tq	% A

4.6.3 Reverse rotation check

Be sure to check if negative(-) speed is displayed when inverter power is on and rotates the motor in the reverse direction.

-xx.xrpm	SPD
Tq	% A

- If speed is displayed 0.0 rpm or unchanged or speed polarity is reversed, check if wiring for the pulse encoder is properly done.
- In case the motor shaft cannot be rotated with hands, refer to next chapter.

4.7 Operation by Keypad

4.7.1 Parameter setting for keypad operation to rotate the motor at 100 rpm

FUN▶ Run/Stop Src
01 Keypad

① RUN/STOP command setting by keypad

FUN▶ Spd Ref Sel
02 Keypad1

② Operating speed reference setting by keypad

FUN▶ Speed 0
12 100.0 rpm

③ Operating speed setting

4.7.2 Forward / Reverse Run (FWD / REV)

① Low speed operation

- Check if motor speed is +100 rpm in the start-up LCD screen after pressing [FWD] key.

+100.0rpm SPD
Tq % A

- Check if motor speed is -100 rpm in the start-up LCD screen after pressing [REV] key.

-100.0rpm SPD
Tq % A

- The following table describes the cases of abnormal rotation due to the incorrect wiring of encoder and/or motor.

Command	Rotating direction	Speed display	Torque display	Wiring Status
FX	Forward	+100.0(rpm)	Below +10%	Normal
RX	Reverse	-100.0(rpm)	Below -10%	
FX	Forward	-10 ~ -40(rpm)	150%(Torque Limit)	Encoder wiring reversed
RX	Reverse	10 ~ 40(rpm)	-150%(Torque Limit)	
FX	Reverse	-10 ~ -40(rpm)	150%(Torque Limit)	Phase V and W wiring reversed
RX	Forward	10 ~ 40(rpm)	-150%(Torque Limit)	
FX	Reverse	+100.0(rpm)	Below +10%	Encoder and Motor all reversed
RX	Forward	-100.0(rpm)	Below -10%	

- If A and B phase are reversed, be sure to replace A with B phase wire after checking the pulse encoder wiring. Or user does not need to change wiring if PAR_11(Enc Dir Set) setting value is changed from "A Phase Lead" to "B Phase Lead".
- If Motor wires are reversed, be sure to replace V with W phase wire after checking the motor output wiring.
- Torque display is on the basis of the no load operation.

② High Speed Operation

Change the value of FUN_12 to 1000.0(rpm) and Check the display LCD by pressing [FWD], [REV] keys shown below.

- When pressing [FWD] key;

+1000.0rpm	SPD
Tq	% A

- When pressing [REV] key;

-1000.0rpm	SPD
Tq	% A

4.8 Operation by Control Terminal

4.8.1 Parameter setting

FUN▶	Run/Stop Src
01	Terminal 1

- ① Setting RUN/STOP command by terminal

FUN▶	Spd Ref Sel
02	Analog

- ② Setting Speed reference by Analog

FUN▶	Max Speed
04	1800.0 rpm

- ③ Setting Max. Frequency

I/O▶	Ai1 Define
11	Speed Ref


- ④ Ai1(Analog input terminal) define

I/O▶	Ai1 Source
12	

- ⑤ Ai1(Analog input terminal) Source define : Select
(-10->10V, 0->10V, 10->0V, 4->20mA, 20->4mA)

4.8.2 Wiring example when issuing speed reference using speed potentiometer on AI1 terminal

Connect the potentiometer to VREF, AI1 and 5G as shown below.



4.8.3 Adjusting Ai1 Gain and Bias

① Gain Adjustment

- Apply 10V between Ai1 and 5G (for setting by potentiometer, adjust it to Max).
- Move to I/O_13 (Ai1 Gain) and press [PROG] key. Then the following will be shown as below;

I/O▶	Ai1	xxx.xx %
13	Gain	xxx.xx %

←1) Current input value of Ai1

←2) Current setting value of Ai1 Gain

- Adjust the value by pressing [▲(Up)], [▼(Down)] key until 1) Current input value of Ai1 becomes 100.00 %.

② Bias Adjustment

- Apply 0V between Ai1 and 5G (for setting by potentiometer, adjust it to Min).
- Move to I/O_14 (Ai1 Bias) and press [PROG] key. Then the following will be shown as below;

I/O▶	Ai1	x.xx %
14	Bias	x.xx %

← 3) Current input value of Ai1 Bias

← 4) Current setting value of Ai1 Bias

- Adjust the value by pressing [▲(Up)], [▼(Down)] key until 3) Current input value of Ai1 Bias becomes 0.00 %.

4.8.4 FX / RX Operation

1) FX Operation (Forward Run Command by Control Terminal)

- ① Apply 0V between AI1 and 5G (for setting by potentiometer, adjust it to Min).
- ② Check the motor speed display in display group shows "+0.0rpm" after connecting the terminals FX and CM.
- ③ Increase AI1 voltage little by little and check the speed is increasing (for setting by potentiometer, turn the pot to max. smoothly).
- ④ To stop the motor, disconnect the FX and CM terminal.

2) RX Operation (Reverse Run Command by Control Terminal)

- ① Apply 0V between AI1 and 5G (for setting by potentiometer, adjust it to Min).
- ② Check the motor speed display in display group shows "-0.0rpm" after connecting the terminals RX and CM.
Increase AI1 voltage little by little and check the speed is increasing (for setting by potentiometer, turn the pot to max. smoothly).
- ③ To stop the motor, disconnect the RX and CM terminal.

3) The cases of abnormal rotation due to the wrong wiring of encoder and/or motor during low speed (about 100rpm) operation by control terminal.

Command	Rotating direction	Speed display	Torque display	Wiring Status
FX	Forward	+100.0(rpm)	Below +10%	Normal
RX	Reverse	-100.0(rpm)	Below -10%	
FX	Forward	-10 ~ -40(rpm)	150%(Torque Limit)	Encoder wiring reversed
RX	Reverse	10 ~ 40(rpm)	-150%(Torque Limit)	
FX	Reverse	-10 ~ -40(rpm)	150%(Torque Limit)	Phase V and W wiring reversed
RX	Forward	10 ~ 40(rpm)	-150%(Torque Limit)	
FX	Reverse	+100.0(rpm)	Below +10%	Encoder and Motor all reversed
RX	Forward	-100.0(rpm)	Below -10%	

- If A and B phase are reversed, be sure to replace A with B phase wire after checking the pulse encoder wiring.
- If motor wires are reversed, be sure to replace V with W phase wire after checking the motor output wiring.
- It does not need to change wiring if user changes the setting value of PAR_11(Enc Dir Set) from "A Phase Lead" to "B Phase Lead".
- Torque display is on the basis of the no load operation.

Chapter 5 - Function Code Table

5.1. Display Group (DIS_[][])

CODE NO.	CODE NAME	LCD DISPLAY	SETTING DATA			Adj. During Run(1)	Page
			RANGE	UNIT	DEFAULT		
DIS_00	Motor Speed / Control Mode OutputTorque/Output Current	0.0rpm SPD Tq 0.0% 0.0A					42
DIS_01	User Display 1	Ai1 Value		%	PreRamp Ref	Yes	42-43
		Ai2 Value		%			
		Ai3 Value		%			
		PreRamp Ref		rpm			
		PostRamp Ref		rpm			
		ASR Inp Ref		rpm			
		Output Freq		rpm			
		Motor Speed		rpm			
		Speed Dev		rpm			
		ASR Out		%			
		Torque Bias		%			
		PosTrq Limit		%			
		NegTrq Limit		%			
		RegTrq Limit		%			
		Torque Ref		%			
		IqeRef		A			
		Iqe		A			
		Flux Ref		%			
		Ide Ref		A			
		Ide		A			
		ACR_Q Out		V			
		ACR_D Out		V			
		VdeRef		V			
		VqeRef		V			
		Out Amps RMS		A			
		Out Volt RMS		V			
		Power		kW			
		DC Bus Volt		V			
		Proc PI Ref		%			
		Proc PI F/B		%			
		Proc PI Out		%			
		Mot Temp		deg			
		Inv Temp		deg			
		Inv i2t		%			
		MP Output		%			
		Ctrl Mode					
		S/W Version					
		Run Time					
		Terminal In					
		Terminal Out					
		Run Status					
DIS_02	User Display 2	Same as DIS 01			DC Bus Volt	Yes	42-43
DIS_03	User Display 3	Same as DIS 01			Terminal In	Yes	42-43
DIS_04	Process PID Output Ref / FB	PIDOut 0.0% *xx.x% 0.0%					44
DIS_05	Fault display	Faults					44
DIS_06	User group display setting	Usr Grp Disp	Not Used Dis+User Grp Display ALL		Not Used	Yes	45

1) Yes: possible to set or change the parameters while driving. No: Not available

5.2. I/O Group (I/O_[][])

CODE NO.	CODE NAME	LCD DISPLAY	SETTING DATA			Adj. During Run(1)	Page
			RANGE	UNIT	DEFAULT		
I/O_00	Jump for quick view	Jump Code	1 ~ 71			Yes	46
I/O_01	Multi-function input terminal P1 definition	P1 define	Not Used			No	46-57
			Speed-L				
			Speed-M				
			Speed-H				
			Jog Speed				
			MOP Up				
			MOP Down				
			MOP Clear				
			MOP Save				
			Analog Hold				
			Main Drive				
			2nd Func				
			Xcel-L				
			Xcel-H				
			3-Wire				
			Ext Trip-B				
			Prohibit FWD				
			Prohibit REV				
			Proc PID Dis				
			Timer Input				
			SoftStrtCncl				
			ASR Gain Sel				
			ASR P/PI Sel				
			Flux Ref Sel				
			PreExcite				
			Spd/Trq Sel				
			Use Max Trq				
			Use Trq Bias				
I/O_02	Multi-function input terminal P2 definition	P2 define	Same as 01		Not Used	No	46-57
I/O_03	Multi-function input terminal P3 definition	P3 define	Same as 01		Not Used	No	46-57
I/O_04	Multi-function input terminal P4 definition	P4 define	Same as 01		Not Used	No	46-57
I/O_05	Multi-function input terminal P5 definition	P5 define	Same as 01		Not Used	No	46-57
I/O_06	Multi-function input terminal P6 definition	P6 define	Same as 01		Not Used	No	46-57
I/O_07	Multi-function input terminal P7 definition	P7 define	Same as 01		Not Used	No	46-57
I/O_08	Negative function of multi-function input terminal	Neg Function	0000000 ~ 1111111	bit	0000000	No	57
I/O_09	Multi-function input LPF time constant	Terminal LPF	0 ~ 2000		5	Yes	57
I/O_10	Negative Function of Multi-function Auxiliary Output Terminal	Neg Func. Out	00000 ~ 11111	Bit	00000	No	58
I/O_11	Multi-function analog input Ai1 definition	Ai1 Define	Not Used			No	58-60
			Speed Ref				
			Proc PID Ref				
			Proc PID F/B				
			Draw Ref				
			Torque Ref				
			Flux Ref				
			Torque Bias				
			Torque Limit				
I/O_12	Multi-function analog input Ai1 source	Ai1 Source	-10 → 10V 0 → 10V 10 → 0V 4 → 20mA 20 → 4mA		-10 ~ 10V	Yes	58-60

5. Function code table

CODE NO.	CODE NAME	LCD DISPLAY	SETTING DATA			Adj. During Run(1)	Page
			RANGE	UNIT	DEFAULT		
I/O_13	Multi-function analog input Ai1 gain	Ai1 Gain	0.00 ~ 250.00	%	100.00	Yes	
I/O_14	Multi-function analog input Ai1 bias	Ai1 Bias	-100.00 ~ Ai1 Gain	%	0.00	Yes	
I/O_15	Multi-function analog input Ai1 LPF time constant	Ai1 LPF	0 ~ 2000	ms	0	Yes	
I/O_16	Multi-function analog input Ai2 definition	Ai2 Define	"		Not Used	Yes	
I/O_17	Multi-function analog input Ai2 source	Ai2 Source			-10 ~ 10V	Yes	
I/O_18	Multi-function analog input Ai2 gain	Ai2 Gain			100.00	Yes	
I/O_19	Multi-function analog input Ai2 bias	Ai2 Bias			0.00	Yes	
I/O_20	Multi-function analog input Ai2 LPF time constant	Ai2 LPF			0	Yes	
I/O_21	Multi-function analog input Ai3 definition	Ai3 Define	"		Not Used	Yes	
I/O_22	Multi-function analog input Ai3 source	Ai3 Source			-10 ~ 10V	Yes	
I/O_23	Multi-function analog input Ai3 gain	Ai3 Gain			100.00	Yes	
I/O_24	Multi-function analog input Ai3 bias	Ai3 Bias			0.00	Yes	
I/O_25	Multi-function analog input Ai3 LPF time constant	Ai3 LPF			0	Yes	
I/O_41	Definition of multi-function Auxiliary output (AX1)	AX1 Define	Not Used INV Ready Zero Spd Det Spd Det. Spd Det(ABS) Spd Arrival Timer Out LV Warn Run Regenerating Mot OH Warn Inv OH Warn Spd Agree Trq Det. Trq Lmt Det. Overload Stop Steady		Not Used	Yes	61-65
I/O_42	Definition of multi-function Auxiliary output (AX2)	AX2 Define	Same as 41		Not Used	Yes	
I/O_43	Definition of Multi-function Auxiliary output (OC1)	OC1 Define	Same as 41		Not Used	Yes	
I/O_46	Fault relay mode selection (A, B, C)	Relay Mode	000 ~ 111	bit	011	Yes	65
I/O_47	Zero speed detection level	ZSD Level	0.0 ~ 480.0	rpm	10.0	Yes	61-62
I/O_48	Zero speed detection band	ZSD Band	0.1 ~ 10.0	%	0.5	Yes	
I/O_49	Speed detection level	SD Level	-3600 ~ 3600	rpm	0	Yes	62
I/O_50	Speed detection band	SD Band	0.1 ~ 10.0	%	0.5	Yes	
I/O_51	Speed arrival band	SA Band	0.1 ~ 10.0	%	0.5	Yes	63
I/O_52	Speed deviation band	SEQ Band	0.1 ~ 10.0	%	0.5	Yes	
I/O_53	Torque detection level	TD Level	0.0 ~ 250.0	%	0.0	Yes	64
I/O_54	Torque detection band	TD Band	0.1 ~ 10.0	%	0.5	Yes	
I/O_55	Timer On delay time	TimerOn Dly	0.1 ~ 3600.0	sec	0.1	Yes	63-64
I/O_56	Timer Off delay time	TimerOff Dly	0.1 ~ 3600.0	sec	0.1	Yes	
I/O_57	Overload warning level	OL Level	30 ~ 250	%	150	Yes	65
I/O_58	Overload warning time	OL Time	0 ~ 30	sec	10	Yes	65
I/O_59	Overload trip selection	OLT Select	Yes/No		Yes	Yes	66
I/O_60	Overload trip level	OLT Level	30 ~ 250	%	180	Yes	66

5. Function code table

CODE NO.	CODE NAME	LCD DISPLAY	SETTING DATA			Adj. During Run(1)	Page
			RANGE	UNIT	DEFAULT		
I/O_61	Overload trip time	OLT Time	0 ~ 60	sec	60	Yes	66
I/O_62	Inverter overheat warning temp.	IH Warn Temp	50 ~ 85	deg	75	Yes	64
I/O_63	Inverter overheat warning band	IH Warn Band	0 ~ 10	deg	5	Yes	
I/O_64	Motor overheat warning temp.	MH Warn Temp	75 ~ 130	deg	120	Yes	
I/O_65	Motor overheat warning band	MH Warn Band	0 ~ 10	deg	5	Yes	
I/O_66	Multi-function analog output AO1 definition	AO1 Define	Not Used		Not Used	Yes	66
			Ai1 Value				
			Ai2 Value				
			Ai3 Value				
			PreRamp Ref				
			PostRamp Ref				
			ASR Inp Ref				
			Motor Speed				
			Speed Dev				
			ASR Out				
			Torque Bias				
			PosTrq Limit				
			NegTrq Limit				
			RegTrq Limit				
			Torque Ref				
			IqeRef				
			Iqe				
			Flux Ref				
			IdeRef				
			Ide				
			ACR_Q Out				
			ACR_D Out				
			VdeRef				
			VqeRef				
			Out Amps RMS				
			Out Volt RMS				
			Power				
			DC Bus Volt				
			Proc PI Ref				
			PROC PI F/B				
			Proc PI Out				
			Mot Temp				
			Inv Temp				
			Inv i2t				
I/O_67	Multi-function analog output AO1 gain	AO1 Gain	0.0 ~ 500.0	%	100.0	Yes	66
I/O_68	Multi-function analog output AO1 bias	AO1 Bias	-100.0 ~ I/O_67	%	0.0	Yes	
I/O_69	Multi-function analog output AO2 definition	AO2 Define	I/O_66~I/O_68		Not Used	Yes	
I/O_70	Multi-function analog output AO2 gain	AO2 Gain		%	100.0	Yes	
I/O_71	Multi-function analog output AO2 bias	AO2 Bias		%	0.0	Yes	

5.3. Parameter group (PAR_[][])

CODE NO.	CODE NAME	LCD DISPLAY	SETTING DATA			Adj. During Run(1)	Page
			RANGE	UNIT	DEFAULT		
PAR_00	Jump for quick view	Jump Code	1 ~ 32			Yes	68
PAR_01	Initialize parameters	Para. init	No All Groups DIS I/O PAR FUN CON EXT USR 2ND E/L		No	No	68
PAR_02	Read parameters	Para. read	No/Yes		No	No	68-69
PAR_03	Write parameters	Para. write	No/Yes		No	No	
PAR_04	Parameter write protection	Para. lock	0 ~ 255		0	Yes	69
PAR_05	Password	Password	0 ~ 9999		0	Yes	69
PAR_07	Motor capacity selection 1)	Motor select	2.2/3.7/5.5/7.5 11.0/15.0/18.5/22.0 30.0/45.0/55.0/75.0 90.0/110.0/132.0 160.0/220.0 User Define	kW		No	70
PAR_08	Motor cap. selection of USER	UserMotorSel	1.5 ~ 220.0	kW	5.5	No	70
PAR_09	Motor cooling type	Cooling Mtd	Self-cool/Forced-cool		Forced-cool	Yes	70
PAR_10	Pulse no. of encoder	Enc Pulse	360 ~ 4096		1024	No	70
PAR_11	Encoder direction setting	Enc Dir Set	A Phase Lead B Phase Lead		A Phase Lead	No	70
PAR_12	Encoder error check enable	Enc Err Chk	Yes/No		Yes	No	70
PAR_13	Encoder LPF time constant	Enc LPF	0 ~ 100	ms	1	Yes	70
PAR_14	Encoder error detection time	EncFaultTime	0.00 ~ 10.00	sec	0.00	No	71-72
PAR_15	Encoder error reference speed	EncFaultPerc	0.0 ~ 50.0	%	25.0	No	
PAR_17	Motor base speed	Base Speed	100.0 ~ 3600.0	rpm	1800.0	No	73
PAR_18	Motor rated voltage	Rated Volt	120 ~ 560	V		No	73
PAR_19	Motor number of poles	Pole number	2 ~ 12		4	Yes	73
PAR_20	Motor efficiency	Efficiency	70.0 ~ 100.0	%		Yes	73
PAR_21	Motor rated slip	Rated-Slip	10 ~ 250	rpm		Yes	73
PAR_22	Motor rated current	Rated-Curr	1.0 ~ 450.0	A		Yes	73
PAR_23	Auto tuning type selection	AutoTuneType	Standstill/Rotational		Rotational	No	74-77
PAR_24	Auto tuning range setting 2)	Auto Tuning	None ALL1/ALL2 Encoder Test Rs Tuning Lsigma Flux Curr Ls Tuning Tr Tuning		None	No	
PAR_25	Tuning Torque	Tune Torue	10.0 ~ 100.0	%	70	Yes	
PAR_26	Motor flux current	Flux Curr	0.0 ~ PAR_22* 70%	A		Yes	
PAR_27	Rotor time constant	Tr	30 ~ 3000	ms		Yes	
PAR_28	Leakage inductance	Ls	0.00 ~ 500.00	mH		Yes	78
PAR_29	Leakage coefficient	Lsigma	0.00 ~ 100.00	mH		Yes	78
PAR_30	Stator resistance	Rs	0.000 ~ 5.000	ohm		Yes	78

1) When PAR_07 is set to "User Define", PAR_08 will be displayed.

2) If PAR_23 (Auto-tuning type select) is set to "Standstill", the order of display in PAR_24 (Auto-tuning range setting) will be None→ ALL1→ Rs Tuning→ Lsigma→ If/Tr/Ls Tune.

5.4. Function group (FUN_[][])

CODE NO.	CODE NAME	LCD DISPLAY	SETTING DATA			Adj. During Run(1)	Page
			RANGE	UNIT	DEFAULT		
FUN_00	Jump for quick view	Jump code	1 ~ 64			Yes	81
FUN_01	RUN/STOP command source selection	Run/Stop Src	Terminal 1/Terminal 2 Keypad/Option		Terminal 1	No	81
FUN_02	Speed setting source selection	Spd Ref Sel	Analog Keypad1/Keypad2 Option		Keypad1	No	82
FUN_03	Stop mode selection	Stop mode	Decel/Free-run		Decel	No	82
FUN_04	Max. motor speed	Max Speed	400.0 ~ Max. Speed	rpm	1800.0	No	83
FUN_12	Multi-step speed 0	Speed 0	0.0 ~ Max. Speed	rpm	0.0	Yes	83
FUN_13	Multi-step speed 1	Speed 1	0.0 ~ Max. Speed	rpm	0.0	Yes	83
FUN_14	Multi-step speed 2	Speed 2	0.0 ~ Max. Speed	rpm	0.0	Yes	83
FUN_15	Multi-step speed 3	Speed 3	0.0 ~ Max. Speed	rpm	0.0	Yes	83
FUN_16	Multi-step speed 4	Speed 4	0.0 ~ Max. Speed	rpm	0.0	Yes	83
FUN_17	Multi-step speed 5	Speed 5	0.0 ~ Max. Speed	rpm	0.0	Yes	83
FUN_18	Multi-step speed 6	Speed 6	0.0 ~ Max. Speed	rpm	0.0	Yes	83
FUN_19	Multi-step speed 7	Speed 7	0.0 ~ Max. Speed	rpm	0.0	Yes	83
FUN_20	JOG speed	Jog Speed	0.0 ~ Max. Speed	rpm	100.0	Yes	83
FUN_21	Dwell Speed	Dwell Speed	0.0 ~ Max. Speed	rpm	100.0	No	83
FUN_22	Dwell Time	Dwell Time	0.00 ~ 100.00	sec	0.00	No	83
FUN_33	Acc./Dec. reference Speed	Acc/Dec Ref	Max Speed/Ref Speed		Max speed	No	84
FUN_36	S ratio 1 in acceleration start	Acc S Start	0.0 ~ 50.0	%	0.0	No	85-87
FUN_37	S ratio 2 in acceleration end	Acc S End	0.0 ~ 50.0	%	0.0	No	
FUN_38	S ratio 1 in deceleration start	Dec S Start	0.0 ~ 50.0	%	0.0	No	
FUN_39	S ratio 2 in deceleration end	Dec S End	0.0 ~ 50.0	%	0.0	No	
FUN_40	Acceleration time 1	Acc Time-1	0.00 ~ 6000.0	sec	2.00	Yes	84-85
FUN_41	Deceleration time 1	Dec Time-1	0.00 ~ 6000.0	sec	2.00	Yes	
FUN_42	Acceleration time 2	Acc Time-2	0.00 ~ 6000.0	sec	3.00	Yes	
FUN_43	Deceleration time 2	Dec Time-2	0.00 ~ 6000.0	sec	3.00	Yes	
FUN_44	Acceleration time 3	Acc Time-3	0.00 ~ 6000.0	sec	4.00	Yes	
FUN_45	Deceleration time 3	Dec Time-3	0.00 ~ 6000.0	sec	4.00	Yes	
FUN_46	Acceleration time 4	Acc Time-4	0.00 ~ 6000.0	sec	5.00	Yes	
FUN_47	Deceleration time 4	Dec Time-4	0.00 ~ 6000.0	sec	5.00	Yes	
FUN_48	Deceleration time selection for zero speed	Use 0 Dec T	No/Yes		No	Yes	87
FUN_49	Deceleration time for zero speed	0 Dec Time	0.00 ~ 6000.0	sec	0.00	Yes	87
FUN_51	Deceleration time for emergency stop	BX Time	0.0 ~ 6000.0	sec	0.0	Yes	88
FUN_52	Pre-excitation time	PreExct Time	0 ~ 10000	ms	0	No	88
FUN_53	Hold Time	Hold Time	100 ~ 10000	ms	1000	No	88
FUN_54	Electronic thermal selection	ETH Select	No/Yes		No	Yes	89-90
FUN_55	Electronic thermal level for 1 minute	ETH 1 min	FUN_56 ~ 200	%	150	Yes	
FUN_56	Electronic thermal level for continuous	ETH Cont	50 ~ FUN_55 (But, up to 150%)	%	100	Yes	
FUN_57	Switching frequency select	PWM Freq	2.5 ~ 10.0	kHz	8.0	No	90
FUN_58	Power on Run selection	Power-on Run	No/Yes		No	Yes	91
FUN_59	Restart after fault reset	RST Restart	No/Yes		No	Yes	91
FUN_60	Number of auto restart try	Retry Number	0 ~ 10		0	Yes	91-92
FUN_61	Delay time before Auto restart	Retry Delay	0.0 ~ 60.0	sec	1.0	Yes	
FUN_62	Wait time for Restart upon Stop	Restart Time	0.00 ~ 10.00	sec	0.00	No	93
FUN_63	Overspeed Detection Level	OverSpdLevel	100.0 ~ 130.0	%	120.0	No	93
FUN_64	Overspeed Detection Time	OverSpd Time	0.00 ~ 2.00	sec	0.00	No	93

5.5. Control group (CON_[][])

CODE NO.	CODE NAME	LCD DISPLAY	SETTING DATA			Adj. During Run	Page
			RANGE	UNIT	DEFAULT		
CON_00	Jump for quick view	Jump Code	1 ~ 49			Yes	94
CON_01	Control mode setting	Control Mode	Speed Torque		Speed	No	
CON_02	Application mode setting	Application	General Vect Elevator		General Vect	No	
CON_03	ASR P Gain 1	ASR P Gain1	0.1 ~ 200.0	%	50.0	Yes	94-96
CON_04	ASR I Gain 1	ASR I Gain1	0 ~ 50000	ms	300	Yes	
CON_05	ASR LPF time constant 1	ASR LPF1	0 ~ 20000	ms	0	Yes	
CON_06	ASR P Gain 2	ASR P Gain2	0.1 ~ 200.0	%	5.0	Yes	
CON_07	ASR I Gain 2	ASR I Gain2	0 ~ 50000	ms	3000	Yes	
CON_08	ASR LPF time constant 2	ASR LPF2	0 ~ 20000	ms	0	Yes	
CON_09	Ramp time for ASR gain switch-over	ASR RAMP	10 ~ 10000	ms	1000	Yes	
CON_10	Target Speed after ASR gain switch-over	ASR TarSpd	0.0 ~ 3600.0	rpm	0.0	No	
CON_11	Process PID reference (keypad)	Proc PID Ref	-100.0 ~ 100.0	%	0.0	Yes	97-98
CON_12	Process PID position reference	Proc PosiRef	0 ~ 65535		0	No	
CON_13	Process PID P gain	Proc PID Kp	0.0 ~ 999.9	%	0.0	Yes	
CON_14	Process PID I gain	Proc PID Ki	0.0 ~ 100.0	%	0.0	Yes	
CON_15	Process PID D gain	PROC PID Kd	0.0 ~ 100.0	%	0.0	Yes	
CON_16	Process PID positive limit	Proc Pos Lmt	-100.0 ~ 100.0	%	100	Yes	
CON_17	Process PID negative limit	Proc Neg Lmt	-100.0 ~ 100.0	%	100	Yes	
CON_18	Process PID output LPF time constant	Proc Out LPF	0 ~ 500	ms	0	Yes	
CON_19	Process PID output gain	Proc OutGain	-250.0 ~ 250.0	%	0.0	Yes	
CON_20	Process PID output enable	Proc PID Enb	Disable Enable Terminal		Disable	No	
CON_21	Process PID Hold Time	PIDHoldTime	0 ~ 10000	ms	0	No	98
CON_22	Draw quantity	Draw %	-100.0 ~ 100.0	%	0.0	Yes	99
CON_23	Droop quantity	Droop %	0.0 ~ 100.0	%	0.0	Yes	101-102
CON_24	Low speed limit of Droop control	Droop MinSpd	0.0 ~ 3600.0	rpm	0.0	Yes	
CON_25	Starting torque of Droop control	Droop MinTrq	0.0 ~ 100.0	%	0.0	Yes	
CON_26	Torque reference source selection	Trq Ref Src	None Analog Option		None	No	103
CON_27	Torque Reference(keypad)	Torque Ref	-180.0 ~ 180.0	%	0.0	Yes	103
CON_28	Torque limit source selection	Trq Lmt Src	Kpd Kpd Kpd Kpd Kpd Ax Kpd Ax Kpd Kpd Ax Ax Ax Kpd Kpd Ax Kpd Ax Ax Ax Kpd Ax Ax Ax Opt Opt Opt		Kpd KpdKpd	No	104-105
CON_29	Torque limit in forward run	Pos Trq Lmt	0.0 ~ 250.0	%	150.0	Yes	
CON_30	Torque limit in reverse run	Neg Trq Lmt	0.0 ~ 250.0	%	150.0	Yes	
CON_31	Torque limit in regeneration	Reg Trq Lmt	0.0 ~ 250.0	%	150.0	Yes	
CON_32	Torque Bias source selection	Trq Bias Src	None Analog Keypad Option		None	No	103
CON_33	Torque Bias quantity	Trq Bias	-150.0 ~ 150.0	%	0.0	Yes	103
CON_34	Torque bias feedforward	Trq Bias FF	-150.0 ~ 150.0	%	0.0	Yes	104
CON_35	Torque Balance quantity	Trq Balance	0.0 ~ 100.0	%	50.0	Yes	104
CON_49	Speed search setting	Speed Search	0000 ~ 1111		0100	No	106

5.6. User group (USR_[][])

CODE NO.	CODE NAME	LCD DISPLAY	SETTING DATA			Adj. During Run	Page
			RANGE	UNIT	DEFAULT		
USR_00	Jump for quick view	Jump Code	1 ~ 67			Yes	107
USR_01	Initialize Macro	Macro Init	User Define E/L		User Define	No	107
USR_02	User data save selection	User Save	No Yes		No	No	107
USR_03	Recall saved user data	User Recall	No Yes		No	No	107
USR_04	User group	User Grp				No	107-108

5.7. Second motor function (2nd_[][])


CODE NO.	CODE NAME	LCD DISPLAY	SETTING DATA			Adj. During Run	Page
			RANGE	UNIT	DEFAULT		
2nd_00	Jump for quick view	Jump Code	1 ~ 33			Yes	109
2nd_01	2 nd motor Control mode setting	2nd Ctl Mode	Speed Torque		Speed	No	
2nd_02	Max. speed of 2 nd motor	2nd Max Spd	400.0 ~ 3600.0	rpm	1800.0	No	
2nd_04	Multi-step speed 0 of 2 nd motor	2nd Spd 0	0.0 ~ 2nd_02	rpm	0.0	Yes	
2nd_05	2 nd motor S ratio 1 in acceleration start	2nd Acc S St	0.0 ~ 50.0	%	0.0	No	110
2nd_06	2 nd motor S ratio 2 in acceleration end	2nd Acc S Ed	0.0 ~ 50.0	%	0.0	No	110
2nd_07	2 nd motor S ratio 1 in deceleration start	2nd Dec S St	0.0 ~ 50.0	%	0.0	No	110
2nd_08	2 nd motor S ratio 2 in deceleration end	2nd Dec S Ed	0.0 ~ 50.0	%	0.0	No	110
2nd_09	Acceleration time of 2 nd motor	2nd Acc time	0.00 ~ 6000.0	sec	10.00	Yes	110
2nd_10	Deceleration time of 2 nd motor	2nd Dec time	0.00 ~ 6000.0	sec	10.00	Yes	110
2nd_11	Cooling method of 2 nd motor	2nd Cool Mtd	Self-cool Forced-cool		Self-cool	Yes	110
2nd_12	Encoder pulse no. of 2 nd motor	2nd Enc #	360 ~ 4096		1024	No	110
2nd_13	Encoder direction setting of 2 nd motor	2nd Enc Dir	A Phase Lead B Phase Lead		A Phase Lead	No	110
2nd_14	Encoder error check enable of 2 nd motor	2nd Enc chk	Yes No		Yes	No	110
2nd_15	Encoder LPF time constant of 2 nd motor	2nd Enc LPF	0 ~ 100	ms	1	Yes	110
2nd_17	Base speed of 2 nd motor	2nd BaseSpd	300.0 ~ 3600.0	rpm	1800.0	No	110
2nd_18	Rated voltage of 2 nd motor	2nd R-Volt	120 ~ 560	V		No	110
2nd_19	2 nd motor number of poles	2nd Pole #	2 ~ 12		4	No	110
2nd_20	Efficiency of 2 nd motor	2nd Mot Eff.	70 ~ 100	%		Yes	110
2nd_21	Rated slip of 2 nd motor	2nd R-Slip	10 ~ 250	rpm		Yes	110
2nd_22	Rated current of 2 nd motor	2nd R-Curr	1.0 ~ 450.0	A		Yes	110
2nd_23	Flux current of 2 nd motor	2nd Flx Cur	0.0 ~ 70% of 2nd_22	A		Yes	110
2nd_24	Rotor time constant of 2 nd motor	2nd Mot Tr	30 ~ 3000	ms		Yes	110
2nd_25	Leakage inductance of 2 nd motor	2nd Mot Ls	0.00 ~ 500.00	mH		Yes	110
2nd_26	Leakage coefficient of 2 nd motor	2nd Mot sLs	0.00 ~ 100.00	mH		Yes	110
2nd_27	Stator resistance Of 2 nd motor	2nd Mot Rs	0.000 ~ 5.000	ohm		Yes	110
2nd_32	Electronic thermal level for 1 minute of 2 nd motor	2nd ETH 1min	100 ~ 150	%	150	Yes	110
2nd_33	Electronic thermal continuous level of 2 nd motor	2nd ETH cont	50 ~ 150	%	100	Yes	110

Chapter 6 – Function Description

6.1 Display group (DIS_[][])

6.1.1 DIS_00 (Motor control status monitoring)

Displayed when Power ON.



Code	Parameter name	Unit	Description
DIS_00	Motor speed	rpm	Actual motor rotating speed displayed in rpm.
	Motor control mode		SPD : Speed control mode
			TRQ : Torque control mode
			BX : BX operating
	Output torque	%	100% = Rated torque of motor
	Inverter output current	A	Inverter actual output current displayed

6.1.2 DIS_01 ~ 03 (User display 1, 2, 3)

Select one of the followings each to be displayed in DIS_01, 02 and 03.

Factory default: **DIS_01**= " PreRamp Ref ", **DIS_02**= "DC Bus Volt", **DIS_03**= " Terminal In "

Code	Parameter name	LCD display	Unit	Description
DIS_01 ~ DIS_03	Multi-function analog input value	Ai1 Value ~ Ai3 Value	%	Displayed as the percentage of multi-function analog input value (10V / 100%, 20mA / 100%)
	Pre Ramp Reference	PreRamp Ref	rpm	Speed reference before ramping
	Post ramp reference	PostRamp Ref	rpm	Speed reference after ramping
	ASR Input Reference	ASR Inp Ref	rpm	Final speed reference input value to ASR (Automatic Speed Regulator) displayed (Draw and Droop included)
	Motor Rotating Speed	Motor Speed	rpm	Actual motor rotating speed
	Speed Deviation	Speed Dev	rpm	Deviation between speed ref and actual rotating speed
	ASR Output	ASR Out	%	ASR output to rated torque
	Torque bias	Torque Bias	%	Torque bias to rated torque
	Positive Trq Limit	Pos Trq Limit	%	Positive torque limit to rated torque


6. Function Description (DIS)

Code	Parameter name	LCD display	Unit	Description									
	Negative Trq Limit	Neg Trq Limit	%	Negative torque limit to rated torque									
	Regeneration Trq Limit	Reg Trq Limit	%	Regeneration torque limit to rated torque									
	Torque Reference	Torque Ref	%	Torque reference to rated torque									
	Torque current ref.	IqeRef	%	Torque current reference to rated torque current									
	Torque current	Iqe	%	Actual torque current to rated torque current									
	Flux reference	Flux Ref	%	Flux reference to the rated flux									
	Flux Current ref.	IdeRef	%	Flux current reference to rated flux current									
	Flux Current	Ide	%	Actual flux current to rated flux current									
	ACR output of axis Q	ACR_Q Out	V	ACR output value of axis Q									
	ACR output of axis D	ACR_D Out	V	ACR output value of axis D									
	Voltage reference of axis D	VdeRef	V	Voltage reference value of axis D									
	Voltage reference of axis Q	VqeRef	V	Voltage reference value of Q axis Q									
	Output current	Out Amps RMS	A	Inverter output current (rms)									
	Output voltage	Out Volt RMS	V	Inverter output voltage (rms)									
	Output power	Power	kW	Motor output power									
	DC LINK voltage	DC Bus Volt	V	Inverter DC link voltage									
	Process PI reference	Proc PI Ref	%	Reference value of Process PID routine									
	Process PI Feedback	Proc PI F/B	%	Feedback value of Process PID routine									
	Process PI output	Proc PI Out	%	Output value of Process PID routine									
	Motor temperature	Mot Temp	deg	Motor temp displayed. 25℃ displayed when motor NTC is not provided with the motor.									
	Inverter temperature	Inv Temp	deg	Inverter Heatsink temp displayed									
	Inverter i2t	Inv i ² t	%	Inverter overload capability displayed. In the case Overload capability is 150% for 1 min, i ² t becomes 100% when 150% of rated current is flowing for 1 min.									
	MOP output	MP Output	%	Set value displayed when operation is done by potentiometer on terminal input.									
	Control mode	Ctrl Mode		Selected control mode displayed									
	Software version	S/W Version		S/W version displayed									
	Running time	Run Time		Inverter running time displayed after Power On									
	Input terminal status	Terminal In		ON/OFF status of Input terminal displayed (0: OFF, 1: ON)									
				FX	RX	BX	P1	P2	P3	P4	P5	P6	P7
				0 : OFF 1 : ON	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1	0/1
	Output terminal status	Terminal Out		ON/OFF status of open collector output, fault relay and contact output. (0: OFF, 1: ON)									
AX1				AX2	OC1	NC	NC	30A (30B)					
0 : OFF 1 : ON				0/1	0/1	0/1	0	0	0/1				
Running status	Run Status		Operating status displayed										

6. Function Description (DIS)

6.1.3 DIS_04 (Process PID Controller)

Information on Output, reference, F/B values of Process PID controller is displayed in this code.



6.1.4 DIS_05 (Fault display)

Current fault status, previous two faults, the number of faults occurred and faults information reset are available using [SHIFT/ESC] key in DIS_05.

Code	LCD display	Parameter name	Description
DIS_05	Faults	Current Trip displayed	"-----" displayed when normal. Trip information given when tripped.
	Last Fault1	2 nd fault displayed	Refer to Chapter 8. Troubleshooting.
	Last Fault2	1 st fault displayed	
	Fault Count	Total number of faults	The number of total faults in memory is displayed.
	Fault Clear	Reset	Clear the faults and initialize to "0".

Faults information, speed reference before fault occurs, speed F/B value, output frequency/ current/ Voltage, torque current reference & actual value, DC Link voltage, input terminal status, output terminal status, Run status, running time can be monitored using [PROG], [▲(Up)] / [▼(Down)] keys. Pressing [ENT] key will return to top. To enter the fault info into memory as [Last Fault 1], press [RESET] key. Refer to [Chapter 8 troubleshooting and maintenance] for more details.

No	Trip information	LCD display	No	Trip information	LCD display
1	Overcurrent in Phase U	OC-U	12	Ground fault	Ground Fault
2	Overcurrent in Phase V	OC-V	13	Inverter overheat	InvOver Heat
3	Overcurrent in Phase W	OC-W	14	Electronic thermal	E-Thermal
4	Fuse open	Fuse Open	15	Overload trip	Over Load
5	Overvoltage	Over Voltage	16	External trip B	Ext-B Trip
6	IGBT short in phase U	Arm Short-U	17	Option error	Option Err
7	IGBT short in phase V	Arm Short-V	18	Inverter overload	Inv OLT
8	IGBT shot in phaseW	Arm Short-W	19	Motor overheat	MotOver Heat
9	IGBT shot in phase DB	Arm Short-DB	20	Inverter thermal open	InvThem OP
10	Encoder Error	Encoder Err	21	Motor thermal open	MotThem OP
11	Low voltage	Low Voltage	22	Motor overspeed	Over Speed

6. Function Description (DIS)

※ Note :

When multiple faults occur at the same time, the MOST CRITICAL fault will be displayed and the rest of others can be inferred from the value using [PROG], [▲(Up)] / [▼(Down)] keys .

6.1.5 DIS_06(User group display selection)

User can make "User group" by collecting frequently used codes. In DIS_06, user can set whether User group is displayed or not in three selections.

Code	LCD display	Parameter name	Description	
DIS_06	Usr Grp Disp	User group display selection	Not Used	User group not displayed
			Dis+Usr Grp	Only Display + User group displayed. The rest of groups are not displayed. If you want to display the rest, move to other group in Jump code or change the selection.
			Display ALL	Display all groups including User group. But, 2nd group is displayed only when 2 nd group is defined. EXT group is displayed when Option board is installed.

6.2 I/O group (I/O_[][])

6.2.1 Jump code (I/O_00)

In I/O_00, jumping directly to any parameter code can be accomplished by entering the desired code number.

(Example) Moving to I/O_05

Press [PROG] and set to 5 using [SHIFT/ESC] / [▲(Up)] / [▼(Down)] and press [ENT] key to move to I/O_05. If the desired code cannot be set, the closest code will be displayed.

I/O▶	P5 define
05	Not Used

Jumping other code is available using [▲(Up)] / [▼(Down)] keys.

6.2.2 Multi-function Input Terminal

1) I/O_01 ~ I/O_07 (Multi-function input terminal P1 ~ P7 define)

It defines Multi-function input terminals. SV-IV5 has 7 dedicated terminals (P1 ~ P7) for the setting of parameters below. However, the multiple terminals cannot be selected for the same function and if so, the invalid terminal definition is displayed as "Not Used". And the selected function cannot be adjusted while running.

No	Set value	Description	No	Set value	Description
1	Speed-L	Multi-step speed-Low	15	Ext Trip-B	External trip B contact
2	Speed-M	Multi-step speed-Middle	16	Prohibit FWD	Forward Run Disabled
3	Speed-H	Multi-step speed-High	17	Prohibit REV	Reverse Run Disabled
4	Jog Speed	Jog speed	18	Proc PID Dis	PID operation disabled
5	MOP Up	MOP UP operation	19	Timer Input	Timer ON
6	MOP Down	MOP Down operation	20	SoftStrtCncl	Cancel Soft start
7	MOP Clear	MOP Speed Clear (Reset)	21	ASR Gain Sel	Switch ASR gain
8	MOP Save	MOP Speed Save	22	ASR P/PI Sel	Switch ASR P/PI
9	Analog Hold	Analog speed ref. Hold	23	Flux Ref Sel	Switch Flux reference
10	Main Drive	Exchange between Option and Inverter	24	PreExcite	Pre-excitation
11	2nd Func	The 2 nd function	25	Spd/Trq Sel	Speed/Torque control select
12	Xcel-L	Multi-accel/decel-Low	26	Use Max Trq	Torque limit ON/OFF
13	Xcel-H	Multi-accel/decel-High	27	Use Trq Bias	Torque bias ON/OFF
14	3-Wire	3 Wire			

6. Function Description (I/O)

1.1) Speed-L

1.2) Speed-M

1.3) Speed-H

1.4) JOG operation

By defining P1 ~ P4 as "Speed-L", "Speed-M", "Speed-H" and "Jog Speed", the selected references in FUN group 12 ~ 20 (Multi-step speed 0 ~ 7 and Jog speed) become active as speed reference.

(Example) To define Multi-function input terminals P1, P2, P3 as Speed-L, Speed-M, Speed-H and P4 as Jog Speed;

Code	LCD display	Description	Setting range	Unit	Set value
I/O_01	P1 define	Multi-function input terminal P1 define			Speed-L
I/O_02	P2 define	Multi-function input terminal P1 define			Speed-M
I/O_03	P3 define	Multi-function input terminal P3 define			Speed-H
I/O_04	P4 define	Multi-function input terminal P4 define			Jog Speed

When multi-step speed 0 (FUN_12: Speed 0) is selected (P1, P2, P3 = OFF), speed reference is input by the method set in FUN_02 (Analog, keypad 1/2, option). If the jog (FUN_20) is active, inverter operates with jog frequency regardless of other terminal signal input.

P1	P2	P3	P4	Set Vaule
OFF	OFF	OFF	OFF	FUN_02: keypad→ FUN_12(Speed 0)
ON	OFF	OFF	OFF	FUN_13(Speed 1)
OFF	ON	OFF	OFF	FUN_14(Speed 2)
ON	ON	OFF	OFF	FUN_15(Speed 3)
OFF	OFF	ON	OFF	FUN_16(Speed 4)
ON	OFF	ON	OFF	FUN_17(Speed 5)
OFF	ON	ON	OFF	FUN_18(Speed 6)
ON	ON	ON	OFF	FUN_19(Speed 7)
X	X	X	ON	FUN_20(Jog Speed)

1.5) MOP (Motor Operated Potentiometer) Up

1.6) MOP Down

1.7) MOP Clear

1.8) MOP Save

When multi-function input terminals P1 ~ P7 is set to "MOP Up", "MOP Down", inverter performs Accel/Decel Constant Run according to the terminal input. Generally, MOP function is used to adjust the speed simply with terminal ON/OFF. When MOP UP/Down is selected, inverter ignores FUN_02 setting, and performs MOP operation. To cancel it, change the defined terminal to "Not Used". If this function is selected with "Main Drive" function, operating reference is done by MOP and the rest will be defined by "Main Drive" function. Max speed limit is FUN_04(Max Speed).

If "MOP Save" is entered during MOP operation, the current speed reference value is saved as "MOP Data" and

6. Function Description (I/O)


retained. When the MOP operation resumes, the retained value will be used as speed reference.

“MOP Clear” resets the MOP Data value to “0”. It is used to change the saved value.

(Example) MOP function setting and operation method is as follows;


Code	LCD display	Description	Setting range	Unit	Set value
I/O_01	P1 define	Multi-function input terminal P1 define			MOP Up
I/O_02	P2 define	Multi-function input terminal P1 define			MOP Down
I/O_03	P3 define	Multi-function input terminal P3 define			MOP Clear
I/O_04	P4 define	Multi-function input terminal P4 define			MOP Save

(MOP Up/Down example 1) This is used only if terminal ON/OFF is required for speed control.




6. Function Description (I/O)

(MOP Save example 2) In case terminal input assigned to MOP Save function is ON, operation speed at that instant is memorized and operates at the saved speed when operation resumes.




6. Function Description (I/O)

(MOP Clear setting example 3) To clear the saved speed by MOP Save function, use "MOP Clear ON/OFF". If MOP Clear is ON during running, the inverter decelerates its speed to zero speed. If MOP is ON during stop, this function resets the speed reference to "0".



1.9) Analog Hold

When FUN_02 is set to “analog” and one of the selected terminal set to “Analog Hold” is ON, inverter fixes its output frequency, regardless of the frequency reference change. The changed frequency reference is applied when the terminal is OFF. This function is useful when a system requires constant speed after acceleration.



1.10) Main Drive

When an option board is installed and used for the frequency setting and the RUN/STOP command, the inverter operation can be changed to manual using this function without changing the user-setting parameter values. To make this function active, set the selected terminal for “Main Drive” to ON during stop. When this terminal is ON, changing operating speed reference, operating method, and torque limit is done via Keypad ONLY. To turn off the terminal, the changed value is not saved and previous value is restored. Changing control mode during Main Drive operation is available only when the 2nd function is defined using terminal ON/OFF.

The following parameters cannot be changed while Main Drive function is active.

Code	Description	Note
FUN_01	Run/Stop Src (RUN/STOP source select)	
FUN_02	Spd Ref Sel (speed reference selection)	
CON_01	Control Mode (Control mode setting)	Adjustable during the 2nd function
CON_28	Trq Lmt Src (Torque limit source)	

1.11) 2nd Func (the 2nd function setting)

The iV5 inverter has the capability to control 2 motors independently. A second motor may be active by selecting one terminal for this function and turn it ON. 2nd function is not displayed if the terminal is not defined for this or the defined terminal is OFF.

6. Function Description (I/O)

※ Cross reference table for 1st function and 2nd function

Parameter	2 nd function		1 st function	
Acceleration time	2nd_09	2nd Acc time	FUN_40	Acc. Time 1
Deceleration time	2nd_10	2nd Dec time	FUN_41	Dec. time 1
Encoder-related parameter	2nd_12 ~ 2nd_14		PAR_11 ~ PAR_15	
Motor constants	2nd_15 ~ 2nd_26		PAR_16 ~ PAR_30	
Electronic thermal level for 1 min	2nd_32	2nd ETH 1min	FUN_55	ETH 1min
Electronic thermal level for continuous	2nd_33	2nd ETH Cont	FUN_56	ETH Cont

※ Note : 1st & 2nd function switch-over should be selected when the motor is stopped.

If selected during RUN, 2nd function is not active until motor stop.

1.12) XCEL-L

1.13) XCEL-H


Refer to FUN_40 ~ 47 (Accel/ Decel time 1, 2, 3, 4).

Code	LCD display	Description	Factory setting
FUN_40	Acc Time-1	Accel time 1	2.00(sec)
FUN_41	Dec Time-1	Decel time 1	2.00(sec)
FUN_42	Acc Time-2	Accel time 2	3.00(sec)
FUN_43	Dec Time-2	Decel time 2	3.00(sec)
FUN_44	Acc Time-3	Accel time 3	4.00(sec)
FUN_45	Dec Time-3	Decel time 3	4.00(sec)
FUN_46	Acc Time-4	Accel time 4	5.00(sec)
FUN_47	Dec Time-4	Decel time 4	5.00(sec)

1.14) 3-Wire operation

When FX or RX terminal is turned ON and turned OFF, the terminal is maintained ON using this parameter.

(Operating method when P2 is set to 3-Wire)



1.15) Ext Trip-B (External trip signal input by b contact)


If the terminal set to this function is off, the inverter disables the gating of IGBT and then the motor freely rotates to a stop. The message written as "External Trip Signal B contact" appears on the LCD screen and STOP LED is blinking in the keypad. This signal can be used as an external latch trip.

1.16) Prohibit FWD (Prohibition of Forward Rotation)

1.17) Prohibit REV (Prohibition of Reverse Rotation)

If Prohibit FWD or Prohibit REV is set, it prohibits forward or reverse rotation, respectively. If Prohibit FWD is used, speed command becomes 0 when it has positive value. Similarly, If Prohibit REV is used, speed command becomes 0 when it has negative value.

(Example) When multi-function input terminal P1 is set to “prohibit FWD” and P2 to “prohibit REV” the following diagram will be shown.



1.18) Proc PID Dis (Process PID Disabled)

This function is used to disable the Process PID controller. If Proc PID Enb at the CON_20 is ON and also this terminal is ON, the output of Process PID controller becomes zero. Otherwise, Process PID controller generates its output depending on the controller operation. 'Proc PID Enb' at CON_20 determines whether this function is used or not. The setting for this code is as follows.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_20	Proc PID Enb	Proc PID controller Enable/Disable	Disable Enable Terminal		Disable


'Disable' at CON_20 blocks the output of Process PID controller and 'Enable' at CON_20 enables the Process PID controller. If 'Terminal' is set, the multi-function terminal set to 'Proc PID Dis' determines whether the output of Process PID controller is enabled or not. To prevent the saturation of Process PID controller, Process PID controller is enabled only if the multi-function input terminal is set to 'Proc PID Dis' and its terminal input is OFF and operation command is 'ON'. Process PID controller does not work if operation command is not ON or 'Process PID Disable' is not set. Truth table is as follows.

CON_20	Proc PID Dis	Operating reference	
	Multi-function input signal	ON	OFF
Terminal	ON	Disable	Disable
	OFF	Enable	Disable
Enable		Enable	Disable
Disable		Disable	Disable

1.19) Timer Input

The multi-function input terminals P1~P7 can generate the timer output based on the timer ON delay time at I/O_55 and timer Off delay time at I/O_56. The following example is the case where I/O_05 is set to timer input and the multi-function output terminal AX1 at I/O_41 is set to 'Timer Out'.

Code	LCD display	Description	Setting range	Unit	Setting value
I/O_05	P5 Define	Multi-function input terminal P5 Define			Timer Input
I/O_41	AX1 Define	Multi-function output terminal AX1 Define			Timer Out
I/O_55	TimerOn Dly	Timer On Delay Time	0.1 ~ 3600.0	sec	
I/O_56	TimerOff Dly	Timer Off Delay Time	0.1 ~ 3600.0	sec	



1.20) SoftStartCncl (Soft Start Cancel)

Soft start cancel is used when the shortest acceleration/deceleration time is required without using the existing accel/decel time. In this case, real acceleration/deceleration time depends on the load condition and response characteristic of speed controller. The following table shows what kind of acceleration/deceleration time is used when P1, P2 and P3 are used for the transfer of accel/decel time or soft start cancel function is enabled.

(Example) Programming P3 as SoftStrtCncl

P1 (Xcel-L)	P2 (Xcel-H)	P3 (SoftStartCncl)	Accel/Decel time
OFF	OFF	OFF	Accel/Decel 1
ON	OFF	OFF	Accel/Decel 2
OFF	ON	OFF	Accel/Decel 3
ON	ON	OFF	Accel/Decel 4
X	X	ON	The shortest Accel./Decel.

1.21) ASR Gain Sel (Switch Automatic Speed Regulator PI gain)

Using 'ASR Gain Sel' function, one of the two P and I gains can be selected for PI speed controller (ASR).

(Example) Programming P5 as ASR PI Gain

Code	LCD display	Description	Setting range	Unit	Setting value
I/O_05	P5 define	Multi-function input terminal P5 Define			ASR Gain Sel
CON_03	ASR P Gain1	ASR (Automatic Speed Regulator) P Gain 1	0.0 ~ 200.0	%	<u>P5 : OFF</u>
CON_04	ASR I Gain1	ASR I Gain 1	0 ~ 50000	ms	
CON_05	ASR LPF1	ASR LPF time constant 1	0 ~ 20000	ms	
CON_06	ASR P Gain2	ASR P Gain 2	0.0 ~ 200.0	%	<u>P5 : ON</u>
CON_07	ASR I Gain2	ASR I Gain 2	0 ~ 50000	ms	
CON_08	ASR LPF2	ASR LPF time constant 2	0 ~ 20000	ms	

1.22) ASR P/PI Sel (ASR P/PI Transfer)

The ASR could be P controller or PI controller by MFi programmed as ASR P/PI Sel. When the ASR Gain is switched to each other, the effective P gain could be changed gradually with the time ASR Ramp CON_09 in order to prevent the shock in the machine because of the quick change of P gain.

(Programming Example) Programming P6 as ASR P/PI Sel.

Code	LCD display	Description	Setting range	Unit	Factory setting
I/O_05	P5 define	Multi-function input terminal P5 Define			ASR P/PI Sel

1.23) Flux Ref Sel (Flux reference selection)

If the flux reference selection is ON, flux reference is set to the value which analog voltage (-10 ~ 10V) is converted to % ratio of the rated flux.

1.24) PreExcite (Pre-excitation)

This function enables the motor to build up the flux by flowing the magnetizing current into it before run command is ON so that speed control characteristic can be improved at the time of the acceleration of the motor.

1.25) Spd/Trq Sel (Speed/Torque Control Transfer)

Speed and torque control can be switched using this function. This terminal input overrides the input from the keypad.

1.26) Use Max Torque (Maximum Torque Enable)

If this input is ON, the torque limit value of the speed controller is fixed to its maximum value. On the contrary, when this input turns off, the value defined at CON_29 ~ CON_31 applies to torque limit value. This function disables the inverter continuous operation.

If this function is used continuously, it may lead to damage to the motor and inverter. Take caution when using this function.

1.27) Use Trq Bias (Torque Bias Enable)

If one of the multi-function terminals (P1 ~ P7) is selected as "Use Trq Bias", torque bias value is fed into the inverter following the input signal. Besides, if "Use Trq Bias" is not set, and 'Keypad' is set at CON_32, torque bias value set at CON_33 is fed into the inverter. And, if "Analog" is set at CON_32 (Trq Bias Src), and the input is selected as "Torque Bias", the torque bias value is fed into the inverter. Therefore, in order not to use the torque bias value, 'None' should be set at CON_32 or one of the multi-function terminals (P1 ~ P7) should be selected as "Use Trq Bias" and then be kept the terminal Open.

2) I/O_08 (Reversal of Multi-function input terminal)

Multi-function input terminal is based on the 'A' contact operation. If a specific terminal should be changed to 'B' contact operation, the relevant terminal setting should be set from '0' to '1'. Once the relevant terminal is set to '1', the terminal operates on the basis of 'B' contact and it is effective before it is changed to '0'. But, in case of the external trip 'B' contact, it is changed to 'A' contact operation. Terminals are displayed in the order of P1, P2, P3, P4, P5, P6 and P7 from the beginning.

(P1 ~ P7: A contact)

I/O ► Neg Function	
08	0000000

(P1, P6: B contact)

I/O ► Neg Function	
08	1000010

3) I/O_09 (Low Pass Filter Time Constant for the Terminals)

This setting affects the response speed of the control circuit terminals (FX, RX, BX, P1 ~ P7, RST). It is greatly effective when electro-magnetic noise signal is present in the input signal. The larger the time constant becomes, the slower response speed becomes. Response speed is approximately proportional to the setting value times 2.5 [m sec].

4) I/O_10 Inversion of Multi-function aux contact output (Relay output, Open collector output)

Factory default setting of Multi-function Relay outputs is A contact. To change it to B contact, set it to "1".

See the below for setting example: (terminal layout is AX1, AX2, OC1, NC, NC from left.)

(Setting example)

(AX1 ~ OC1: A contact)

I/O ► Neg Func.Out
10 00000

(AX1, OC1: B contact)

I/O ► Neg Func.Out
10 10100

6.2.3 Multi-function analog input

1) I/O_11 ~ 25(Definition of Multi-function analog input terminal, Gain, Bias, LPF time constant)

3 analog inputs are assigned for IO board. Ai3 serves as the Motor NTC input port and voltage or current signal can be fed into Ai1 and Ai2 by the jumper setting. Analog input on the control circuit terminal can be used as single function among the following 8 functions on the table shown below (9 functions for Ai3). Voltage input range is $-10 \sim +10\text{V}$ and current input range is $4 \sim 20\text{mA}$. Any analog input cannot be set as the same function as the other inputs. If 2 analog inputs are set to the same function, last set analog input is changed to 'Not Used'. In case analog input is changed to the other function, previously set value is initialized to 0.

Set value	Parameter name	description
Speed Ref	Speed Reference	$\pm 10\text{V}$ input is equivalent to $\pm 100\%$ of maximum speed
Proc PID Ref	Process PID Reference	$\pm 10\text{V}$ input is equivalent to $\pm 100\%$ of reference of Process PI controller
Proc PID F/B	Process PID F/B	$\pm 10\text{V}$ input is equivalent to $\pm 100\%$ of feedback of Process PI controller
Draw Ref	Draw Reference	$\pm 10\text{V}$ input is equivalent to $\pm 100\%$ of reference of Draw controller
Torque Ref	Torque reference	$\pm 10\text{V}$ input is equivalent to $\pm 100\%$ of rated torque It can be set up to $-250 \sim 250\%$ of rated torque by the gain and bias adjustment.
Flux Ref	Flux Reference	$\pm 10\text{V}$ input is equivalent to 100% of rated flux
Torque Bias	Torque Bias	$\pm 10\text{V}$ input is equivalent to $\pm 100\%$ of rated torque It can be set up to $-250 \sim 250\%$ of rated torque by the gain and bias adjustment.
Torque Limit	Torque Limit	10V input is equivalent to 100% of rated torque It can be set up to $0 \sim 250\%$ of rated torque by the gain and bias adjustment.
Use Mot NTC	Use Motor NTC	Thermal sensor in the motor is fed into this terminal. In this case, the motor temperature is displayed and motor overheat alarm and trip signal can be triggered. Caution: This is applied only to LG-OTIS Vector-controlled Motor.


6. Function Description (I/O)

Code setting related to multi-function analog input is shown in the table below.

Code	Display	Description	Range	Unit	Default
I/O_11	Ai1 Define	Multi function analog input Definition of Ai1	Speed Ref Proc PID Ref Proc PID F/B Draw Ref Torque Ref Flux Ref Torque Bias Torque Limit		Not Used
I/O_12	Ai1 Source	Multi function analog input Definition of Ai1 input source	-10 → 10V 0 → 10V 10 → 0V 4 → 20mA 20 → 4mA		-10 → 10 V
I/O_13	Ai1 Gain	Input gain of Ai1	0.00 ~ 250.00	%	100.0
I/O_14	Ai1 Bias	Input bias of Ai1	-100.00 ~ 100.00	%	0.0
I/O_15	Ai1 LPF	Input LPF time constant of Ai1	0 ~ 2000	ms	0

I/O_16 ~ I/O_25 (Ai2 ~ Ai3) setting method is the same as 1(Ai1) above.

The following figures are the example of 50% input gain and 25% of input bias for 0 ~ 10V analog input.



Maximum of the setting value depends on the Gain and starting point on the Bias. In the example above, Maximum value is set to 50% by the Gain and starting point to 25% by the Bias. Consequently, 25 to 50% of the analog command value is effective for 0 to 10V of input voltage.

2) Adjusting Gain and Bias by Keypad

- Gain Adjustment: Supply 10V to terminal Ai1 and follow next steps.

(The same procedure is applied to Ai2/Ai3. Set the potentiometer High (Max).)

Key	LCD Display	Description
	I/O ► Ai1 Gain 13 100.00 %	Initial Gain (Factory setting)
PROG	I/O ► Ai1 98.00 % 13 Gain 100.00 %	When pressing the [PROG] key, current output [%] to input value is displayed on the first line and current setting gain on the second line.
▲	I/O ► Ai1 100.00 % 13 Gain 102.00 %	If you want to adjust Gain to be 100.00% at 10V input on the first line, adjust gain to be 102.00% using [▲(Up)] key.
ENT	I/O ► Ai1 Gain 13 102.00 %	After setting 102.00% Gain and pressing [ENT] key, it is displayed and the changed gain is saved.

- Bias Adjustment: Supply 0V to Ai1 and follow next steps.

(The same procedure is applied to Ai2/Ai3. Set the potentiometer Low (Min).)

Key	LCD Display	Description
	I/O ► Ai1 Bias 14 0.00 %	Initial Gain (Factory setting)
PROG	I/O ► Ai1 0.18 % 14 Bias 0.00 %	When pressing the [PROG] key, current output [%] to input value is displayed on the first line and current setting bias on the second line.
▲	I/O ► Ai1 0.00 % 14 Bias 0.18 %	If you want to adjust Bias to be 0.00% at 0V input on the first line, adjust it to be 0.00% using [▲(Up)] key.
ENT	I/O ► Ai1 Bias 14 0.18 %	After setting 0.00% Bias and pressing [ENT] key, it is displayed and the changed value is saved.

6.2.4 Multi Function Outputs (MFO)

1) I/O_41 ~ 43 (Multi-function aux contact output (AX1 ~ AX2) and Open collector (OC1) output setting)

Multi-function digital output terminal serves as one of the functions listed in the table below. Multi-function aux contact is activated when the selected function is ON.


No	Set value	No	Set value
1	Not Used	10	Regenerating
2	INV Ready	11	Mot OH Warn
3	Zero Spd Det	12	INV OH Warn
4	Spd Det.	13	Speed Agr.
5	Spd Det (ABS)	14	Trq Det.
6	Spd Arrival	15	Trq Lmt Det.
7	Timer Out	16	OverLoad
8	LV Warn	17	Stop
9	Run	18	Steady

1.1) Not Used

It is set unless multi-function output is not used as any function listed above.

1.2) INV Ready

INV Ready becomes ON when inverter is ready to operate normally. If trip signal occurs, INV Ready is left OPEN immediately as shown in the figure below.




1.3) Zero Spd Det

Detects zero speed of motor. See the figure below.

Code	Display	Description	Range	Unit	Default
I/O_47	ZSD Level	Zero Speed Detect Level	0.0 ~ 480.0	rpm	10
I/O_48	ZSD Band	ZSD hysteresis band	0.1 ~ 10.0	%	0.5

- I/O_48(ZSD Band) is set as the percentage of FUN_04 Max motor speed.




1.4) Spd Det. – Polarity valid

1.5) Spd Det.(ABS) – Polarity invalid

This is ON when the real motor speed reaches the arbitrary speed. The polarity of detecting speed is valid for Spd Det. But, the polarity is invalid for Spd Det(ABS).

Code	Display	Description	Range	Unit	Default
I/O_49	SD Level	Speed Detect Level	-3600 ~ 3600	rpm	0
I/O_50	SD Band	Speed Hysteresis Band	0.1 ~ 10.0	%	0.5

- I/O_49(SD Level) is set as the percentage of FUN_04 Max motor speed.
Detection signal



1.6) Spd Arrival


It detects whether the motor reaches the set speed band.

Code	Display	Description	Range	Unit	Default
I/O_51	SA Band	SA hysteresis band	0.1~10.0	%	0.5

1.7) Spd Agree

This is ON when the motor speed becomes equal to the set speed.


Code	Display	Description	Range	Unit	Default
I/O_52	SEQ Band	SEQ hysteresis band	0.1 ~ 10.0	%	0.5



1.8) Timer Out

Timer Out acts as an output signal to the timer input signal defined in the one of the multi-function input terminals P1~P7 and it uses the set values of Timer On delay time at I/O_55 and of Timer Off delay time at I/O_56. The example of code setting is shown in the table below when I/O_07 is set to Timer Input and I/O_41 is set to Timer Output.

Code	Display	Description	Range	Unit	Default
I/O_07	P7 define	Definition of P7			Timer Input
I/O_41	AX1 Define	Definition of multi-function output terminal relay output 1 (1A, 1B)			Timer Out
I/O_55	TimerOn Dly	Timer On delay	0.1 ~ 3600.0	sec	0.1
I/O_56	TimerOff Dly	Timer Off delay	0.1 ~ 3600.0	sec	0.1



1.9) LV

LV is enabled when the DC link voltage of the inverter is less than the detecting level of low voltage alarm.

1.10) Run

It is ON when the inverter is running.

1.11) Regenerating

It is ON when the motor is regenerating.

1.12) Mot OH Warn (Motor Overheat Warning)

Using NTC signal built in the motor, Motor Overheat is ON when the temperature inside the motor is higher than the overheat alarm level. This signal is only for an alarm, not for the inverter trip. Active when I/O_21 [Ai3 Define] is set to

"Use Mot Ntc".

Code	Display	Description	Range	Unit	Default
I/O_64	MH Warn Temp	Motor overheat detect	75 ~ 150	°C	140
I/O_65	MH Warn Band	MH hysteresis band	0 ~ 10	°C	5

1.13) Inv OH Warn (Inverter Overheat Warning)

Inverter Overheat is ON, when the heatsink inside the inverter is higher than the overheat alarm level. This signal is only for an alarm, not for the inverter trip.

Code	Display	Description	Range	Unit	Default
I/O_62	IH Warn Temp	Inverter Overheat Detection Temperature	50 ~ 85	°C	75
I/O_63	IH Warn Band	Inverter Overheat Detection Bandwidth	0 ~ 10	°C	5

1.14) Trq Det.

Trq Det is ON when the torque output of ASR reaches the setting torque level.

Code	Display	Description	Range	Unit	Default
I/O_53	TD level	Torque Detect Level	0.0 ~ 250.0	%	0.0
I/O_54	TD Band	TD hysteresis band	0.1 ~ 10.0	%	0.5

1.15) Trq Lmt Det

Trq Lmt Det is ON when the output of ASR (Torque reference) is saturated so that its limit value is generated.


1.16) OverLoad

Overload is ON when the inverter output current is higher than the overload alarm level. (On the basis of the rated current of the motor) Refer to the following values of overload alarm level (I/O_57) and overload alarm time (I/O_58).

- **I/O_57: [Overload warning level], I/O_58 [Overload warning time]**

If the inverter output current keeps flowing more than overload alarm level (I/O_57) and longer than overload alarm time (I/O_58), alarm signal is triggered. The overload signal is canceled when the inverter output current flows less than overload alarm level (I/O_57) and longer than overload alarm time (I/O_58) has passed.

Overload alarm signal can be generated by the multi-function outputs (1A-1B, 2A-2B, OC1-EG). "OL" should be set in the I/O_41, 42 and 43 [Multi-function auxiliary terminal output setting] to use this function. Even if overload occurs, its alarm signal is generated through the multi-function output terminal and the inverter keeps running.



Code	Display	Description	Range	Unit	Default
I/O_57	OL level	Overload warning level	30 ~ 250	%	150
I/O_58	OL time	Overload warning time	0 ~ 30	sec	10

- Note: The set value of overload alarm level is of percentage(%) to the rated current of the motor.

1.17) Stop

'Stop' is ON when the inverter keeps stopping.

1.18) Steady

This is ON when the inverter is running at the constant speed.

6. Function Description (I/O)

2) I/O_46 (Fault Output Relay (30A, 30B, 30C))

This function can be used when the inverter fault signal is generated through the relay contact. the fault alarm is triggered differently by setting the bits related to the low voltage trip, inverter trip and the number of retry.

Code	Display	Description	Range	Unit	Default
I/O_46	Relay mode	Relay mode	000 ~ 111		011

Code	Bit 2 (Number of Auto retry)	Bit 1 (Inverter trip)	Bit 0 (LV trip)
I/O_46	0/1	0/1	0/1

Bit	Setting	Description
Bit 0 (LV)	0	Deactivated at Low Voltage Trip
	1	Activated at Low Voltage Trip
Bit 1 (Trip)	0	Deactivated at any fault
	1	Activated at any fault except Low Voltage Trip
Bit 2 (Retry)	0	Deactivated at the auto retry attempt
	1	Activated at the number of auto retry attempt

3) I/O_59 ~ 61 (Overload trip enable, level, time)

If the inverter output current higher than the overload limit level is kept for the overload limit time, the inverter blocks the gating of IGBTs and issues the trip message.

Code	Display	Description	Range	Unit	Default
I/O_59	OLT select	Overload trip enable	Yes/No		Yes
I/O_60	OLT level	Overload trip level	30 ~ 250	%	180
I/O_61	OLT time	Overload trip time	0 ~ 60	sec	60

- Note: I/O_60 is set as the percentage of Motor rated current.

6.2.5 Analog output

SV-IV5 has 2 analog outputs [AO1, AO2] (-10V ~ +10V) and are defined as one of 29 functions as below.

Code	Display	Description	Range	Unit	Default
I/O_66	AO1 Define	Definition of Multi-function analog output 1			Not Used
I/O_67	AO1 Gain	AO1 Gain	0.0 ~ 500.0	%	100.0
I/O_68	AO1 Bias	AO1 Bias	-100.0 ~ 100.0	%	0.0
I/O_69	AO2 Define	Definition of Multi-function analog output 1			Not Used
I/O_70	AO2 Gain	AO2 Gain	0.0 ~ 500.0	%	100.0
I/O_71	AO2 Bias	AO2 Bias	-100.0 ~ 100.0	%	0.0

6. Function Description (I/O)

Setting	Description	Output signal level
AiX Value	Analog input value	± 10 V: 10V, 20mA
PreRamp Ref	Pre Ramp Reference	± 10 V: Max Speed
PostRamp Ref	Post ramp reference	± 10 V: Max Speed
ASR Inp Ref	ASR Input Reference	± 10 V: Max Speed
Motor Speed	Motor Rotating Speed	± 10 V: Max Speed
Speed Dev	Speed Deviation	± 10 V: Rated slip * 2
ASR Out	ASR Output	± 10 V: 250%
Torque Bias	Torque bias	+6 V: 150%
PosTrq Limit	Positive Trq Limit	10V: 250%
NegTrq Limit	Negative Trq Limit	10V: 250%
RegTrq Limit	Regeneration Trq Limit	10V: 250%
Torque Ref	Torque Reference	± 10 V: 250%
IqeRef	Torque current ref.	± 10 V: 250% of rated torque current
Iqe	Torque current	± 10 V: 250% of rated torque current
Flux Ref	Flux reference	10V: Flux rating * 2
IdeRef	Flux Current ref.	± 10 V: Rated flux current * 2
Ide	Flux Current	± 10 V: Rated flux current * 2
ACR_Q Out	ACR output of axis Q	± 10 V: 300/600
ACR_D Out	ACR output of axis D	± 10 V: 300/600
VdeRef	Voltage reference of axis D	± 10 V: 300/600
VqeRef	Voltage reference of axis Q	± 10 V: 300/600
Out Amps RMS	Output current	10 V: Rated current * 2
Out Volt RMS	Output voltage	± 10 V : 300/600
Power	Output power	± 10 V: Rated output * 2
DC Bus Volt	DC LINK voltage	10 V: 500/1000V
Proc PI Ref	Process PI reference	± 10 V: Rating
Proc PI FB	Process PI Feedback	± 10 V: Rating
Proc PI Out	Process PI output	± 10 V: Rating
Mot Temp	Motor temperature	± 10 V: 150°C
Inv Temp	Inverter temperature	± 10 V: 100°C
Inv i2t	Inverter i2t	10 V: 150%

6.3 Parameter group (PAR_[][])

6.3.1 Jump code (PAR_00)

In PAR_00, jumping directly to any parameter code can be accomplished.

(Example) Moving to PAR_30

Press [PROG] and set to 30 using [SHIFT/ESC] / [▲(Up)] / [▼(Down)] and press [ENT] key. If the desired code cannot be set (void), the nearest code will be displayed.

PAR ▶ Rs
 30 0.346 ohm

Use [▲(Up)] / [▼(Down)] to move to other codes.

6.3.2 Parameter group function

1) PAR_01 (Parameter initialize)

This is used to initialize all parameters or each group back to the factory defaults. After performing this, be sure to check **PAR_07 (Motor Select)** is properly set.

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_01	Para. init	Initialize parameters as factory defaults	No All Groups DIS I/O PAR FUN CON EXT USR E/L ¹⁾ 2ND		No


1) E/L is only displayed when CON_02 "Application" is set to "Elevator".

2) PAR_02 ~ 03 (All Parameter Read/Write)

Parameters setting can be copied to other inverters using keypad. To do this, set **PAR_02** 'Parameter Read' to "Yes" to upload the parameter setting from the inverter. Take the keypad out and install it to the copied inverter and set **PAR_03** 'Parameter Write' to "Yes" to download the function parameters.

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_02	Para. Read	All Paramter Read	No Yes		No
PAR_03	Para. Write	All Paramter Write	No Yes		No

6. Function Description (PAR)



3) PAR_04 (Parameter Lock)

Set it to "12" to disable "paramter change".

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_04	Para. Lock	Parameter lock	0 ~ 255		0

4) PAR_05 (Password)

When user put any four-digit number except "0" and cycle the power, only Display groupd will appear. Press [Mode] key and PAR_05 "Password" will be directed. If the right password is entered, all other groups can be accessed and adjustable. To clear the password, set it to "0". When you forget the password, enter "5052". It is the master password and it resets the password to "0".

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_05	Password	Password	0 ~ 9999		0

6. Function Description (PAR)

6.3.3 Motor parameters setting

1) PAR_07(Motor rating setting), PAR_08(Motor cap. Selection of User)

Select the motor rating. Its factory default value is the same as inverter capacity. If this is set, motor parameters are automatically set. These are designed to fit for LG-OTIS vector motor. When other makers' motor is used, program the motor parameters properly. When using a motor having a rating not specified in this code, select "User Define". Then, PAR_08 will be displayed. Enter motor rating in this code. Then, enter motor parameters in the name plate and perform Auto-tuning to gain proper parameters before use.

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_07	Motor select	Motor rating select	2.2 ~ 220.0 User Define	kW	Same as inverter rating
PAR_08	UserMotorSel	Motor cap. Selection of User	1.5 ~ 220.0	kW	5.5

2) PAR_09 (Motor Cooling method)



Select the cooling method of the motor to use. 'Motor cooling method' is used to check if the motor is currently overloaded or not. The self-cooled motor should be set to 'Self-Cool' and the forced cooled motor to 'Forced-Cool'.

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_09	Cooling Mtd	Motor Cooling method	Forced-cool Self-cool		Forced-cool

3) Encoder parameters (PAR_10 ~ 13: Pulse number of Encoder, direction, Error detection, LPF)

Enter the pulse number of encoder mounted on the motor shaft at the **PAR_10 (the pulse number of encoder)**. If **PAR_12(Encoder error check enable)** is set to 'Yes', Encoder error signal is detected and then triggers fault alarm in the case of the wire cut or the miswiring. But, **for open collector type encoder, it is unable to detect the encoder error, therefore PAR_12 should be set to 'No'**. In case the wiring for encoder (A, B phase) or inverter output (U, V, W) is changed, 'Enc AB Chgd' message is shown during the auto-tuning operation. In this case, **PAR_11 (Enc Dir Set)** can be changed without changing the wiring of pulse encoder. If encoder signal is mixed with electromagnetic noise signal, encoder signal may be less affected by the electromagnetic noise signal by adjusting **PAR_13 (Encoder LPF Time Constant)**.

Code	LCD display	Description	Setting range	Factory setting
PAR_11	Enc Dir Set	Encoder direction setting	A Phase Lead/B Phase Lead	A Phase Lead

Setting	Description	Encoder pulse (In FWD RUN)
A Phase Lead	A phase leads in FWD rotation. B phase leads in REV rotation.	
B Phase Lead	B phase leads in FWD rotation. A phase leads in REV rotation.	

6. Function Description (PAR)

Improper setting of encoder parameters may deteriorate accurate speed control and lead to “overcurrent” or “overvoltage” trips. Refer to chapter 8 “Troubleshooting”.

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_10	Enc Pulse	Number of encoder pulse	360 ~ 4096		1024
PAR_12	Enc Err Chk	Encoder error check	Yes No		Yes
PAR_13	Enc LPF	Encoder LPF time constant	0 ~ 100	ms	1

6.3.4 Encoder S/W error detection (PAR_14 ~ 15: Encoder error detection time, encoder error reference speed)

To achieve correct motor speed detection and control using encoder, proper wiring of encoder and motor should be preceded. If operation is continued with faulty wiring of Encoder/Motor, overcurrent flows to the motor, damaging the motor. Therefore, encoder should have functions to detect encoder input error and wrong wiring.

SV-iV5 can monitor encoder H/W error by setting PAR_12 to “Yes” and it monitors encoder pulse signal input status to detect H/W faults such as encoder disconnection error. However, wrong wiring error cannot be detected with this function. In this case, perform “Rotational Auto-tuning”. Set PAR_23 (AutoTuneType) to “Rotational” and perform Encoder Test. Then wiring problem can be detected by applying voltage and checking speed detection level while motor is running.

There are some loads (ex. Elevator) performing Encoder Test described above is difficult. To solve this fault, iV5 adopts the following functions to detect S/W faults.



Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_14	EncFaultTime	Encoder error detection time	0.00 ~ 10.00	sec	0.00
PAR_15	EncFaultPerc	Encoder error reference speed	0.0 ~ 50.0	%	25.0
PAR_21	Rated-Slip	Motor rated slip	10 ~ 250	rpm	

When encoder/motor wiring is reversed, motor cannot perform acceleration due to overcurrent. Encoder S/W error detection is adopted to detect the errors such as wrong wiring and incorrect pulse input during normal operation, not during Auto-tuning. Inverter determines encoder error if motor speed is not accelerated proportional to operating time and target speed after PAR_14 EncFaultTime elapses and polarity does not match.

6. Function Description (PAR)

To activate S/W error detection function, set CON_01 = Speed, Auto Tuning is not selected and set EncFaultTime except 0. If run command is removed before "EncFaultTime" elapses or acceleration is turned to deceleration due to target speed change, inverter cannot detect encoder S/W error. Inverter determines encoder S/W error by comparing motor speed and Target speed X EncFaultPerc while operation status is acceleration after EncFaultTime elapses.

Encoder S/W error detection is performed only once after operation starts and activates when target speed becomes twice the rated slip. For example, when target speed is 500(rpm) and rated slip is 40(rpm), the detection active level is 80(rpm).



6. Function Description (PAR)

6.3.5 Auto-Tuning

The motor parameters for the Vector Control are autotuned by Starvert-iV5. The stator resistance, Stator Inductance, Leakage Inductance and Rotor time constant are found and saved. User can select the type of Auto-tuning in Rotational or Standstill mode.

1) Motor and Encoder parameters setting for Auto-tuning

The following parameters should be set according to motor nameplate to find motor parameters correctly.

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_07	Motor Select	Motor capacity selection	2.2 ~ 220.0 User Define		
PAR_08	UserMotorSel	Motor cap. selection of USER	1.5 ~ 220.0		5.5
PAR_10	Enc Pulse	Pulse no. of encoder	360 ~ 4096		1024
PAR_17	Base Speed	Motor base speed	100.0 ~ 3600.0	rpm	1800.0
PAR_18	Rated Volt	Motor rated voltage	120 ~ 560	V	220 or 440
PAR_19	Pole Number	Motor number of poles	2 ~ 12		4
PAR_20	Efficiency	Motor efficiency	0.0 ~ 100.0	%	
PAR_21	Rated-Slip	Motor rated slip	10 ~ 250	rpm	
PAR_22	Rated-Curr	Motor rated current	1.0 ~ 450.0	A	

PAR_17 "Motor base speed" is the frequency inverter outputs its rated voltage. It is to be set within the range of Motor Max speed. **Set motor speed and rated voltage according to motor rating.** When standard motor is used, 60Hz (1800rpm) is the normal rating.

PAR_18 "Motor rated voltage"

For 200V class inverters, factory default is 220(V) and for 400V class is 440(V). When input voltage is 380(V), change it to 380V. This value is input to Voltage controller and used to prevent voltage saturation. It should be set correctly because it affects Flux current value during Auto-tuning.


PAR_20 "Motor efficiency" should be entered for (PAR_23[AutoTuneType] : StandStill), not needed for (PAR_23[AutoTuneType] : Rotational).

PAR_21 "Motor rated slip"

It is calculated by Motor speed – Motor nameplate rated speed. For example, Motor speed is 1800(rpm) with 1740(rpm) rated speed. Then, Motor rated slip would be 60(rpm).

2) Rotational Auto-tuning

2.1) Precaution

 <h2 style="margin: 0; display: inline;">CAUTION</h2>
<p>Be sure to remove the load connected to the motor shaft before performing rotational auto-tuning. Otherwise, it may lead to damage to the motor or bodily injury. DB resistor should be installed because the inverter repeats abrupt Accel/Decel many times to find the motor constant (Tr) during tuning.</p>

2.2) Parameter setting

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_23	AutoTuneType	Auto tuning type selection	Rotational StandStill		Rotational
PAR_24	Auto Tuning	Auto tuning range setting	None ALL1 ALL2 Encoder Test Rs Tuning Lsigma Flux Curr Ls Tuning Tr Tuning		None
PAR_25	Tune Torque	Tuning Torque	10.0 ~ 100.0	%	70

There are 8 types of auto-tuning selection for Rotational mode.

- ALL2: Rs→ Lsigma→ Flux Current→ Ls→ Tr
- ALL1: Encoder test →Perform ALL2

Rs, Lsigma, Flux Current, Ls, Tr: Perform each parameter separately. Tr follows Rs, Ls auto-tuning to find exact value. To save tuning time, increase PAR_25 "Tuning torque for Auto-tuning" when load inertia is high during Tr tuning. FWD/REV LED is blinking during auto-tuning.

Auto-tuning type	Description
None	No Operation
ALL1	Rs, Lσ, I Flux, Ls, Tr are tuned continuously after Encoder test
ALL2	Rs, Lσ, I Flux, Ls, Tr are tuned continuously except Encoder Test
Encoder Test	Encoder Test Only The motor is rotating at 1500 rpm in forward direction and the encoder wiring status is checked.
Rs Tuning	Rs tuning Only. The stator resistance is tuned at standstill.
Lsigma	Lsigma tuning Only. The Leakage Inductance is tuned at standstill.
Flux Curr	Flux current Only. The motor is rotating at 1500 rpm and finds Flux current.
Ls Tuning	Ls Only. The motor is rotating at 1500 rpm and finds Rotor Inductance.
Tr Tuning	Tr Only The motor is ramping UP and DOWN continuously. But tuning time can vary. It should be autotuned after Rs, Lσ, and Ls.

2.3) Rotational Auto-tuning procedure

LCD display	Description	Tuning time
PAR ► AutoTuneType 23 Rotational	Set it to " Rotational ".	-
PAR ► Auto tuning 24 ALL1	Auto-tuning starts when it is set to " ALL1 ".	-
PAR ► Auto tuning 24 Enc Testing	Checks whether the encoder wiring is properly done and an encoder works well by rotating the motor at base speed in forward direction.	30~35(Sec)
PAR ► Auto tuning 24 Rs Tuning	Stator resistance (Rs) is measured without rotating the motor.	10~20(Sec)
PAR ► Auto tuning 24 sL Tuning	The leakage inductance (sL) of the motor is measured without rotating the motor.	5 ~ 20(Sec)
PAR ► Auto tuning 24 IF Tuning	The flux current (IF) is measured by rotating the motor at base speed.	30~60(Sec)
PAR ► Auto tuning 24 Ls Tuning	Stator self-inductance (Ls) is measured by rotating the motor at base speed.	50~60(Sec)
PAR ► Auto tuning 24 Tr Tuning	Accel/Decel is performed repeatedly to find motor constant (Tr) so that DB Resistor should be connected before starting tuning. Otherwise, "Over Voltage " trip will occur.	20~60(Sec)
PAR ► Auto tuning 24 None PAR ► Auto tuning 24 [[]] Error	When auto-tuning is complete successfully, "None" is displayed. If error occurs during auto-tuning, "[[]] Error" is displayed. In this case, verify motor parameters and encoder setting is done properly and redo the auto-tuning. If the problem persists, contact LS representative.	Total: 3 ~ 5 (Min.)

3) Standstill Auto Tuning

3.1) Precaution

Be sure to lock the motor shaft using magnetic brake to find motor parameters correctly.

3.2) Parameter setting

	LCD display	Description	Setting range	Unit	Factory setting
PAR_23	AutoTuneType	Auto tuning type selection	Rotational StandStill		StandStill
PAR_24	Auto Tuning	Auto tuning range setting	None ALL1 Rs Tuning Lsigma If/Tr/Ls Tune		None

There are 4 modes for Standstill auto-tuning.

ALL1: Rs→ Lsigma→ If→ Ls→Tr

Rs Tuning, Lsigma, If/Tr/Ls Tune: Perform each parameter separately.

Auto-tuning type	Description
None	No Operation
ALL1	Rs, $L\sigma$, If/Tr/Ls are tuned continuously except Encoder Test
Rs Tuning	Rs tuning Only. The stator resistance is tuned at standstill.
Lsigma	$L\sigma$, tuning Only. The Leakage Inductance is tuned at standstill.
If/Tr/Ls Tune	Finds If/Tr/Ls by applying DC current pulse.

- FWD/REV LEDs are blinking during auto-tuning.

6. Function Description (PAR)

3.3) StandStill Type Auto-tuning procedure

LCD Display	Description	Tuning Time
PAR ► AutoTuneType 23 StandStill	Set the auto-tuning type to "Standstill".	-
PAR ► Auto tuning 24 ALL1	Auto-tuning starts if ALL1 is set.	-
PAR ► Auto tuning 24 Rs Tuning	Stator resistance (Rs) is measured without rotating the motor.	20-30 Sec
PAR ► Auto tuning 24 sL Tuning	The leakage inductance (sL) of the motor is measured without rotating the motor.	90-150 Sec
PAR ► Auto tuning 24 If/Tr/Ls Tuning	Flux current (IF), rotor time constant (τ_r) and stator self-inductance (Ls) is measured simultaneously without rotating the motor.	40-70 Sec
PAR ► Auto tuning 24 None	When auto-tuning is complete successfully, "None" is displayed. If error occurs during auto-tuning, "[] [] Error" is displayed. In this case, verify motor parameters and encoder setting is done properly and redo the auto-tuning. If the problem persists, contact LS representative.	Total: 3-5 minutes
PAR ► Auto tuning 24 [] [] Error		

4) Motor parameters

The following parameters are found during Auto-tuning.

Motor parameters described below are entered based on LG-OTIS vector motor.

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_26	Flux-Curr	Motor flux current	0.0 ~ 70% of motor rated current	A	
PAR_27	Tr	Rotor time constant	30 ~ 3000	ms	
PAR_28	Ls	Leakage inductance	0.00 ~ 500.00	mH	
PAR_29	Lsigma	Leakage coefficient	0.00 ~ 100.00	mH	
PAR_30	Rs	Stator resistance	0.000 ~ 5.000	ohm	

Additional functions are as follows;

- User can stop tuning during tuning using [STOP] key.
- In case Encoder test is failed, inverter does not conduct Rs tuning and displays "Encoder Err".
If this happens, press [Reset] key and retry Encoder test.
- Tr Tuning result can be slightly different for times. Perform it couple of times.

6. Function Description (PAR)

5) Auto tuning error message

LCD Display	Description and Solution
PAR ► Auto tuning 24 Enc Error	Displayed when phase loss of A or B occurs and/or error between reference speed and encoder feedback speed exceeds motor rated slip. Check whether wiring of encoder power (PE, 5G) and A/B phase is conducted correctly.
PAR ► Auto tuning 24 Enc AB Chgd	Displayed in case of reverse wiring of phase A/B or U, V, W. Wire the U, V, W in a correct order or change the encoder direction setting to "B Phase Lead" in PAR_11.
PAR ► Auto tuning 24 Rs Error	Displayed when RS value is greater than 5[Ω] or less than 0.002[Ω]. Check for wiring of inverter and motor and motor damage. It may occur when motor rating is much lower than that of inverter.
PAR ► Auto tuning 24 sL Error	Displayed when sL is higher than 100[mH]. Check for wiring of inverter and motor and motor damage.
PAR ► Auto tuning 24 IF Error	Displayed when motor rpm exceeds 1650 rpm (1800 rpm rated motor) during flux current calculation or flux current is not measured for a long time. Check for wiring of inverter and motor and number of motor phase.
PAR ► Auto tuning 24 Ls Error	Displayed when motor rpm exceeds 1650 rpm (1800 rpm rated motor) during Ls calculation or Ls is not measured for a long time. Check for wiring of inverter and motor and number of motor phase.
PAR ► Auto tuning 24 PAR 27 DOWN	Displayed when initial set value of PAR_27 is set too high. Repeat the calculation after lowering 30% to initial value.
PAR ► Auto tuning 24 PAR 27 UP	Displayed when initial set value of PAR_27 is set too low. Repeat the calculation after increasing 30% to initial value.

Notes:

6.4 Function group (FUN_[][])

6.4.1 Jump code (FUN_00)

Jumping directly to any parameter code can be accomplished using FUN_00 [Jump code].

Press [PROG] key first and set 2 using [▲(Up)], [▼(Down)], [SHIFT/ESC] and press [ENT] key to jump to FUN_02. If the desired code cannot be accessed or void, it automatically jumps to closest code.

FUN ▶ Spd Ref Sel
02 Analog

After jumping, it is available to jump to other codes using [▲(Up)], [▼(Down)].

6.4.2 Operating method select

1) FUN_01 (RUN/STOP source select)

There are four methods for issuing RUN/STOP command of the motor.

- Terminal 1/ Terminal 2: Digital input of the FX/RX terminal
- Keypad: [FWD], [REV], [STOP] key on the keypad
- Option: using Option card. (Factory setting: Terminal 1)

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_01	Run/Stop Src	RUN/STOP source select	Terminal 1 Terminal 2 Keypad Option		Terminal 1

Difference between Terminal 1 and Terminal 2 setting

Run/Stop source select	Terminal ON/OFF		FWD/REV select
Terminal 1	FX	ON	FWD run command
		OFF	Stop command
	RX	ON	REV run command
		OFF	Stop command
Terminal 2	FX	ON	Run command
		OFF	Stop command
	RX	ON	REV rotation
		OFF	FWD rotation

For Analog speed setting, applying (+) Voltage marks FWD Run command and (-) voltage REV Run command.

Analog speed setting range	FX / FWD / Option FWD	RX / REV / Option REV
0 ~ +10 V	Forward direction	Reverse direction
-10 ~ 0 V	Reverse direction	Forward direction

2) FUN_02 (Speed setting method)

There are four methods to set operating speed.

- Keypad 1/Keypad 2: Digital setting via keypad
- Analog: speed setting via analog input terminal define
- Option: speed setting via option card

To change speed reference in Keypad 1 method, change the value in FUN_12 Speed 0 using [▲(Up)], [▼(Down)] key and press [ENT] key to enter the value into memory. However, in Keypad 2, the changed value is reflected real-time without pressing [ENT] key.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_02	Spd Ref Src	Speed setting method	Analog Keypad 1 Keypad 2 Option		Keypad 1

3) FUN_03 (Stop method)

This determines the stop mode of the motor. If this is set to 'Decel' and then stop command is ON, the motor decelerates to a stop within the deceleration time set at FUN_39 (Deceleration Time 1). But, if the motor does not stop within the deceleration time, it is freely rotating after the deceleration time. If this is set to 'Free-run' and then stop command is ON, the motor freely rotates immediately.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_03	Stop Mode	Stop method	Decel Free-run		Decel

6.4.3 Motor Max Speed Reference

Maximum value of the speed command to the motor is set to the sum of setting speed, reference speed in Draw control, reference speed in Process PID control and reference speed in Droop control. In this case, final speed command output is limited to the maximum speed command to the motor.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_04	Max Speed	Max. motor speed	400.0 ~ 3600.0	rpm	1800.0

6.4.4 Multi-step speed and Dwell Speed setting methods

1) FUN_12 ~ 19(Multi-step speed 0 ~ 7)

2) FUN_20(JOG speed command)

If the multi-function terminal is selected as a multi-step speed setting or jog operation, the speed command is determined by the combination of multi-function terminals P1 to P7 and jog speed command.

Multi-speed command by the combination of P1, P2 and P3 is generated as follows. In case multi-step speed 0 is selected (P1, P2 and P3 all are OFF), One of the speed commands from the keypad, analog voltage input and option board is fed into the inverter. In case P4 is ON, it ignores the speed command selection by other terminals and jog

6. Function Description (FUN)

operation command has a priority. In this case, the motor is operated at the speed of FUN_20 (Jog speed command).

P1	P2	P3	P4	Setting speed
OFF	OFF	OFF	OFF	Speed command source is selected at FUN_02. (One of analog inputs, FUN_12 and Option board)
ON	OFF	OFF	OFF	FUN_13
OFF	ON	OFF	OFF	FUN_14
ON	ON	OFF	OFF	FUN_15
OFF	OFF	ON	OFF	FUN_16
ON	OFF	ON	OFF	FUN_17
OFF	ON	ON	OFF	FUN_18
ON	ON	ON	OFF	FUN_19
X	X	X	ON	FUN_20 (JOG speed command)

The values of the multi-step speed command are shown below.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_12	Speed 0	Multi-step speed 0	0.0 ~ FUN_04	rpm	0.0
FUN_13	Speed 1	Multi-step speed 1	0.0 ~ FUN_04	rpm	0.0
FUN_14	Speed 2	Multi-step speed 2	0.0 ~ FUN_04	rpm	0.0
FUN_15	Speed 3	Multi-step speed 3	0.0 ~ FUN_04	rpm	0.0
FUN_16	Speed 4	Multi-step speed 4	0.0 ~ FUN_04	rpm	0.0
FUN_17	Speed 5	Multi-step speed 5	0.0 ~ FUN_04	rpm	0.0
FUN_18	Speed 6	Multi-step speed 6	0.0 ~ FUN_04	rpm	0.0
FUN_19	Speed 7	Multi-step speed 7	0.0 ~ FUN_04	rpm	0.0
FUN_20	Jog Speed	JOG speed	0.0 ~ FUN_04	rpm	100.0


- FUN_04: Max. motor speed

3) FUN_21(Dwell Speed), FUN_22(Dwell Time)

Acceleration is instantly stopped and restarted before driving a heavy load such as hoists when selected.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_21	Dwell Speed	Dwell Speed	0.0 ~ FUN_04	rpm	100.0
FUN_22	Dwell Time	Dwell Time	0.00 ~ 100.00	sec	0.00

- FUN_04: Maximum motor speed
- disabled when FUN_22 is set to "0".




6.4.5 Accel/Decel pattern and time selection


1) FUN_33 (Accel/Decel reference speed)

Acceleration time, deceleration time and BX time is set on the basis of the value at **FUN_33(Accel./decel. reference speed)**, which is 'Max speed' or 'Ref speed'.

(Setting example 1) if FUN_33= "Max Speed", Max motor speed= 3000rpm and Operating speed= 1500rpm, Accel time= 5 sec, accel time from 0 (stop) to 1500rpm would be 2.5 sec.



(Setting example 2) If FUN_33 is set to 'Ref Speed' and speed command and acceleration time is set to 1500rpm and 5 seconds, respectively, it takes 5 seconds to accelerate from the standstill to 1500rpm.



2) FUN_40 ~ 47(Accel/Decel time 1 ~ 4)


Accel/Decel time 1-4 can be set in SV-iv5 as shown below.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_40	Acc Time-1	Acceleration time 1	0.00 ~ 6000.0	sec	2.00
FUN_41	Dec Time-1	Deceleration time 1	0.00 ~ 6000.0	sec	2.00
FUN_42	Acc Time-2	Acceleration time 2	0.00 ~ 6000.0	sec	3.00
FUN_43	Dec Time-2	Deceleration time 2	0.00 ~ 6000.0	sec	3.00
FUN_44	Acc Time-3	Acceleration time 3	0.00 ~ 6000.0	sec	4.00
FUN_45	Dec Time-3	Deceleration time 3	0.00 ~ 6000.0	sec	4.00
FUN_46	Acc Time-4	Acceleration time 4	0.00 ~ 6000.0	sec	5.00
FUN_47	Dec Time-4	Deceleration time 4	0.00 ~ 6000.0	sec	5.00

6. Function Description (FUN)

(Example) Programming P1, P2 as Xcel-L and Xcel-H

Code	LCD display	Description	Setting range	Unit	Factory setting
I/O_01	P1 define	Definition of P1 input			Xcel – L
I/O_02	P2 define	Definition of P2 input			Xcel – H




P1 (Xcel-L)	P2 (Xcel-H)	P3 (SoftStartCncl)	Accel/Decel time
OFF	OFF	OFF	Accel/Decel 1
ON	OFF	OFF	Accel/Decel 2
OFF	ON	OFF	Accel/Decel 3
ON	ON	OFF	Accel/Decel 4
X	X	ON	Max Accel/Decel

3) FUN_36 ~ 39(S curve ratio during Accel/Decel 1 ~ 2)

The ramping pattern of the Linear and S Curve could be used by setting the parameters below. S Curve pattern is used to control the acceleration of the machine as linear to minimize the shock at the start. The parameters, FUN_36 ~ 39 determine the rate of S Curve pattern as in the figure below. FUN_36, 37 are applied in the acceleration and FUN_38, 39 in the deceleration.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_36	Acc S Start	Curve ratio at the beginning of acceleration	0.0 ~ 50.0	%	0.0
FUN_37	Acc S End	Curve ratio at the end of acceleration	0.0 ~ 50.0	%	0.0
FUN_38	Dec S Start	Curve ratio at the beginning of deceleration	0.0 ~ 50.0	%	0.0
FUN_39	Dec S End	Curve ratio at the end of deceleration	0.0 ~ 50.0	%	0.0

- Programming example of S curve pattern



- Basic equation

$$St1_time = AccTime * (FUN_36 / 50.0\%)$$

$$St2_time = AccTime * (FUN_37 / 50.0\%)$$

$$St1_ \Delta rpm = St1_time * (MaxSpeed / AccTime) * 0.5$$

$$St2_ \Delta rpm = St2_time * (MaxSpeed / AccTime) * 0.5$$

● Calculation 1

$$\Delta rpm \geq St1_ \Delta rpm + St2_ \Delta rpm$$

Δrpm = The difference between the current speed and the target speed

$$L_time = (\Delta rpm - St1_ \Delta rpm - St2_ \Delta rpm) * (AccTime / MaxSpeed)$$

$$Effective\ Acceleration\ Time = St1_time + L_time + St2_time$$

● Calculation 2

$$\Delta rpm < St1_ \Delta rpm + St2_ \Delta rpm$$

$$St1'_time = \sqrt{\{ [\Delta rpm * AccTime^2 * St1_time^2] / [25 * MaxSpeed * (St1_time + St2_time)] \}}$$

$$St2'_time = \sqrt{\{ [\Delta rpm * AccTime^2 * St2_time^2] / [25 * MaxSpeed * (St1_time + St2_time)] \}}$$

$$Effective\ Acceleration\ Time = St1'_time + St2'_time$$

Δrpm : Speed difference

$MaxSpeed$: Maximum speed (FUN_04)

$AccTime$: Set acceleration time (FUN_40, 42, 44, 46)

$St1_ \Delta rpm$: Acc S Start ST (%) of FUN_36 at the time of acceleration,

Dec S End ST (%) of FUN_39 at the time of deceleration

$St2_ \Delta rpm$: Acc S End ST (%) of FUN_37 at the time of acceleration,

Dec S Start ST (%) of FUN_38 at the time of deceleration

$St1_time$: The time when $St1_ \Delta rpm$ is formed.

$St2_time$: The time when $St2_ \Delta rpm$ is formed.

4) FUN_48 (Deceleration time for zero speed selection)

5) FUN_49 (Zero speed deceleration time)

This is the time when the motor decelerates from the arbitrary speed to 0 rpm in speed. This is valid only when FUN_48 is set to 'Yes'. If 'No' is set, the set deceleration time is applied.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_48	Use 0 Dec T	Deceleration time selection for zero speed	No/Yes		No
FUN_49	0 Dec Time	Deceleration time for zero speed	0.00~6000.0	sec	0.00

6. Function Description (FUN)

6) FUN_51(Decel time when BX is ON)

When the motor should be stopped immediately in case of emergency, BX on the control circuit terminal can be used. When BX is ON, the motor decelerates to a stop within 'Emergency deceleration time' set at FUN_51. But, if the motor does not stop within the deceleration time, it rotates freely after the deceleration time. If the motor is intended to stop at the instant BX is ON, FUN_51 is set to '0'.


Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_51	BX Time	Deceleration time for emergency stop	0.0 ~ 6000.0	sec	0.0

7) FUN_52 (Pre-excitation)

FUN_52 (Motor Pre-excitation Time) can be used for the flux build-up in the induction motor to obtain the best control characteristic.

- FUN_52 is activated only when FUN_02(Spd Ref Sel) is set to Keypad1 or Keypad2.**

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_52	PreExct Time	Pre-excitation time	0 ~ 10000	ms	0



8) FUN_53(Hold Time)

The motor maintains the zero speed for 'Motor Hold Time' after the motor decelerates to a stop.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_53	Hold Time	Motor Hold Time	100 ~ 10000	ms	1000


6.4.6 Electronic Thermal (Motor I^2T) Selection

These functions are required when the motor should be protected against the overheat without installing the thermal relay between the inverter and the motor. If electronic thermal protection is ON, the inverter blocks the IGBT gating signals and issues the trip message.


Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_54	ETH Select	Electronic thermal selection	No Yes		No
FUN_55	ETH 1 Min	Electronic thermal level for 1 minute	FUN_56 ~ 200	%	150
FUN_56	ETH Cont	Electronic thermal level for continuous	50 ~ FUN_55 (But, up to 150%)	%	100
PAR_09	Cooling Mtd	Motor cooling method	Self-cool Forced-cool		Forced-cool

Electronic thermal protection level is set in % based on the 'Motor rated current' at PAR_22. '1 min.level of electronic thermal' at FUN_55 is the current level which should be referred to when the motor is operated for a minute and the motor is estimated to be overheated. 'Continuous level of electronic thermal' at FUN_56 is the current level which should be referred to when the motor is operated continuously and the motor is estimated to be in thermal equilibrium. Continuous level is set to the motor rated current (100%) and should be less than '1 min.level of electronic thermal' at FUN_55. PAR_09 'Cooling type' should be set correctly to ensure the proper electronic thermal protection.

- **Self-cool** : This should be set when cooling fan mounted on the motor shaft is used for cooling. The cooling performance is greatly reduced when the motor is operated at the low speed. Compared to high speed region, the motor is rapidly overheated at the low speed region even if the same current flows into it.
- **Forced-cool** : This should be set when the cooling fan is powered by the separate power supply. 'Continuous level of electronic thermal' at FUN_56, which is allowable continuous current is applied, regardless of the operating frequency.



[The characteristic of allowable continuous current with respect to 4 pole, 60Hz motor]



- The motor protection is possible by calculating and accumulating I^2t even in load variation and frequent run/stop.

6.4.7 Inverter switching frequency select

1) FUN_57 (Inverter switching frequency select)

This parameter affects the audible sound of the motor, noise emission from the inverter, inverter temperature, and leakage current. If the ambient temperature where the inverter is installed is high or other equipment may be affected by potential inverter noise, set this value lower. (setting range: 2.5 ~ 10.0 kHz).

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_57	PWM Freq	Switching frequency select		kHz	

2) Setting range and factory setting of switching frequency



Voltage	Inverter capacity (kW)	Setting range (kHz)	Factory setting (kHz)
200V	2.2 ~ 22(kW)	2.5 ~ 10(kHz)	10(kHz)
	30/37(kW)	2.5 ~ 7(kHz)	5(kHz)
400V	2.2 ~ 22(kW)	2.5 ~ 10(kHz)	10(kHz)
	30 ~ 75(kW)	2.5 ~ 7(kHz)	5(kHz)
	90 ~ 132(kW)	2.5 ~ 5(kHz)	4(kHz)
	160/220(kW)	2.5 ~ 4(kHz)	4(kHz)

- Continuous Operation Derating Information**

15kW-400V(MD) class model among 5.5 ~ 22kW-200/400V class models applies the following load rating.

6. Function Description (FUN)

1) Rated load classified by the switching frequency



2) The above graph is only applied when the inverter is operated in the allowable temperature. Pay attention to the air cooling when the inverter is installed in a panel box, and the inside temperature should be within an allowable temperature range.

3) This derating curve is based on inverter current rating when rated motor is connected.

6.4.8 Power ON Start Selection (FUN_58)

In case 'No' is set, the inverter can be operated only if the terminal should be 'On' again after it is 'Off' once. In case 'Yes' is set, the inverter starts to run at the instant the power is supplied to the inverter if FX terminal input is 'On' or RX terminal input is 'On'. If the inverter starts to run while the motor is freely rotating, first, the motor decelerates to a stop and restart.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_58	Power-on Run	Power on start selection	Yes No		No



CAUTION

Particular attention should be directed to this function due to potential hazard as motor starts to run suddenly upon applying AC input power.

6.4.9 Restart after fault reset (FUN_59)

In case 'No' is set, the inverter can be operated only if the terminal should be 'On' again after it is 'Off' once. In case 'Yes' is set, the inverter starts to run at the instant the inverter fault is cleared if FX terminal input is 'On' or RX terminal input is 'On'. At the time of the inverter trip, the motor start to coast to a stop because the inverter blocks the IGBT gating signals. If the inverter starts to run while the motor is freely rotating, first, the motor decelerates to a stop and restart. If set CON_49 [Speed search] to bit 1 from previous bit 2, operation begin by speed search function when fault is reset.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_59	RST Restart	Restart after fault reset	Yes No		No



CAUTION

Take caution for this function. When FUN_59 is set, motor runs immediately upon fault is reset.

6.4.10 Restart After Fault Reset

1) FUN_60 (Number of auto restart try)

2) FUN_61 (Delay time before Auto restart)

This function prevents the permanent stop of the inverter due to the trip. The inverter automatically resets the fault and restarts and continues to run after the fault occurs if the number of automatic restart is set and the inverter operation is possible.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_60	Retry Number	Number of auto restart try	0 ~ 10		0
FUN_61	Retry Delay	Delay time before Auto restart	0.0 ~ 60.0	sec	1.0

In case the inverter trip occurs, the inverter restarts by '**The number of automatic restart**' at FUN_60. In case of the inverter trip, the inverter resets the fault automatically and waits for '**Delay time before automatic restart**' at FUN_61 and restarts. The inverter will not restart any more, blocks the IGBT gating signals and issues the trip message if the inverter trip occurs more than '**The number of automatic restart**' at FUN_60.



CAUTION

- Particular attention should be directed to this function as the inverter clears the fault automatically and motor suddenly restarts when trip occurs.
- Auto restart function is disabled when the following trips occur.
 - ① BX (Emergency stop)
 - ② Low Voltage
 - ③ Arm Short-U (V, W, DB)
 - ④ Fuse Open
 - ⑤ Ext Trip-B (External trip B)
 - ⑥ InvOver Heat (inverter overheated)
 - ⑦ MotOver Heat (Motor overheated)
 - ⑧ Encoder Err (Encoder error)
 - ⑨ Over Load (Overload trip)
 - ⑩ E-Thermal (Electronic thermal protection)
- If trip does not occur for 30 sec after restart, inverter adds the number of restart by one automatically and this cannot exceed setting value.


6. Function Description (FUN)

6.4.11 Wait time for restart upon stop

- Only active when FUN_03 is set to 'Free-run' and operating method is 'Terminal'.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_62	Restart Time	Wait time for Restart upon Stop	0.00 ~ 10.00	sec	0.00
FUN_03	Stop mode	Stop method	Decel Free-run		Decel

Even though restart command is input after stopping the operation, inverter does not run until FUN_62 setting time elapses.



6.4.12 Overspeed error detection

- Inverter detects error if motor rpm exceeds its limit. User can set the detection level and time of overspeed.

Code	LCD display	Description	Setting range	Unit	Factory setting
FUN_63	OverSpdLevel	Overspeed Detection Level	100.0 ~ 130.0	%	120.0
FUN_64	OverSpd Time	Overspeed Detection Time	0.00 ~ 2.00	sec	0.00

- FUN_63 is based on 100% of FUN_04(Max Speed).
- When motor speed exceeds FUN_63 (Overspeed Detection Level) and FUN_64(Overspeed Detection Time) elapses, overspeed error detection is activated.
- If FUN_64 is set to 0.00(sec) and motor rpm exceeds FUN_63, inverter immediately detects overspeed error.

6.5 Control group (CON_[][])

6.5.1 Jump code (CON_00)

Jumping directly to any parameter code can be accomplished using CON_00 [Jump code].

Press [PROG] key first and set 11 using [▲(Up)], [▼(Down)], [SHIFT/ESC] and press [ENT] key to jump to CON_11.

If the desired code cannot be accessed or void, it automatically jumps to closest code.

CON▶ Proc PID Ref
 11 0.0 %

After jumping, it is available to jump to other codes using [▲(Up)], [▼(Down)].

6.5.2 Control mode select (CON_01)

In the motor control mode, there are **speed** and **torque** control modes based on the vector control. The speed sensor such as the pulse encoder is required if speed control ('**Speed**') and torque control ('**Torque**') are to be used.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_01	Control Mode	Control mode selection	Speed Torque		Speed

6.5.3 Application mode (CON_02)

General vector mode or Elevator mode can be selected in CON_02.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_02	Application	Application mode setting	General Vect Elevator		General Vect

※ Only displayed with Elevator option board (EL_IO) installed.

6.5.4 Automatic Speed Regulator: ASR

1) CON_05(ASR LPF Time Constant 1)

2) CON_08(ASR LPF Time Constant 2)

One of the two PI gains of ASR can be selected depending on the status of the multi-function terminal input set as the 'ASR Gain Selection'. That is, if the multi-function terminal input is 'Off', 1-numbered gain and LPF time constant is selected. On the contrary, if this input is 'On', 2-numbered gain and LPF time constant are selected.

6. Function Description (CON)

(Example) Programming P4 as ASR PI Gain

Code	LCD display	Description	Setting range	Unit	Set value
I/O_04	P4 define	Multi-function input terminal P4 definition			ASR Gain Sel

The two sets of Lowpass Filter are as follow:

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_05	ASR LPF1	ASR LPF time constant 1	0 ~ 20000	ms	0
CON_08	ASR LPF2	ASR LPF time constant 2	0 ~ 20000	ms	0

3) CON_03 ~ 04(ASR PI Gain 1)

4) CON_06 ~ 07(ASR PI Gain 2)

One of 2 sets of PI gain can be selected by "ASR Gain Sel" in Multi-function input terminal.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_03	ASR P Gain1	ASR P Gain 1	0.0 ~ 200.0	%	50.0
CON_04	ASR I Gain1	ASR I Gain 1	0 ~ 50000	ms	300
CON_06	ASR P Gain2	ASR P Gain 2	0.0 ~ 200.0	%	5.0
CON_07	ASR I Gain2	ASR I Gain 2	0 ~ 50000	ms	3000

5) CON_09 (Ramp time for ASR gain Transfer)

6) CON_10 (Motor Speed at the time of ASR Gain Transfer)

ASR PI controller can be transferred to P controller depending on the status of the multi-function terminal input set as 'ASR P/PI transfer'.


(Example) When P6 is set to ASR P/PI transfer:

Code	LCD display	Description	Setting range	Unit	Factory setting
I/O_06	P6 define	Multi-function input terminal P6 definition			ASR P/PI Sel

To avoid the shock to the control system due to the rapid change P and I gain in case of ASR gain transfer, if the multi-function terminal input set to 'ASR Gain Sel' is 'On', the transferred P gain changes gradually for the time set at CON_09. P gain 2 is transferred to P gain 1 at the higher speed than the value set at CON_10. This happens when the multi-function terminal input set to 'ASR Gain Sel' is 'On', not 'Off'


6. Function Description (CON)

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_09	ASR Ramp	Ramp time for ASR gain switch-over	10 ~ 10000	ms	1000
CON_10	ASR TarSpd	Target Speed after ASR gain switch-over	0.0 ~ 3600.0	rpm	0.0



● How to set the P and I gain of the ASR (Automatic Speed Regulator)

The P gain(%) of ASR becomes equal to the torque reference(%) when the speed difference between the speed command and the real speed fed back to the ASR is identical to the rated slip. The I gain is the time to be taken to accumulate the torque reference from 0 to 100%. That is, The output of ASR becomes equal to the 100% of the torque reference when P gain is set to 100% and the speed difference is equal to the rated slip. Speed response characteristic may be better, but the control system may be unstable when P gain is increased or I gain is decreased. On the contrary, Speed response characteristic may be degraded if P gain is decreased or I gain is increased.



6. Function Description (CON)

6.5.5 Process PID Control

Process PID controller is added outside the speed control loop and a wide variety of process control can be implemented without using the stand-alone PID controller outside the speed control loop or PLC. 'Process PID Enb' at CON_20 determines whether Process PID controller is enabled or not. 'Process PID Enb' at CON_20 can be set as follows.

(Example) programming CON_20 "Process PID Enable/Disable"

CON_20 (Proc PID Enb)	RUN/STOP command	
	ON	OFF
Disable	Disable	Disable
Enable	Enable	Disable
Terminal	Depending on terminal definition	Disable

If 'Process PID Enb' at CON_20 is set to 'Terminal', Process PID controller is enabled using 'Proc PID Dis', which is the one of the functions of the multi-function terminal input. To avoid the saturation of the process PID controller, process PI controller is enabled only when the multi-function terminal is set to 'Proc PID Dis' and the terminal is 'OFF' and the run command is 'ON'.

Multi-function input terminal defined as "Proc PID Dis"		RUN/STOP command	
Input signal		ON	OFF
Defined	ON	Disable	Disable
	OFF	Enable	Disable
Not defined		Disable	Disable

The command to Process PID controller uses the digital value (CON_10) set using the keypad or the analog value ('Process PID F/B') which is the one of the multi-function analog output. The setting range of Process PID digital input at CON_11 is from -100 to 100% and the setting range of analog input command is from -10 to 10V.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_11	Proc PID Ref	Process PID Reference Source (Keypad)	-100.0 ~ 100.0	%	0.0

6. Function Description (CON)

The definition of P gain and I gain in the Process PID controller is as follows. If P gain is 100% and I gain is 0% and the input error of the Process PID controller (CON_11 + Proc PID Ref - Proc PID F/B) is 100%, the output of Process PID controller is 100%. If I gain is 10% and P gain is 0 and the input error is 100%, it takes the output of the Process PI controller 1 second to be accumulated up to 100%. The higher I gain becomes, the faster the response becomes reducing the accumulated time. Finally, the output of Process PID controller (%) multiplied by the maximum motor speed (FUN_04) is added to the total speed command.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_13	Proc PID Kp	Process PID P gain	0.0 ~ 999.9	%	0.0
CON_14	Proc PID Ki	Process PID I gain	0.0 ~ 100.0	%	0.0
CON_15	Proc PID Kd	Process PID D gain	0.0 ~ 100.0	%	0.0

To prevent the Process PID controller from being saturated by the malfunction of the Process PID controller, the output of the Process PID controller can be limited to the positive or negative value, separately from the main speed controller.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_16	Proc Pos Lmt	Process PID positive limit	-100 ~ 100	%	100
CON_17	Proc Neg Lmt	Process PID negative limit	-100 ~ 100	%	100

Low pass filter at the output of the Process PID controller can be used. In this case, filter output is multiplied by the output gain and fed to the speed command.


Code	LCD display	Description	Setting range	Unit	Factory setting
CON_18	Proc Out LPF	Process PID output LPF time constant	0 ~ 500	ms	0
CON_19	Proc OutGain	Process PID output gain	-250.0 ~ 250.0	%	0.0

If the output error of Process PID exists at stopping, it keeps current motor speed during "PIDHoldTime" and then free-runs to stop. If output error is "0", motor is stopped regardless of "PIDHoldTime" setting.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_21	PIDHoldTime	Process PID Hold Time	0 ~ 10000	ms	0

6.5.6 Draw Control

Draw control is a sort of Open Loop tension control. Draw is the ratio of speed difference between one roll and the other. Tension is generated as in the following equation.



$$T = E \times S \times \frac{V1 - V2}{V2} = E \times S \times D$$

Where,

V1, V2: Transfer speed of each roll (m/min)


T: Tension (kg)

E: Elasticity coefficient of processed material (kg/mm²)

S: Sectional area of processed material (mm²)

6. Function Description (CON)

Draw reference multiplied by draw quantity set at CON_22 is added up to the speed command and the sum acts as the final speed command.




One of the multi-function analog input is set to the draw command ranging from -100% to 100% and the speed command multiplied by Draw quantity is added up to the speed command (Speed Ref) to obtain the final speed command.

(Example) Programming Ai2 as the Draw Reference

Code	LCD display	Description	Setting range	Unit	Factory setting
I/O_16	Ai2 Define	Multi-function analog input Ai2 definition			Draw Ref
FUN_02	Spd Ref Sel	Speed reference selection			Keypad1
FUN_12	Speed 0	Multi-speed 0	0.0 ~ 3600.0	rpm	500.0
CON_22	Draw %	Draw Quantity	-100.0 ~ 100.0	%	

☛ $\text{Run speed} = \text{Spd Ref value} + (\text{Spd Ref value} \times [\text{Draw quantity}(\%) / 100(\%)] \times [\text{Analog input}(V) / 10(V)])$




6.5.7 Droop Control

Droop control uses the drooping characteristic of the speed with respect to the torque reference. This control method is used to prevent the saturation of the speed controller due to the difference between the speed reference and the real speed when the inverter is used for load balancing of the multiple motors and helper roll, which is the auxiliary device of the main roll. As shown in the figure below, the speed command is adjusted properly depending on the torque reference.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_23	Droop %	Droop Quantity	0.0 ~ 100.0	%	0.0
CON_24	Droop MinSpd	Low speed limit of Droop control	0.0 ~ 3600.0	rpm	0.0
CON_25	Droop MinTrq	Starting torque of Droop control %	0.0 ~ 100.0	%	0.0

If the torque reference (the output of the speed controller) becomes higher than the set Droop start torque, it reduces the speed command and consequently, decreasing the torque reference. Speed command in the Droop control is as in the following equation.



((Droop Control Calculation))

- **When Torque Ref is Positive:**

$$\text{Droop Ref speed} = (\text{Torque Ref [\%]} - \text{Droop Starting Torque[\%]}) * \text{Droop Quantity[\%]}$$

The result value becomes positive. Therefore, final speed ref value decreases and it should be,

$$(\text{Speed Ref} - \text{Droop Ref speed}) > \text{Droop low limit speed}$$

$$\text{Droop Ref speed} < (\text{Speed Ref} - \text{Droop low limit speed})$$

Therefore, positive limit is "**Speed Ref – Droop Low Limit Speed**".

- **When Torque Ref is Negative:**

$$\text{Droop Ref speed} = - (\text{Torque Ref [\%]} - \text{Droop Starting Torque[\%]}) * \text{Droop Quantity [\%]}$$

The result value becomes negative. Therefore, final speed ref value increases and it should be,

$$(\text{Speed Ref} - \text{Droop Ref speed}) < \text{Max Motor speed}$$

$$\text{Droop Ref speed} > - (\text{Max Motor speed} - \text{Speed Ref})$$

Therefore, negative limit is "**Max Motor speed – Speed Ref**".

6.5.8 Torque Control

One mode among the speed control mode and torque control mode can be set at CON_01('Control Mode'). The default is the speed control mode. Control mode can be selected using the multi-function terminal input set to 'Speed/Torque control selection'. This method has a priority over the one by CON_01.

(Setting example) Programming P6 as Torque control

Code	LCD display	Description	Setting range	Unit	Setting
I/O_06	P6 define	Multi-function input terminal P6 definition			Spd/Trq sel
CON_01	Control Mode	Control mode setting	Speed Torque		Torque

1) CON_26 (Torque Reference Source Selection)

In the speed control mode, the output of the ASR acts as the torque reference. In the torque control mode, the torque reference is set by the analog input signal defined as 'Trq Ref Src' on the control circuit terminal or by the option board and the polarity is reversed if the direction of the speed command is changed. If the analog input is used as the torque reference, the analog input ranging from -10V to 10V is converted to the percentage of the rated torque (-100~100%) to obtain the torque reference, which can set from -250% to 250% by the settings of Gain and Bias.

CON_27 "Torque Ref" defines torque ref. value when torque source is set to Keypad.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_26	Trq Ref Src	Torque reference source selection	None/Analog Keypad/Option		None
CON_27	Torque Ref	Torque Ref (keypad)	-180.0 ~180.0	%	0.0

2) CON_32 (Torque Bias Source Select)

The Torque Bias is the feedforward compensation which is added to the Torque Reference. The source of Torque Bias could be selected by the Keypad (CON_32) as one of Multi Function Analog Input and the Option. The Torque Bias is enabled by MFi programmed as UseTrq Bias. The MFI should be ON for enabling the Torque Bias.

The Analog Input [-10~+10V] is converted to [-100~+100%] and this could be expanded up to [-250~+250%] with gain and bias.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_32	Trq Bias Src	Torque Bias source selection	None Analog Keypad Option		None
CON_33	Trq Bias	Torque Bias quantity	-150.0 ~ 150.0	%	0.0

3) CON_35 (Torque Balance)

In the lift use, the load torque balance can be adjusted to obtain a good riding comfort at start-up using the load cell, which is a sort of an weighing devices installed at the bottom of the lift. CON_35 is adjusted to show 50% after the car weight becomes equal to the weight of counter-weight.

The value displayed when pressing [PROG] key on the keypad is the loadcell voltage input to the inverter. Therefore, adjust the percent using [▲(Up)] / [▼(Down)] to make it to be setpoint of actual load compensation.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_35	Trq Balance	Torque Balance quantity	0.0 ~ 100.0	%	50.0

4) Torque Bias Enable/Disable

Torque bias is enabled depending on the status of the multi-function terminal input set to 'Torque bias enable'. But, if 'Torque bias enable' is not set and CON_32 is set to 'Keypad', the torque bias command set at CON_32 by the keypad, is fed directly to the torque bias quantity regardless of the status of the terminal. Therefore, In order not to use the torque bias command set at CON_33, CON_32 should be set to 'None' or the multi-function terminal input should be set to 'Torque bias enable' and then the terminal should be left open.

(Example) Programming P5 as Torque Bias EnableTorque Bias

Code	LCD display	Description	Setting range	Unit	Factory setting
I/O_05	P5 define	Multi-function input terminal P5 definition			Use Trq Bias

5) CON_34(Torque Bias F/F)

This is the torque bias quantity to compensate for the friction loss, which varies with the rotational direction of the motor and added up to the torque bias quantity.


Code	LCD display	Description	Setting range	Unit	Factory setting
CON_34	Trq Bias FF	Torque compensation for Friction loss	-150.0 ~ 150.0	%	0.0

6) CON_28 ~ 31 (Torque Limit Define, Torque Limit during FWD RUN /REV RUN/Regenerating)

The torque limit can be selected separately depending on the motor control mode such as forward rotation and reverse rotation and regeneration modes. In all modes, the limit values can be set by the function code, the multi-function terminal input and the option board, respectively.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_28	Trq Lmt Src	Torque Limit Source select			Kpd Kpd Kpd

6. Function Description (CON)



Torque Limit value is determined one of the 9 different combinations shown below depending on CON_28 setting.

CON_28 set value	Positive Torque Limit	Negative Torque Limit	Regenerating Torque Limit
Kpd Kpd Kpd	CON_29	CON_30	CON_31
Kpd Kpd Ax	CON_29	CON_30	Vx
Kpd Ax Kpd	CON_29	Vx	CON_31
Kpd Ax Ax	CON_29	Vx	Vx
Ax Kpd Kpd	Vx	CON_30	CON_31
Ax Kpd Ax	Vx	CON_30	Vx
Ax Ax Kpd	Vx	Vx	CON_31
Ax Ax Ax	Vx	Vx	Vx
Opt Opt Opt	Positive Torque Limit of Option	Negative Torque Limit of Option	Regenerating Torque Limit of Option

※ Vx marks the Torque Limit value defined in analog input terminal.

7) Torque Current reference

The torque reference is converted to the torque current reference. The torque current reference is generated from the rated current and magnetizing current of the motor.

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_07	Motor Select	Motor capacity selection	2.2 ~ 220.0	kW	
PAR_22	Rated-Curr	Motor rated current	1.0 ~ 450.0	A	
PAR_26	Flux-Curr	Motor flux current	0.0 ~ 70% of PAR_22	A	

6. Function Description (CON)

6.5.9 Speed Search

This is used to restart the motor during coasting without stopping the motor. CON_49 are required for this function. The proper values should be set depending on the inertia moment (GD^2) of the load and the torque of the motor in use.

Code	LCD display	Description	Setting range	Unit	Factory setting
CON_49	Speed Search	Speed search setting	1111		0100
FUN_58	Power-on Run	Power on Run selection	Yes No		No
FUN_59	RST Restart	Restart after fault reset	Yes No		No

CON_49 speed search setting is as follows.

Code	Set value				Description
	Bit4	Bit3	Bit2	Bit1	
CON_49				√	Speed search during Accelerating
			√		Speed search during a Fault Reset restarting
		√			Speed search during Instant Power Failure restarting.
	√				Speed search when FUN_58 Power ON starting is set to "Yes"

(1) Bit 1

0: The motor is normally accelerated without the speed search operation.

1: The speed search operation is enabled at the time of acceleration.

(Automatic restart and FUN_58[Power-on start enable] included)

(2) Bit 2

0: The motor is normally accelerated without the speed search operation after the trip occurs.

1: The speed search is enabled at the time of restart after the trip occurs.

(Automatic restart and FUN_59[Restart enable after fault reset] included)

(3) Bit 3

0: The motor stops when instantaneous power failure occurs. Run command should be turned ON again to restart the operation.

1: The speed search is enabled at the time of restart after the instantaneous power failure occurs.

(4) Bit 4

0: The motor is normally accelerated only when FUN_58 [Power-on start enable] is set to Yes.

1: The speed search operation is enabled at the time of acceleration when FUN_58 [Power-on start enable] is set to Yes.

6.6 User Group (USR_[][])

User group can be generated by collecting the frequently-used function codes, and it also can be created by using the existing function codes for the specific application.

6.6.1 Jump code (USR_00)

Jumping directly to any parameter code can be accomplished using USR_00.

(Example) Jumping to USR_03

Press [PROG] key first and set 3 using [▲(Up)], [▼(Down)], [SHITF/ESC] and press [ENT] key to jump to USR_03. If the desired code cannot be accessed or void, it automatically jumps to closest code.

USR ► User Recall
03 --- No ---

After jumping, it is available to jump to other codes using [▲(Up)], [▼(Down)].

6.6.2 Macro

1) USR_01 (Macro Init)

The initialization of the code type can be defined according to the application the user defines.

Code	LCD display	Description	Setting range	Unit	Factory setting
USR_01	Macro Init	Use Macro Definition	User Define E/L		User Define

2) USR_02(User Save)

This enables the code type and the set value which the user define to be saved into the memory.

3) USR_03(User Recall)

This enables the code type and the set value saved by USR_02('User Save') to be recalled from the memory.

Code	LCD display	Description	Setting range	Unit	Factory setting
USR_02	User Save	User data save selection	No Yes		No
USR_03	User Recall	Recall saved user data	No Yes		No


6.6.3 User code define (USR_04 ~ 67)

It displays the type and value of the user code when [PROG] key is pressed. The code can be set in the same manner as the codes in the other group can be. If the code is 'User Grp' and its set value is 'Not Used', the code can be changed by pressing the [PROG] key once more.

6. Function Description (USR)

Total 64 user group data can be programmed and saved. To make the unused data invisible, set it to "Not Used".

Changing User group codes



6.7 2nd Function Group (2nd_[][])

2nd function group is equivalent to the parameter group which includes the data related to the 2nd motor in case single inverter controls 2 motors. One of the multi-function terminal input P1 ~ P7 (I/O_01 ~ I/O_07) should be set to '2nd Func'. The setting ranges and usage of the 2nd motor parameters is basically the same as those of the 1st motor parameters. If the multi-function terminal input enables the 1st motor, the 1st motor parameters become valid. Similarly, if the multi-function terminal input enables the 2nd motor, the 2nd motor parameters become valid.

6.7.1 Jump function (2nd_00)

You can move on to the code you want to check using 2nd_00.

(Example) If you want to move on to 2nd_02,

After pressing the [PROG] key, set to 02 using [SHIFT/ESC] / [▲(Up)] / [▼(Down)] keys and then press the [ENT] key. If the code to jump to is not found, the nearest code number is selected.

2nd ▶ 2nd Max Spd
 02 1800.0 rpm

You can check the other code using [▲(Up)] / [▼(Down)] keys.

6.7.2 2nd motor control mode selection (2nd_01)

In the motor control mode, there are **speed** and **torque** control modes based on the vector control. The speed sensor such as the pulse encoder is required if speed control ('**Speed**') and torque control ('**Torque**') is to be used.

Code No.	LCD display	Function	Setting range	Unit	Factory setting
2nd_01	2nd Ctl Mode	2 nd motor control mode selection	Speed Torque		Speed

6.7.3 2nd motor speed setting

1) 2nd_02: The 2nd motor maximum speed

2) 2nd_04: The 2nd digital speed setting

Code No.	LCD display	Function	Setting range	Unit	Factory setting
2nd_02	2nd Max Spd	2 nd motor maximum speed	400.0 ~ 3600.0	rpm	1800.0
2nd_04	2nd Spd 0	2 nd motor multi-step speed 0	0.0 ~ 3600.0	rpm	0.0

6. Function Description (2nd)

6.7.4 2nd motor parameters related to acceleration and deceleration

Setting range and factory setting value should be referred to FUN_36 to FUN_41.

Code No.	LCD display	Function	Setting range	Unit	Factory setting
2nd_05	2nd Acc S St	2 nd motor S ratio 1 in accel. start	0.0 ~ 50.0	%	0.0
2nd_06	2 nd Dec S Ed	2 nd motor S ratio 2 in accel. end	0.0 ~ 50.0	%	0.0
2nd_07	2nd Dec S St	2 nd motor S ratio 1 in decel. start	0.0 ~ 50.0	%	0.0
2nd_08	2nd Dec S Ed	2 nd motor S ratio 2 in decel. end	0.0 ~ 50.0	%	0.0
2nd_09	2nd Acc time	2 nd motor acceleration time	0.01 ~ 6000.0	sec	10.0
2nd_10	2nd Dec time	2 nd motor deceleration time	0.01 ~ 6000.0	sec	10.0

6.7.5 2nd motor parameters related to the pulse encoder

Code No.	LCD display	Function	Setting range	Unit	Factory setting
2nd_12	2nd Enc #	2 nd motor encoder pulse number	360 ~ 4096	%	1024
2nd_13	2nd Enc Dir	2 nd motor encoder direction set	A Phase Lead B Phase Lead		A Phase Lead
2nd_14	2nd Enc Chk	2 nd motor encoder test enable	Yes No		Yes
2nd_15	2nd Enc LPF	2 nd motor encoder LPF time constant	00 ~ 100	ms	1

6.7.6 2nd motor parameters

Code No.	LCD display	Function	Setting range	Unit	Factory setting
2nd_17	2nd BaseSpd	2 nd motor base speed	300.0 ~ 3600.0	rpm	1800.0
2nd_18	2nd R-Volt	2 nd motor rated voltage	120 ~ 560	V	
2nd_19	2nd Pole #	the number of poles of the 2 nd motor	2 ~ 12		4
2nd_20	2nd Mot Eff.	2 nd Motor Efficiency	70 ~ 100	%	72
2nd_21	2nd R-Slip	2 nd motor rated slip	10 ~ 250	rpm	
2nd_23	2nd Flx Cur	2 nd motor magnetizing current	0.0~ Inverter rated current	A	
2nd_24	2nd Mot Tr	2 nd motor rotor time constant	30 ~ 3000	ms	
2nd_25	2nd Mot Ls	2 nd motor stator inductance	0.00 ~ 500.00	mH	
2nd_26	2nd Mot sLs	2 nd motor leakage coefficient	0.00 ~ 10.00	mH	
2nd_27	2nd Mot Rs	2 nd motor stator resistance	0.000 ~ 5.000	ohm	

6.7.7 2nd motor miscellaneous parameters

Code No.	LCD display	Function	Setting range	Unit	Factory setting
2nd_11	2nd Cool Mtd	2 nd motor cooling method	Same as the 1 st motor		Self-cool
2nd_32	2nd ETH 1min	2 nd motor 1 min. level for electronic thermal protection	Same as the 1 st motor		150
2nd_33	2nd ETH Cont	2 nd motor continuous level for electronic thermal protection	Same as the 1 st motor		100

Chapter 7 –Inspection and replacement

The iV5 series is an industrial electronic product with advanced semiconductor elements. However, temperature, humidity, vibration and aging parts may still affect it. To avoid this, it is recommended to perform routine inspections.

7.1 Precautions



CAUTION

- Be sure to remove the drive power input while performing maintenance.
- Be sure to perform maintenance only after checking that the bus has discharged. The bus capacitors in the electronic circuit can still be charged even after the power is turned off.
- The correct output voltage can only be measured by using a rectifier voltage meter. Other voltage meters, including digital voltage meters, are likely to display incorrect values caused by the high frequency PWM output voltage of the drive.

7.2 Inspection

1) Routine Inspection

Be sure to check the following before operation:

- The conditions of the installation location
- The conditions of the drive cooling
- Abnormal vibration
- Abnormal heating

2) Periodical Inspection

- Are there any loose bolt, nut or rust caused by surrounding conditions? If so, tighten them up or replace them.
- Are there any deposits inside the drive-cooling fan? If so, remove using air.
- Are there any deposits on the drive's PCB (Printed Circuit Boards)? If so, remove using air.
- Are there any abnormalities in the various connectors of the drive's PCB? If so, check the condition of the connector in question.
- Check the rotating condition of the cooling fan, the size and condition of the capacitors and the connections with the magnetic contactor. Replace them if there are any abnormalities.

3) Megger test

- ① For Exterior main circuit, remove all cables from inverter terminals to ensure that test voltage is not applied to the inverter.
- ② Use DC 500V meggar and isolate the main power before starting measurement. If the test voltage is connected to the control circuit, remove all connection cables to the control circuit.
- ③ Perform the Meggar test only between the common cables connected to the main circuit and ground.

7.3 Parts replacement

Part name	Period	Comments
Cooling fan	2 years	Exchange for a new part after consulting LS A/S center.
Electrolytic capacitor on the PCB board	3 years	Exchange for a new part after consulting LS A/S center.
Relay on the PCB board	-	Exchange for a new part after consulting LS A/S center.
DC Resistor	-	Exchange for a new part after consulting LS A/S center.
Motor	2000 time or 5 years	Exchange for a new part after consulting LS A/S center.

- The life expectancy of a part depends on the type of part, the environment, and operating conditions.

Chapter 8 – Troubleshooting and maintenance

8.1 Fault display



CAUTION

When a fault occurs, the inverter turns off its output and displays the fault status described below. In this case, the cause must be corrected before the fault can be cleared. If protective function keeps active, it could lead to reduction in product life and damage to the equipment.

Protective function	Keypad display	Description
Over Current	OC-U OC-V OC-W	The inverter turns off its output when the output current of the inverter flows more than 200% of the inverter rated current.
Ground Fault Protection	Ground Fault	The inverter turns off its output when a ground fault occurs and the ground fault current is more than the internal setting value of the inverter. Over current trip function may protect the inverter when a ground fault occurs due to a low ground fault resistance
Over voltage protection	Over Voltage	The inverter turns off its output if the DC voltage of the main circuit increases higher than the rated value (200V class: 400V DC, 400V class: 820 V DC) when the motor decelerates or when regenerative energy flows back to the inverter due to a regenerative load. This fault can also occur due to a surge voltage generated at the power supply system.
Low Voltage Protection	Low Voltage	The inverter turns off its output if the DC voltage is below the detection level because insufficient torque or over heating of the motor can occurs when the input voltage of the inverter drops.
Overload Protection	Over Load	The inverter turns off its output if the output current of the inverter flows at 180% of the inverter rated current for more than the current limit time (S/W).
Fuse Open	Fuse Open	The inverter turns off its output by opening the fuse when something is wrong with the main circuit IGBT to protect the wiring from being damaged from short currents.
Heat Sink Over Heat	InvOver Heat	The inverter turns off its output if the heat sink over heats due to a damaged cooling fan or an alien substance in the cooling fan by detecting the temperature of the heat sink.
Inverter NTC Thermistor Open	InvThem OP	When inverter NTC Thermistor is open, inverter stops its output.
Motor overheat	MotOver Heat	When motor temp exceeds 150℃ , inverter stops its output to protect motor from overheated.
Motor NTC Thermistor Open	MotThem OP	When motor NTC Thermistor is open, inverter stops its output.
Electronic Thermal	E-Thermal	The internal electronic thermal of the inverter determines the over heating of the motor. If the motor is overloaded the inverter turns off the output. The inverter cannot protect the motor when driving a multi-pole motor or when driving multiple motors, so consider thermal relays or other thermal protective devices for each motor. Overload capacity: 150% for 1 min.
External fault B	Ext Trip-B	Use this function if the user needs to turn off the output by an external fault signal.
IGBT Short	Arm Short-U Arm Short-V Arm Short-W Arm Short-DB	Inverter output is stopped when IGBT Arm short or output short occurs.

8. Troubleshooting & maintenance

Protective function	Keypad display	Description
Encoder Error	Encoder Err	Displayed when Encoder signal fault occurs.
BX protection (Instant Cut Off)	BX	Used for the emergency stop of the inverter. The inverter instantly turns off the output when the BX terminal is turned ON, and returns to regular operation when the BX terminal is turned OFF. Take caution when using this function.
Motor overspeed	Over Speed	Displayed when motor rotates over 120% its rated speed.
Communication Error	COM Error CPU Error	This fault is displayed when the inverter cannot communicate with the keypad.

8.2 Monitoring fault condition

8.2.1 monitoring fault display

Code	LCD display	Description
DIS_05	OC-U	Current fault displayed. (U-phase overcurrent)

- Check the current fault display before pressing reset key. pressing [PROG] key and [▲(Up)],[▼(Down)] shows operating status at the time of the fault such as output frequency, current, voltage, F/B value, torque current reference/actual value, dc link voltage, input/output terminal status, operating status and run time) and the fault contents. Press [ENT] key to exit. Pressing [RESET] key will store the value in DIS_05 [Last Fault1].

8.2.2 Monitoring previous faults

- Previous 2 faults are saved in DIS_05 "Last fault 1/2". Last fault 1 is more recent fault than Last fault 2. Refer to "8.2.1 monitoring fault display" to check the fault contents.

Code	LCD display	Description
DIS_05	Last Fault1	Previous fault 1
DIS_05	Last Fault2	Previous fault 2

- DIS_05 " Fault Clear" removes Last Fault1, Last Fault2 data.

8.3 Fault reset

There are 3 ways to reset the inverter. After performing this, the number of automatic restart is initialized.

- 1) Use [RESET] key on the keypad.
- 2) Short the RST-CM terminal to reset.
- 3) Cycle the power (turn the power OFF and turn it ON).

8.4 Fault remedy

8.4.1 Check the below diagnosis before troubleshooting.

- 1) Is the wiring of a motor and an inverter conducted correctly?

☞ Refer to Main Circuit Terminal

- 2) Is the Encoder-type jumper on I/O PCB set correctly?

☞ Refer to Encoder wiring

If encoder type is either Complementary or Open collector, slide JP1 switch to "OC" and short the JP2 jumper to "P15". If encoder type is Line Drive, slid the JP1 switch to "LD" and short the JP2 jumper to "P5".

Factory default: Line Drive Type

- 3) Is motor rotating direction set correctly?

☞ Refer to Monitoring Encoder operation

STARVERT-iV5 defines Forward rotation when motor rotates in clockwise from the view of Rear Bracket (Motor FAN).

- 4) Is inverter operating correctly in no load condition?

☞ Refer to Operation via Keypad and Control Terminal

8.4.2 Check list before installation

Check (1) ~ (9) before installation. Check (10) ~ (16) when problem has occurred during use.

1) The Motor Does Not Rotate when Red lamp on [STOP], [REV], [FWD] key is ON.

- ① Is red lamp lit?

☞ Check whether other trips occur in DIS_05.

If fault occurs, press [RESET] key to clear trip status and try operation.

8. Troubleshooting & maintenance

- ☞ Check whether BX (Emergency stop) signal is applied on keypad and input terminal defined as BX is ON in DIS_03. If so, release BX and try operation.

DIS 03	▶	Terminal In 0010000000
-----------	---	---------------------------

- ② RUN/STOP method is properly set ?

- ☞ Check FUN_01 RUN/STOP method setting matches the actual operation mode(RUN/STOP via keypad or terminal). If FUN_01 is set to terminal but operation is not performed, change it to keypad mode and try operation. If FUN_02 is set to Keypad but operation is not performed, change it to Terminal and try operation. If either way cannot work, refer to (6).

2) The motor does not rotate when Green lamp on [REV], [FWD] key is ON.

- ① Is inverter U, V, W output correctly wired to motor U, V, W output?

- ☞ Refer to Main circuit terminal

- ② Is the motor shaft jammed by brake or other mechanical devices?

- ☞ check the directly connected brake's relay on time and brake open time.

- ③ On DIS_01 PreRamp Ref, is speed reference displayed not "0"?

- ☞ set the desired speed reference if it is set to "0". If it is incorrectly set, refer to (7).

- ④ Is PAR_07 [motor rating] properly set?

- ☞ check the motor nameplate and setting matches.

- ⑤ Is PAR_16 [motor speed] properly set?

☞ check the motor nameplate and setting matches.

- ⑥ Is PAR_22 [motor rated current] properly set?

☞ check the motor nameplate and setting matches.

- ⑦ Is PAR_26 [motor flux current] properly set?

☞ If LG-OTIS vector motor is not used, consult LS representative or set the correct value in accordance with application. However, it cannot set to exceed PAR_22 [motor rated current]. Normally it is 30~40 % of rated motor current.

- ⑧ Is PAR_21 [motor rated slip] properly set?

☞ check the motor nameplate and setting matches.

- ⑨ Is PAR_27 [Motor secondary time constant (Tr) properly set?

☞ if motor is not LG-OTIS vector motor, perform the Auto-tuning or set this correctly. If it is incorrectly set, inverter performance will be dramatically deteriorated.

- ⑩ Is PAR_19 [number of motor poles] properly set?

☞ check the motor nameplate and setting matches.

- ⑪ CON_28 [Torque limit setting] is set to " Kpd Kpd Kpd ". Is CON_29 ~ CON_31 setting correct?

☞ CON_29 ~ CON_31 marks upper limit in inverter output torque. For the application lower torque limit is required, when torque shortage occurs, increase this value a little. STARVERT-iv5 's overload capacity is 150%/1 min. when using torque limit over 150%, time and the number of use should be limited.

- ⑫ When CON_28[torque limit setting] Analog or Option, the corresponding input value is properly set?

☞ CON_28 is set to Analog, one of Ai1/Ai2/Ai3 should be defined as "Torque limit". If set to Option, refer to Option manual for proper setting.

3) Motor speed is not increasing while it is running.

- ① Is PAR_10 [number of Encoder pulse] set properly?

☞ factory default is 1024. If it is not LG-OTIS vector motor, contact with Encoder maker.

- ② FUN_01 is set to "Keypad", FUN_02 to "Keypad1", FUN_12(Speed 0) to 100.0rpm and press [FWD] key but motor speed is not 100.0rpm. In this case, check for encoder wiring.

☞ If encoder wiring is disconnected or switched, it rotates only uni-direction with low speed (30.0 ~ 60.0rpm) and over 150% its rated current. Check the encoder wiring and whether wiring of defined terminal and motor encoder terminal is shorted.

- ③ If motor speed does not increase and keeps abnormally 30.0 ~ 60.0 rpm, stop the motor and switch the wiring of A and B phase of Encoder. Check whether motor rotating direction is reversed as seen in (4).

☞ In the case of Line Drive type encoder, wire A+, A- phase to B+, B- and B+, B- phase to A+, A-.

Complementary / for the case of Open Collector type encoder, reverse the wiring of PA and PB.

Or switch the encoder direction in **PAR 11 (Enc Dir Set) and try RUN.**

4) Motor rotates in reverse direction.

☞ Switch the wiring of output phase V and W. Switch the wiring of encoder phase A and B as indicated in (3).

Or switch the encoder direction in PAR 11(Enc Dir Set) and try RUN.

5) Motor rotating direction cannot be changed.

- ① Is RUN/STOP setting proper?

☞ Check FUN_01 RUN/STOP command setting matches the actual operating mode. If FUN_01 is set to Terminal (Keypad) but operation cannot be made, change it to Keypad (Terminal). If it does not work, refer to (2.6).

- ② Is one of the terminal defined as FWD/REV Run Disable ON?

☞ Check one of I/O_01 ~ I/O_07 terminals is defined as "Prohibit FWD" or "Prohibit REV". If so, check input terminal status in DIS_01 ~ DIS_03. If rotating direction is not changed, check the terminal is ON.

6) Keypad or terminal malfunctions.

- ① When [REV], [FWD], [STOP] key on the keypad is lit Red or Green

☞ Refer to (1) if RUN/STOP is not activated by Keypad or Terminal. If setting change is not available, PAR_04 may set to prohibit parameter write. To release this setting, enter 12 in PAR_04. If problem persists, contact LS representatives.

- ② When [STOP] key is blinking

☞ This marks trip condition or BX active status. Check any other trips occur in DIS_05. Reset the trip and try run. Check BX signal is ON on the keypad and input terminal signal in DIS_01 ~ DIS_03. Reset BX and try run.

- ③ When green lamp on [REV], [FWD] key is blinking

☞ It marks accel/decel is in operation. If inverter keeps operation in this condition, it means load capacity calculation is incorrect and exceeds inverter rating. Refer to (16).

7) Operating speed does not change during run.

- ① Is FUN_02 speed setting proper?

☞ Speed setting methods in STARVERT-IV5 are Analog input, Keypad and Option. Select appropriate one among them.

- ② Is DIS_01(PreRamp Ref) setting the correct value?

☞ Current speed ref. Values are displayed in DIS_01 ~ DIS_03. Check the displayed value matches the setting value. If speed is not variable, check the encoder. (Refer to 13)

- ③ Speed setting method is "Keypad" and speed ref displayed DIS_01 ~ DIS_03 is not correct.

☞ Check terminal setting in I/O_01 ~ I/O_07 defined as Multi-step speed setting.

- ④ When speed setting method is Analog and DIS_01 ~ DIS_03 display is not desired value

☞ Check one of Ai1 ~ Ai3 is defined as "Speed Ref."

8) Motor keeps rotating at OV condition when speed setting is via Analog input.

- ① When I/O_11 Definition of Ai1 input is set to "Speed Ref"

☞ Adjust the Ai1_Bias at I/O_14. (Setting unit: %)

The displayed value is speed command. Set the desired value (ex: 0.0%) and press [ENTER] key.

- ② Follow the same steps to check Ai2 ~ Ai3.

9) Motor detects speed reference but motor rpm is showing decreasing while motor is overheated or hunting.

- ① Check the motor wiring.

☞ There is a possibility of incorrect motor wiring when motor is 220V / 380V dual rating. Motor does not normally rotate when pole number setting is incorrect. However, motor may get damaged in case of miswiring.

If this problem occurs, contact motor sales office. Refer to Power terminal description in this manual.

- ② Is motor capacity set correctly?

☞ Check PAR_07 motor rating selection is set the same as motor in use. See the nameplate for motor rating.

- ③ Is motor parameter set correctly?

☞ Motor parameters vary by manufacturer. STARVERT-iV5 setting is based on LG-OTIS vector motor as default. Motor parameters should be changed when other makers' motor is used.

10) Nothing displayed on the LCD?

- ① Is the connection of inverter and keypad tight?

☞ Check the inverter and Keypad connection.

- ② Is input power turned on ?

☞ Check inverter power is applied. If nothing is displayed on the LCD in this condition, contact LS representatives.

11) Motor speed oscillates and speed is not constant during constant Run.

- ① Is encoder wired using twisted shield cable?

☞ encoder signal wiring should be conducted with Twisted Shield Cable. Otherwise, speed may oscillate at low speed (or high speed) due to encoder input noise, leading to motor vibration or abnormal motor sound at stop.

8. Troubleshooting & maintenance

- ② Is the connection of inverter and motor and encoder grounding proper?

☞ Check the grounding of inverter and encoder is connected. This could occur when not connected. Fixed screw for the connection of encoder grounding and the inverter is located on the right bottom side of the control PCB. Loosen the fixed screw and insert the ground wire of the encoder and tighten the screw. (Refer to encoder wiring diagram). For grounding the motor, use G of the inverter Main terminal.

- ③ Connect inverter panel grounding connected with motor grounding to the building grounding.

☞ If not, incorrect motor speed may be input due to encoder input noise.

- ④ Is too large speed gain assigned to the inverter while motor load is light?

☞ Motor oscillates at stop when PI gain is set much larger than the actual load in CON_03 and CON_04. Therefore, gain should be set accordingly. Responsiveness increases when P gain is set higher and I lower but system may become unstable. Gain value varies system but generally set **30 ~ 70%** for **P gain** and set **100** **~ 500ms** for **I gain**.

- ⑤ Increase PAR_13 Enc LPF setting value.

- ⑥ Is there slip present at the connection of encoder and motor shaft?

☞ Poor encoder and motor connection may generate slip. Check the connection is tight.

12) Parameter change is not saved.

☞ Turn the power off and turn it on. If problem persists, contact LS representatives.

13) "Fuse Open" trip occurs constantly.

① is the input (line) voltage normal?

☞ Check the line voltage input. If phase to phase unbalance exceeds 2%(greater than 6V for 380V input), an AC reactor should be provided. Otherwise, inverter may get damaged and A/S fee will be charged during Warranty period.

② is the phase sequence of the output terminal U, V, W correct?

☞ Check the level of the input signal.

③ Is the motor insulation damaged?

☞ Various types of malfunction occur when the insulation is damaged. In general, operation stops at a certain speed (and more), overload or "OC-U (V,W)" trip occurs during regenerating. Or motor overheating and rotating speed oscillates. This condition persists for a while and then "Fuse Open" trip occurs. It marks motor insulation is damaged. In this case, replace the motor.

14) Motor input current is too large.

① Check the motor wiring.

☞ Check the motor wiring for the use of 220V / 380V transition type motor. (Refer to Main circuit terminal)

② Are motor and inverter capacity set correctly?

③ Is the setting of motor constants appropriate?

☞ Refer to (2) and (9) and check the motor and inverter setting.

15) OC-U (V,W) trip occurs frequently during operation. (Motor input current is oscillating.)

- ① check the encoder installation.

☞ If encoder connection is poor, motor vibration affects encoder and incorrect encoder signal is input to the inverter. Vector inverter controls the speed from Encoder F/B value so it follows the input signal whether correct or not, increasing inverter current. If so, contact motor maker or encoder commission company.

- ② Is there no inverter output phase loss?

- ③ Is the motor insulation not damaged?

☞ Refer to 2.13 and check the inverter and motor.

16) Accel/Decel cannot be made properly and green lamp in [REV], [FWD] key is blinking.

(load and frequency reference signal is oscillating.)

- ① Check motor wiring.

- ② FUN_40 ~ FUN_47 Accel/Decel time and DIS_00 motor load.

☞ Blinking Green lamp marks motor is accelerating or decelerating. If the rotating speed oscillates and green lamp is blinking, it marks inverter output torque shortage due to mis-calculation of load. In this case, increase the torque limit to enable inverter to accelerate/decelerate within its rating. If load is set too high, it will shorten inverter life or damage to the unit.


1) MCCB(LS), ELB(LS), Magnetic contactor(LS), input/output wire specifications

Voltage	Motor (kW)	Inverter models	MCCB, ELB (LS)	Magnetic contactor (LS)	Wire (mm ²)		
					R,S,T	U,V,W	Ground
200V	5.5	SV055iV5-2DB	ABS53b,EBS53b	GMC-32	5.5	5.5	5.5
	7.5	SV075iV5-2DB	ABS63b,EBS63b	GMC-40	8	8	5.5
	11	SV110iV5-2DB	ABS103b,EBS103b	GMC-50	14	14	14
	15	SV150iV5-2DB	ABS103b,EBS103b	GMC-65	22	22	14
	18.5	SV185iV5-2DB	ABS203b,EBS203b	GMC-80	30	30	22
	22	SV220iV5-2DB	ABS203b,EBS203b	GMC-100	38	30	22
	30	SV300iV5-2	ABS203b,EBS203b	GMC-150	60	60	22
	37	SV370iV5-2	ABS203b,EBS203b	GMC-180	60	60	22
400V	5.5	SV055iV5-4DB	ABS33b,EBS33b	GMC-22	3.5	2	3.5
	7.5	SV075iV5-4DB	ABS33b,EBS33b	GMC-22	3.5	3.5	3.5
	11	SV110iV5-4DB	ABS53b,EBS53b	GMC-22	5.5	5.5	8
	15	SV150iV5-4DB	ABS63b,EBS63b	GMC-32	14	8	8
	18.5	SV185iV5-4DB	ABS103b,EBS103b	GMC-40	14	8	14
	22	SV220iV5-4DB	ABS103b,EBS103b	GMC-50	22	14	14
	30	SV300iV5-4(380V)	ABS203b,EBS203b	GMC-85	22	22	14
	37	SV370iV5-4(380V)	ABS203b,EBS203b	GMC-100	22	22	14
	45	SV450iV5-4(380V)	ABS203b,EBS203b	GMC-125	38	38	22
	55	SV550iV5-4(380V)	ABS203b,EBS203b	GMC-150	38	38	22
	75	SV750iV5-4(380V)	ABS203b,EBS203b	GMC-180	60	60	22
	90	SV900iV5-4(380V)	ABS403b,EBS403b	GMC-220	60	60	38
	110	SV1100iV5-4(380V)	ABS403b,EBS403b	GMC-300	80	80	38
	132	SV1320iV5-4(380V)	ABS403b,EBS403b	GMC-400	100	100	38
	160	SV1600iV5-4(380V)	ABS403b,EBS403b	GMC-400	100	100	60
	220	SV2200iV5-4(380V)	ABS603b,EBS603b	GMC-600	2 X 100	2 X 100	60

2) AC input fuse, AC reactor, DC reactor

Voltage	Motor (kW)	Inverter models	AC input fuse	AC reactor	DC reactor
200V	5.5	SV055iV5-2DB	40 A	0.39 mH, 30 A	1.37 mH, 29 A
	7.5	SV075iV5-2DB	50 A	0.28 mH, 40 A	1.05 mH, 38 A
	11	SV110iV5-2DB	70 A	0.20 mH, 59 A	0.74 mH, 56 A
	15	SV150iV5-2DB	100 A	0.15 mH, 75 A	0.57 mH, 71 A
	18.5	SV185iV5-2DB	100 A	0.12 mH, 96 A	0.49 mH, 91 A
	22	SV220iV5-2DB	125 A	0.10 mH, 112 A	0.42 mH, 107 A
	30	SV300iV5-2	150A	0.08 mH, 134 A	0.35 mH, 152 A
	37	SV370iV5-2	200A	0.07 mH, 160 A	0.30 mH, 180 A
400V	5.5	SV055iV5-4DB	20 A	1.22 mH, 15 A	5.34 mH, 14 A
	7.5	SV075iV5-4DB	30 A	1.14 mH, 20 A	4.04 mH, 19 A
	11	SV110iV5-4DB	35 A	0.81 mH, 30 A	2.76 mH, 29 A
	15	SV150iV5-4DB	45 A	0.61 mH, 38 A	2.18 mH, 36 A
	18.5	SV185iV5-4DB	60 A	0.45 mH, 50 A	1.79 mH, 48 A
	22	SV220iV5-4DB	70 A	0.39 mH, 58 A	1.54 mH, 55 A
	30	SV300iV5-4(380V)	100 A	0.33 mH, 67 A	1.19 mH, 76 A
	37	SV370iV5-4(380V)	100 A	0.27 mH, 82 A	0.98 mH, 93 A
	45	SV450iV5-4(380V)	100 A	0.22 mH, 100 A	0.89 mH, 112 A
	55	SV550iV5-4(380V)	150 A	0.15 mH, 121 A	0.75 mH, 135 A
	75	SV750iV5-4(380V)	200 A	0.13 mH, 167 A	0.44 mH, 187 A
	90	SV900iV5-4(380V)	250 A	0.11 mH, 201 A	0.35 mH, 225 A
	110	SV1100iV5-4(380V)	300 A	0.09 mH, 245 A	0.30 mH, 274 A
	132	SV1320iV5-4(380V)	400 A	0.08 mH, 290 A	0.26 mH, 324 A
	160	SV1600iV5-4(380V)	400 A	0.06 mH, 357 A	0.22 mH, 399 A


- SV055, 075, 110, 150, 185, 220iV5-2(DB)
- SV055, 075, 110, 150, 185, 220iV5-4(DB)



● Dimensions (unit: mm [inches])

Models	W1	W2	W3	W4	W5	L1	L2	L3	D1	D2	D3	H1	H2	H3
SV055iV5-2/4DB	234.4	180	180	27.2	27.2	406.2	391.2	7.5	221.1	209.5	75	6	Φ 6	Φ 12
SV075iV5-2/4DB	[9.22]	[7.08]	[7.08]	[1.07]	[1.07]	[15.9]	[15.4]	[0.29]	[8.7]	[8.24]	[2.95]	[0.23]		
SV110iV5-2/4DB														
SV150iV5-2/4DB	335	284	284	25.5	25.5	526	509	10	248.6	237	100	7	Φ 7	Φ 14
SV185iV5-2/4DB	[13.1]	[11.1]	[11.1]	[1.00]	[1.00]	[20.7]	[20.0]	[0.39]	[9.78]	[9.33]	[3.93]	[0.27]		
SV220iV5-2/4DB														


- SV 110, 150, 185, 220iV5-2DB(MD)
- SV 110, 150, 185, 220iV5-4DB(MD)



● Dimensions (unit : mm[inches])

인버터 용량	W1	W2	H1	H2	D1
SV110iV5-2/4DB(MD)	250	230	385	370	221
SV150iV5-2/4DB(MD)	[9.84]	[9.06]	[15.16]	[14.57]	[8.70]
SV185iV5-2/4DB(MD)	304	284	460	445	254
SV220iV5-2/4DB(MD)	[11.97]	[11.18]	[18.11]	[17.52]	[10.00]


- SV300, 370iV5-2
- SV300, 370, 450, 550, 750iV5-4



● Dimensions (unit: mm [inches])

Models	W1	W2	W3	W4	L1	L2	L3	D1	D2	D3	D4	P1	P2
SV300iV5-2/4	270	270	319.2	350	635	660	680	120	197	256.6	308.2	16.9	8
SV370iV5-2/4	[10.6]	[10.6]	[12.5]	[13.7]	[25.0]	[26.0]	[26.7]	[4.72]	[7.76]	[10.1]	[12.1]	[0.66]	[0.31]
SV450iV5-4	275	275	359.6	375	730.6	758.5	780	82.3	189.3	259	326	24.5	10.5
SV550iV5-4	[10.8]	[10.8]	[14.1]	[14.7]	[28.7]	[29.8]	[30.7]	[3.24]	[7.45]	[10.2]	[12.8]	[0.90]	[0.41]
SV750iV5-4													


■ SV900, 1100, 1320, 1600iV5-4



Dimensions (unit: mm [inches])

Models	W1	W2	W3	L1	L2	L3	D1	D2	D3	D4	P1	P2
SV900iV5-4	430	507	530	729	760	780	83.2	234.6	286.2	335	23.5	8.5
SV1100iV5-4	[16.9]	[19.9]	[20.8]	[28.7]	[29.9]	[30.7]	[3.27]	[9.23]	[11.2]	[13.2]	[0.92]	[0.33]
SV1320iV5-4	430	507	530	949	980	1000	95.2	231.6	298	345	23.5	8.5
SV1600iV5-4	[16.9]	[19.9]	[20.8]	[37.3]	[38.5]	[39.3]	[3.75]	[9.12]	[11.7]	[13.5]	[0.92]	[0.33]

■ SV2200iV5-4




● Dimensions (unit: mm [inches])

Models	W1	W2	W3	L1	L2	L3	L4	D1	D2	D3	D4	P1	P2
SV2200	540	649	680	922	968.5	998	150	100.2	271	343	403	38	12
iV5-4	[21.26]	[25.55]	[26.77]	[36.3]	[38.13]	[39.29]	[5.91]	[3.94]	[10.67]	[13.5]	[15.87]	[1.49]	[0.47]


Appendix C – Encoder Division Option Card (OC Type)

1) Encoder Division Option Card Installation

- Connect the option card's CN2 connector to CN4 on the control board.



► **Control board**



► **I/O board**

2) Wiring guide for Encoder Division Option Card

- Connect Encoder output terminal (Open collector output) on I/O board to input terminal of the option card.

Terminal name		Description	Connection board and terminal
Input	PA_IN	Encoder Phase A Division Input	I/O Board: RA (Phase A Output)
	G24	GND	I/O Board: GE (GND)
	PB_IN	Encoder Phase B Division Input	I/O Board: RB (Phase B Output)
	G24	GND	I/O Board: GE (GND)
Output	RT_A	Encoder Phase A Division Input	External controller: Phase A Input
	G24	GND	External controller: GND
	RT_B	Encoder Phase B Division Input	External controller: Phase B Input
	G24	GND	External controller: GND

Appendix C – Encoder Division Option Card (OC Type)

Encoder Division Output

Only available when Encoder Division Output Option Card is installed.

Sets the division ratio for monitoring the Encoder pulse signals.

Code	LCD display	Description	Setting range	Unit	Factory setting
PAR_31	EncDiv Ratio	Encoder Pulse Output Division Rate	1 ~ 1128		1
PAR_32	EncDivFilter	Encoder Division Output Filter	0 ~ 15		0

Encoder division output option card outputs one pulse signal when input pulse number matches the value set in PAR_31. A/B pulse output follows input pulse phase. The relationship between output of A, B pulse follows the same as input pulse. Division ration can be set within the range of 1 (1 output pulse per 1 input pulse) ~ 1/128(1 output pulse to 128 input pulse).

PAR_31 setting range: 0001 ~ 1128. Division ratio cannot be set higher than 1 and only 1 or 2 can be set for numerator.

The below is Division ratio calculation formula.

N refers to the value from thousand (Q000) and M refers to value less than thousand (0000)

PAR_31 set value = $N \times 1000 + M$.

$$\text{Division ratio} = (1+N)/M$$

Setting range: N (0, 1), M (1 ~ 128)

PAR_31 =

\uparrow \uparrow
 N M

When PAR_31 setting value is below 1000 (N=0), a numerator value becomes 1 and when above 1000 (N=1), a numerator value becomes 2. For example, if PAR_31 is set to 15, the division ratio is 1/15 and if 1015, the ratio is 2/15. Division ratio is settable up to 1/128 and greater than 1 is not settable. Using Up key on the keypad PAR_31 value is increased and increase routine is 1 → 2 → 3 → 4 → ... → 127 → 128(Division ratio: 1/128) → 1002 (Division ratio: 1) → 1003 → ... → 1128 (Division ratio: 1/64) and decrease routine (using Down key on the keypad) is the same as increase routine.

Appendix D – Braking Resistor and Braking Unit

1) The Selection of Dynamic Braking Resistor

Resistor values shown in the following table is calculated on the basis of 150% of rated braking torque, 5% ED 1). Power rating of resistor should be doubled for 10% ED use. Additional braking unit should be installed for above SV 300iV5-2 / SV300iV5-4.

Type No.	Inverter	Rated Capacity (5% ED)	
		[Ω]	[W] ⁽²⁾
BR0800W020J	SV 055iV5-2 DB	20	800
BR1200W015J	SV 075iV5-2 DB	15	1200
BR2400W010J	SV 110iV5-2 DB	10	2400
BR2400W008J	SV 150iV5-2 DB	8	2400
BR3600W005J	SV 185iV5-2 DB	5	3600
BR3600W005J	SV 220iV5-2 DB	5	3600
BR1000W085J	SV 055iV5-4 DB	85	800
BR1200W060J	SV 075iV5-4 DB	60	1200
BR2000W040J	SV 110iV5-4 DB	40	2400
BR2400W030J	SV 150iV5-4 DB	30	2400
BR3600W020J	SV 185iV5-4 DB	20	3600
BR3600W020J	SV 220iV5-4 DB	20	3600

- ✓ (1): ED is based on 100 seconds.
- ✓ (2): Rated capacity is based on the self-cooling.

2) Wiring of the Temperature sensor on Braking Resistor

Temperature sensor is attached in the LSIS braking resistors to prevent the fire.

Terminal of Braking Resistor	Power Terminal of Inverter	Action
B1, B2	P, BR	
P7, CM	One of the multi-function input terminals (P1 ~ P7) should be set to 'External Fault Signal b Contact'.	Contact is normally ON at the ambient temperature and is OFF in case of over-temperature.

3) Braking Unit

There is only single braking unit of 37kW for 200V class and are two kinds of the braking unit of 37kW and 55kW for 400V class. Above SV 900iV5-4 (90kW, 400V), The Combination of two braking unit for 400 class is possible.

- ① SV037DBH-2: 37kW/200V Class Braking Unit
- ② SV037DBH-4: 37kW/400V Class Braking Unit
- ③ SV075DBH-4: 75kW/400V Class Braking Unit

4) Combination of Braking Unit


Inverter Braking Unit		SV□□□iV5 -2		SV□□□□iV5-4									
		300	370	300	370	450	550	750	900	110 0	132 0	160 0	220 0
200V	37kW	1	1										
400V	37kW			1	1				1	1			
	75kW					1	1	1	1	1	2	3	

Note)


- Example) Combine two braking units of 75kW-400V Class for SV-900iV5-4(90kW) Class.
- Refer to the Braking Unit user manual that came with the braking unit.

5) Braking Resistor for Braking unit


Braking Unit	100% of Braking Torque, 10% ED	
	Resistance [Ω]	Rated Power [kW]
37kW-200V	4	11.1
37kW-400V	16	11
75kW-400V	8	22.5




Setpoint setting (I/O : AI1)




* AI2 ~ AI3 setting follow this Sequence.




**Gain, Bias setting
(10~0V, 20~4mA)**





**Gain, Bias setting
(-10~-10V, 4~20mA)**





**Gain, Bias setting
(10~0V, 20~4mA)**




Freq./Speed setting





Freq./Speed Reference




Drive Sequence Section





















MFi Output Signal



ADDITIONAL UL MARKING

1. Short Circuit Rating

“Suitable For Use On A Circuit Capable Of Delivering Not More Than Table1* RMS Symmetrical Amperes, 240 for rated 240V drives or 480 for rated 480V drives Volts Maximum,” or equivalent.

Table1*

Inverter Capacity	Rating
200/400V Class: 5.5kW, 7.5kW, 11kW, 15kW, 18.5 kW, 22kW, 30kW, 37kW	5,000A
400V Class: 45kW, 55kW, 75kW, 90kW, 110kW, 132kW	10,000A
400V Class: 160kW, 220kW	18,000A

2. SHORT CIRCUIT FUSE/BREAKER MARKING

Use Class H or K5 UL Listed Input Fuse and UL Listed Breaker Only. See the table below for the Voltage and Current rating of the fuses and the breakers.

Input [V]	Inverter [kW]	External Fuse		Breaker		Internal Fuse			
		Current [A]	Voltage [V]	Current [A]	Voltage [V]	Current [A]	Voltage [Vac/dc]	Manufacturer	Model Number
200 Class	5.5	40	500	50	220	60	250	Hinode Elec	250GH-60
	7.5	50	500	60	220	60	250	Hinode Elec	250GH-60
	11	70	500	100	220	125	250	Hinode Elec	250GH-125
	15	100	500	100	220	150	250	Hinode Elec	250GH-150
	18.5	100	500	225	220	175	250	Hinode Elec	250GH-175
	22	125	500	225	220	225	250	Hinode Elec	250GH-225
	30	150	500	225	220	250	250	Hinode Elec	250GH-250S
	37	200	500	225	220	250	250	Hinode Elec	250GH-250S
400 Class	5.5	20	500	30	460	35	660	Hinode Elec	660GH-35
	7.5	30	500	30	460	35	660	Hinode Elec	660GH-35
	11	35	500	50	460	63	660	Hinode Elec	660GH-63
	15	45	500	60	460	80	660	Hinode Elec	660GH-80
	18.5	60	500	100	460	100	660	Hinode Elec	660GH-100
	22	70	500	100	460	125	660	Hinode Elec	660GH-125
	30	100	500	100	460	125	600	Hinode Elec	600FH-125S
	37	100	500	225	460	150	600	Hinode Elec	600FH-150S
	45	100	500	225	460	200	600	Hinode Elec	600FH-200S
	55	150	500	225	460	200	600	Hinode Elec	600FH-200S
	75	200	500	225	460	125	600	Hinode Elec	600FH-125S
	90	250	500	400	460	200	600	Hinode Elec	600FH-200S
	110	300	500	400	460	200	600	Hinode Elec	600FH-200S
	132	400	500	400	460	300	600	Hinode Elec	600FH-300S
	160	400	500	400	460	300	600	Hinode Elec	600FH-300S
	220	—	—	600	460	600	600	Hinode Elec	600SPF-600UL

3. FIELD WIRING TERMINAL

- 1) Use Copper wires only with Copper conductors, 75°C
- 2) Input and motor output terminal blocks are intended only for use with ring type connectors.

4. CAUTION-Risk of Electric Shock

“Before opening the cover, disconnect all power and wait at least 10 minutes”

Units suitable only for use in a pollution degree 2 environment. Be sure to mount the inverter in a forced-ventilated operating panel.

Warranty

Maker	LS Industrial Systems Co., Ltd.		Installation (Start-up) Date	
Model No.	SV-iV5		Warranty Period	
Customer Information	Name			
	Address			
	Tel.			
Sales Office (Distributor)	Name			
	Address			
	Tel.			

Warranty period is 12 months after installation or 18 months after manufactured when the installation date is unidentified. However, the guarantee term may vary on the sales term.

■ IN-WARRANTY service information

If the defective part has been identified under normal and proper use within the guarantee term, contact your local authorized LS distributor or LS Service center.

■ OUT-OF WARRANTY service information

The guarantee will not apply in the following cases, even if the guarantee term has not expired.

- Damage was caused by misuse, negligence or accident.
- Damage was caused by abnormal voltage and peripheral devices' malfunction (failure).
- Damage was caused by improper repair or altering by other than LS authorized distributor or service center.
- Damage was caused by an earthquake, fire, flooding, lightning, or other natural calamities.
- When LS nameplate is not attached.
- When the warranty period has expired.

Leader in Electrics & Automation

LS Industrial Systems Co., Ltd.

10310000420

■ HEAD OFFICE

Yonsei Jaedan Severance Bldg. 84-11 5ga, Namdaemun-ro,
Jung-gu Seoul 100-753, Korea
Tel. (82-2)2034-4643~4649
Fax. (82-2)2034-4879, 2034-4885
<http://www.lsis.biz>

• LS Industrial Systems Tokyo Office >> Japan

Address: 16F, Higashi-Kan, Akasaka Twin Towers 17-22, 2-chome, Akasaka,
Minato-ku Tokyo 107-8470, Japan
Tel: 81-3-3582-9128 Fax: 81-3-3582-0065 e-mail: dongjins@lsis.biz

• LS Industrial Systems Dubai Rep. Office >> UAE

Address: P.O.Box-114216, API World Tower, 303B, Sheikh Zayed road,
Dubai, UAE.
Tel: 971-4-3328289 Fax: 971-4-3329444 e-mail: hwyim@lsis.biz

• LS-VINA Industrial Systems Co., Ltd. >> Vietnam

Address: LSIS VINA Congty che tao may dien Viet-Hung Dong Anh Hanoi,
Vietnam
Tel: 84-4-882-0222 Fax: 84-4-882-0220 e-mail: srjo@hn.vnn.vn

• LS Industrial Systems Hanoi Office >> Vietnam

Address: Room C21, 5Th Floor, Horison Hotel, 40 Cat Linh, Hanoi, Vietnam
Tel: 84-4-736-6270/1 Fax: 84-4-736-6269

• Dalian LS Industrial Systems Co., Ltd. >> China

Address: No. 15 Liaohexi 3 Road, economic and technical development zone,
Dalian, China
Tel: 86-411-8273-7777 Fax: 86-411-8730-7560 e-mail: lxk@lgis.com.cn

• LS Industrial Systems International Trading (Shanghai) Co., Ltd. >> China

Address: Room 1705-1707, 17th Floor Xinda Commercial Building No 322,
Xian Xia Road Shanghai, China
Tel: 86-21-6278-4291 Fax: 86-21-6278-4372 e-mail: xuhg@lgis.com.cn

• LS Industrial Systems (Wuxi) Co., Ltd. >> China

Address: 102-A National High&New Tech Industrial Development Area, Wuxi,
Jiangsu, China
Tel: 86-510-534-6666 Fax: 86-510-522-4078 e-mail: Xuhg@lgis.com.cn

• LS Industrial Systems Beijing Office >> China

Address: Room 602, North B/D EAS, 21 Xiao Yun Road, Dongsanhuan Beilu,
Chaoyang District Beijing 100027, China
Tel: 86-10-6462-3254 Fax: 86-10-6462-3236 e-mail: linsz@lgis.com.cn

• LS Industrial Systems Guangzhou Office >> China

Address: Room 1403, 14F, New Poly Tower, 2 Zhongshan Liu Road,
Guangzhou, China
Tel: 86-20-8326-6754 Fax: 86-20-8326-6287 e-mail: zhangch@lgis.com.cn

• LS Industrial Systems Chengdu Office >> China

Address: Room 2907, Zhong Yin B/D, No. 35, RenminZhong(2)-Road,
Chengdu, China
Tel: 86-28-8612-9151 Fax: 86-28-8612-9236 e-mail: hongkonk@vip.163.com

• LS Industrial Systems Qingdao Office >> China

Address: 7B40, Haixin Guangchang Shenyue Building B, No. 9,
Shandong Road Qingdao, China
Tel: 86-532-580-2539 Fax: 86-532-583-3793 e-mail: bellkuk@hanmail.net

* LS Industrial Systems constantly endeavors to improve its product so that
information in this manual is subject to change without notice