

Digital DRIVE for Brushless motor IMDL Series

INSTALLATION GUIDE

Read manual before installing and respect
all indications with this icon:



Table of Contents

1- Introduction	4
<i>1-1- Warning</i>	<i>4</i>
<i>1-2- IMDL series drive description</i>	<i>5</i>
2- Installation	7
<i>2-1- General</i>	<i>7</i>
<i>2-2- Front view</i>	<i>8</i>
<i>2-3- Top view</i>	<i>9</i>
<i>2-4- Bottom view</i>	<i>10</i>
<i>2-5- Mounting</i>	<i>11</i>
<i>2-6- Connector pin assignments</i>	<i>12</i>
<i>2-7- Cables</i>	<i>23</i>
<i>2-8- Connection diagrams / Protections</i>	<i>24</i>
<i>2-9- Stand-alone drive</i>	<i>25</i>
<i>2-10- Drive controlled by a motion controller</i>	<i>26</i>
<i>2-11- Connecting a motor brake</i>	<i>27</i>
<i>2-12- System checks before starting</i>	<i>27</i>
<i>2-13- STATUS DISPLAY</i>	<i>28</i>
<i>2-14- Error messages:</i>	<i>31</i>

1- Introduction

1-1- Warning



Read this manual before first installing, nonobservance may result in property damages and in personal injuries.

Only suitable qualified personnel should undertake the mounting, installation, operation and maintenance of the equipment must be complied with the general setup and safety regulations for work on power installations (e.g. DIN, VDE, EN, IEC or other national and international regulations).

It is important that all safety instructions are strictly followed. Personal injury can result from a poor understanding of the safety requirements.

The following safety regulations should be followed:

• VDE 0100	Specification for the installation of power systems up to 1000 V
• VDE 0113	Electrical equipment of machines
• VDE 0160	Equipment for power systems containing electronic components.

- ***Never open the equipment.***
- ***Dangerous high voltages exist within the equipment and on the connectors. Because of this, before removing any of the connectors, it is necessary to remove the power and wait at least 5 minutes to allow the capacitors to discharge.***
- ***Never connect or disconnect the drive with power applied.***
- ***Some of the drive's surfaces can be very hot.***

Some of the drive's components are susceptible to damage from electrostatic discharges. Always handle the equipment using appropriate anti-static precautions.

We have gone to great lengths to ensure this documentation is correct and complete. However, since it is not possible to produce an absolutely error-free text. No responsibility will be assumed by SERAD for all damages caused by using this documentation and software.

We reserve the right to make changes to all or part of the specification without prior notice.

1-2- IMDL series drive description

Supply :	IMDL230 : 230V AC ±10% single phase IMDL400 : 400V AC ±10% three phase			
Auxiliary supply :	24 V DC ±10%, 0.4A typical (0,7A max if all options)			
Supply filter :	Integral			
Switching frequency :	6.67 kHz sine-wave PWM			
DC bus voltage :	310 V for IMDL 230 series, 560V for IMDL 400 series			
Braking resistance :	Integral IMDL 230 : 110 ohms 30W IMDL 400 : 150 ohms 30W Facility to add an external resistor :			
	Type	Min. value	Max.cont. power	Max imp. power
	IMDL230 /2	60 Ω	1000W	2300W
	IMDL230 /5	30 Ω	1800W	4600W
	IMDL400 /1 ou /5	80 Ω	2800W	7000W
Protection :	Short circuit between phases, phase to earth, over current, I2t Over voltage, under voltage Motor feedback fault			
Motor feedback :	Resolver SinCos encoder Hiperface ^(option)			
Master encoder :	Incremental encoger Absolute encoder SSI SinCos encoder Hiperface ^(option) Virtual			
Encoder emulation :	Incremental : A, /A, B, /B, Z, /Z 1 to 100 000 points per rev			
Diagnostic :	STATUS display			
Communication :	RS 232 MODBUS RTU RS 422 ^(option) , RS 485 MODBUS RTU ^(option) EtherCAT ^(option) CANopen ^(option)			
Digital inputs :	4 inputs (with 2 fast inputs I3 and I4) 12 additional inputs with expansion module (with 2 fast inputs I15 and I16) Type: PNP, 24V DC, 8mA per input and 15 per fast input Logic 0: Between 0 and 5 V Logic 1: Between 8 and 30 V			
Digital outputs :	2 outputs as standard S1 : Relay, 48V dc / 48V ac, 3A max S2 : NPN (open collector) 24V dc, 100mA 8 additional outputs with expansion module Type : PNP 24V dc, 500mA max per output Protected against short circuit and over temperature.			
Analogue inputs :	2 inputs : Input voltage : ±10 V Maximum voltage : ±12 V Input impedance : 20 Kohms Resolution : 16 bits for input 1 and 12 bits for input 2			

Analogue output :	1 output : Output voltage : ± 10 V Maximum current : 5 mA Resolution : 8 bits, bandwidth 20Hz
Architecture :	Processor :150 MHz DSP and 100 000 gates FPGA FLASH memory for programs and parameters RAM memory for data FRAM memory for variables Real-time, multi-tasking kernel
Control loops :	Current loop : 75 μ s Speed loop : 150 μ s Position loop : 150 μ s
Operating modes :	Torque mode Speed mode Position mode Stepper Mode (pulse input, direction) Motion functions (absolute, relative and infinite movements, S profile) Advanced motion functions (gearbox, CAM profiles, CAMBOX functions, triggered movement)
Operating temperature :	0 to 40°C
Storage temperature :	-10 to 70°C
Degree of protection :	IP 20
Weight	3,6 Kg

Drive	Rated current	Peak current (2s)	Rated power	Dimensions w x h x d
IMDL230 / 2	2,5 Aeff	5 Aeff	0,7 kVA	64 x 293 x 201
IMDL230 / 5	5 Aeff	10 Aeff	1,5 kVA	64 x 293 x 201
IMDL400 / 1	1,25 Aeff	2,5 Aeff	0,7 kVA	64 x 293 x 201
IMDL400 / 4	4 Aeff	8 Aeff	2,2 kVA	64 x 293 x 201

2- Installation


2-1- General



It is very important to adhere to the following:

- ⚡ A badly earthed connection can damage electronic drive components.
- ⚡ The drive must be installed vertically in free air to ensure cooling by natural convection.
- ⚡ It must be protected from excess humidity, liquids, and dirt.
- ⚡ The motor, resolver and encoder cables must be screened, the screen being earthed at both ends of the cable.
- ⚡ The analogue I/O must use screened cable, the screen being earthed at one end only.
- ⚡ The cable for the RS 232 serial link between the drive and the PC must be screened, the screen being earthed at both ends of the cable. It should be disconnected from the drive when no longer in use. All of these cables, as well as the I/O cables, should be run separately from the power cables.
- ⚡ Diodes must be fitted across the loads on all static digital outputs (Q2 to Q10). These diodes must be positioned as close to the load as possible. The supply and signal cables must be free from over-voltage transients.
- ⚡ Safety standards specify a manual reset after a stop caused either by a supply interruption, or by an emergency stop or by a drive fault.
- ⚡ For all serious faults, it is obligatory to remove the high voltage supply to the drive.
- ⚡ The Drive Ready output should be connected in series in the emergency stop loop.
- ⚡ In the case of axis over-travel, the over-travel limit switches must be connected to the limit inputs or in series with the emergency stop loop. It is also recommended to use the software limits.
- ⚡ If the drive is configured in speed loop, the drive enable input should be controlled by the supervisory controller (CNC, PLC etc).
- ⚡ If the drive is configured in position loop, the parameter "Maximum following error" should be set appropriately.
- ⚡ If the drive contains an application program developed using iDPL, connect a signal 'Cabinet supplies OK' to one of the digital inputs and monitor it in a non-blocking safety task. On detection of an excess following error the drive will be put in open loop mode and the drive ready relay will be opened. If another action is required you should use the SECURITY instruction.

2-2- Front view



STATUS

X1 COM

X2 EXT1

X3 EXT2


7-segment diagnostic display

RS-232 serial port for communication with a PC

Extension: Optional communications ports

Extension: Optional communications ports

2-3- Top view




X4	ENCODER OUTPUT	Multifunction encoder output
X5	ENCODER INPUT	Multifunction encoder input
X6	AUX. SUPPLY 24VCC	Auxiliary 24V DC supply
X7	DIGITAL I/O	Digital I/O
X8	BALLAST	External braking resistor
X9	EXTENDED I/O	Option: I/O expansion board
X	SAFE	Option : Secure input



The voltage on connector X8 can reach 400V for an IMDL 230 and 800V for an IMDL 400!

2-4- Bottom view



X10	POWER	Single / Three-phase supply Motor armatures
X11	FEEDBACK	Motor position feedback (resolver / encoder)
X12	ANALOG	Analogues I/O
X 13	SINCOS	Motor position feedbacks (if SINCOS encoder is used)




Care must be taken when making connection to connector X10. An incorrect connection can seriously damage the drive. Dangerous voltages are present on X10.

Wait at least 5 minutes to allow the capacitors to discharge before remove connector.


2-5- Mounting

Several drives can be mounted side-by-side provided that enough space (at least 20 mm) is left to ensure good natural convection. Let a space greater than 90 cm over and under drives to allow for the various connectors and cables to be fitted



2-6- Connector pin assignments


X1: RJ45 serial port for downloading programs and parameters.

N°	Name	Type	Description
1			
2	RXD	Inp	Receive data
3	TXD	Out	Transmit data
4			
5	GND		0V
6			
7			
8	CTS	Inp	Clear to send
	SHIELD		Connect the shield to the shell of the connector


In the iDPL software, the RS232 communication is established when the icon in the bottom left side is in this fixed state :



If the connection is not stable (state icon connected/disconnected), check if the cable and the USB-serial converter are certified by SERAD. Otherwise please contact our technical department.



X2 & X3: Extension: Optional communications port

N°	Module RS 232	Module RS 422	Module RS 485	Module CANopen	Module EtherCAT	Module TCP
1					TD +	TD +
2	RXD	RX+			TD -	TD -
3	TXD	RX-			RD +	RD +
4						
5	GND	GND	GND	GND		
6					RD -	RD -
7		TX-	TRX-	CAN_L		
8		TX+	TRX+	CAN_H		
	Connect the shield to the shell of the connector					

- X2 and X3 are identical and have the same connection. They make easier drive network connection.
- For the TCP module, refer to the documentation [TCP option installation guide](http://www.serad.fr) available on www.serad.fr
- Node Address : For RS422, RS485 and CANopen, the NodeID corresponds to the five firstly dipswitchs + 1

Ex:

Node ID n°	1	2	3	4	5	6	7	8	9	10	...	32
Dip switch												
1	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON		ON
2	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF		ON
3	OFF	OFF	OFF	OFF	ON	ON	ON	ON	OFF	OFF		ON
4	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	ON		ON
5	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF		ON

For the RS422, RS485 and CANopen module, the terminal resistor is activated by the dip switch n°6 (120Ω).



In CANopen, do not use the Node ID n° 1 if you have a multi drive project.



RS232 communication allows communication with only 1 device (ex: 1 PLC and 1 IMD drive).

- Node Address : For RS422, RS485 and CANopen, the NodeID corresponds to the six firstly dipswitchs + 1

Ex:


Node ID n°	1	2	3	4	5	6	7	8	9	10	...	64
Dip switch												
1	OFF	ON	OFF	ON	OFF	ON	OFF	ON	OFF	ON		ON
2	OFF	OFF	ON	ON	OFF	OFF	ON	ON	OFF	OFF		ON
3	OFF	OFF	OFF	OFF	ON	ON	ON	ON	OFF	OFF		ON
4	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	ON	ON		ON
5	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF		ON
6	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF		ON

X4: Multifunction encoder output:

- Encoder emulation output

The choice of the number of points is made from the iDPL software.

Connector : SUBD 9 way female

N°	Name	Type	Encoder emulation
1	A	Out	Channel A
2	/A	Out	Channel A inverted
3	B	Out	Channel B
4	/B	Out	Channel B inverted
5	Z	Out	Channel Z
6	/Z	Out	Channel Z inverted
7			
8	GND		0V
9			
	SHIELD		Connect the shield to the shell of the connector

NC (Not connected): It is forbidden to connect this pins.


X5: Multifunction encoder input:

- Incremental encoder input
- SSI encoder input
- Stepper input

The choice of the input is made in iDPL software in the Multifunction encoder input windows

TTL 5V encoder (0-5V, differential)

Connector : SUBD 9 way male

N°	Name	Type	Incremental encoder	Codeur SSI	Stepper
1	A	Inp	Channel A	Data	Direction
2	/A	Inp	Channel A inverted	/Data	/Direction
3	B	Inp	Channel B	NC	Pulse
4	/B	Inp	Channel B inverted	NC	/Pulse
5	Z	I/O	Zero marker	Clock	NC
6	/Z	I/O	Zero marker inverted	/Clock	NC
7	+5Vdc	Out	Supply for external encoder, 100 mA max.*	NC	NC
8	GND		0V	0V	0V
9		Inp	NC	SSI selection : Connect pins 8 and 9	NC
	SHIELD		Connect the shield to the shell of the connector		

* If the feedback is SINCOS then don't use 5V powersupply (pin 7 of connector X5) but an external powersupply.



NC (Not connected): It is forbidden to connect this pins.

X6: 24V dc supply

Connector: Removable 2 ways, 5.08mm pitch

N°	Name	Type	Description
1	XGND		0V
2	24Vdc	Inp	Control card supply, backup motor position

X7: Digital I/O

Connector: Removable 8 ways, 3.81mm pitch

N°	Name	Type	Description
1	Q2	Out	Output 2, programmable : type NPN, 24 Vdc, 100mA
2	Q1	Out	Output 1, programmable : standard function DRIVE READY
3	Q1		Relay contact, N/O between terminals 2 and 3
4	DGND		0V digital I/O
5	I4	Inp	Input 4, programmable
6	I3	Inp	Input 3, programmable
7	I2	Inp	Input 2, programmable
8	I1	Inp	Input 1, programmable:standard function ENABLE



The output Q2 is NPN open collector: the load must be connected between Q2 and +24V DC.

X8: High voltage supply

Connector: Removable 4 ways, 7.62mm pitch

No.	Name	Type	Description
1	RI		Internal braking resistor *
2	RB		Braking resistor *
3	DC Bus +	Out	DC bus (310 V for IMDL 230, 560 V for IMDL 400)
4	DC Bus -	Out	DC bus (310 V for IMDL 230, 560 V for IMDL 400)

*Selection of the braking resistor:

- Internal resistor: Fit a link between terminals 1 and 2

- External resistor: Remove the link between terminals 1 and 2


Connect the external resistor between terminals 2 and 3



The voltage on connector X8 can reach 400V for an IMDL 230 and 800V for an IMDL 400!

X9: Option: Expansion module, 12 inputs / 8 outputs

Connector: SUBD 25 way female

N°	Name	Type	Description
1	I5	Inp	Input 5, programmable
2	I6	Inp	Input 6, programmable
3	I7	Inp	Input 7, programmable
4	I8	Inp	Input 8, programmable
5	I9	Inp	Input 9, programmable
6	I10	Inp	Input 10, programmable
7	IOGND*		0V digital I/O
8	Q3	Out	Output 3, programmable
9	Q4	Out	Output 4, programmable
10	Q5	Out	Output 5, programmable
11	Q6	Out	Output 6, programmable
12	IO 24Vdc**	Inp	External supply, 24 V dc
13	IO 24Vdc**	Inp	External supply, 24 V dc
14	I11	Inp	Input 11, programmable
15	I12	Inp	Input 12, programmable
16	I13	Inp	Input 13, programmable
17	I14	Inp	Input 14, programmable
18	I15	Inp	Input 15, programmable
19	I16	Inp	Input 16, programmable
20	Q7	Out	Output 7, programmable
21	Q8	Out	Output 8, programmable
22	Q9	Out	Output 9, programmable
23	Q10	Out	Output 10, programmable
24	IOGND*		0V digital I/O
25	IOGND*		0V digital I/O
	SHIELD		Connect the shield to the shell of the connector

* Pins 7, 24, 25: internal connection

** Pins 12, 13: internal connection


X10: Motor armature

Connector: Removable 8 ways, 7.62mm pitch


No.	Name	Type	Description
1	PE		Supply earth
2	L1*	In	Supply L1 (230V for IMDL 230, 400V for IMDL 400)
3	L2*	In	Supply L2 (230V for IMDL 230, 400V for IMDL 400)
4	L3	In	Supply L3 (230V for IMDL 230, 400V for IMDL 400)
5	PE		Motor earth
6	U	Out	Motor phase U
7	V	Out	Motor phase V
8	W	Out	Motor phase W

For a 230V ac single-phase supply, connect Live to L1 and Neutral to L2

SERAD MOTOR



DESCRIPTION	
1	Phase U
4	Phase V
3	Phase W
2	Earth
C	Break +
D	Break -



Attention. Care must be taken when making connection to connector X10. An incorrect connection can seriously damage the drive. Dangerous voltages are present on X10.


The armoured motor cable must arrive directly on the terminals of the drive.


Connect the shield (on drive side) to the screw provided (see 2-2 Front view).

The maximum length for the power and feedback cables is 20m. For more than 20m, please contact our technical support.

X11: Motor position feedback (resolver)


Connector: SUBD 9 way female

N°	Name	Type	Description
1	S2	Inp	Sine Hi
2	S1	Inp	Cosine Hi
3	AGND		0V analogue
4	R1	Out	Reference Hi
5	°CM+	Inp	Motor temperature sensor Hi
6	S4	Inp	Sine Lo
7	S3	Inp	Cosine Lo
8	°CM-	Inp	Motor temperature sensor Lo
9	R2	Out	Reference Lo
	SHIELD		Connect the shield to the shell of the connector




X12: Analogue I/O

Connector : SUBD 9 way male

N°	Name	Type	Description
1	IN2 -	Inp	Analogue input 2
2	IN2+	Inp	Analogue input 2 : assigned to torque limit
3	IN1-	Inp	Analogue input 1
4	IN1+	Inp	Analogue input 1 : assigned to speed or torque command
5	AGND		0V analogue
6	-12V	Out	-12V, 20 mA output
7	AGND		0V analogue
8	+12V	Out	+12V, 20 mA output
9	OUT	Out	Analogue output (function monitor)
	SHIELD		Connect the shield to the shell of the connector

X13: Option: SinCos encoder input

Connector: SUBD 15 way male

N°	Name	Type	Description
1	°CM +	Inp	Motor temperature sensor Hi
2	AGND		0V analogue
3	/DATA	I/O	/DATA (EnDat*) /RS485 (HIPERFACE)
4	/CLK	Out	/CLOCK (EndDat*)
5	+5V	Out	+5V, 200 mA output (EnDat*)
6			
7	REFCOS	Inp	Cosine Hi
8	REFSIN	Inp	Sine Hi
9	°CM-	Inp	Motor temperature sensor Lo
10	+8,3V	Out	+8.3V, 150 mA output(HIPERFACE)
11	DATA	I/O	DATA (EnDat*) RS485 (HIPERFACE)
12	CLK	Out	CLOCK (EndDat*)
13			
14	COS	Inp	Cosine Lo
15	SIN	Inp	Sine Lo
	SHIELD		Connect the shield to the shell of the connector

* EnDat in develloping

X SAFE : Option : Secure input SIL2

Connector removable 2 ways, 3.81mm pitch

N°	Name	Type	Description
1	0V	In	0V
2	24V	In	Input

Refer to the documentation [Safety option installation guide](http://www.serad.fr) available on www.serad.fr

2-7- Cables

We can made you all cables with connectors (standard, robotics ...), contacts us.

- RS 232 serial communication cable, X1:

Screened cable, 4 core

Connect the shield on each extremity, to the shell of the connector (RJ45 and SUBD).

- Encoder cable, X4/X5:

Screened cable with 4 twisted pairs, 0.25 mm²

Connect the shield on each extremity, to the shell of the connector.

- Analogue cable, X12:


Screened cable, 2 core, 0.25 mm² per analogue input.

Connect the shield: on drive side to the screw provided (see 2-2 Front view) and on the other side to the shell equipment (ex. Motion controller ...)

- Motor feedback cable (resolver), X11:

Screened cable with 4 twisted pairs, 0.25 mm²

Ground the shield of the feedback SUBD as shown below:



- Motor power cable, X10:

Screened cable, 4 core, (+2 for a brake), 1.5 mm² until 8A drive else use 2,5 mm²

Connect the shield (on drive side) to the screw provided (see Front view of the drive).

2-8- Connection diagrams / Protections



All connections must be realised by qualified personnel. The cables must be tested before being connected as any wiring fault can give rise to serious problems

Remove all voltages before inserting the connectors.

Ensure that the earth connection to the drive is correctly made (pin 4 of the connector X8).

Connect the motor earth to the drive (pin 5 of the connector X10) before applying any voltages.


For the shielded cables, to connect the braid to the frame at each extremity via the caps of the connectors (for the SUBD) or the screws provided for this purpose (X7) in order to ensure an optimal equipotentiality.

Preventive reference rejection measures should be taken for control panel, such as connections contactors (obligatory on brake) and relay using RC elements or diodes(ex 1N4007).

Drive	Input voltage	Max. input current	Safety device : cutout C curve	Wire
IMDL230 / 2	230V monophasé	7A	10A maxi	1,5 ²
IMDL230 / 5	230V monophasé	14A	10A maxi	1,5 ²
IMDL400 / 1	400V three phase	2,2A	10A maxi	1,5 ²
IMDL400 / 4	400V three phase	6,6A	10A maxi	1,5 ²


Caution: the ringing current can reach 25A during 10ms.

2-9- Stand-alone drive




The output Q2 is NPN open collector, 100mA max. The load must be connected between Q2 and +24Vdc.

2-10- Drive controlled by a motion controller



The output Q2 is NPN open collector, 100mA max. The load must be connected between Q2 and +24Vdc.

2-11- Connecting a motor brake



The output Q2 is NPN open collector, 100mA max. The load must be connected between Q2 and +24Vdc.

Using the iDPL parameter set-up window, select the function Brake for output 2.



It is obligatory to put the 2 protection diodes else drive components can be damaged.

2-12- System checks before starting

- ✎ With the Enable input off, switch on the auxiliary 24V dc supply.
- ✎ Ensure that on the **STATUS display**, the point blinking.
- ✎ Apply power.
- ✎ If the Status display shows an **error message** check the list of error codes.

2-13- STATUS DISPLAY


▪ When the drive is starting


1) BOOT initialisation

Before the initialisation of the boot, the STATUS DISPLAY display :



In case of initialisation fault, you may have the following faults :


➤  : Checksum fault during the initialisation.

➤  : The OS is not loaded correctly. Refer to the documentation [loading of operating system](#) available on www.serad.fr


➤  : Internal fault

2) OS initialisation

The segments switch on fastly in the following order :



3) **End initialisation**, the number of OS version is displayed




The example above gives you the OS version 3.38


▪ Drive running

• Blinking of the point


If system is linking (IDPL link) :



If the drive is not linked :




• Enable state



If the instructions display is used in a tasks, the display is a priority.

• Motor position state

The segments around are moving serving the motor position.



Rotation
moving +



Rotation
moving -




If the instructions display is used in a tasks, the display is a priority.

- **X-SAFE state**

In case of drive with safety option :

- 3 segments horizontales blinking indicate they don't have 24v on the X-safe connector.



- When the 24v is back again on the X-safe connector, the status display go back on normal running, if the instruction display have been used before, the status display can be locked on this state :



When a new instruction display is used the status display will change.

2-14- Error messages:

E01

DC Bus over-voltage : an over-voltage has been detected on the internal dc bus. This fault can be due either to an over-voltage on the supply or to the braking resistance being insufficient.

E02

DC Bus under-voltage : an under-voltage has been detected on the internal dc bus. This condition is only monitoring when the drive is active (Enable = ON, tension DC Bus voltage lesser then a drive's parameter) and when drive try to pass enable (DC Bus voltage lesser than 250V).

E03

I²t motor : I²t motor detected.

E04

Over-current : a current greater than the maximum current has been detected. The drive must be powered 24Vdc (Connector X6) for 15 min before it can be unlocked (iDPL v3.38 or higher). Immediate unlocking possible by computer in advanced mode.

E05

Short-circuit : a short-circuit between phases or between a motor phase and earth has been detected. The drive must be powered 24Vdc (Connector X6) for 15 min before it can be unlocked (iDPL v3.38 or higher). Immediate unlocking possible by computer in advanced mode.

E06

Temperature IGBT : maximum temperature attained in the drive.

E07

Temperature motor : maximum motor temperature attained.

E08

Resolver fault : Resolver feedback or absolute encoder or SinCOS signals defective.

E09

Invalid parameters : checksum error on the drive parameters or parameters not initialised.

E10

Drive type error : the parameter file does not correspond to the drive type or parameters not configured.

E11

iDPL error : an error has been detected during the execution of the iDPL tasks (division by zero, not correct instruction, CAM or synchro. movement error ...).

E12

Following error : the maximum following error has been exceeded. Contact technical support.

E13

FLASH memory error: impossible writting. Contact technical support.

E 14

FPGA error : impossible loading or CAN communication error.
Contact technical support.

E 15

Over velocity : motor velocity is higher than nominal speed in torque mode

E 16

Feedback saturation error. Feedback or SinCos signals are too high.

E 17

Power supply error (24v). Please check the power supply (see 1-2).

E 18

Error during a writing operation on the memory stick.

E 19

The loading from the memory stick to the drive have failed, because the datas are corrupted. The memory stick have been remove and update by the drive project.

E 20

External communication failed. The EtherCAT communication lost.

