TOSHIBA

Instruction Manual

The new high-performance inverter TOSVERT™ VF-AS1

200V class 0.4~75kW 400V class 0.75~500kW

NOTICE

- Make sure that this instruction manual is delivered to the end user of the inverter unit.
- Read this manual before installing or operating the inverter unit, and store it in a safe place for reference.

E65813014

Safety precautions	I
Introduction	II
Contents	
Read first	1
Connection equipment	2
Operations	3
Searching and setting parameters	4
Basic parameters	5
Extended parameters	6
Operation with external signal	7
Monitoring the operation status	8
Taking measures to satisfy the CE/UL/CSA standards	9
Selection of peripheral devices	10
Table of parameters	11
Specifications	12
Before making a service call	13
Inspection and maintenance	14
Warranty	15
Disposal of the inverter	16

I. Safety precautions

The items described in these instructions and on the inverter itself are very important so that you can use the inverter safely prevent injury to yourself and other people around you as well as prevent damage to property in the area. Thoroughly familiarize yourself with the symbols and indications shown below and then continue to read the manual. Make sure that you observe all cautions given.

Explanation of markings

Marking	Meaning of marking
Warning	Indicates that errors in operation may lead to death or serious injury.
A Caution	Indicates that errors in operation may lead to injury (*1) to people or that these errors may cause damage to physical property. (*2)

(*1) Such things as injury, burns or shock that will not require hospitalization or long periods of outpatient treatment.

(*2) Physical property damage refers to wide-ranging damage to assets and materials.

Meanings of symbols

Marking	Meaning of marking
\Diamond	Indicates prohibition (Don't do it). What is prohibited will be described in or near the symbol in either text or picture form.
0	Indicates something mandatory (must be done). What is mandatory will be described in or near the symbol in either text or picture form.
Δ	Indicates warning. What is warned will be described in or near the symbol in either text or picture form. Indicates caution. What the caution should be applied to will be described in or near the symbol in either text or picture form.

■ Limits in purpose

This inverter is used for controlling speeds of three-phase induction motors in general industrial use.

♠ Safety precautions

- ▼ The inverter cannot be used in any device that would present danger to the human body or which a malfunction or error in operation would present a direct threat to human life (nuclear power control device, aviation and space flight control device, traffic device, life support or operation system, safety device, etc.). If the inverter is to be used for any special purpose, first get in touch with the supplier.
- ▼When using inverters for critical equipment, even though the inverters are manufactured under strict quality control always fit your equipment with safety devices to prevent serious accident or loss should the inverter fail (such as failure to issue an inverter trouble signal)
- ▼ Do not use the inverter for loads other than those of properly applied three-phase induction motors in general industrial use.
 - (Use in other than properly applied three-phase induction motors may cause an accident.)
 - When the inverter is used to control the operation of a permanent magnet motor, a combination test must be conducted in advance. For details on the test, contact your supplier.

■ General Operation

<u> </u>		Reference
Disassembly	Never disassemble, modify or repair. This can result in electric shock, fire and injury. For repairs, call your sales agency.	2.
prohibited		
	Never remove the front cover when power is on or open door if enclosed in a cabinet. The unit contains many high voltage parts and contact with them will result in electric shock.	2.
	Don't stick your fingers into openings such as cable wiring hole and cooling fan covers. This can result in electric shock or other injury.	2.
Prohibited	Don't place or insert any kind of object into the inverter (electrical wire cuttings, rods, wires). This can result in electric shock or fire.	2.
	Do not allow water or any other fluid to come in contact with the inverter. This can result in electric shock or fire.	2.
	Turn power on only after attaching the front cover or closing door if enclosed in a cabinet.	2.
	If power is turned on without the front cover attached or closing door if enclosed in a cabinet, this can result in electric shock or other injury.	3.
V	If the inverter begins to emit smoke or an unusual odor, or unusual sounds, immediately turn power off. If the equipment is continued to operate in such a state, the result may be fire.	3.
Mandatory	Call your local sales agency for repairs.	
	 Always turn power off if the inverter is not used for long periods of time since there is a possibility of malfunction caused by leaks, dust and other material. The leakage current caused by the contamination may result in fire. 	3.

	⚠ Caution	Reference
Prohibited contact	Do not touch any radiating fins or radiating resistors. They can become very hot, and you may get burned if you touch them.	3.

■ Transportation & installation

	<u> </u>	Reference
	Do not install or operate the inverter if it is damaged or any component is missing. This can result in electric shock or fire. Please consult your local sales agency for repairs.	2.
Prohibited	Do not place any inflammable objects nearby. If a flame is emitted due to malfunction, it may result in a fire.	1.4.4
Trombited	Do not install in any location where the inverter could come into contact with water or other fluids. This can result in electric shock or fire.	2.
	Must be used in the environmental conditions prescribed in the instruction manual. Use under any other conditions may result in malfunction.	1.4.4
	Must be installed in non-inflammables such as metals. The rear panel gets very hot. If installation is in an inflammable object, this can result in fire.	1.4.4
V	Do not operate with the front panel cover removed. Doing so could result in electric shock. As a supplemental to the first shock of the firs	1.4.4
Mandatory	 An emergency stop device must be installed that fits with system specifications (e.g. shut off input power then engage mechanical brake). Operation cannot be stopped immediately by the inverter alone, thus risking an accident or injury. 	10. 1.4.4
	All options used must be those specified by Toshiba. The control of the con	
	The use of any other option may result in an accident.	1.4.4

	⚠ Caution	Reference
Prohibited	When operating, do not hold by the front panel covers. The covers may come off and the unit will drop out resulting in injury. Do not install in any area where the unit would be subject to large amounts of vibration. That could result in the unit falling, resulting in injury. Do not expose the drive to halogen group disinfectants.	2. 1.4.4
Mandatory	Failure to comply may cause damage to the electrical components in the drive. Models (20kg or more in weight) designed for 200V-18.5kW or larger and 400V-22kW or larger should be carried by 2 people more, or it could fall and cause an injury. Handle large capacity models using a crane. Lifting heavy inverters can cause injury to persons. Taking care of safety for users, handle carefully in order not to damage the inverter. Carefully lift up the inverter, hanging wires on the hanging bolts or holes on the top or bottom of the inverter.	2.
	Note 1: Always keep the two sling ropes in balance when lifting the inverter, and take care that unexpected force does not apply to the inverter during lifting. Note 2: Always protect the inverter with a cover when transporting it. Note 3: Do not put your hand in the wiring port or do not hold it when transporting the	
	inverter. • The main unit must be installed on a base that can bear the unit's weight. If the unit is installed on a base that cannot withstand that weight, the unit may fall resulting in injury.	1.4.4
	 in injury. Install a mechanical brake whenever the motor requires a brake (device which retains the motor shaft). Failure to do so could lead to injury to persons because the inverter itself has no function of mechanically retaining the brake shaft. 	1.4.4

■ Wiring

	<u> </u>	Reference
	Do not connect input power to the output (motor side) terminals (U/T1,V/T2,W/T3). That will destroy the inverter and may result in fire.	2.2
\bigcirc	 Do not connect resistors to the DC terminals (between PA/+ and PC/-, or between PO and PC/-). That may cause a fire. 	2.2 5.19
Prohibited	Connect resistors as directed by the instructions for "Installing separate braking resistors." Within 15 minutes after turning off input power, do not touch wires of devices (MCCB) connected to the input side of the inverter. That could result in electric shock.	2.2
	Electrical construction work must be done by a qualified expert. Connection of input power by someone who does not have that expert knowledge may result in fire or electric shock.	2.
	Connect output terminals (motor side) correctly. If the phase sequence is incorrect, the motor will operate in reverse and that may result in injury.	2.
	Wiring must be done after installation. If wiring is done prior to installation that may result in injury or electric shock.	2.
Mandatory	The following steps must be performed before wiring. Turn off all input power to the inverter. What at least 15 minutes and check to make sure that the charge lamp is no longer lit. What at least 15 minutes and check to make sure that the charge lamp is no longer lit. What the voltage to the DC main circuits (between PA/+ and PC/-) is 45V or less. If these steps are not properly performed, the wiring will cause electric shock.	2.
	Tighten the screws on the terminal board to specified torque. If the screws are not tightened to the specified torque, it may lead to fire.	2.
	 Check to make sure that the input power voltage is +10%, -15% of the rated power voltage written on the rating label (±10% when the load is 100% in continuous operation). If the input power voltage is not +10%, -15% of the rated power voltage (±10% when the load is 100% in continuous operation) this may result in fire. 	1.4.4
•	Ground must be connected securely. If the ground is not securely connected, it could lead to electric shock or fire when a malfunction or current leak occurs.	2. 2.2 10.
Be Grounded		

	⚠ Caution	Reference
Prohibited	Do not attach equipment (such as noise filters or surge absorbers) that have built-in capacitors to the output (motor side) terminals. That could result in a fire.	2.1

<u>^</u>

Caution



• Charged capacitors can present a shock hazard even after source power is removed.

 Drives with EMC filters will retain a charge on the input terminals for up to 15 min. after the power has been removed. To avoid electrical shock, don't touch the connector terminals and uninsulated source cables at either the main circuit disconnect or the drive until the capacitive charge has dissipated.

■ Operations

	<u> </u>	Reference
	 Do not touch inverter terminals when electrical power is applied to the inverter even if the motor is stopped. Touching the inverter terminals while power is connected to it may result in electric shock. 	3.
	Do not touch switches when thands are wet and do not try to clean the inverter with a damp cloth.	3.
\Diamond	Such practices may result in electric shock. Do not go near the motor in alarm-stop status when the retry function is selected. The motor may suddenly restart and that could result in injury. Take measures for safety, e.g. attaching a cover to the motor, against accidents when the motor unexpectedly restarts.	3.
Prohibited	 The inverter is tuned automatically (auto-tuning F 400=2, 3) when the inverter is started for the first time after setup. During auto-tuning, which takes several seconds, the motor is energized, although it is standing still. Noise may be produced by the motor during auto-tuning, which, however, 	6.22
	does not indicate that something is wrong with the inverter or the motor. • Do not set the stall prevention level ($F \in \mathcal{G} : 1$) extremely low. If the stall prevention level parameter ($F \in \mathcal{G} : 1$) is set at or below the no-load current of the motor, the stall preventive function will always be active and increase the frequency when it judges that regenerative braking is taking place. Do not set the stall prevention level parameter ($F \in \mathcal{G} : 1$) below 30% under normal use conditions.	6.33.1
Ω	Do not turn on the power before attaching the front cover. When storing inside the cabinet and using with the front cover removed, always close the cabinet doors first and then turn power on. If the power is turned on with the front cover or the cabinet doors open, it may result in electric shock.	3. 10.
Mandatory	Make sure that operation signals are off before resetting the inverter after malfunction. If the inverter is reset before turning off the operating signal, the motor may restart suddenly causing injury.	3.
	 Provide cranes and hoists with sufficient circuit protection such as mechanical braking. Without sufficient circuit protection, the resulting insufficient motor torque during tuning could create a risk of machine stalling/falling. 	6.22

	⚠ Caution	Reference
Mandatory	Observe all permissible operating ranges of motors and mechanical equipment. (Refer to the motor's instruction manual) Not observing these ranges may result in injury.	3.

When sequence for restart after a momentary failure is selected

	<u> </u>	Reference
Mandatory	Stand clear of motors and mechanical equipment. If the motor stops due to a momentary power failure, the equipment will start suddenly when power is restored. This could result in unexpected injury. Attach cautions about sudden restart after a momentary power failure on inverters, motors and equipment for prevention of accidents in advance.	5.18.1

When retry function is selected

	<u> </u>	Reference
Mandatory	Stand clear of motors and equipment. If the motor and equipment stop when the alarm is given, selection of the retry function will restart them suddenly after the specified time has elapsed and alarm condition has disappeared. This could result in unexpected injury. To prevent accidents, stick caution notices that the inverter has a retry function to the inverter, the motor and the machine.	6.14.1

Maintenance and inspection

	<u> </u>	Reference
Prohibited	Never replace any part by yourself. This could be a cause of electric shock, fire and bodily injury. To replace parts, call the local sales agency.	14.2
Mandatory	The equipment must be inspected every day. If the equipment is not inspected and maintained, errors and malfunctions may not be discovered which could lead to accidents. Before inspection, perform the following steps. The transpection of the inverter. Wait at least 15 minutes and check to make sure that the charge lamp is no longer lit. Sue a tester that can measure DC voltage 800VDC or more, and check to make sure that the voltage to the DC main circuits (between PA/+ and PC/-) is 45V or less. If inspection is performed without performing these steps first, it could lead to electric shock.	14. 14. 14.2

Disposal

	⚠ Caution	Reference
Mandatory	If you throw away the inverter, have it done by a specialist in industry waste disposal*. If you throw away the inverter by yourself, this can result in explosion of capacitor or produce noxious gases, resulting in injury. (*) Persons who specialize in the processing of waste and known as "industrial waste product collectors and transporters" or "industrial waste disposal persons." If the collection, transport and disposal of industrial waste is done by someone who is not licensed for that job, it is a punishable violation of the law. (Laws in regard to cleaning and processing of waste materials)	16.

Attach caution labels

Shown here are examples of caution labels to prevent, in advance, accidents in relation to inverters, motors and other equipment.

If the inverter has been programmed for auto-restart function after momentary power failure or retry function, place caution labels in a place where they can be easily seen and read.

If the inverter has been programmed for restart sequence of momentary power failure, place caution labels in a place where they can be easily seen and read.

(Example of caution label)



Caution

(Functions programmed for restart)

Do not go near motors and equipment. Motors and equipment that have stopped temporarily after momentary power failure will restart suddenly after recovery. If the retry function has been selected, place caution labels in a location where they can be easily seen and read. (Example of caution label)



**** Caution

(Functions programmed for retry)

Do not go near motors and equipment.

Motors and equipment that have stopped temporarily after an alarm will restart suddenly after the specified time has elapsed and alarm condition has disappeared.

II. Introduction

Thank you for your purchase of the Toshiba "TOSVERT VF-AS1" industrial inverter.

II

This instruction manual is intended for inverters with CPU version 150 or later.

The CPU version will be frequently upgraded.

- Contents -

		ecautionstion	1 7			
1.	Rea	Read first A-				
	1.1	Check the product	A-1			
	1.2	Contents of the product code ·····	A-1			
	1.3	Structure of the main body ·····	A-2			
	1.3.1	Names and functions	A-2			
	1.3.2	Detaching the cover	A-9			
	1.3.3	Grounding capacitor switching method	A-12			
	1.3.4	Installing the DC reactor	A-16			
	1.4	Notes on the application	A-17			
	1.4.1	Motors	A-17			
	1.4.2	Inverters	A-19			
	1.4.3	What to do about the leak current	A-20			
	1.4.4	Installation	A-22			
2.	Con	nection equipment	B-1			
	2.1	Cautions on wiring	B-1			
	2.2	Standard connections	B-3			
	2.3	Description of terminals	B-10			
	2.3.1	Main circuit terminals	B-10			
	2.3.2	Control circuit terminal block	B-11			
	2.3.3	Serial RS485 communication connector	B-16			
3.		rations·····	C-1			
	3.1	Setting/monitor modes	C-2			
	3.2	Simplified operation of the VF-AS1 ·····	C-3			
	3.2.1	Terminal board operation	C-3			
	3.2.2	Panel operation	C-7			
4.	Sea	rching and setting parameters	D-1			
	4.1	How to set parameters	D-2			
	4.1.1	Setting parameters in the selected quick mode	D-2			
	4.1.2	Setting parameters in the standard setting mode	D-3			
	4.2	Functions useful in searching for a parameter or changing a parameter setting	D-4			
5.	Bas	ic parameters	E-1			
	5.1	History function	E-1			
	5.2	Setting acceleration/deceleration time	E-2			
	5.2.1	Automatic acceleration/deceleration	E-2			
	5.2.2	Manually setting acceleration/deceleration time	E-3			
	5.3	Increasing starting torque	E-3			
	5.4	Setting parameters by operating method	E-5			
	5.5	Selection of operation mode	E-6			
	5.6	Selecting control mode	E-11			
	5.7	Manual torque boost–increasing torque boost at low speeds	E-16			
	5.8	Base frequency	E-16			
	5.9	Maximum frequency	E-17			
	5.10	Upper limit and lower limit frequencies	E-17			
	5.11	Setting frequency command characteristics	E-18			
	5.12	Preset speed operation (speeds in 15 steps))	E-18			
	5.13	Selecting forward and reverse runs (operation panel only)	E-21			
	5.14	Setting the electronic thermal	E-22			
	5.15	Changing the display unit % to A (ampere)/V (volt)	E-26			
	5.16	Meter setting and adjustment	E-27			

	5.17	PWM carrier frequency	E-31
	5.18	Trip-less intensification	E-32
	5.18.1	Auto-restart (Restart during coasting)	E-32
5.18.		Regenerative power ride-through control/Deceleration stop during power failure/	
		Synchronized acceleration/deceleration	E-33
	5.19	Dynamic (regenerative) braking - For abrupt motor stop	E-36
	5.20	Standard default setting ·····	E-42
	5.21	Searching for all reset parameters and changing their settings	E-44
	5.22	EASY key function	E-45
6.	Evto	ended parameters	F-1
0.	6.1	Input/output parameters	F-1
	6.1.1	Low-speed signal	F-1
	6.1.2	Putting out signals of arbitrary frequencies	F-2
	6.2	Input signal selection	F-3
	6.2.1	Priority when forward/reverse run commands are entered simultaneously	F-3
	6.2.2	Assigning priority to the terminal board in the operation panel and operation mode	F-4
	6.2.3	Analog input signal switching	F-5
	6.3	Terminal function selection	F-6
	6.3.1	Keeping an input terminal function always active (ON)	F-6
	6.3.2	Modifying input terminal functions	F-6
	6.3.3	Using the servo lock function	F-8
	6.3.4	Modifying output terminal functions	F-8
	6.3.5	Response time of input/output terminals	F-9
	6.4	Basic parameters 2	F-9
	6.4.1	Switching among V/f characteristics 1, 2, 3 and 4 from input terminal	F-9
	6.5	V/f 5-point setting	F-11
	6.6	Speed command switching	F-11
	6.6.1	Using two types of frequency (speed) commands	F-11
	6.7	Operation frequency	F-13
	6.7.1	Start frequency/Stop frequency	F-13
	6.7.2	Run/Stop control with frequency setting signals	F-13
	6.7.3	Frequency setting signal 0Hz dead zone handling function	F-14
	6.8	DC braking	F-14
	6.8.1	DC braking	F-14
	6.8.2	Motor shaft fixing control	F-16
	6.8.3	Function of issuing a 0Hz command during a halt	F-17
	6.9	Auto-stop in case of lower-limit frequency continuous operation (Sleep/Wake-up function)	F-18
	6.10	Jog run mode	F-19
	6.11	Setting frequency via external contact input (Up/Down frequency setting)	F-20
	6.12	Jump frequency - jumping resonant frequencies	F-22
	6.13	Preset speed operation frequencies	F-23
	6.13.1		F-23
	6.13.2		F-23
	6.14	Trip-less intensification	F-24
	6.14.1		F-24
	6.14.2	0 11 0	F-25
	6.14.3	3	F-25
	6.14.4	Reverse run prohibition	F-27
	6.14.5		F-27
	6.15	Drooping control	F-27
	6.16	Light-load high-speed operation function	F-29
	6.17	Braking function	F-29
	6.18	Acceleration/deceleration suspend function	F-31
	6.19	Commercial power/inverter switching	F-32
	6.20	PID control	F-34
	6.21	Stop position control function	F-38
	6.22	Setting motor constants	F-38

6.23	Inc	reasing the motor output torque further in low speed range
6.24		que control
6.24.		Torque command ····· F
6.24.		Speed limits in torque control mode
6.24.	3	Torque bias and load sharing gain
6.25	Tor	que limit
6.25.	1	Torque limit switching
6.25.		Torque limit mode selection at acceleration/deceleration
6.26	Sta	Il prevention function ······ F
6.26.	1	Power running stall continuous trip detection time
6.26.	2	Regenerative braking stall prevention mode selection
6.26.	3	Stall prevention control switching
6.27	Cui	rent and speed control adjustment
6.27.	1	Current and speed control gain
6.27.	2	Prevention of motor current oscillation at light load
6.27.	3	Max output voltage modulation rate
6.28	Fin	e adjustment of frequency setting signalF
6.29	Ope	erating a synchronous motor
6.30	Acc	releration/deceleration 2F
6.30.		Setting acceleration/deceleration patterns and switching acceleration/deceleration
		patterns 1, 2, 3 and 4
6.31	Pat	tern operationF
6.32		set speed modeF
6.33	Pro	tection functionsF
6.33.	1	Setting of stall prevention level
6.33.	2	Inverter trip record retention
6.33.	3	Emergency stopF-
6.33.	4	Output phase failure detection
6.33.	5	OL reduction starting frequency
6.33.	6	Motor 150%-overload time limit
6.33.	7	Input phase failure detections
6.33.	8	Control mode for low current
6.33.	9	Detection of output short circuit
6.33.	10	Overtorque trip
6.33.	11	Cooling fan control selection
6.33.		Cumulative operation time alarm setting
6.33.		Abnormal speed detection
6.33.		Overvoltage limit operation
6.33.		Undervoltage trip
6.33.		Regenerative power ride-through control level
6.33.		Braking answer waiting time
6.33.		VI/II analog input wire breakage detection level······ F-l
6.33.		Guide to time of replacement
6.33.		Rush current suppression relay activation time
6.33.		Motor thermal protection
6.33.		Braking resistance overload curve
6.33.		Selection of a restart condition for the motor stopped with a mechanical brake
6.33.		Protection against a failure of the control power backup device (optional CPS002Z)······ F-
6.34		erride ·········F-
6.35		ustment parameters
6.35.		Pulse train output for meters F-
6.35.		Setting of optional meter outputs
6.35.		Calibration of analog outputs
6.36		eration panel parameter
6.36.		Prohibition of key operations and parameter settings
6.36.		Displaying the rotational speed of the motor or the line speed
6.36.		Changing the steps in which the value displayed changes F-
6.36.		Changing the standard monitor display
0.00.		Tanging in Standard monitor diopidy

	6.36.	5 Canceling the operation command	·- F-7
	6.36.6	Selection of operation panel stop pattern	·· F-7
	6.36.		
	6.36.8		
	6.37	Tracing functions	
	6.38	Integrating wattmeter	
	6.39	Communication function ·····	
	6.39.	1 2-wire RS485/4-wire RS485	·· F-8
	6.39.2	2 Open network option	·· F-8
	6.40	My function	·· F-8
	6.41	Traverse function	·· F-8
	6.42	Instruction manuals for optionally available devices and special functions	·· F-8
7.		eration with external signal	
	7.1	External operation	
	7.2	Applied operation with input and output signals (operation by terminal board)	
	7.2.1	Functions of input terminals (in case of sink logic)	
	7.2.2	Functions of output terminals (incase of sink logic)	
	7.2.3	· · ·	
	7.2.4	Analog input filter	
	7.3	Setup of external speed command (analog signal)	
	7.3.1	Setup by analog input signals (RR/S4 terminal)	
	7.3.2	Setup by analog input signals (VI/II terminal)	
	7.3.3	Setup by analog input signals (RX terminal)	G-
8.	Mor	nitoring the operation status	Н-
ο.		Screen composition in the status monitor mode	
	8.1	Monitoring the status	
	8.2	Status monitor under normal conditions-	
	8.2.1		
	8.2.2		
	8.3	Changing status monitor function-	
	8.4	Display of trip information	
	8.4.1	Trip code display	
	8.4.2	Monitor display at tripping	
	8.5	Display of alarm, pre-alarm, etc.	Н-
9.	Tak	ing measures to satisfy the CE/UL/CSA standards	I-1
٠.	9.1	How to cope with the CE standard	
	9.1.1	EMC directive	
	9.1.2	Measures to satisfy the EMC directive ·····	
	9.1.3	Low-voltage directive	
	9.1.4	Measures to be taken to satisfy the low-voltage directive	
	9.2	Measures to be taken to satisfy the UL/CSA standards	
	9.2.1	Caution in installing the inverter	
	9.2.1	Caution in viring and rated current	
	9.2.2		
	9.2.4	Caution as to the protection of motors from overload	
		,	. 0
10). Sele	ection of peripheral devices ·····	
	10.1	Selection of wiring materials and devices	
	10.2	Installation of a magnetic contactor	
	10.3	Installation of an overload relay ·····	
	10.4	Application and functions of options	
	10.5	Optional internal devices	
	10.6	Connection of a DC power supply and other electric units	
	10.6.	1 Connection of a single-phase 200V power supply	J-
	10.6.2		J-

11. 7	Table of parameters	K-1
12. \$	Specifications	L-1
12.1	Models and their standard specifications	L-1
12.2	Outside dimensions and weight	L-5
13. E	Before making a service call- Trip information and remedies	M-1
13.1	Trip causes/warnings and remedies	M-1
13.2	Method of resetting causes of trip	M-7
13.3	If the motor does not run while no trip message is displayed	M-8
13.4	How to check other troubles	M-9
14. I	nspection and maintenance	N-1
14.1	Regular inspection	N-1
14.2	Periodical inspection	N-2
14.3	Making a call for servicing	N-4
14.4	Keeping the inverter in storage	N-4
15. \	Warranty	0-1
16 [Disposal of the inverter	D_1

1. Read first

1.1 Check the product


Before using the product you have purchased, check to make sure that it is exactly what you ordered.




Caution



Use an inverter that conforms to the specifications of the power supply and three-phase induction motor being used. If the inverter being used does not conform to those specifications, not only will the three-phase induction motor not rotate correctly, but it may cause serious accidents through overheating and fire.



1. 2 Contents of the product code



^{*1):} This code represents the factory default logic setting. You can switch from one input/output logic to the other using slide switch SW1. ⇒ For more details, refer to Section 2.3.2.


Warning: Always shut power off first then check the ratings label of inverter held in a cabinet.

^{*2):} WN and WP only above 280kW.


1. 3 Structure of the main body

1.3.1 Names and functions

1) Outside view




[Front panel]



Note: Remove this cover when installing the inverter side by side with other inverters where the ambient temperature will rise above 40°C. ⇒ For more details, refer to Section 1.4.4.

■ Operation panel




Note 1: \Rightarrow For details EASY Key functions, refer to Section 5.22.


Note 2: When parameter $F ? \exists \mathcal{Q}$ is set to I, the operation frequency cannot be set even if this lamp is lit.

2) Main circuit terminal


VFAS1-2004PL~2015PL VFAS1-4007PL~4022PL




VFAS1-2022PL, 2037PL VFAS1-4037PL




VFAS1-2055PL VFAS1-4055PL, 4075PL




VFAS1-2075PL VFAS1-4110PL



VFAS1-2110PM, 2150PM VFAS1-4150PL, 4185PL




VFAS1-2185PM, 2220PM VFAS1-4220PL





terminal block.


using the socket head cap screw provided in the terminal block. VFAS1-4300PL, 4370PL



VFAS1-2300PM~2450PM VFAS1-4450PL~4750PL







Fan terminal


M4 screw

0000


M10 screw


Grounding terminal(M12 screw)

VFAS1-4200KPC~4280KPC




VFAS1-4355KPC, 4400KPC





3) Control circuit terminal block

The control circuit terminal block is common to all equipment.




⇒ For details on all terminal functions, refer to Section 2.3.2.

1.3.2 Detaching the cover

■ Main circuit terminal cover

To wire the main circuit terminal for models 200V-15kW or smaller and 400V-18.5kW or smaller, remove the main circuit terminal cover in line with the steps given below.





Open the main circuit terminal cover.


* To open the cover, lift it with your finger placed at the part ▷ on the right side of the cover.


Remove the main circuit terminal cover.

- (1) Turn the screw securing the cover counterclockwise by 90° to release the lock (Do not turn the screw by more than 90°. Or else the screw might be broken.)
- (2) Hold the cover by both ends, and then pull up the cover with slightly bending it inward.

For 200V/0.4kW to 200V/15kW models and 400V/0.75kW to 400V/18.5kW models, cut off the tabs (part A in the figure below) on the main circuit terminal cover if necessary for connecting the cables from the power supply.


200V-0.4kW~3.7/4.0kW 400V-0.75kW~3.7/4.0kW 200V-5.5kW~15kW 400V-5.5kW~18.5kW






■ Front cover

To wire the main circuit terminal for models 200V-18.5kW or more and 400V-22kW or more, remove the front cover.



■ Control circuit terminal cover


To wire the control circuit terminal, open the control circuit terminal cover in line with the steps given below. (A) (B)



Control circuit terminal

Open the control circuit terminal cover.

* To open the cover, lift it with your finger placed at the ▷ part on the right side of the cover.



Remove the terminal, if necessary.

* To do so, open the main circuit terminal cover, loosen the screws that fix the terminal, using a (-) screwdriver or torx (T20H) screwdriver, placed your finger on part

and pull out the terminal.


■ Charge lamp

This lamp is lit when a high voltage remains in the inverter. When removing the main circuit terminal cover or opening the front cover, be sure to check that this lamp is off and follow the instructions about wiring on page 4.


The mounting position of the charge lamp varies from model to model.

VFAS1-2004PL~2150PM VFAS1-4007PL~4185PL


This lamp is placed behind the main circuit terminal cover.



VFAS1-2185PM~2450PM VFAS1-4220PL~4750PL



VFAS1-2550P, 2750P VFAS1-4900PC~4500KPC



1.3.3 Grounding capacitor switching method

The inverter is grounded through a capacitor. The leakage current from the inverter can be reduced using the selector switch, switching bar or switching screw (depending on the model) on the main circuit terminal board. This switching device is used to detach the capacitor from the grounding circuit or to reduce its capacitance.

Some models have capacitors that can be detached completely, while others have capacitors whose capacitances can be reduced.

Note 1: Please note that, without the capacitor, the inverter does not comply with the EMC directive.

Note 2: When attaching or detaching the capacitor, be sure to turn off power.

■ 200V/45kW - 400V/75kW models and smaller: Grounding capacitor switching switch

⚠ Warning




-When the grounding capacitor is detached from the inverter with a capacity of 400V-3.7/4.0kW or less, be sure to set the carrier frequency (\mathcal{E}) at 4kHz or less. If the carrier frequency is set above 4kHz, internal parts of the inverter may overheat and become damaged.

•When the grounding capacitor is detached from the inverter and the cables connecting the inverter to the motor is 100 m or more in length with a capacity between 400V-5.5kW and 400V-18.5kW, be sure to set the carrier frequency ($\mathcal{L} \mathcal{F}$) at 4kHz or less. If the carrier frequency is set above 4kHz, internal parts of the inverter may overheat and

200V 0.4kW~15kW 400V 0.75kW~18.5kW


become damaged.



There are two places according to the model.

 \Rightarrow For details, refer to Section 1.3.1.

200V 18.5kW~45kW 400V 22kW~75kW



200V 0.4kW~7.5kW, 18.5kW, 22kW 400V 0.75kW~18.5kW



To connect and ground the capacitor, push in the button.
(Factory default position)



Pull up this part to detach the capacitor to prevent it from being


*2: For 400V-3.7/4.0kW model and smaller, the switch is fixed with a label saying "CF/SFr ≤ 4kHz." If such a label is affixed to your inverter, you should set the carrier frequency (∑F) at 4kHz or less according to the instructions when switching.

200V 11kW, 15kW, 30kW~45kW 400V 22kW~75kW


Large Small




To change the capacitance from Small to Large, push in the button. (Factory default position)




To change the capacitance from Large to Small, pull up the button.





400V 30kW、37kW






200V 30kW~45kW 400V 45kW~75kW





■ 200V/55kW models and larger 400V/90kW, 110kW models: Grounding capacitor switching bar




⚠ Warning

 \bigcirc

In case of one phase grounding system (A three-phase supply power is connected in delta), do not change the connection of grounding capacitor before factory setting. If connection changed (this means the capacitance is increased), the capacitor may become damaged.

Note: If a neutral grounding system is used, 400V-90kW and 110kW models meet required EMC directive by changing the connection of the grounding capacitor as shown in the figure at the top (changing the capacitance from Small to Large).

■ 400V/132kW models and larger: Grounding capacitor switching screw «132kW, 160kW»




⚠ Warning

Prohibited

In case of one phase grounding system (A three-phase supply power is connected in delta), do not change the connection of grounding capacitor before factory setting. If connection changed (this means the capacitance is increased), the capacitor may become damaged.

Note: If a neutral grounding system is used, changing the connection of the grounding capacitor as shown in the figure at the top (changing the capacitance from Small to Large) makes the inverter compliant with the EMC directive.

«200kW~280kW»




** Warning**

In case of one phase grounding system (A three-phase supply power is connected in delta), do not change the connection of grounding capacitor before factory setting. If connection Prohibited changed (this means the capacitance is increased), the capacitor may become damaged.

Note: If a neutral grounding system is used, changing the connection of the grounding capacitor as shown in the figure at the top (changing the capacitance from Small to Large) makes the inverter compliant with the EMC directive.

«355kW~500kW»



Warning


In case of one phase grounding system (A three-phase supply power is connected in delta), do not change the connection of grounding capacitor before factory setting. If connection changed (this means the capacitance is increased), the capacitor may become damaged.


Note: If a neutral grounding system is used, changing the connection of the grounding capacitor as shown in the figure at the top (changing the capacitance from Small to Large) makes the inverter compliant with the EMC directive.

1.3.4 Installing the DC reactor

■ How to install (Example: VFAS1-4160KPC)

(1)







Remove the front cover.

Mount the reactor case on an inner wall of the cabinet and secure the reactor unit to the case with screws.

(3)






Connect the reactor unit to the PO and PA/+ terminals on the main-circuit terminal board. Then connect the supplied earth wire.


⇒ See the figures on the next page. Fix the front cover after connecting.

Secure the cover, front panel and top panel to the reactor case with screws.


■ Example of wiring of each model



«VFAS1-4160KPC~4280KPC»



«VFAS1-4355KPC~4500KPC»



1.4 Notes on the application

1.4.1 Motors

Keep the following in mind when using the VF-AS1 to drive a motor.





Use an inverter that conforms to the specifications of power supply and three-phase induction motor being used. If the inverter being used does not conform to those specifications, not only will the three-phase induction motor not rotate correctly, but it may cause serious accidents through overheating and fire.

Comparisons with commercial power operation

The VF-AS1 Inverter employs the sinusoidal PWM system to supply the motor. This is why compared to operation with a commercial power there will be a slight increase in motor temperature, noise and vibration. The main supply voltage and current will also be distorted due to harmonic distortion while increase the line current.

Operation in the low-speed area

When running continuously at low speed in conjunction with a general purpose motor, there may be a decline in that motor's cooling effect. If this happens, operate with the output decreased from rated load.

To carry out low-speed operation continuously at the rated torque, we recommend to use a inverter rated motor or a forced cooled motor designed for use with an inverter. When operating in conjunction with a inverter rated motor, you must change the inverter's motor overload protection level to VF motor use $(\Omega L \Omega)$.

Adjusting the overload protection level

The VF-AS1 Inverter protects against overloads with its electronic thermal overload detection circuits. The electronic thermal's reference current of the inverter must be adjusted in line with the rated current of the motor being used in combination.

High-speed operation at and above 50Hz/60Hz (rated frequency)

Operating at frequencies greater than 50Hz/60Hz will increase noise and vibration. There is also a possibility that such operation will exceed the motor's mechanical strength under these conditions and the bearing limits. You should verify with the motor's manufacturer operating.

Method of lubricating load mechanisms

Operating an oil-lubricated reduction gear and gear motor in the low-speed areas will worsen the lubricating effect. Check with the manufacturer to find out about operable speed range.

Low loads and low inertia loads

The motor may demonstrate instability such as abnormal vibrations or overcurrent trips at light loads of 50% or under of the rated load, or when the load's moment of inertia is extremely small. If that happens reduce the carrier frequency.

Occurrence of instability

Unstable phenomena may occur under the load and motor combinations shown below.

- Combined with a motor that exceeds applicable motor ratings recommended for the inverter
- · Combined with special motors

To deal with the above lower the settings of inverter carrier frequency. (When performing vector control, set the carrier frequency at 2kHz or more. If the carrier frequency is set below 2kHz, it will be automatically corrected to 2kHz by the inverter.)

· Combined with couplings between load devices and motors with high backlash

In this case, set the S-pattern acceleration/deceleration function and adjust the response time inertial moment setting during vector control or switch to V/f control (P = G).

• Combined with loads that have sharp fluctuations in rotation such as piston movements In this case, adjust the response time inertial moment setting during vector control or switch to V/f control (P = 0). If it is operated in vector control mode (For torque control mode), only a motor whose capacity is same as inverter standard or 1 ranking lower should applied.

Braking a motor when power supply is lost


A motor with its power cut off goes into freewheel, and does not stop immediately. To stop the motor quickly as soon as the power is cut off install an auxiliary brake. There are different kinds of brake devices, both electrical and mechanical. Select the brake that is best for the system.


Loads that generate negative torque

When combined with loads that generate negative torque the protection for overvoltage and overcurrent on the inverter will go into operation and may cause a trip. For this kind of situation, you must install a dynamic braking resistor, etc. that complies with the load conditions.

Motor with brake

If a brake motor is used with the braking circuit connected to the output terminals of the inverter, the brake cannot be released because of a voltage drop at startup. Therefore, when using the inverter along with a brake motor, connect the braking circuit to the power supply side of the inverter, as shown in the figure below. In most cases, the use of a brake motor causes an increase in noise at low-speed.





In circuit configuration 1, the brake is turned on and off through MC2 and MC3. If the circuit is configured in some other way, the overcurrent trip may be activated because of the locked rotor current when the brake goes into operation.

Circuit configuration 2 uses low-speed signal OUT1 to turn on and off the brake. Turning the brake on and off with a low-speed detection (OUT1 function) may be better in such applications as elevators. Please confer with your supplier before designing the system.

Measures to protect motors against surge voltages

In a system in which a 400V-class inverter is used to control the operation of a motor, very high surge voltages may be produced. When applied to the motor coils repeatedly for a long time this can cause deterioration of their insulation, depending on the wire length, wire routing and types of wires used. Here are some examples of measures against surge voltages.

- (1) Lower the inverter's carrier frequency.
- (2) Set the parameter $F \ni f F$ (Carrier frequency control mode selection) to F = F F or F = F F.
- (3) Use motors with a high dielectric strength.
- (4) Insert an reactor or a surge voltage suppression filter between the inverter and the motor.

1.4.2 Inverters

Protecting inverters from overcurrent


The inverter has an overcurrent protection function. The programmed current level is set to the inverter's maximum applicable motor. If the motor used has a small capacity, the stall prevention level, overcurrent level and the motor electronic thermal protection must be readjusted. If adjustment is necessary, refer to Section 5.14, and make adjustments as directed.

Inverter capacity

Do not operate a large capacity motor with a small capacity (kVA) inverter even with light loads. Current ripple will raise the output peak current making it easier to set off the overcurrent trip.

Power factor correction capacitor


Power factor correction capacitors cannot be installed on the output side of the inverter. When a motor is run that has a power factor correction capacitor attached to it, remove the capacitors. This can cause inverter malfunction trips and capacitor destruction.



Operating at other than rated voltage

Connections to voltages other than the rated voltage described in the rating label cannot be made. If a connection must be made to a power supply other than one with rated voltage, use a transformer to raise or lower the voltage to the rated voltage.

Circuit interrupting when two or more inverters are used on the same power line.



Breaking of selected inverter

There is no fuse in the inverter's main circuit. Thus, as the diagram above shows, when more than one inverter is used on the same power line, you must select interrupting characteristics so that only the MCCB2 will trip and the MCCB1 will not trip when a short occurs in the inverter (INV1). When you cannot select the proper characteristics install a circuit interrupting fuse between the MCCB2 and the INV1.

If power supply distortion is not negligible

If the power supply distortion is not negligible because the inverter shares a power distribution line with other systems causing distorted waveforms, such as systems with thyristers or large-capacity inverters, install an input reactor to improve the input power factor, to reduce higher harmonics, or to suppress external surges.

■ Disposal

If an inverter is no longer usable, dispose of it as industrial waste.

1.4.3 What to do about the leak current




Current may leak through the inverter's input/output wires because of insufficient electrostatic capacity on the motor with bad effects on peripheral equipment. The leakage current's value is affected by the carrier frequency and the length of the input/output wires. Test and adopt the following remedies against leakage current.

(1) Effects of leakage current across ground

Leakage current may flow not just through the inverter system but also through ground wires to other systems.

Leakage current will cause earth leakage current breakers, leakage current relays, ground relays, fire alarms and sensors to operate improperly, and it will cause superimposed noise on the CRT screen or display of incorrect current values during current detection with the CT.



Remedies: There is the following method for reduce leakage current across ground.

- Reduce PWM carrier frequency.
- The setting of PWM carrier frequency is done with the parameter [F.]
- 3. Use high frequency remedial products for earth leakage breakers.
 - If you use equipment like this, there is no need to reduce the PWM carrier frequency.
- 4. If the sensors and CRT are affected, it can be remedied by reducing the PWM carrier frequency described in 1 above, but if this cannot be remedied because of the increase in the motor's electric magnetic noise, please consult with your supplier.
 - * Cautions for applying models with a built-in noise filter.


For the models with a built-in noise filter, the leakage current value at power supply of Δ (delta) connecting wire (single-phase earth) can be larger than normal inverter, so be careful.

<Standard leakage current value (single-phase earth)>

VFAS1-2004PL~2150PM; Approx. 15mA

VFAS1-2185PM~2450PM: Approx. 1mA

(2) Affects of leakage current across supply lines




Leakage current path across wires

(1) Thermal relays

The high frequency component of current leaking into electrostatic capacity between inverter output wires will increase the effective current values and make externally connected thermal relays operate improperly. If the motor cables are more than 50m long, external thermal relay may operate improperly with models having motors of low rated current, especially the 400V class low capacity (3.7/4.0kW or less) models, because the leakage current will be high in proportion to the motor rating.

Remedies:

- Use the electronic thermal overload built into the inverter.
 The setting of the electronic thermal overload is done using parameter \(\textit{G}\)! \(\textit{G}\) or \(\textit{F}\).
- Reduce the inverter's PWM carrier frequency. However, that will increase the motor's acoustic noise.
 The setting of PWM carrier frequency is done with the parameter \(\int \infty \).
- This can be improved by installing 0.1μ~0.5μF-1000Vdc film capacitor to the input/output terminals of each phase in the thermal overload relay.



(2) CT and ammeter

If a CT and ammeter are connected externally to measure inverter output current, the leakage current's high frequency component may destroy the ammeter or CT. If the motor cables are more than 50m long, it will be easy for the high frequency component to pass through the externally connected CT and be superimposed on and burn the ammeter with models having motors of low rated current, especially the 400V class low capacity (3.7/4.0kW or less) models, because the leakage current will increase in proportion to the motor's rated current.

Remedies:

- 1. Use a meter output terminal in the inverter control circuit.
 - The output current can be output on the meter output terminal (AM, FM). If the meter is connected, use an ammeter of 1mAdc full scale or a voltmeter of 7.5Vdc-1mA full scale.
- Inverter output terminal (FM) can be changed to 0-20mAdc (4-20mAdc) with F & 8 1.

 2. Use the monitor functions built into the inverter.
 - Use the monitor functions on the panel built into the inverter to check current values.

1.4.4 Installation

■ Installation environment

The VF-AS1 Inverter is an electronic control instrument. Take full consideration to installing it in the proper operating environment.

• Do not place any inflammable substances near the VF-AS1 Inverter. If an accident occurs in which flames are emitted, this could lead to fire.

Operate under the environmental conditions prescribed in the instruction manual.
 Operation under any other conditions may result in malfunction.


Mandatory

Caution Do not install the VF-AS1 Inverter in any location subject to large amounts of vibration. This could cause the unit to fall, resulting in bodily injury. Check to make sure that the input power supply voltage is +10%, -15% of the rated supply voltage written on the rating label (±10% when the load is 100% in continuous operation). If the input power voltage is not +10%, -15% of the rated power voltage (±10% when the load is 100% in continuous operation) this may result in fire.



- Do not install in any location of high temperature, high humidity, moisture condensation and freezing.
- Avoid locations where there is exposure to water and/or where there may be large amounts of dust and metallic fragments.
- Do not install the inverter where there are gases that corrode metal or solvents that adversely affect plastic.
- Operate in areas where ambient temperature ranges from -10°C to 60°C. When installing the inverter where the
 ambient temperature will rise above 40°C, remove the protective cover from the top cover (depending on the
 capacity of the inverter used). When installing the inverter where the ambient temperature will rise above 50°C, it is
 necessary to operate in lower current than rated value.





Note: The inverter is a heat-emitting body. Make sure to provide proper space and ventilation when installing in cabinet. When installing inside a cabinet, we recommend the removal of the protective cover.


• Do not install in any location that is subject to large amounts of vibration.



Note: If the VF-AS1 Inverter is installed in a location that is subject to vibration, anti-vibration measures are required.

Please consult with your supplier about these measures.

• If the VF-AS1 Inverter is installed near any of the equipment listed below, provide measures to insure against errors in operation.



Solenoids: Attach surge suppressor on coil.

Brakes: Attach surge suppressor on coil.

Magnetic contactors: Attach surge suppressor on coil.

Fluorescent lamps: Attach surge suppressor on coil.

Resistors: Place far away from VF-AS1 Inverter.

• Do not touch the heat sink, because it becomes hot during operation.



■ How to install

\triangle

Warning



Do not operate the inverter if it is damaged or any component is missing.
 This can result in electric shock or fire. Call your local sales agency for repairs.

Prohibited

• Must be installed in non-inflammables such as metals.

Must be installed in non-initial initialists such as metals.
 The rear panel gets very hot. If installation is in an inflammable object, this can result in fire.
 Do not operate with the front panel cover removed.



7 |.

- This can result in electric shock.

 An emergency stop device must be installed that fits with system specifications. (e.g. shut off input
- power then engage mechanical brake)
 Operation cannot be stopped immediately by the inverter alone, thus risking an accident or injury.
- All options used must be those specified by Toshiba.
 The use of any other option may result in an accident.

⚠ Caution



The main unit must be installed on a base that can bear the unit's weight.
If the unit is installed on a base that cannot withstand that weight, the unit may fall resulting in lighting.


Mandatory

If braking is necessary (to hold motor shaft), install a mechanical brake.
 The brake on the inverter will not function as a mechanical hold, and if used for that purpose, injury may result.

Install the inverter in a well-ventilated indoor place and mount it on a flat metal plate in portrait orientation.

If you are installing more than one inverter, the separation between inverters should be at least 5cm, and they should be arranged in horizontal rows.

If the inverters are horizontally arranged with no space between them (side-by-side installation), remove of the protective cover on top of the inverter. (200V-55kW or lager and 400V-90kW or larger models dose not need to remove the protective cover)



*2 200V 18.5kW~45kW, 400V 0.75kW~75kW

	H1(cm)	H2(cm)	H3(cm)
200V 75kW or smaller 400V 110kW or smaller	10	10 (Note1)	10 (Note1)
400V 132, 160kW	15	15 (Note1)	25 (Note1)
400V 200~280kW	20	15 (Note1)	25 (Note1)
400V 355, 400kW	30	25 (Note1)	25 (Note1)
400V 500kW	40	25 (Note1)	25 (Note1)

The space shown in the diagram is the minimum allowable clearance. Make the space on top and bottom as large as possible to allow for air passage.

Note1: For models designed for 200V-75kW and 400V-110kW motors or larger, leave a space of 30cm or more above and below the inverter.

Note2: Do not install in any location where there is high humidity or high temperatures and where there are large amounts of dust and metallic fragments. If you are going to install the equipment in any area that presents a potential problem, please consult with your supplier before doing so.


■ Current reduction curve


Depending on the way in which the inverter is installed, the ambient temperature and the carrier frequency setting, you may need to reduce the inverter's continuous output current.


Reduction rates vary depending on the capacity of the inverter. The capacities shown in these diagrams are capacities with the highest reduction rates. Refer to section 12, you can find 100 % value of output current there. The VFAS1 has the function of adjusting the inverter's overload resistance automatically according to the ambient temperature, as shown in the figure below. This function enhances the inverter's overload resistance when the

ambient temperature is low. To use this function, set the parameter F 5 3 1 to 1.


If F & 3 I is set to I (default setting), protection will be provided by reducing the output current (approximate linear reduction) in 12, "Specifications," by adjusting the PWM carrier frequency or at the occurrence of the event shown in the diagram below, which occurs first.









200V 0.75、2.2、3.7、15kW (See lines shown in --- for 15kW) 400V 7.5、15 kW (See lines shown in --- for 7.5kW and 15kW)





200V 5.5、11kW 400V 5.5、11、18.5kW







400V 2.2kW






400V 3.7kW







200V 18.5kW









200V 22, 37kW (See lines shown in --- for 15kW)




●Side-by-side installation (without top cover)




200V 30kW




●Side-by-side installation (without top cover)




200V 45kW 400V 22、30、45、55kW



●Side-by-side installation (without top cover)









200V 55, 75kW

Standard installation / Side-by-side installation




400V 132、200、280kW (See lines shown in --- for 200kW)

● Standard installation / Side-by-side installation




400V 355、400、500kW (See lines shown in --- for 355kW)

Standard installation / Side-by-side installation




Side-by-side installation (without top cover)




400V 90、110 kW

●Standard installation / Side-by-side installation



400V 160、220kW (See lines shown in --- for 160kW)

Standard installation / Side-by-side installation



■ Calorific values of the inverter and the required ventilation

The energy loss when the inverter converts power from AC to DC and then back to AC is about 5%. In order to suppress the rise in temperature inside the cabinet when this loss becomes heat loss, the interior of the cabinet must be ventilated and cooled.

The amount of forced air-cooling ventilation required and the necessary heat exchange surface area when operating in a sealed cabinet according to motor capacity are as follows.

Voltage	Applicable Motor	Calorific values	Part of inside calorific values		Heat exchange surface area required for sealed
class	(kW)	(W)	(W) (note3)	required (m³/min)	storage cabinet (m²)
	0.4	50	25	0.29	1.0
	0.75	70	28	0.40	1.4
	1.5	113	32	0.65	2.3
	2.2	135	39	0.78	2.7
	3.7/4.0	191	40	1.1	3.8
	5.5	307	60	1.8	6.2
	7.5	408	72	2.4	8.2
200V	11	593	83	3.4	11.9
200 V	15	692	91	4.0	13.9
	18.5	800	120	4.6	16.0
	22	865	124	5.0	17.3
	30	1140	152	6.6	22.8
	37	1340	167	7.7	26.8
	45	1570	185	9.0	31.4
	55	1720	154	9.9	34.4
	75	2210	154	12.7	44.2
	0.75	57	28	0.33	1.2
	1.5	82	30	0.47	1.7
	2.2	112	33	0.64	2.3
	3.7/4.0	136	41	0.78	2.8
	5.5	262	58	1.5	5.3
	7.5	328	66	1.9	6.6
	11	448	77	2.6	9.0
	15	577	104	3.3	11.6
	18.5	682	106	3.9	13.7
	22	720	111	4.2	14.4
	30	980	134	5.6	19.6
	37	1180	138	6.8	23.6
400V	45	1360	165	7.8	27.2
	55	1560	179	9.0	31.2
	75	2330	226	13.4	46.6
	90	2410	237	13.8	48.2
	110	2730	261	15.6	54.6
	132	3200	296	18.3	64.0
	160	3820	350	21.9	76.4
	200	4930	493	28.2	98.6
	220	5405	586	30.9	108.1
	280	6830	658	39.1	136.6
	355	7960	-	45.5	159.2
	400	9300	-	53.2	186.0
	500	11400	-	65.2	228.0

Note1: The heat loss for the optional external devices (input reactor, DC reactor, radio noise reduction filters, etc.) is not included in the calorific values in the table. With the exception of inverters indented for motors with capacities of 355kW and more, in which case the calorific value of the DC reactor is included.

Note2: Each calorific value in the table refers to the quantity of heat that an inverter produces when it is operated continuously at the factory default $\mathcal{L} \mathcal{F}$ (carrier frequency) under a load factor of 100%.

Note3: This value is power dissipated inside the enclosure with using heatsink outer option.

■ Panel designing taking into consideration the effects of noise


The inverter generates high frequency noise. When designing the control panel setup, consideration must be given to that noise. Examples of measures are given below.

- Wire so that the main circuit wires and the control circuit wires are separated. Do not place them in the same conduit, do not run them parallel, and do not bundle them.
- · Provide shielding and twisted wire for control circuit wiring.
- Separate the input (power) and output (motor) wires of the main circuit. Do not place them in the same conduit, do not run them parallel, and do not bundle them.
- Ground the inverter ground terminals (⊥).
- Install surge suppressor on any magnetic contactor and relay coils used around the inverter.
- · Install noise filters if necessary.

■ Installing more than one unit in a cabinet

If you are installing two or more inverters in one cabinet, pay attention to the following.

- Inverters may be installed side by side with each other with no space left between them.
- When installing inverters side by side, remove the protective cover on the top surface of each inverter.
 The output current may need to be reduced, depending on the ambient temperature and the carrier frequency, so see "How to install" in this section.
- Ensure a space of at least 20cm on the top and bottom of the inverters.
- Install an air deflecting plate so that the heat rising up from the inverter on the bottom does not affect the inverter on the top.



2. Connection equipment

Warning



Never disassemble, modify or repair.

This can result in electric shock, fire and injury. For repairs, call your sales agency.

Disassembly prohibited



 Don't stick your fingers into openings such as cable wiring hole and cooling fan covers. This can result in electric shock or other injury.

Don't place or insert any kind of object into the inverter (electrical wire cuttings, rods, wires). This can result in electric shock or fire.

 Do not allow water or any other fluid to come in contact with the inverter. That may result in electric shock or fire.

Caution



Do not transport the inverter with its front door detached.

The covers may come off and the unit will drop out resulting in injury.



 Models (20kg or more in weight) designed for 200V-18.5kW or larger and 400V-22kW or larger should be carried by at least two persons. Carrying it alone could cause injury.

2.1 Cautions on wiring

Warning



Never remove the front cover when power is on or open door if enclosed in a cabinet. The unit contains many high voltage parts and contact with them will result in electric shock.



 Turn power on only after attaching the front cover or closing door if enclosed in a cabinet. If power is turned on without the front cover attached or closing door if enclosed in a cabinet. This can result in electric shock or other injury.

Mandatory

- Electrical construction work must be done by a qualified expert. Connection of input power by someone who does not have that expert knowledge may result in fire
- or electric shock.
- · Connect output terminals (motor side) correctly.
- If the phase sequence is incorrect, the motor will operate in reverse and that may result in injury. Wiring must be done after installation.
- If wiring is done prior to installation that may result in injury or electric shock.
- The following steps must be performed before wiring.
- (1) Shut off all input power.
- (2) Wait at least 15 minutes and check to make sure that the charge lamp is no longer lit.
- (3) Use a tester that can measure DC voltage (800 VDC or more), and check to make sure that the voltage to the DC main circuits (between PA/+ and PC/-) is 45 V or less.
- If these steps are not properly performed, the wiring will cause electric shock.
- Tighten the screws on the terminal board to specified torque. If the screws are not tightened to the specified torque, it may lead to fire.



Be Grounded

Ground must be connected securely.

If the ground is not securely connected, it could lead to electric shock or fire when a malfunction or current leak occurs.





 Do not attach devices with built-in capacitors (such as noise filters or surge absorber) to the output (motor side) terminal.
 This could cause a fire.

■ Preventing radio noise

To prevent electrical interference such as radio noise, separately bundle wires to the main circuit's power terminals (R/L1, S/L2, T/L3) and wires to the motor terminals (U/T1, V/T2, W/T3).

■ Control and main power supply

The control power supply and the main circuit power supply for the VF-AS1 are the same. If a malfunction or trip causes the main circuit to be shut off, control power will also be shut off.

If you want to keep the control circuit alive when the main circuit shuts off due to trouble or tripping, you use an optional control power supply backup unit (CPS002Z).

■ Wiring

- Because the space between the main circuit terminals is small use sleeved pressure terminals for the connections.
 (stripped wires may be connected directly for 200V/18.5kW to 200V/45kW models and 400V/22kW to 400V/75kW models). Connect the terminals so that adjacent terminals do not touch each other.
- For ground terminal G/E use wires of the size that is equivalent to or larger than those given in table below and always ground the inverter.

Use as large and short a ground wire as possible and wire it as close as possible to the inverter.

Voltage class	Applicable Motor	Grounding wire size (AWG) [Note]	Grounding wire size (mm ²) [Note]
	0.4~2.2 kW	14	2.5
	3.7, 4.0 kW	12	4
	5.5 kW	10	6
	7.5 kW	10	10
200V	11, 15 kW	10	16
2001	18.5, 22 kW	8	16
	30 kW	6	25
	37, 45 kW	6	35
	55 kW	2	70
	75 kW	2	95
	0.75~4.0 kW	14	2.5
	5.5 kW	12	2.5
	7.5 kW	12	4
	11 kW	10	6
	15~22 kW	10	10
	30 kW	10	16
	37, 45 kW	8	16
	55 kW	6	25
	75 kW	6	35
400V	90 kW	2	70
	110 kW	2	95
	132 kW	1/0	95
	160 kW	1/0	120
	200 kW	1/0	150
	220 kW	2/0	150
	280 kW	3/0	120×2
	355 kW	4/0	120×2
	400 kW	4/0	150×2
	500 kW	250MCM	150×2

Note1: The recommended cable size is that of the cable (e.g. 600V class, HIV cable) with continuous maximum permissible temperature of 75℃. Ambient temperature is 40℃ or less and the wiring distance is 30m or less.

- Refer to the table in Section 10.1 for wire sizes.
- The length of the main circuit wire in Section 10.1 should be no longer than 30m. If the wire is longer than 30m, the wire size (diameter) must be increased.
- Tighten the screws on the terminal board to specified torque.


Recommended tightening torque for screws on		
the terminal board		
	N-m	lb-ins
M3	0.6	5.3
M4	1.4	12.4
M5	3.0	26.6
M6	5.4	47.8
M8	12.0	106
M10	24.0	212
M12	41.0	360

2.2 Standard connections

Otariac	
	<u> </u>
Prohibited	 Do not connect input power to the output (motor side) terminals (U/T1, V/T2, W/T3). Connecting input power to the output could destroy the inverter or cause a fire. Do not connect a regenerative braking resistor to any DC terminal (between PA/+ and PC/-, or between PO and PC/-). If a braking resistor is connected by mistake, it may overheat extremely and cause a fire. Connect resistors as directed in the instructions for Section 5.19. Within 15 minutes after turning off input power, do not touch wires of devices (MCCB) connected to the input side of the inverter. That could result in electric shock.
•	Ground must be connected securely. If the ground is not securely connected, it could lead to electric shock or fire when a malfunction or current leak occurs.
Be Grounded	


[Standard connection diagram – sink logic]

The figure below shows an example of typical wiring in the main circuit 200V 0.4-45kW/400V 0.75-75kW inverter.



- *1: The inverter is shipped with the terminals PO and PA/+ shorted with a bar (200V-45kW or smaller, 400V-75kW or smaller). Remove this shorting bar when installing a DC reactor (DCL).
- *2: The DC reactor is built in for models 200V-11kW~45kW and 400V-18.5kW~75kW.
- *3: The noise filter is built in for models 200V-45kW or smaller and all of 400V.
- *4: External braking resistor (option). Dynamic braking drive circuit built-in (GTR7) as standard for models 160kW or smaller.
- *5: To supply a DC power, connect the cables to the PA/+ and PC/- terminals.
- *6: If you want to use a DC power supply to operate the inverter (200V: 18.5kW or more, 400V: 22kW or more), be sure to contact your supplier customer support center, because an inrush current limiting circuit is required in such a case.
- *7: \Rightarrow Refer to Section 2.3.2 for chip switch functions.
- *8: The functions assigned to terminals OUT1, VI/II and RR/S4 can be switched by changing parameter settings.
 ⇒ For details refer to Section 2.3.2.
- *9: To supply control power from an external power supply for backing up the control power supplied from the inverter, an optional control power backup device (CPS002Z) is required. In such a case, the backup device is used at the same time with the internal power supply of the inverter.
 - The optional control power backup unit can be used with both 200V and 400V models.
 - To back up control power, set the parameter F § 4 7 (Control power supply backup option failure monitoring) properly.
 - ⇒ For more information, refer to 6.33.24.
- *10: When RES-CC is shorted and then opened, the inverter protective status is canceled.

[Standard connection diagram - sink logic]




- *1: Be sure to connect the DC reactor.
- *2: To supply a DC power, connect the cables to the PA/+ and PC/- terminals.
- *3: If you want to use a DC power supply to operate the inverter, be sure to contact your supplier customer support center, because an inrush current limiting circuit is required in such a case.
- *4: The noise filter is built in for models all of 400V.
- *5: For models 200V-75kW and 400V-110kW or larger, three-phase power input is necessary to drive the fan if you want to use a DC power supply.
- *6: Every 200V model of any capacity and every 400V model with a capacity of 160kW or less come with dynamic braking unit drive circuits (GTR7) built into them as standard equipment, so if your inverter is among these models, connect an external braking resistor (optional) alone.
- *7: If you are using a 400V/200kW model or larger, use a braking unit (optional) and an external braking resistor (optional) in combination.
- *8: ⇒ Refer to Section 2.3.2 for switch functions.
- *9: The functions assigned to terminals OUT1, VI/II and RR/S4 can be switched by changing parameter settings.

 For details refer to Section 2.3.2.
- *10: To supply control power from an external power supply for backing up the control power supplied from the inverter, an optional control power backup device (CPS002Z) is required. In such a case, the backup device is used at the same time with the internal power supply of the inverter.
 - The optional control power backup unit can be used with both 200V and 400V models.
 - To back up control power, set the parameter F § 4 7 (Control power supply backup option failure monitoring) properly. ⇒ For more information, refer to 6.33.24.
- *11: When RES-CC is shorted and then opened, the inverter protective status is canceled.

[Standard connection diagram - sink logic]


The figure below shows an example of typical wiring in the main circuit 400V 355-500kW inverter.



- *1: Be sure to connect the DC reactor.
- *2: To supply a DC power, connect the cables to the PA/+ and PC/- terminals.
- *3: If you want to use a DC power supply to operate the inverter, be sure to contact your supplier customer support center, because an inrush current limiting circuit is required in such a case.
- *4: Three-phase power input is necessary to drive the fan if you want to use a DC power supply.
- *5: Use a braking unit (optional) and an external braking resistor (optional) in combination.
- *6: ⇒ Refer to Section 2.3.2 for switch functions.
- *7: The functions assigned to terminals OUT1, VI/II and RR/S4 can be switched by changing parameter settings.
 - \Rightarrow For details refer to Section 2.3.2.
- *8: To supply control power from an external power supply for backing up the control power supplied from the inverter, an optional control power backup device (CPS002Z) is required. In such a case, the backup device is used at the same time with the internal power supply of the inverter.
 - To back up control power, set the parameter *F § 4 7* (Control power supply backup option failure monitoring) properly. \Rightarrow For more information, refer to 6.33.24.
- *9: When RES-CC is shorted and then opened, the inverter protective status is canceled.

[Standard connection diagram - source logic]

The figure below shows an example of typical wiring in the main circuit 200V 0.4-45kW/400V 0.75-75kW inverter.




- *1: The inverter is shipped with the terminals PO and PA/+ shorted with a bar (200V-45kW or smaller, 400V-75kW or smaller). Remove this shorting bar when installing a DC reactor (DCL).
- *2: The DC reactor is built in for models 200V-11kW~45kW and 400V-18.5kW~75kW.
- *3: The noise filter is built in for models 200V-45kW or smaller and all of 400V.
- *4: External braking resistor (option). Dynamic braking drive circuit built-in (GTR7) as standard for models 160kW or smaller.
- *5: To supply a DC power, connect the cables to the PA/+ and PC/- terminals.
- *6: If you want to use a DC power supply to operate the inverter (200V: 18.5kW or more, 400V: 22kW or more), be sure to contact your supplier customer support center, because an inrush current limiting circuit is required in such a case.
- *7: ⇒ Refer to Section 2.3.2 for chip switch functions.
- *8: The functions assigned to terminals OUT1, VI/II and RR/S4 can be switched by changing parameter settings.
 - ⇒ For details refer to Section 2.3.2.
- *9: To supply control power from an external power supply for backing up the control power supplied from the inverter, an optional control power backup device (CPS002Z) is required. In such a case, the backup device is used at the same time with the internal power supply of the inverter.

The optional control power backup unit can be used with both 200V and 400V models.

- To back up control power, set the parameter F & 4 7 (Control power supply backup option failure monitoring) properly. ⇒ For more information, refer to 6.33.24.
- *10: When RES-CC is shorted and then opened, the inverter protective status is canceled.

[Standard connection diagram - source logic]



- *1: Be sure to connect the DC reactor.
- *2: To supply a DC power, connect the cables to the PA/+ and PC/- terminals.
- *3: If you want to use a DC power supply to operate the inverter, be sure to contact your supplier customer support center, because an inrush current limiting circuit is required in such a case.


(or voltage signal between RR/S4 and CCA.0~10V)

- *4: The noise filter is built in for models all of 400V.
- *5: For models 200V-75kW and 400V-110kW or larger, three-phase power input is necessary to drive the fan if you want to use a DC power supply.
- *6: Every 200V model of any capacity and every 400V model with a capacity of 160kW or less come with dynamic braking unit drive circuits (GTR7) built into them as standard equipment, so if your inverter is among these models, connect an external braking resistor (optional) alone.
- *7: If you are using a 400V/200kW model or larger, use a braking unit (optional) and an external braking resistor (optional) in combination.
- *8: ⇒ Refer to Section 2.3.2 for switch functions.
- *9: The functions assigned to terminals OUT1, VI/II and RR/S4 can be switched by changing parameter settings.

 ⇒ For details refer to Section 2.3.2.
- *10: To supply control power from an external power supply for backing up the control power supplied from the inverter, an optional control power backup device (CPS002Z) is required. In such a case, the backup device is used at the same time with the internal power supply of the inverter.
 - The optional control power backup unit can be used with both 200V and 400V models.
 - To back up control power, set the parameter F 5 4 7 (Control power supply backup option failure monitoring) properly. ⇒ For more information, refer to 6.33.24.
- *11: When RES-CC is shorted and then opened, the inverter protective status is canceled.

[Standard connection diagram - source logic]

The figure below shows an example of typical wiring in the main circuit 400V 355-500kW inverter.



^{*1:} Be sure to connect the DC reactor.

^{*2:} To supply a DC power, connect the cables to the PA/+ and PC/- terminals.

^{*3:} If you want to use a DC power supply to operate the inverter, be sure to contact your supplier customer support center, because an inrush current limiting circuit is required in such a case.

^{*4:} Three-phase power input is necessary to drive the fan if you want to use a DC power supply.

^{*5:} Use a braking unit (optional) and an external braking resistor (optional) in combination.

^{*6: ⇒} Refer to Section 2.3.2 for switch functions.

^{*7:} The functions assigned to terminals OUT1, VI/II and RR/S4 can be switched by changing parameter settings.

⇒ For details refer to Section 2.3.2.

^{*8:} To supply control power from an external power supply for backing up the control power supplied from the inverter, an optional control power backup device (CPS002Z) is required. In such a case, the backup device is used at the same time with the internal power supply of the inverter.

To back up control power, set the parameter *F §* 4 7 (Control power supply backup option failure monitoring) properly. ⇒ For more information, refer to 6.33.24.


^{*9:} When RES-CC is shorted and then opened, the inverter protective status is canceled.

2.3 Description of terminals


2.3.1 Main circuit terminals

This diagram shows an example of wiring of the main circuit. Use options if necessary.

■ Power supply and motor connections



■ Connection with peripheral equipment



■ Main circuit


■ Main circuit			
Terminal symbol	Terminal function		
(Grounding terminal for inverter casing		
R/L1, S/L2, T/L3 (R/L1.1, S/L2.1, T/L3.1, R/L1.2, S/L2.2, T/L3.2) *1	Power input terminal 200V class: 0.4~75kW Three-phase 200~240V-50/60Hz 0.75~90kW Three-phase 380~480V-50/60Hz 110~500kW Three-phase 380~440V-50Hz Three-phase 380~480V-60Hz		
U/T1, V/T2, W/T3	Connect to a (3-phase induction) motor.		
PA/+, PB (PA, PB) *2	Connect a braking resistor. Change the parameters Pb , Pbr and Pb [P if necessary. 200kW models and larger are not equipped with terminal PB.		
PC/-	This is a negative potential terminal in the internal DC main circuit. DC power supply can be input across the PA/+ terminals (positive potential). (For 200V-18.5kW or more models, and 400V-22kW or more models, an optional circuit is needed to suppress a rush current.)		
PO, PA/+	Terminals for connecting a DC reactor (DCL: optional external device). Shorted by a short bar when shipped from the factory (200V: 45kW or smaller, 400V: 75kW or smaller). Before installing DCL, remove the short bar. (The rating of 400V-355–500 kW have the double terminals of PO.)		
RO, SO, TO	200V class: 75kW 400V class:110kW~500kW Inverter's cooling fan power input terminals. When using a DC power supply, connect three-phase power cables. When using DC power for the main circuit, be sure to connect a three-phase power supply to these terminals. For more information, refer to 10.6.5.		

^{*1:} Value in () 400V-355~500kW.

^{*2:} Value in () 200V-55kW or larger, 400V-90~160kW.

2.3.2 Control circuit terminal block

The control circuit terminal block is common to all equipment.



⇒ How to set input terminal function, refer to section 7.

Terminal	Input/		Function (Sink logic) VFAS1-****-WN, HN	Function (Source logic) VFAS1-****-WP	Electrical specifications
symbol	output		Shorting across F-CC causes forward	Shorting across F-P24/PLC causes	Voltage free contact
F	Input		rotation; open causes deceleration	forward rotation; open causes	input
'	IIIput		stop. (Across ST-CC is short state.)	deceleration stop.	24Vdc-5mA or less
		ł	Shorting across R-CC causes reverse	Shorting across R-P24/PLC causes	24VUC-3111A 01 1655
R	lan.ut		rotation; open causes deceleration	reverse rotation; open causes	Lan current signal.
K	Input			deceleration stop.	Choose low current
		4	stop. (Across ST-CC is short state.)	·	contacts to avoid
		_	The motor is on standby if ST and CC are connected. It coasts to a stop if this	The motor is on standby if ST and P24/PLC are connected. It coasts to a	poor attaching.
ST	Input	Į.	connection is broken. This terminal can		*Sink/source selectable
		Ξŧ		stop if this connection is broken. This	with SW1
		Multifunction programmable	be used for interlocking.	terminal can be used for interlocking.	Sink input
		ġ.	Shorting and then opening RES-CC	Shorting and then opening RES-	ON:Less than DC10V
		<u>0</u>	cancels the status held by an inverter	P24/PLC cancels the status held by an	OFF:DC16V or more
RES	Input	go.	protective function. When the inverter	inverter protective function. When the	Source input
		ar	is operating normally, shorting and	inverter is operating normally, shorting	ON:DC11V or more
		I	then opening RES-CC produces no	and then opening RES-P24/PLC	OFF:Less than DC5V
		ab	effect.	produces no effect.	OI 1 .Less than Dosv
٠.	١	е	Shorting across S1-CC causes preset	Shorting across S1-P24/PLC causes	Note:
S1	Input	Š	speed operation.	preset speed operation.	Even when an
		contact input			external power supply
		Ē	Shorting across S2-CC causes preset	Shorting across S2-P24/PLC causes	is used (in sink logic
S2	Input	ng	speed operation.	preset speed operation.	mode, i.e., when
		=	speed operation.	preset speed operation.	SINK (PLC) is
		1			selected), connect the
S3	Input		Shorting across S3-CC causes preset	Shorting across S3-P24/PLC causes	reference
00	put		speed operation.	preset speed operation.	potential-side (0V
		ł	SW3: When SW3 is in the S4 position,	SW3: When SW3 is in the S4 position,	side) cable from the
RR/S4	Input		S4 and CC are shorted and preset	S4 and P24/PLC are shorted and preset	power supply to the
111/04	IIIput		speed operation is selected.	speed operation is selected.	CC terminal.
	SW1-SB	NIK (I			
				LC): Sink logic (When an SW1=SOURCE ower supply is used) Source logic (W	(INT/PLC): hen the internal 24V
				power supply or	an external 24V power
	P24/PL	.c	If SW1 is set to 1	If SW1 is set to 2 supply is used)	If SW1 is set to 3
	SW		V SW1	2.2kΩ 3.3k	<u> </u>
	SINK	丫厂	P24 SOURCE SINK	SOURCE 2.2kΩ 2.2kΩ 2.2kΩ	
2700 TV					
	↓ □			SINK &	SOURCE 1
	2.2kΩ		2.2kΩ	SW1 j j	1.1
	cc_			→ PZMFLC CC	
	1		v I	v	

Terminal symbol	Input/ output	Function (Sink Source logic)	Electrical specifications	Inverter internal circuits
P24/	Output	24Vdc power output (when SW1 is in any position other than PLC) 24V internal output terminal	24Vdc-200mA	-
PLC	Input	If SW1 is turned to the PLC position, this terminal can be used as a common terminal when an external power supply is used.	-	
CC *1	Common to input/ output	Digital signal equipotential (0V) terminal for the control circuit and equipotential (0V) terminal for an optional control power supply backup.	-	-
PP	Output	Analog input setting power output	10Vdc (Permissible load current:10mAdc)	Constant voltage circuit
RR/S4	Input	SW3: Multifunction programmable analog input terminal when SW3 is in the RR position. Standard default setting:0~10Vdc input and 0~60Hz frequency.	10Vdc (Internal impedance:30 kΩ)	2.2k S4 12.7k P5 12.7k SW3 15k V
VI/I I	Input	Multifunction programmable analog input. Standard default setting: 0~10Vdc input and 0~60Hz frequency. This terminal can also be used as a 4-20mAdc (0-20mAdc) input terminal, if the parameter F 108 set to 1.	$10Vdc \\ (Internal impedance: 30 \ k\Omega) \\ 4{\sim}20mA \\ (Internal impedance: 242\Omega)$	15k P5
RX	Input	Multifunction programmable analog input. Standard default setting:0-±10Vdc input and 0-±60Hz frequency.	$\begin{array}{c} \text{10Vdc} \\ \text{(Internal impedance:22 k}\Omega) \end{array}$	15k \(\frac{1}{\sqrt{7}}\)
FM	Output	Multifunction programmable analog output. Standard default setting: output frequency Use this terminal to connect a 1mAct full-scale ammeter. This terminal can also be used as a 0-10V (F 5 8 != !), if the SW2 switch is set to 0-10V/0-20mA side.	1mA full-scale DC ammeter (Allowable load resistance 7.5kΩ or less) or 7.5Vdc-1mA full-scale DC voltmeter 0-10V full-scale DC voltmeter (Allowable load resistance 500Ω or more)/0-20mA (4-20mA) Full-scale DC ammeter voltmeter (Allowable load resistance 500Ω or less)	0-10V 0-20mA 0-10V 0-20mA 120 120 4.7k 0-1mA 0-20mA
АМ	Output	Multifunction programmable analog output. Standard default setting: output current Use this terminal to connect a 1mAdc full-scale ammeter or 7.5Vdc (10Vdc)-1mA full-scale voltmeter.	1mA full-scale DC ammeter ammeter (Allowable load resistance 7.5kΩ or less) or 7.5Vdc-1mA full-scale DC voltmeter	4.7k
OUT1		Multifunction programmable open collector output. The default setting is to output a signal when output low speed threshold has been reached. Depending on the SW4 setting, pulses are output with frequencies of 1.00kHz to 43.20kHz. Standard default setting:3.84kHz	Open collector output 24Vdc-50mA	OUT1 SW4 PPULS
OUT2	Output	Multifunction programmable open collector output. By default, it is set to output a signal indicating the completion of acceleration or deceleration.	*Sink logic/source logic switchable	
NO		Digital output signal equipotential (0V) terminal for the control circuit. It is isolated from the CC terminal.		No The state of th
CCA *1	Common to input/ output	Analog input/output signal equipotential (0V) terminal for the control circuit.	-	

^{1:} Although the CC terminal and the CCA terminal are not insulated, they should be used separately, one for the logic circuit and the other for the analog circuit

Terminal symbol	Input/ output	Function (Sink Source logic)	Electrical specifications	Inverter internal circuits
+SU	Input	DC power input terminal for operating the control circuit. Connect a control power backup device (optional) between +SU and CC.	Voltage:24Vdc±10% Use a power supply with a current rating of 1.05A or more. (In case of not install options, current rating is 300mA)	+SU 1 P24
FLA FLB FLC	Output	Relay contact output. Contact rating Used to detect the activation of the inverter's protective function. Contact across FLA-FLC is closed and FLB-FLC is opened during protection function operation.	250Vac-2A 30Vdc-1A :at resistance load 250Vac-1A :cos∳=0.4	FLA FLE FL

<u> </u>			
SW	SW settings	Default setting (Settings marked with •)	Function
	SOURCE SINK INT/PLC PLC INT	• (-WN, HN)	Setting for using the inverter's internal power supply in sink logic mode
SW1	SOURCE SINK INT/PLC PLC INT		Setting for using the inverter's external power supply in sink logic mode
	SOURCE SINK INT/PLC PLC INT	• (-WP)	Setting for operating the inverter in source logic mode
	0-10V FM 0-20mA 0-1mA	•	Setting for using the analog output terminal FM to output current of 0-1mA
SW2	0-10V FM 0-20mA 0-1mA		Setting for using the analog output terminal FM to output current of 0-10V or 0-20mA (4-20mA) 0-10V ($F \in B \mid I=I$) or 0-20mA ($F \in B \mid I=I$) can be selected by changing parameter settings.
SW3	RR/S4 S4 RR	•	Setting for using the input terminal RR/S4 as an analog input terminal (0-10Vdc)
5003	RR/S4 S4 RR		Setting for using the input terminal RR/S4 as a contact input terminal
SWA	OUT1 PULS LO	•	Setting for using the output terminal OUT1 as a logic output terminal When turning the switch to this position, always set the parameter F 5 5 9 to \$\mathcal{G}\$ (logic output).
SW4	OUT1 PULS Lo		Setting for using the output terminal OUT1 as a pulse output terminal When turning the switch to this position, always set the parameter F 5 5 9 to 1 (pulse output).


■ Sink logic/source logic (When inverter's internal power supply is used)


Current flowing out turns control input terminals on. These are called sink logic terminals.


The method generally used in Europe is source logic in which current flowing into the input terminal turns it on. Sink logic terminals and source logic terminals are sometimes referred to as negative logic terminals and positive logic terminals, respectively.


Each logic is supplied with power from either the inverter's internal power supply or an external power supply, and its connections vary depending on the power supply used.

<Examples of connections when the inverter's internal power supply is used>










^{*1:}Be sure to short across NO-CC

■ Sink logic/source logic (When an external power supply is used)


The P24/PLC terminal is used to connect to an external power supply or to insulate a terminal from other input or output terminals. Use the slide switch SW1 to switch between sink logic and source logic configurations.

<Examples of connections when an external power supply is used>




Note: Be sure to connect the 0V terminal on the external power supply to the CC terminal on the inverter.

"When OUT1 is used as a pulse output terminal (when SW4 is in the PULS position), the circuit shown below is always formed regardless of the logic selected (sink or source) and the power supply used (internal or external power supply).



2.3.3 RS485 communication connector

The VF-AS1 is equipped with two connectors: a two-wire RS485 connector (on the operation panel) and a four-wire RS485 connector. The two wire RS485 connector is used to connect an external option (such as remote keypad or computer) to the inverter. To connect to a network, use the four-wire RS485 connector, following the instructions below.



2-wire RS485

Signal name	Pin number	Description
DA	4	Same phase data
DB	5	Anti-phase data
SG	8	Ground line of signal data


This table shows signal line of inverter side.

4-wire RS485

wife 100-000		
Pin	Description	
number	Description	
4	Same phase reception data (positive line)	
5	Anti-phase reception data (positive line)	
3	Same phase transmitting data (positive line)	
6	Anti-phase transmitting data (positive line)	
2, 8	Ground line of signal data	
	Pin number 4 5 3 6	

This table shows signal line of inverter side. (Example: RXA signal is received by inverter.)

■ Connecting diagram for 4-wire RS485 communication



■ Note

- * Separate the communication line and the main circuit wiring by 20cm or more.
- * Never use pin-1 (P24) and pin-7 (P11).
- * Connect RXA and RXB, between TXA and TXB using twisted pair cable.
- * Connect terminating resistances at both ends of a transmission line.
- * When using 2-wire type, short RXB to TXB and RXA to TXA.

When connecting a communications device via the two-wire connector, carefully read the precautions for use in the operating manual for the communications device.

* When connecting the VF-AS1 to other inverters, you do not need to connect the master receive lines (pins 4 and 5) or the slave send lines (pins 3 and 6).

^{*} Never use pin-1, 2, 3, 6 and 7.

^{*} Never use pin-1 (P24) and pin-7 (P11).

3. Operations

This section explains the basics of operation of the inverter.

Check the following again before starting operation.

- 1) Are all wires and cables connected correctly?
- 2) Does the supply voltage agree with the rated input voltage?

Warning Do not touch inverter terminals when electrical power is applied to the inverter even if the motor

Prohibited

is stopped.

Touching the inverter terminals while power is connected to it may result in electric shock.

Do not touch switches when the hands are wet and do not try to clean the inverter with a damp

Such practices may result in electric shock.

Do not go near the motor in alarm-stop status when the retry function is selected.
The motor may suddenly restart and that could result in injury.
Take measures for safety, e.g. attaching a cover to the motor, against accidents when the motor unexpectedly restarts.



- Turn power on only after attaching the front cover or closing door if enclosed in a cabinet.
 If power is turned on without the front cover attached or closing door may result in electric shock or other injury.
- If the inverter begins to emit smoke or an unusual odor, or unusual sounds, immediately turn power off.
 If the equipment is continued in operation in such a state, the result may be fire. Call your local
- sales agency for repairs.

 Always turn power off if the inverter is not used for long periods of time.
- Do not turn on the power before attaching the front cover.
 When enclosed inside a cabinet and using with the front cover removed, always close the cabinet doors first and then turn power on. If the power is turned on with the front cover or with the
- Make sure that operation signals are off before resetting the inverter after malfunction.
 If the inverter is reset before turning off the operating signal, the motor may restart suddenly causing injury.

$\overline{\mathbb{N}}$

Warning



Do not touch heat radiating fins or discharge resistors.
 These devices are hot, and you'll get burned if you touch them.

cabinet doors open, it may result in electric shock.



Prohibited

Observe all permissible operating ranges of motors and mechanical equipment. (Refer to the motor's instruction manual.)

 New York in the motor's instruction manual.)

Not observing these ranges may result in injury.

Setting/monitor modes 3.1

The VF-AS1 has the following three setting/monitor modes.

Standard monitor mode

The standard inverter mode. This mode is enabled when inverter power goes on.

This mode is for monitoring the output frequency and setting the frequency reference value. If also displays information about status alarms during running and trips.

- Setting frequency reference values ⇒ Refer to Section 3.2.2.
- Status alarm

If there is an error in the inverter, the alarm signal and the frequency will flash alternately in the LED display.

- [: When a current flows at or higher than the overcurrent stall prevention level.
- P: When a voltage is generated at or higher than the over voltage stall prevention level.
- L: When the cumulative amount of overload reaches 50% or more of the overload trip value.
- H: When temperature inside the inverter rises above overheating protection alarm level (about 95°C)

Setting monitor mode

The mode for setting inverter parameters.

⇒ How to set parameters, refer to Section 4. 1.

This mode is divided into two modes according to the parameter readout mode selected.

Quick mode :Eight frequently used basic parameters are just displayed.

The maximum 32 parameters that you select by

yourselves are displayed.

Standard setting mode :Both basic and extended all parameters are displayed.

Status monitor mode

The mode for monitoring all inverter status.


Allows monitoring of set frequencies, output current/voltage and terminal information

⇒ Refer to Section 8.

Pressing the key



will move the inverter through each of the modes.



How to search and set

⇒ Refer to Section 4.1.

3.2 Simplified operation of the VF-AS1

On of three operation modes can be selected: terminal board operation, operation panel and combination of both. \Rightarrow For other operation modes, refer to Section 5.5.

Terminal board mode :Operation by means of external signals

Operation panel mode :Operation by pressing keys on the operation panel

Operation panel + terminal board mode :Frequency, start/stop signals can be sent individually from the operating panel and terminal board.


3.2.1 Terminal board operation


In this mode, the motor is started or stopped according to the ON/OFF signal to input terminals (such as the ST terminal and the F terminal). Also, the frequency is set according to the potentiometer/voltage/current signals to analog input terminals (such as the RR/S4 terminal, VI/II terminal and RX terminal).

⇒ For more details, refer to Section 7.


■ Example of standard connection

F and CC






are connected: Forward run




OFF

■ Frequency setting

1) Setting the frequency using potentiometer




2) Setting the frequency using input voltage (0~10V)



3) Setting the frequency using current input (4(0)~20mA)


point setting 1" parameter $F \supseteq \Omega \mid I$ to $\supseteq \Omega$.

F 108 to 1.



To bring the operation frequency to OHz at an input current of 4mA, set the "VI/II input

4) Setting the frequency using input voltage (0~10Vdc)




Set the "extended parameter analog input VI/II voltage/current switching" parameter F \(\Pi\) or \(I\).

In addition, set the "basic parameter frequency setting mode selection 1" parameter \(F\) \(I\) or \(I\) to \(I\) (default setting).

5) Setting the frequency using input voltage (0~±10Vdc)

The direction can be changed by switching between positive and negative signals.



Note: Set reference frequency priority selection $F \supseteq \square \square$ to \square ($F \sqcap \square \square d / F \supseteq \square$? terminal switching, default setting). Changing the settings of two speed command parameters at a time, refer to Section 6.6.


[Example of setting: To set the frequency by applying a current of 4(0)-20mAdc via the VI/II terminal.]


Key operated	LED display	Operation	
	0.0	Displays the operation frequency. (Perform during operation stopped.) (When standard monitor display selection F 7 $IG=G$ [Output frequency])	
MODE	ЯИН	Displays the first basic parameter "History function (用じH)."	
\bigcirc	FNOd	Press either the △ or ▽ key to select "F # # # d."	
ENT	2	Press the ENTER key to display the parameter setting (Default setting: 2).	
l Press the ∇ key to change the parameter to 1.		Press the key to change the parameter to 1.	
ENT	I⇔F∏Od	Press the ENTER key to save the changed parameter. FnDd and the parameter are displayed alternately.	

Key operated	LED display	Operation	
$\bigcirc \bigcirc$	F !	Press either the \triangle key or the ∇ key to change to the parameter group F I	
ENT	F 100	Press the ENTER key to display the first extended parameter F 100.	
\Diamond	F 108	Press the △ key to change to F 108.	
ENT	0	Pressing the ENTER key allows the reading of parameter setting. (Default setting: \mathcal{G})	
l Press the △ key		Press the \triangle key to change the parameter to $\ I.$	
(ENT) i⇔FiiiH		Press the ENTER key to save the changed parameter. F 10 8 and the parameter are displayed alternately.	
	F2	Press either the \triangle key or the ∇ key to change to the parameter group F $\stackrel{?}{\sim}$	
ENT F 200 Press the ENTER key to		Press the ENTER key to display the first extended parameter F 200.	
Pressing the ENTER key allows to (Default setting: (1))		Press the △ key to change to F ≥ 0 1.	
		Pressing the ENTER key allows the reading of parameter setting. (Default setting: \mathcal{G})	
		Press the \triangle key to change the parameter to $\mathcal{Z} \mathcal{Q}$.	
ENT	20⇔F20 I	Press the ENTER key to save the changed parameter. F 2 0 1 and the parameter are displayed alternately.	

3.2.2 Panel operation

This section describes how to start/stop the motor, and set the operation frequency with the operating panel.





■Changing parameter settings

during operation.

For control panel operation, parameter settings need to be changed in advance.

If you use parameter RU that makes it possible to select an operation mode in one operation, you can complete this operation by just making settings once.

Here are the steps to be followed to change the setting to 5 (frequency setting and operation by means of the control panel).

[Setting procedure]

Key operated	LED display	Operation	
	0.0	Displays the operation frequency (operation stopped). (When standard monitor display selection F 7 1 \$\mathcal{I} = \mathcal{I}\$ [Output frequency])	
EASY		Press the EASY key.	
MODE	ЯИЧ	$\mbox{\it RUV}$ (automatic function setting) at the head of the basic parameters available in quick mode is displayed.	
ENT	0	Press the ENTER key to display the parameter setting (Default setting: ①).	
\bigcirc	5	Press the \triangle key to change the parameter to 5 (Frequency setting and operation on operation panel).	
ENT	5⇔RU4	Press the ENTER key to save the changed parameter. R L Y and the parameter are displayed alternately.	

^{*}Pressing the MODE key returns the display to standard monitor mode (displaying operation frequency).

■ Example of operation panel control

Key operated	LED display	Operation
	0.0	The running frequency is displayed. (When standard monitor display selection F 7 ! [] = [] [Output frequency])
$\bigcirc \bigcirc \bigcirc$	5 0.0	Set the operation frequency.
ENT	5 0.0 ⇔F C	Press the ENTER key to save the operation frequency. F [and the frequency are displayed alternately.
RUN	<i>0.0</i> ⇒ 5 <i>0.0</i>	Pressing the RUN key causes the motor to accelerate to the set frequency in the specified acceleration time.
$\bigcirc \bigcirc \bigcirc$	60.0	Pressing the \triangle key or the ∇ key will change the operation frequency even during operation.
STOP	60.0⇒0.0	Pressing the STOP key reduces the frequency and causes the motor to decelerate to a stop.

■ Selecting a stop mode with the operation panel

In addition to deceleration stop by pressing (STOP) key (in the specified deceleration time), the operating panel has

the following two stop modes.



Stop mode	Action	Operation, setting, etc.
Coast stop	In this mode, power supply from the inverter to the motor is shut off instantaneously, which causes the motor to coast stop.	This stop mode is enabled only in modes where the operation panel can be used for operation. To enable the coast stop mode, set the parameter F ? ₹ != t. ⇒ For more details, refer to Section 6.36.6. *Default setting: F ? ₹ != ₽ (Deceleration stop)
Emergency stop (from the operation panel in modes other than the panel operation mode)	A stop mode can be selected from among: • Coast stop • Deceleration stop • Emergency DC braking • Deceleration stop Note: Default setting: F & B 3 = B (Coast stop)	In modes other than the operation panel operation mode, you can stop the motor (emergency stop) by entering a command from the operation panel. (To quickly stop the motor in the operation panel operation mode, set the parameter <i>F</i> ? <i>2</i> 1 to this mode.) Pressing the STOP key on the panel twice enables emergency stop. (1) Press the STOP key. "E □ F F" starts blinking. (2) Press the STOP key again. F ⑤ □ 3 (Emergency stop) = □ to 3, the motor makes an emergency stop (or trips) according to the setting. "E" will be displayed and a failure detection signal generated (FL activated). Select the output terminal function 13 4 (13 5) to deactivate FL. To clear "E □ F F", press any key other than the STOP key while "E □ F F" is being displayed. ⇒ For more details, refer to Section 6.33.3. "Default setting: F ⑤ □ 3 = □ (Coast stop) - Warning - The emergency stop function is designed to forcefully stop the motor by pressing the Stop key on the operation panel in modes other than the operation panel control mode. The emergency stop function cannot be disabled by any setting. Every emergency stop is memorized as a trip in the trip history record.

4. Searching and setting parameters

There are two types of setting mode quick mode and standard setting mode.

Quick mode


: EASY kev: ON

Eight frequently used basic parameters are just displayed (Factory default position).

Quick mode (EASY)

Title	Function
ЯЦЧ	Automatic function setting
PE	V/f control mode selection
FH	Maximum frequency
ACC	Acceleration time 1
d E C	Deceleration time 1
Ł H r	Motor electronic thermal protection level 1
FN	FM terminal meter adjustment
PSEL	Registered parameter display selection

Parameters you selected can be displayed by changing the parameter. (Up to 32 parameters)



For reasons of safety, the following parameters have been set up so that they cannot be reprogrammed while the inverter is running.

<i>(</i>		٠		
[Basic pa	[Basic parameters]			
AU!	(Automatic acceleration/deceleration)	:		
RU∂	(Automatic torque boost)	i		
ЯШЧ	(Automatic function setting)	i		
CUOA	(Command mode selection)	i		
FNOd	(Frequency setting mode selection 1)	i		
PŁ	(V/f control mode selection)	i		
υĹ	(Base frequency 1)	i		
uLu	(Base frequency voltage 1)	i		
FH	(Maximum frequency)			
U u 5	(Auto-restart control selection)	•		
Uυ[(Regenerative power ride-through control)	-		
РЬ	(Dynamic braking selection)			
Pbr	(Dynamic braking resistance)	-		
P6[P	(Allowable continuous braking resistance)			
£ YP	(Factory default setting)	i		
·		i		

 $[\]Rightarrow$ To write-protect extended parameters during operation, refer to Section 11.


4.1 How to set parameters

This section explains how to set parameters, while showing how parameters are organized in each setting monitor mode.

4.1.1 Setting parameters in the selected quick mode

To place the inverter in this mode, press the (EASY) key (the LED lights up), and then press the (MODE) key

Note that extended parameters are not displayed in the quick mode.



■ Adjustment range and display of parameters


(3) Change the parameter value. (Press the (4) Press this key to save the change. (Press the

- H 1: An attempt has been made to assign a value that is higher than the programmable range. Or, as a result of changing other parameters, the programmed value of the parameter that is now selected exceeds the upper limit.
- £ 1: An attempt has been made to assign a value that is lower than the programmable range. Or, as a result of changing other parameters, the programmed value of the parameter that is now selected exceeds the lower limit.

If the above alarm is flashing on and off, no setting can be done of values that are equal to or greater than $\mathcal H$ $\mathcal H$ or equal to or lower than $\mathcal L$ $\mathcal G$.

4.1.2 Setting parameters in the standard setting mode

Press the (MODE) key to place the inverter in this mode.



Used to set values and return to previous menu

Enter key

Select key
Used to select item

Mode key
Used to select mode and operation level

* Parameter title and the setting value are displayed alternately.

■ How to set extended parameters

Each extended parameter is composed of an "F" and three figures that follow the f, so first select and read out the heading of the parameter you want "F I - " - "F I - - ":Parameter bearing a number between 100 and 199, "F I - - ":Parameter bearing a number between 900 and 999)

- (1) Select the title of the parameter you want to change. (Press the (\bigwedge) or (\bigvee) key.)
- (2) Press the Enter key to activate the selected parameter. (Press the (ENT)key.)
- (3) Selects parameter to be changed. (Press the \bigwedge or \bigvee key.
- (4) Reads the programmed parameter setting. (Press the (ENT) key.)
- (5) Change the parameter value. (Press the (\(\)\)or_(\(\)\) key.)
- (6) Press this key to save the change. (Press the (ENT)key.)

■ Adjustment range and display of parameters

- H 1: An attempt has been made to assign a value that is higher than the programmable range. Or, as a result of changing other parameters, the programmed value of the parameter that is now selected exceeds the upper limit
- L I: An attempt has been made to assign a value that is lower than the programmable range. Or, as a result of changing other parameters, the programmed value of the parameter that is now selected exceeds the lower limit

If the above alarm is flashing on and off, no setting can be done of values that are equal to or greater than H I or equal to or lower than I I.

4.2 Functions useful in searching for a parameter or changing a parameter setting

This section explains functions useful in searching for a parameter or changing a parameter setting. To use these functions, a parameter needs to be selected or set in advance.

Changed parameter search function

Automatically searches for only those parameters that are programmed with values different from the standard default setting. To use this function, select the $\mathcal{L} \cap \mathcal{U}$ parameter.

⇒ For more details, refer to Section 5.21.

Parameter change history function

⇒ For more details, refer to Section 5.1.

Function of resetting all parameters to their default settings

Use the $\not\vdash \exists P$ parameter to reset all parameters back to their default settings.

⇒ For more details, refer to Section 5.20.

5. Basic parameters

This parameter is a basic parameter for the operation of the inverter.

⇒ Refer to Section 11, Table of parameters.

5.1 History function

₩ : History function

• Function

Automatically searches for 5 latest parameters that are programmed with values different from the standard default setting and displays them in the ###. Parameter setting can also be changed within this group ####.

This function comes in very handy when you adjust the inverter repeatedly using the same parameter.

Note 1: If no history information is stored, this parameter is skipped and the next parameter R 🗓 1.

Note 2: HERd and End are added respectively to the first and last parameters in a history of changes.

[Setting methods]

Key operated	LED display	Operation
	0.0	Displays the operation frequency (operation stopped). (When standard monitor display selection F 7 10=0 [Output frequency])
MODE	яин	The first basic parameter "History function $(\mathcal{H} \mathcal{U} \mathcal{H})$ " is displayed.
ENT	A C C	The parameter that was set or changed last is displayed.
ENT	8.0	Press the ENTER key to display the set value.
$\bigcirc \bigcirc \bigcirc$	5.0	Press the \triangle key and ∇ key to change set value.
ENT	5.0⇔R[[Press the ENTER key to save the changed value. The parameter name and the programmed value will flash on and off alternately.
$\bigcirc (\bigcirc)$	***	Use the same steps as those given above to display parameters that you want to search for or change setting with the \triangle key and ∇ key.
$\bigcirc (\bigcirc)$	HERd (End)	HERd: First historic record End: Last historic record
(MODE) (MODE) (MODE)	Parameter display \$\frac{1}{\text{\$RUH\$}}\$ \$F_{\tau} - F \$\frac{1}{\text{\$O:0}}\$	Press the MODE key to return to the parameter setting mode #UH. After that you can press the MODE key to return to the status monitor mode or the standard monitor mode (display of operation frequency).

5.2 Setting acceleration/deceleration time

RUI: Automatic acceleration/deceleration

: Acceleration time 1

Function

- For acceleration time 1 R L L programs the time that it takes for the inverter output frequency to go from 0Hz to maximum frequency F H.
- For deceleration time 1 d E C programs the time that it takes for the inverter output frequency to got from maximum frequency F H to 0Hz.

5.2.1 Automatic acceleration/deceleration


This automatically adjusts acceleration and deceleration time in line with load size.

A!II = I

* Adjusts the acceleration/deceleration time automatically within the range of 1/8 to 8 times as long as the time set with the REC or dEC, depending on the current rating of the inverter.

AU 1 =2

* Automatically adjusts speed during acceleration only. During deceleration, speed is not adjusted automatically but reduced at the rate set with dE[.



Set ### ! (automatic acceleration/deceleration) to ! or 2.

[Parameter setting]

Title	Function	Adjustment range	Default setting
ЯШ !	Automatic acceleration/deceleration	☐:Disabled (Manual setting) I:Automatic setting C:Automatic setting (during acceleration only)	a

When automatically setting acceleration/deceleration time, always change the acceleration/deceleration time so that it conforms with the load.

The acceleration/deceleration time changes constantly with load fluctuations.

For inverters that requires a fixed acceleration/deceleration time, use the manual settings (R [[, d [[]]]]).

When using a braking resistor or braking unit, do not set the RUII = I. Or the regenerative braking resistor may be overloaded.


Use this parameter after actually connecting the motor.

Setting acceleration/deceleration time ($R \mathcal{L} \mathcal{L}$, $d \mathcal{E} \mathcal{L}$) in conformance with mean load allows optimum setting that conforms to further changes in load.

When the inverter is used with a load that fluctuates considerably, it may fail to adjust the acceleration or deceleration time in time, and therefore may be tripped.

5.2.2 Manually setting acceleration/deceleration time

Set acceleration time from 0 (Hz) operation frequency to maximum frequency $\mathcal{F} \mathcal{H}$ and deceleration time as the time when operation frequency goes from maximum frequency $\mathcal{F} \mathcal{H}$ to 0 (Hz).



[Parameter setting]

Title	Function	Adjustment range	Default setting
ACC	Acceleration time 1	[]. /[Note]~[6 [] [] [] sec.	According to model ⇒ Refer to page K-46.
d E C	Deceleration time 1	Ū. /[Note]~ <i>Б Ѿ Ѿ Ū</i> sec.	According to model ⇒ Refer to page K-46.

Note: The minimum setting of acceleration and deceleration times have been set respectively at 0.1 sec. by default, but they can be changed within a range of 0.01 sec. (setting range:0.01~600.0 sec.) by changing the setting of the parameter £ \$\frac{4}{2} P\$ (default setting).

⇒ For details, refer to Section 5.20.

When running under not connect the motor at setting Pt=2,3,4,7,8, it might to not operate normally. It will be able to running normally by connecting the motor.

If the programmed value is shorter than the optimum acceleration/deceleration time determined by load conditions, overcurrent stall or overvoltage stall function may make the acceleration/deceleration time longer than the programmed time. If an even shorter acceleration/deceleration time is programmed, there may be an overcurrent trip or overvoltage trip for inverter protection.

⇒ For details, refer to Section 13.1.

5.3 Increasing starting torque

RU2 : Automatic torque boost

Function

Simultaneously switches inverter output V/f control and programs motor constants automatically (auto-tuning function 1) to improve torque generated by the motor. This parameter integrates the setting of special V/f control selection such as automatic torque boost or vector control.

- O Constant torque characteristics (default setting)
- O Automatic torque boost+auto-tuning 1
- O Sensorless vector control 1+auto-tuning 1

Note: Square reduction torque control, sensor vector control (optional), etc. can be selected using the V/f control mode selection parameter P Ł.

⇒ For details, refer to Section 5.6.

[Parameter setting]

[· •··•···•·• • •							
Title	Function	Adjustment range	Default setting				
AU S	Automatic torque boost	☐: Disabled (Always ☐ is displayed.) I: Automatic torque boost+auto-tuning 1 Z: Sensorless vector control 1+auto-tuning 1	0				

Note: Parameter displays on the right always return to ${\it G}$ after resetting. The previous setting is displayed on the

Ex. / []

1) Increasing torque automatically according to the load

Set the automatic torque boost ##2 = ! (automatic torque boost+auto-tuning 1)

Automatic torque boost RU2 = I detects load current in all speed ranges and automatically adjusts voltage output from inverter. This gives steady torque for stable runs.

- Note 1: The same characteristic can be obtained by setting the V/f control mode selection parameter $P \not\vdash to \not = 0$ (automatic torque boost) and $F \not\vdash U \cap U$ (auto-tuning 1) to $\not = 0$. \Rightarrow Refer to Section 6.22.
- Note 2: Setting RU2 to I automatically programs PE to Z.
- Note 3: If stable operation cannot be achieved with this setting, set the parameters UL (base frequency), ULU (base-frequency voltage), FUUU (rated capacity of motor), FUUU (rated number of revolutions of motor) as specified on the motor nameplate, and then set FUUU to UU and UUU to UU again.

2) When using vector control (increasing starting torque and high-precision operations)

Set the automatic torque boost AU2=2 (sensorless vector control 1+auto-tuning 1)

Setting automatic torque boost RU2 = 2 (Sensorless vector control 1+auto-tuning 1) provides high starting torque bringing out the maximum in motor characteristics from the low-speed range. This suppresses changes in motor speed caused by fluctuations in load to provide high precision operation. This setting is most suitable for transfer and lifting systems that are operated in speed control mode.

- Note 1: The same characteristic can be obtained by setting the V/f control mode selection parameter $P \not\vdash$ to \exists (Sensorless vector control 1) and $F \not\vdash Q Q Q$ (Auto-tuning 1) to $\not\vdash$. \Rightarrow Refer to Section 6.22.
- Note 2: Setting ₱#₽ to ₽ automatically programs ₱₽ to ∃.
- Note 3: If stable operation cannot be achieved with this setting, set the parameters uL (base frequency), uLu (base-frequency voltage), $F \ \ UDS$ (rated capacity of motor), $F \ \ UDS$ (rated current of motor) and $F \ \ UDS$ (rated number of revolutions of motor) as specified on the motor nameplate, and then set $F \ \ UDS$ to $V \ \ UDS$ and $V \ \ UDS$ again.

If vector control cannot be programmed....

First read the precautions about vector control in 5.6, 9).

1) If the desired torque cannot be obtained \Rightarrow Refer to 6.22 selection 3.

2) If auto-tuning error " $\xi \not\models \sigma$ " appears \Rightarrow Refer to 13.1 and 6.22 selection 3.

■ RU2 (automatic torque boost) and PL (V/f control mode selection)

Automatic torque boost is the parameter for setting V/f control mode selection (PE) and auto-tuning 1 (FABB) together. That is why all parameters related to change automatically when ABB is changed.

		Automatically programmed parameters			
RU 2			PĿ	F400	
0	Disabled (Always ♂ is displayed.)	-	Check the programmed value of P Ł . (If R L' is not changed, it becomes C (V/f constant).)	-	
1	Automatic torque boost+auto-tuning 1	2	Automatic torque boost	¿: Executed (☐ after execution)	
2	Sensorless vector control 1+auto-tuning 1	3	Sensorless vector control 1	¿: Executed (☐ after execution)	

3) Increasing torque manually (V/f constant control)

The VF-AS1 inverter is set to this control mode by factory default.

This is the setting of constant torque characteristics that are suited for such things as conveyors. It can also be used to manually increase starting torque.

To return to V/f constant control after changing the ##2 setting:

Set the V/f control mode selection parameter P = 0 (constant torque characteristic).

⇒ Refer to Section 5.6.

Note: If you want to increase torque further, raise the setting value of manual torque boost ub.

How to set manual torque boost parameter ub

⇒ Refer to Section 5.7.

5.4 Setting parameters by operating method

: Automatic function setting

Function


Automatically programs all parameters (parameters described below) related to the functions by selecting the inverter's operating method.

The major functions can be programmed simply.

[Parameter setting]

Title	Function	Adjustment range	Default setting
ЯИЧ	Automatic function setting	### Company Setting By Means of Voltage ### Continuous Setting By Means of Current ### Continuous Setting By Means of Current ### Continuous Setting By Means of Current #### Continuous Setting By Means of S	a

Example: When setting the parameter "AUA = 3", It will be the following indication.



Automatically programmed functions and parameter set values							
	Default setting	☐:Disabled	f:Frequency setting by means of voltage	ご:Frequency setting by means of current	3:Voltage/current switching from external terminal	북: Frequency setting on operation panel and operation by means of terminal	5: Frequency setting and operation on operation panel
C U D 4	☐:Terminal board	-	-	_	-	☐:Terminal board	:Operation panel
FNOd	<i>2</i> :RR/S4	-	<i>2</i> :RR/S4	<i>{</i> :VI/II	₽:RR/S4	당:Operation panel	당:Operation panel
F 108	☐:Voltage input	-	=	:Current input	1:Current input	=	-
F 1 1 7 (S3)	14: Preset speed command 3	-	-	-	1日년:Frequency priority switching	-	-
F 2 0 0	☐:F∏☐d/ F⊇☐7 terminal switching	-	ロ:F Π ロ d / F Z ロ 7terminal switching	0:F II 0 d / F 2 0 7 terminal switching	ロ:F ロロ d / F Z ロ 7 terminal switching	☐:F∏☐d/ F Z ☐ 7terminal switching	D:F∏Dd/ F2D7terminal switching
F20 1	<i>[]</i> %	_	_	20%	20%	-	_
F207	f:VI/II	_	<i>2</i> :RR/S4	f:VI/II	t:VI/II	ዣ:Operation panel	Y:Operation panel
→ Refe	→ Refer to Section 11 for input terminal functions						

⇒ Refer to Section 11 for input terminal functions.

Disabled (R ⊔ Ч=Ū)

No change is made to the parameter setting.

Frequency setting by means of voltage: (AU4=1)

Operation is performed by applying a voltage for setting the RR/S4 terminal 1 frequency.

When sink logic is selected:

ST-CC ON: Standby (ON (short-circuited) by default)

F-CC ON: Forward run R-CC ON: Reverse run

Frequency setting by means of current

This setting is used to set the frequency by applying a current of 4-20mA to the VI/II terminal.

ST-CC ON: Standby (ON (short-circuited) by default)

F-CC ON: Forward run R-CC ON: Reverse run Voltage/current switching by means of an external terminal

Switching between remote and local (different frequency commands) can be performed by turning on or off the S3 terminal. In that case, apply a voltage via the RR/S4 terminal and a current via the VI/II terminal.

S3-CC OFF: The frequency is set according to the voltage applied to the RR/S4 terminal.

S3-CC ON: The frequency is set according to the current applied to the VI/II terminal.

In sink logic mode: ST-CC ON: Standby (ON (short-circuited) by default), F-CC ON: Forward run, R-CC ON: Reverse run,

Frequency setting with operation panel and operation with terminal board

This setting is used to set the frequency using the operation panel and to perform operation control using the terminal board

Use the

and

keys to set the frequency.

In sink logic mode: ST-CC ON: Standby (ON (short-circuited) by default),

F-CC ON: Forward run. R-CC ON: Reverse run.

Frequency setting and operation with operation panel:

This setting is used to set the frequency and to perform operation control, using the operation panel.

Use the

and

keys to set the frequency.

Use the and (RUN) (STOP)

keys to perform operation control.

5.5 Selection of operation mode

☐☐ d : Command mode selection

: Frequency setting mode selection 1

Function

These parameters are to program which command to the inverter (from operation panel, terminal board, remote input device or options) will be given priority in running/stopping the operation and in frequency setting (speed).

<Command mode selection>

[Parameter setting]

Title	Function	Adjustment range	Default setting
cuaa	Command mode selection	☐:Terminal input enabled 1:Operation panel input enabled (including LED/LCD option input) 2:2-wire RS485 communication input 3:4-wire RS485 communication input 4:Communication option input	a

[Programmed value]

Terminal board operation

ON and OFF of an external signal Runs and stops operation.

Operation panel operation

Press the (RUN) and (STOP) keys on the operation panel to Run and stop a run. (including LED/LCD option input)

Run and stop commands are entered from the 2-wire RS485 communications device.

2-wire RS485 communication operation

(Communication No.: FA00) Run and stop commands are entered from the 4-wire

4-wire RS485 communication operation

RS485 communications device. (Communication No.: FA04)

4: Communication option input enabled

Signals from an optional communication device are used to start and stop operation.

⇒ For details, refer to Instruction Manual (E6581281, E6581343, E6581288) specified in Section 6.42.

- * There are two types of function: the function that conforms to commands selected by [] [] [], and the function that conforms only to commands from the terminal board.
- ⇒ Refer to the table of input terminal function selection in Section 7.2.
- * When priority is given to commands from a linked computer or terminal board, they have priority over the setting of Enoa.

<Frequency setting mode selection>

[Parameter setting]

Title	Function	Adjustment range	Default setting
FNOd	Frequency setting mode selection 1	I:VI/II (voltage/current input) 2:RR/S4 (potentiometer/voltage input) 3:RX (voltage input) 4:Operation panel input enabled (including LED/LCD option input) 5:2-wire RS485 communication input 5:4-wire RS485 communication input 7:Communication option input 8:Optional Al1 (differential current input) 9:Optional Al2 (voltage/current input) 10:Up/Down frequency 1:Optional RP pulse input 12:Optional high-speed pulse input 13:- (Note 1)	2

[Programmed value]

- 1: VI/II input Speed setting commands are entered by external signals (0~10Vdc or 4(0)~20mAdc). RR/S4 input Speed setting commands are entered by external signals (RR/S4 terminal:0~10Vdc). RX input Speed setting commands are entered by external signals (RX terminal:0~±10Vdc (±5Vdc)). Operation panel input Press the and (keys on the operation panel to set the freauency. (including LED/LCD option input) 2-wire RS485 communication operation Speed commands are entered from the 2-wire RS485 communications device. (Communication No.:FA01) 4-wire RS485 communication operation Speed commands are entered from the 4-wire RS485 communications device. (Communication No.:FA05)
- 7: Communication option input enabled

Speed commands are entered from an optional communication device.

- ⇒ For details, refer to Instruction Manual (E6581281, E6581343, E6581288) specified in Section 6.42.
- Speed setting commands are entered by external signals (Al1 terminal (option): 0~±10Vdc (±5Vdc)).
- Speed setting commands are entered by external signals (Al2 terminal: 0~10Vdc or 4(0)~20mAdc) (optional).
- ☐: Up/Down frequency

 Speed commands are entered by means of Up/Down frequency signals from the terminal board. ⇒ Refer to Section 7.2.
- 1 1: RP pulse input Speed commands are entered by means of RP pulses (optional).
- 12: High-speed pulse input Speed commands are entered by means of high-speed pulses (optional).

Note 1: For options (unsupported)

The functions assigned to the following control input terminals (contact input: \Rightarrow Refer to Section 7.2) are always activated regardless of the settings of the command mode selection $\mathcal{L}\Pi\Pi d$ and frequency setting mode selection 1.6 $\Pi\Pi d$

- · Reset terminal (default setting: RES, valid only for tripping)
- · Standby terminal (assigned to ST by default)
- · Emergency stop terminal

To make changes in the command mode selection $\mathcal{L} \Pi \mathcal{G} d$ and the frequency setting mode selection 1 $\mathcal{F} \Pi \mathcal{G} d$ first stop the inverter temporarily.

No change can be made to them if the inverter is in operation.

■ Preset speed operation

[[[]]]: Set this parameter at [] (terminal board).


F [] [] d: Any setting is valid.


1) Setting the run, stop and operation frequencies with the operation panel

Title	Function	Example of setting
Euga	Command mode selection	! (Operation panel input)
FNOd	Frequency setting mode selection 1	식 (Operation panel input)

Run/stop :Press the RUN and STOP keys on the operation panel

To switch between forward run and reverse run, use the forward/reverse run selection $\mathcal{F}_{\mathcal{F}}$.





To save the frequency, press the ENTER key. Then, \mathcal{F} \mathcal{E} and the set frequency are displayed alternately for a while.

2) Setting the run and stop frequencies (forward run, reverse run and coast stop) by means of external signals and setting the operation frequency with the operation panel


Title	Function	Example of setting
CUOA	Command mode selection	☐ (Terminal input)
FNOd	Frequency setting mode selection 1	식 (Operation panel input)

Run/stop: ON/OFF of terminals F-CC/R-CC (Standby: connection of terminals ST and CC)

Speed command: Set the frequency, using


the keys on the operation panel.

«Example of a connection diagram: SW1 set to sink logic»




- The inverter is factoryconfigured so that, if F and R are turned on at the same time, the inverter will stop operation. If necessary, the direction of rotation can be reversed by changing parameter settings.
 - ⇒ Refer to Section 6.2.1.
 - For the frequency, press the ENTER key. Then, F and the set frequency are displayed alternately for a while.
- 3) Setting the run and stop frequencies (forward run, reverse run and deceleration stop) with the operation panel and setting the operation frequency by means of external signals

Title	Function	Example of setting
cnoa	Command mode selection	! (Operation panel input)
FNOd	Frequency setting mode selection 1	!(VI/II (voltage/current input)) ¿ (RR/S4 (potentiometer/ voltage input)) ∃ (RX (voltage input))



- (0~+5Vdc) or 4(0)~20mAdc
- (2) RR/S4 terminal: Potentiometer 0~+10Vdc (0~+5Vdc)
- (3) RX terminal: 0~±10Vdc (0~±5Vdc)



- * Other speed setting
- 5:2-wire RS485 input
- 5:4-wire RS485 input enabled
- 7: Communication option input enabled *
- 8: Optional AI1 (differential current input) *
- 9: Optional AI2 (voltage/current input) *
- ##: Up/Down frequency
- 11: Up/Down frequenc
- ! I: RP pulse input *! 2: High-speed pulse input *
- 13: -
- *Commands marked with * are optional. Refer to Instruction Manual of options described in Section 10.


4) Setting the run, stop and operation frequencies (forward run, reverse run and coast stop) by means of external signals (default setting)

Title	Function	Example of setting
cnoa	Command mode selection	☐:(Terminal input)
FNOd	Frequency setting mode selection 1	!(VI/II (voltage/current input)) ¿(RR/S4 (potentiometer/voltage input)) ₃(RX (voltage input))

Run/stop: ON/OFF of terminals F-CC/R-CC
Speed command: External signal input
(1) VI/II terminal: 0~+10Vdc
(0~+5Vdc) or
4(0)~20mAdc
(2) RR/S4 terminal: Potentiometer

(3) RX terminal: 0~±10Vdc (0~±5Vdc)

«Example of a connection diagram: SW1 set to sink logic»



The inverter is factory-configured so that, if F and R are turned on at the same time, the inverter will stop operation. If necessary, the direction of rotation can be reversed by changing parameter settings.

 □ Refer to Section 6.2.1.

0~+10Vdc (0~+5Vdc)

- * Other speed setting
 - 5: 2-wire RS485 input
 - 5: 4-wire RS485 input enabled
- 7: Communication option input enabled *
- 8: Optional Al1 (Differential current input) *
- 9: Optional Al2 (voltage/current input) *
- ##: Up/Down frequency
- ! I: RP pulse input *
 ! 2: High-speed pulse input *
- 13: -
- * Commands marked with * are optional. Refer to Instruction Manual of options described in Section 10.

5.6 Selecting control mode

PE: V/f control mode selection

Function

With "VF-AS1," the V/f controls shown below can be selected.

- 0: Constant torque characteristics
- 1: Voltage decrease curve
- 2: Automatic torque boost (*1)
- 3: Sensorless vector control 1 (*1)
- 4: Sensorless vector control 2
- 5: V/f 5-point setting
- 6: PM control (*2)
- 7: PG feedback control (*3)
- 8: PG feedback vector control (*3)
 - (*1) "Automatic control" parameter automatically sets this parameter and auto-tuning 1 at a time.
 - (2) Use a dedicated motor with permanent magnets.
 - (3) A PG feedback device (optional) is needed for this control.

[Parameter setting] Title Function Adjustment range Default setting : Constant torque characteristics 1: Voltage decrease curve ₽: Automatic torque boost ₹: Sensorless vector control 1 PE П V/f control mode selection 4: Sensorless vector control 2 5: V/f 5-point setting F: PM control 7: PG feedback control 8: PG feedback vector control

⚠ Caution




• When operating the inverter with PE set to E, E, E, E, E, be sure to set the motor constant parameter correctly. Failure to do this may cause the inverter not to control the motor properly, and thus cause the motor not to deliver the desired performance. For more information, see the explanation of each E setting in the following sections.

1) Constant torque characteristics (Normal way of use)

Setting of V/f control mode selection $P = \mathbb{I}$ (Constant torque characteristics)

This is applied to loads with equipment like conveyors and cranes that require the same torque at low speeds as at rated speeds.




^{*} To increase the torque further, increase the setting value of the manual torque boost parameter u b.

 $[\]Rightarrow$ For more details, refer to Section 5.7.

2) Decreasing output voltage

Setting of V/f control mode selection P = 1 (Voltage decrease curve)


This is appropriate for load characteristics of such things as fans, pumps and blowers in which the torque in relation to load rotation speed is proportional to its square.



3) Increasing starting torque

Setting of V/f control mode selection P = 2 (Automatic torque boost)

Detects load current in all speed ranges and automatically adjusts voltage output (torque boost) from inverter. This gives steady torque for stable runs.



Note: This control system can oscillate and destabilize runs depending on the load. If that should happen, set V/f control mode selection $P \not\models t$ to \mathcal{G} (Constant torque characteristics) and increase torque manually.

Motor constant must be set.

The motor constant can be set in any of the following two ways:

1) Automatic setting

Enter the following information that is indicated on the motor nameplate, and then execute the auto-tuning 1 command (Set F 4 0 0 to 4, and then reset F 4 0 0 to 2.).

<Information indicated on motor nameplate>

 $_{\it U}$ L (Base frequency), $_{\it U}$ L $_{\it U}$ (Base frequency voltage), F 4 $_{\it U}$ 5 (Motor rated capacity), F 4 $_{\it U}$ 5 (Motor rated current), F 4 $_{\it U}$ 7 (Motor rated rotational speed)

⇒ Refer to 6.22 selection 2.

2) Manual setting

Set each motor constant manually.

⇒ Refer to 6.22 selection 3.

Vector control-increasing starting torque and achieving high-precision operation.

Setting of V/f control mode selection $PL = \overline{1}$, 4 (Sensorless vector control 1, 2)

Using sensorless vector control with a Toshiba standard motor will provide the highest torque at the lowest speed ranges. The effects obtained through the use of sensorless vector control are described below.

- (1) Provides large starting torque.
- (2) Effective when stable operation is required to move smoothly up from the lowest speeds.
- (3) Effective in elimination of load fluctuations caused by motor slippage.
- (4) Effective in producing high motor torque at low speed.

Set $P \not = 0$ (sensorless vector control 1) to operate multiple motors of the same type in parallel or to operate a motor with a two or more notches lower rating.

To perform torque control, set $P \not\in U$ to U (sensorless vector control 2), which is designed to perform operation control with higher accuracy. In that case, however, the inverter should be used only for operating a single motor with an equal or one notch lower rating.

Motor constant must be set.

The motor constant can be set in any of the following two ways:

1) Automatic setting

Enter the following information that is indicated on the motor nameplate, and then execute the auto-tuning 1 command (Set $F \not = 0$ to $F \not = 0$, and then reset $F \not = 0$ to $F \not = 0$.

<Information indicated on motor nameplate>

 $_{\it UL}$ (Base frequency), $_{\it UL}$ $_{\it U}$ (Base frequency voltage), $_{\it F}$ $_{\it UU}$ 5 (Motor rated capacity), $_{\it F}$ $_{\it UU}$ 7 (Motor rated rotational speed)

- ⇒ Refer to 6.22 selection 2.
- 2) Manual setting

Set each motor constant manually.

⇒ Refer to 6.22 selection 3.

5) Setting of V/f characteristic arbitrarily


Setting of V/f control mode selection P = 5 (V/f 5-point setting)

In this mode, the base frequency and the base frequency voltage for the V/f control need to be set to operate the motor while switching a maximum of 5 different V/f characteristics.

[Parameter setting]


Title	Function	Adjustment range	Default setting
F 190	V/f 5-point setting VF1 frequency	0.0~F H Hz	0.0
F 19 1	V/f 5-point setting VF1 voltage	0.0~ 100 % *	0.0
F 192	V/f 5-point setting VF2 frequency	0.0~F H Hz	0.0
F 193	V/f 5-point setting VF2 voltage	0.0~ 100 % *	0.0
F 194	V/f 5-point setting VF3 frequency	0.0~F H Hz	0.0
F 195	V/f 5-point setting VF3 voltage	0.0~ 100 % *	0.0
F 196	V/f 5-point setting VF4 frequency	0.0~F H Hz	0.0
F 197	V/f 5-point setting VF4 voltage	0.0~ 100 % *	0.0
F 198	V/f 5-point setting VF5 frequency	0.0~F H Hz	0.0
F 199	V/f 5-point setting VF5 voltage	0.0~100% *	0.0

^{*100%} adjustment value (200V class: 200V, 400V class: 400V)



Note 1: Restrict the amount of torque to boost (u b) to 3% or so. Boosting the torque too much may impair the linearity between points.

Note 2: If the V/f 5-point is set within the diagonally shaded area in the figure below, the V/f 5-point is placed automatically on the boundary line (heavy line in the figure).



6) Operating a permanent magnet motor

Setting of V/f control mode selection P = E (PM control)

Permanent magnet motors (PM motors) that are light, small in size and highly efficient, as compared to induction motors, can be operated in sensorless operation mode. Note that this feature can be used only for specific motors. For more information, contact your supplier.

7) Operating the motor at periodic speeds by means of a motor speed sensor

Setting for V/f control mode selection P = 7 (PG feedback contro)

Set $P \not\models$ to \exists to operate the motor at periodic speeds.

A PG feedback device (optional) is needed. In addition, a motor with a speed sensor (encoder) should be used. Use this setting when operating a motor two or more ranks lower in capacity than the inverter at periodic speeds. Note that the accuracy obtained by $P \not = 7$ is lower than that obtained by setting $P \not = 8$. Also, $P \not = 8$ should be set to 8 to perform torque control. $P \not = 8$ cannot be set to 8 in such a case.

Output torque decreases considerably in regenerative low speed operation (motor slip frequency or less). Set $P \not \in \mathcal{B}$ if regenerative low speed torque is necessary.

Motor constant must be set.

The motor constant can be set in any of the following two ways:

1) Automatic setting

Enter the following information that is indicated on the motor nameplate, and then execute the auto-tuning 1 command (Set $F \lor UU$ to \lor , and then reset $F \lor UU$ to \lor .).

uL (Base frequency), uLu (Base frequency voltage), F 4 ⊕ 5 (Motor rated capacity), F 4 ⊕ 6 (Motor rated current), F 4 ⊕ 7 (Motor rated rotational speed) ⇒ Refer to 6.22 selection 2.

2) Manual setting

Set each motor constant manually. \Rightarrow Refer to 6.22 selection 3.

Performing speed control/torque control with high accuracy using the motor speed sensor

Setting for V/f control mode selection P = B (PG feedback vector control)

The torque produced by the motor is controlled by means of specified torque command signals. The rotational speed of the motor depends on the relation between the load torque and the torque produced by the motor. A PG feedback device (optional) is needed. In addition, a motor with a speed sensor (encoder) should be used. Set $P \not E$ to $\mathcal B$ (PG feedback vector control) to perform speed/torque control with high accuracy.

Motor constant must be set.

The motor constant can be set in any of the following two ways:

- 1) Automatic setting
 - Enter the following information that is indicated on the motor nameplate, and then execute the auto-tuning 1 command (Set $F \not= UU$ to V, and then reset $F \not= UU$ to Z.).
 - <Information indicated on motor nameplate>
 - ս է (Base frequency), ս է ս (Base frequency voltage), F Կ ជ 5 (Motor rated capacity), F Կ ជ 5 (Motor rated current), F Կ ជ 7 (Motor rated rotational speed)
 - ⇒ Refer to 6.22 selection 2.
- 2) Manual setting
 - Set each motor constant manually.
 - ⇒ Refer to 6.22 selection 3.

9) Precautions on automatic torque boost mode or vector control


- 1) When operating a motor in automatic torque boost mode or vector control mode (P = 2, 3, 4, 7 or B), enter each motor constant indicated on the nameplate ($_{U} L$ (base frequency), $_{U} L_{U}$ (base-frequency voltage), F Y @ S (rated capacity of motor), F Y @ S (rated current of motor) and F Y @ S (rated number of revolutions of motor)), read the precautions on auto-tuning 1 on section 6.22 (1), and then set F Y @ B to E Y W W (auto-tuning). If the cable length is in excess of 30m, be sure to perform the auto-tuning (F Y W W W W) mentioned above, even when using a standard motor recommended by Toshiba.
- 2) The sensorless vector control exerts its characteristics effectively in frequency areas below the base frequency (u L). The same characteristics will not be obtained in areas above the base frequency.
- 3) When setting $P \not\in V$ to $V \cap V$, use the inverter along with a general-purpose motor with an equal or one notch lower rating.
- 4) Use a motor that has 2 to 16P.
- 5) Always operate the motor in single operation (one inverter to one motor). (Except for; P = 3) Sensorless vector control cannot be used when one inverter is operated with more than one motor.
- 6) The torque produced by the motor decreases more or less around the rated frequency because of a voltage drop cause motor-generated torque in the vicinity of rated frequency to be somewhat lower.
- 7) Connecting a reactor or surge voltage suppression filter between the inverter and the motor may reduce motor-generated torque. Setting auto-tuning 1 may also cause a trip (£ £ n, £ £ n l-3) rendering sensorless vector control unusable. In the event of a trip, perform auto-tuning with the inverter connected directly to the motor, or enter the motor constant calculated from the motor test results.
- 8) Connect speed sensor for vector control with sensor to the motor. Connecting via gear, etc. causes motor's oscillating or inverter's trip by lack of rigidity.
- 9) If running under not connect the motor, please set to P \(\mu = \mathbb{G} \) temporarily. There is a possibility not to operate normally when running at setting Pt=2,3,4,7,8 under not connect the motor.

5.7 Manual torque boost-increasing torque boost at low speeds

ש ה : Manual torque boost 1

Function

If torque is inadequate at low speeds, increase torque by raising the torque boost rate with this parameter.



[Parameter setting]

Title	Function	Adjustment range	Default setting
uЬ	Manual torque boost 1	0.0~30.0%	According to model ⇒ Refer to page K-46.

This parameter is valid when P
otin G (Constant torque characteristics), I (square reduction torque), S (V/f 5-point setting). Note: The optimum value is programmed for each inverter capacity. Boosting torque excessively may cause the inverter to trip because of an overcurrent. If operation is repeated with torque boosted excessively, electronic devices in the main circuit may be damaged, so if high starting torque is needed, it is recommendable to use vector control.

⇒ Refer to 5.6 selection 3) and 4).

If necessary, set the amount of torque to be boosted, as a guide, within +2% of the factory default setting.

5.8 Base frequency


: Base frequency 1

ים בע : Base frequency voltage 1

Function

Sets the base frequency and the base frequency voltage in conformance with load specifications or the motor's rated frequency.

Note: This is an important parameter that determines the constant torque control area.



[Parameter setting]

Title	Function	Adjustment range	Default setting
υL	Base frequency 1	25.0~500.0 Hz	Inverter with a model number ending with -WN, HN: 5 0.0 -WP: 5 0.0
uLu	Base frequency voltage 1	200V class: 5 0~3 3 0 V 400V class: 5 0~5 6 0 V	200V models: 230 400V models: Inverter with a model number ending with -WN, HN: 450 -WP: 400


Note: The output frequency is limited to a frequency 10.5 times as high as the base frequency ($u \downarrow l$). Even if the maximum frequency (FH) or the upper limit frequency (FH) is set above this frequency, this limitation is imposed on the output frequency.

5.9 Maximum frequency

F H : Maximum frequency

Function

- 1) Programs the range of frequencies output by the inverter (maximum output values).
- 2) This frequency is used as the reference for acceleration/deceleration time.



 This function determines the maximum value in line with the ratings of the motor and load.
 Maximum frequency cannot be adjusted during operation. To

adjust, first stop the inverter.

Frequency setting signal [%]

If FH is increased, adjust the upper limit frequency UL as necessary.

[Parameter setting]

Title	Function	Adjustment range	Default setting		
FH	Maximum frequency	30.0~500.0 Hz	8 0.0		

Note: The output frequency is limited to a frequency 10.5 times as high as the base frequency (uL). Even if the maximum frequency (FH) or the upper limit frequency (UL) is set above this frequency, this limitation is imposed on the output frequency.


100%

5.10 Upper limit and lower limit frequencies


: Upper limit frequency : Lower limit frequency

• Function

Programs the lower limit frequency that determines the lower limit of the output frequency and the upper limit frequency that determines the upper limit of that frequency.



Frequencies that go higher than !!! will not be output.



The output frequency cannot be set at less than ∠ ∠.

[Parameter setting]

į. a.aoto	[· dramotor cottang]									
Title	Function	Adjustment range	Default setting							
UL	Upper limit frequency	0.0~F H Hz	Inverter with a model number ending with -WN, HN: 5 C.C -WP: 5 C.C							
LL	Lower limit frequency	0.0~UL Hz	0.0							

Note: The output frequency is limited to a frequency 10.5 times as high as the base frequency ($_{\it U}$ $_{\it L}$). Even if the maximum frequency ($_{\it F}$ $_{\it H}$) or the upper limit frequency ($_{\it U}$ $_{\it L}$) is set above this frequency, this limitation is imposed on the output frequency.

5.11 Setting frequency command characteristics

F201~F203, R1F2 : VI/II point setting
F210~F212, RuF2 : RR/S4 point setting

F 2 15 ~ F 2 19 : RX point setting

F222 ~ F225 : F228 ~ F231 :

It sets up, when using the optional circuit board.

FB 11 - FB 14 : Point 1, 2 setting/ frequency

⇒ For details, refer to Section 7.3.

Function

These parameters adjust the output frequency according to the externally applied analog signal (0~10Vdc voltage, 4(0)~20mAdc current) and the entered command for setting an external contact frequency.

5.12 Preset speed operation (speeds in 15 steps)

| Sr 1 | Sr 7 | : Preset speed operation frequencies 1~7 | F287 | F294 | : Preset speed operation frequencies 8~15 | F560 | F575 | : Preset speed operation frequencies 1~15 operation mode

A maximum of 15 speed steps can be selected just by switching an external contact signal. Preset speed frequencies can be programmed anywhere from the lower limit frequency !!! to the upper limit frequency !!!

[Setting methods]

1) Run/stop

Run and stop control is experienced by the operation panel (Default setting).

Title	Function	Adjustment range	Example of setting
cuoa	Command mode selection	### Terminal input enabled ###: Operation panel input enabled (including LED/LCD option input) ####################################	0

Note 1: If speed commands (analog signal or digital input) are switched in line with preset speed operations, select the terminal board using the frequency setting mode selection 1 F $\Pi \Omega d$.

2) Preset speed frequency setting

Set the speed (frequency) of the number of steps necessary.

Setting from speed 1 to speed 7

Title	Function	Adjustment range	Default setting		
5r 1~5r 7	Preset speed operation frequencies 1~7	LL~UL	0.0		

Setting from speed 8 to speed 15

Title	Function	Adjustment range	Default setting		
F287~F294	Preset speed operation frequencies 8~15	LL~UL	0.0		

[⇒] Refer to 3) or Section 5.5.

Example of preset speed contact input signal: SW1 set to sink logic


O: ON -: OFF (Speed commands other than preset speed commands are valid when all are OFF)

CC	Terminal							Pres	set sp	eed						
	Terminai	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
S1	S1-CC	0	_	0	-	0	_	0	-	0	_	0	-	0	_	0
S2	S2-CC	_	0	0	_	_	0	0	_	_	0	0	_	_	0	0
S3	S3-CC	-	-	-	0	0	0	0	-	-	-	-	0	0	0	0
RR/S4	RR/S4-CC	-	-	-	-	-	-	-	0	0	0	0	0	0	0	0

Terminal functions are as follows. (Default setting)

The RR/S4 terminal is set by default as an analog voltage input terminal. To use it as an input terminal for preset speed operation, turn the SW3 switch to the S4 position.

[An example of the connection of terminals] (SW1 set to sink logic)




3) Using other speed commands with preset speed command

When no preset speed command is issued, the inverter accepts an input command from the operation panel or another analog input device.

Preset speed command	Other speed commands								
		nals from the operation nel	Analog signal input command (VI/II, RR/S4, RX, Al1 and Al2)						
command	Entered	Not entered	Entered	Not entered					
Entered	Preset speed command valid	Preset speed command valid	Preset speed command valid	Preset speed command valid					
Not painted	Operation panel command valid	-	Analog signal valid	-					

The preset speed command is always given priority when other speed commands are input at the same time. To use the RR/S4 terminal as an analog input terminal, turn the SW4 switch to the RR position. Note that this makes it impossible to use the function assigned to S4.

Below is an example of 7-step speed operation.



Example of 7-step speed operation

4) Setting the operation mode

An operation mode can be selected for each preset speed.

Operation mode setting

Title	Function	Adjustment range	Example of setting
F 5 6 0	Preset speed operation mode selection	 G: Preset speed operation with no mode I: Preset speed operation with mode 	0

: Preset speed operation with no mode Only frequency commands are governed by the preset speed command (1 to 15) entered.

If you selected "enabled" ($F \ 5 \ B \ B = 1$), the motor runs operation mode setting directions as below without following terminal F, R.

Operation mode setting

Title	Function	Adjustment range	Example of setting
F56 1-F575	Preset speed operation frequency 1~15 operation mode	### Groward run ### I: Reverse run ### Acceleration/deceleration switching signal 1 ### Swift switching signal 1 #### Signal 2 #### Swift switching signal 2 #### Signal 2 #### Signal 1 #### Signal 1 #### Signal 1 #### Signal 1 ##### Signal 1 ####################################	a

For the settings marked with +, more than one function can be selected at the same time by entering the sum of the numbers of the desired functions.

Ex.) (+ 1) + (+2) = 3

By entering "3", you can activate the reverse run function and the acceleration/deceleration switching signal 1 function at the same time.

5.13 Selecting forward and reverse runs (operation panel only)

Fr

: Forward/reverse run selection

Function

Program the direction of rotation of the motor when the running and stopping are made using the RUN key and STOP key on the operation panel.

Valid when $[\Pi \Pi G]$ (command mode selection) = I (operation panel input).

[Parameter setting]

Title	Function Adjustment range		Default setting
Fr	Forward/reverse run selection	☐: Forward run I: Reverse run Z: Forward run (F/R switching possible) 3: Reverse run (F/R switching possible)	a

Check the direction of rotation on the status monitor.

 $F_{\Gamma} - F$: Forward run $F_{\Gamma} - F$: Reverse run

⇒ For monitoring, refer to Section 8.1.

When the F and R terminals are used for switching between forward run and stop from the terminal board, the F r forward/reverse run selection parameter is rendered invalid.

Short across the F-CC terminals: forward run Short across the R-CC terminals: reverse run

€elf F and CC, as well as R and CC are connected at the same time: Stop (Default setting)

Use the parameter F + 25 to select between reverse run and stop in this case.

⇒ For more details, refer to Section 6.2.1.

This function is valid only when [] [] d is set at ! (Operation panel input enabled).

To switch between forward run and reverse run from the control panel with parameter F_r set to Z or Z, perform these steps: to switch to forward run, press the key while holding the ENT key down, or to switch to reverse run, press the key while holding ENT key down.

5.14 Setting the electronic thermal

EHr: : Motor electronic thermal protection level 1

: Electronic thermal protection characteristic selection

F 5 0 5 : OL reduction starting frequency

F 5 0 7 : Motor 150%-overload time limit

F 6 3 1 : Temperature detection

Function

This parameter allows selection of the appropriate electronic thermal protection characteristics according to the particular rating and characteristics of the motor.

[Parameter setting]

Title	Function		Α	djustment range		Default setting
Ł H r	Motor electronic thermal protection level 1	10~10	10~100%			100
	Electronic thermal protection characteristic selection	Default setting	Motor type	Overload protection	Overload stall	
		0	Standard Motor	O (protect)	× (not stall)	a
		- 1		O (protect)	O (stall)	
OLA		2		× (not protect)	× (not stall)	
ULII		3		× (not protect)	O (stall)	
		4	VF Motor (special motor)	O (protect)	× (not stall)	
	3616611011	5		O (protect)	O (stall)	
		5		× (not protect)	× (not stall)	
		7		× (not protect)	O (stall)	

1) Setting the motor electronic thermal protection level 1 LHr and electronic thermal protection characteristics selection [][]

The electronic thermal protection characteristics selection $\mathcal{GL}\mathcal{R}$ is used to enable or disable the motor overload trip function (\mathcal{GLZ}) and the overload stall function.

The motor overload trip function (\mathcal{GL} 2) needs to be selected with the parameter $\mathcal{GL}\mathcal{R}$, while the inverter overload trip function (\mathcal{GL} 1) is always activated.

Explanation of terms:

Overload stall (Soft stall)

The function of automatically lowering the output frequency before the motor overload trip function \mathcal{BLZ} is activated when the inverter detects that an excessive load is applied to the motor. (Lowers maximum about 48Hz when basic frequency is 60Hz.) This function enables the inverter to output a frequency commensurate with the load current so that the motor can keep running without tripping. This function is useful for such loads as fans, pump, and blowers, which have the square reduction torque characteristic that the current passed decreases as the rotating speed falls.

Note: Do not use this overload stall function for loads with a constant torque characteristic (e.g., a belt conveyer to which a constant load current is always passed regardless of their speed).

[Using standard motors (other than motors intended for use with inverters)]


When a motor is used in the lower frequency range than the rated frequency, that will decrease the cooling effects for the motor. This speeds up the start of overload detection operations when a standard motor is used in order to prevent overheating.

■ Setting of electronic thermal protection characteristics selection 🛛 L 🞵

Default setting	Overload protection	Overload stall	
0	O (protect)	× (not stall)	
1	O (protect)	O (stall)	
2	× (not protect)	× (not stall)	
3	× (not protect)	O (stall)	

If the capacity of the motor is smaller than the capacity of the inverter, or the rated current of the motor is smaller than the rated current of the inverter, adjust the electronic thermal protection level 1 **E Hr** so that it fits the motor's rated current.

Output current reduction factor [%]/[A]



Note: The motor overload starting level is fixed at 30Hz. If necessary, set $GL \cap V$ to V, V, V or V. (See the following section.) Even if the inverter is used with a Toshiba standard motor, the load may need to be reduced at frequencies of 30Hz and below in some cases. In such cases, set $GL \cap V$ to V, V, V, or V and set the $GL \cap V$ reduction starting frequency (V V V V according to the motor.

[Example of setting: When the VFAS1-2007PL is running with a 0.4kW motor having 2A rated current]

Key operated	LED display	Operation
	0.0	Displays the operation frequency. (Perform during operation stopped.) (When standard monitor display selection F 7 $I \vec{B} = \vec{B}$ [Output frequency])
MODE	ЯИН	The first basic parameter "History function (用じH)" is displayed.
\Diamond	EHr	Press either the Δ key or the $ abla$ key to change the parameter to $ abla$ $ abla$ $ abla$.
ENT	100	Press the ENTER key to display the parameter setting (Default setting: 100%).
\Diamond	40	Press the \triangle key to change the parameter to $\mbox{4 } \mbox{\ensuremath{\mathcal{G}}}$ (= motor rated current/inverter output rated current x 100 = 2.0/5.0 x 100)
ENT	40⇔£#r	Press the ENTER key to save the changed parameter. £ H r and the parameter are displayed alternately.

[Using a VF motor (motor for use with inverter)]

Default setting	Overload protection	Overload stall
Ч	O (protect)	× (not stall)
5	O (protect)	O (stall)
Б	× (not protect)	× (not stall)
7	× (not protect)	O (stall)

A VF motor (a motor for use with an inverter) can be used in lower frequency ranges than the standard motor, but if that frequency is extremely low, the effects of cooling on the motor will deteriorate.

In such a case, set the OL reduction start frequency parameter $F \in \mathcal{G} \subseteq \mathcal{F}$ according to the characteristics of the motor. (Refer to the figure below.)

As a guide, it is advisable to set this parameter around the default value (VF motor 6Hz).

[Parameter setting]


Title	Function	Adjustment range	Default setting
F606	OL reduction starting frequency	0.0~60.0 Hz	6.0

Note: F B B B is enabled when $B L B = 4 \sim 7$.

■ Setting of motor electronic thermal protection level 1

If the capacity of the motor is smaller than the capacity of the inverter, or the rated current of the motor is smaller than the rated current of the inverter, adjust the electronic thermal protection level 1 £ H r so that it fits the motor's rated current.


* If the indications are in percentages[%], then 100% equals the inverter's rated output current [A].



Setting the motor overload starting level

2) Motor 150%-overload time limit F507

The motor 150%-overload time limit parameter *F* & 0 ? is used to set the time elapsed before the motor trips under a load of 150% (overload trip 0 t ?) within a range of 10 to 2400 sec.



Motor overload protection characteristics

[Parameter setting]							
Title	Function	Adjustment range	Default setting				
F607	Motor 150%-overload time limit	10~2 4 0 0 sec.	300				

3) Inverter overload characteristics

Set to protect the inverter unit. Cannot be turned off by parameter setting.

The inverter has two overload detecting functions, which can be switched from one to another using parameter *F B 3 1* (temperature detection).


[Parameter setting]

Title	Function	Adjustment range	Default setting
F53!	Temperature detection	☐:Standard (150%-60 sec.) I: Estimation of temperature	0

If the inverter overload trip function (GL I) is activated frequently, this can be improved by adjusting the stall operation level $F \in G$ I downward or increasing the acceleration time $R \in G$ or deceleration time $I \in G$.

■ F 5 3 !=[] (Standard)


Protection is given uniformly regardless of ambient temperature, as shown by the 150%-60 sec overload curve in the figure below.



Inverter overload protection characteristics

■ F 5 3 != ! (Estimation of temperature)

This parameter adjusts automatically overload protection, predicting the inverter internal temperature rise. (diagonally shaded area in the figure below)



Inverter overload protection characteristics

Note 1: If the load applied to the inverter exceeds 150% of its rated load or the operation frequency is less than 0.1Hz, the inverter may trip (0,1,1 or 0,1,1,2,2,3,4) in a shorter time.

Note 2: The inverter is factory-set so that, if the inverter becomes overloaded, it will automatically reduce the carrier frequency to avoid an overload trip (\$\mathbb{G} \cdot \text{ f or } \mathbb{G} \cdot \text{ f P-BC} \cdot \text{3P}\$). A reduction in carrier frequency causes an increase in noise from the motor, but this does not affect the performance of the inverter. If you do not want the inverter to reduce the carrier frequency automatically, set the parameter \$F \cdot \text{1B=B}\$.

Note 3: Overload detection level is variable by condition of output frequency and carrier frequency.

5.15 Changing the display unit % to A (ampere)/V (volt)

d5PU : Current/voltage unit selection

Function

These parameters are used to change the unit of monitor display.

% ⇔A (ampere)/V (volt)


Current 100% = Inverter's rated current

200V-class voltage 100% = 200Vac

400V-class voltage 100% = 400Vac

■ Example of setting

During the operation of the VFAS1-2037PL (rated current 16.6A) at the rated load (100% load), units are displayed as follows:



[Parameter setting]

Title	Function	Adjustment range	Default setting
d5PU	Current/voltage unit selection	<i>I</i>: %<i>I</i>: % → A (ampere)/V (volt)	0

* The d5PU converts the following parameter settings:

Setting of electronic thermal protection level 1/2/3/4 £ Hr, F ! 7 3, F ! 7 7, F ! 8 !, F 5 ! !

F 6 4 0

DC braking current F 25 1
Stall prevention level F 5.7 1

• V display Voltage monitor display

V/f 5-point setting F 19 1, F 19 3, F 19 5, F 19 7, F 19 9

Note: Base frequency voltage 1~4 (u L u, F 1.7 1, F 1.75, F 1.79) is always displayed in the unit of V.

5.16 Meter setting and adjustment

F S S L : FM terminal meter selection F S B Y : FM output filter

FR : FM terminal meter adjustment RR51 : AM terminal meter F578 : Constant at the time of filtering selection

F 5 8 1 : FM voltage/current output R : AM terminal meter

output of AM output

F683: FM bias adjustment **F686**: AM bias adjustment

Function

Inverter's operation data is sent to the FM terminal (AM terminal) as analog voltage signals or analog current signals. To display inverter's operation data, connect a meter to this terminal. The "FM terminal-connected meter adjustment $F\Pi$ " (AM terminal-connected meter adjustment $R\Pi$) parameter is used to calibrate the meter.


Note 1: The signal output from the FM and AM terminal is an analog voltage signal or an analog current signal. (positive (+) side output. In the case of output the signed data, the signal is added offset. Offset level is able to adjust by F & B 3 and F & B 5. If monitoring the output data with positive and negative voltage, you need to use "expansion I/O card2 option".

Note 2: To the FM terminal, connect either a full-scale 0~1mAdc ammeter or a full-scale 0~7.5Vdc (or 10Vdc) voltmeter, if necessary. The FM terminal can also be used as a 0(4)~20mAdc output terminal.

To the AM terminal, connect either a full-scale 0~1mAdc ammeter or a full-scale 0~7.5Vdc (or 10Vdc) voltmeter, if necessary.

Connect meters as shown below.

<Connection to terminal FM>



A frequency meter QS60T is optionally available.

■ Output modes of the FM terminal

When used with a 0~1mAdc ammeter (Default setting)

0-10V FM 0-20mA 0-1mA

When the optional frequency meter QS60T is connected, this mode is selected.


0-10V FM 0-20mA 0-1mA SW2 F 6 8 !=0

When used with a DC0~10V voltmeter

When used with a 0(4)~20mAdc



<Connection to terminal AM >



It is recommendable to use an ammeter with a current rating 1.5 or more times as high as the output current rating of the inverter. [Terminal FM-related parameters]

Title	Function	Adjustment range	Adjustment level	Default setting
FNSL	FM terminal meter selection	## Coutput frequency ## Frequency command value ## Coutput current ## Coutput voltage ## Coutput voltage ## Compensated frequency *2 ## Speed feedback (real-time value) ## Speed feedback (real-time value) ## Speed feedback (real-time value) ## Speed feedback (1 second filter) ## Torque ## Torque ## Torque current ## Filter feedback value ## Motor overload factor (OL2 data) ## Motor overload factor (OL1 data) ## Regenerative braking resistance overload factor (% ED) ## Input power ## Output power ## Output power ## Output power ## Output power ## Soutput power ## Se RX input ## Se RM output ## Filter output 1 ## Filter output 1 ## Communication data output ## Filter output 3 ## Cumulative input power ## Soumulative input power ## Soumulative output power ## Signed output frequency ## Signed output frequency ## Signed speed feedback (real-time value) ## Signed speed feedback (real-time value) ## Signed speed feedback (real-time value) ## Signed orque current ## Signed PID feedback value ## Signed speed feedback (real-time value) ## Signed proque current #	(a) (a) (b) (c) (a) (a) (d) (b) (b) (a) (a) (a) (a) (a) (b) (b) (a) (a) (a) (a) (b) (a) (a) (a) (a) (b) (a) (a) (a) (a) (a) (a) (a) (a) (a) (a	0
FΠ	FM terminal meter adjustment	-	\"/	*3
F678	Constant at the time of filtering *4	4 msec, 8 msec~ 100 msec		64
F68 I	FM voltage/current output switching	#:Voltage output (0~10V), #:Current output (0~20mA)		0
F682	FM output gradient characteristic	 ☐:Negative gradient (downward-sloping), f:Positive gradient (upward-sloping)		1
F683	FM bias adjustment	- 10.0~ 100.0 %		0.0
F 6 8 4	FM output filter	### Comparison of the comparis		0

^{*1:} Monitor adjustment level selected.

^{*2: &}quot;Compensated frequency" refers to the frequency actually sent from an inverter to the motor connected.

^{*3:} Default setting value is adjusted for connection of frequency meters "QS60T". (Between FM and CCA: Approx. 3.6V)

^{*4:} The output current, input voltage, output voltage, compensated frequency, speed feedback (real-time value) torque, torque current and exciting current output (FM/AM/pulse and monitor output) can be filtered.

[Terminal AM-related parameters]

Title	Function	Adjustment range	Default setting
AN5L	AM terminal meter selection	Same as F 7.5 L (2.9:AM output disabled)	2
RN	AM terminal meter adjustment	=	*1
F 685	AM output gradient characteristic	☐:Negative gradient (downward-sloping), 1:Positive gradient (upward-sloping)	1
F 585	AM bias adjustment	- 10.0~ 100.0 %	0.0

- *1: Default setting value is adjusted for connection of frequency meters "QS60T". (Between AM and CCA: Approx. 3.6V)
- Resolution

Both the terminals FM and AM have a maximum resolution of 1/1024.

With the default settings, FM terminal outputs about 4.7V (external impedance is ∞) or about 1mA (external impedance is 0Ω), when running frequency is 80Hz. AM terminal outputs about 4.7V or about 1mA, when the output current reading on the operation panel is 185%.

[Example of the calibration of the frequency meter connected to the terminal FM]

* Use the meter's adjustment screw to pre-adjust zero-point.

Key operated	LED display	Operation		
-	6 O.O	Displays the operation frequency. (When standard monitor display selection F 7 10=0 [Output frequency])		
MODE	ЯШН	The first basic parameter "History function (###)" is displayed.		
	FΠ	Press either the \triangle or ∇ key to select " $F \Pi$."		
ENT	6 O.O	Press the ENTER key to display the operation frequency.		
$\wedge \vee$	60.0	Press either the △ key or the ▽ key to adjust the meter. The meter reading will change at this time but be careful because there will be no change in the inverter's digital LED (monitor) indication. [Hint] It's easier to make the adjustment if you push and hold for several seconds.		
ENT	60.0⇔F∏	The adjustment is complete. $F\Pi$ and the frequency are displayed alternately.		
MODE	6 O.O	The display returns to its original indications. (When standard monitor display selection F 7 ! ### [Output frequency])		

For meter connection, the VF-AS1 inverter has two output terminals; FM and AM, which can be used simultaneously.

■ Meter adjustment 1 when the inverter is at rest (adjustment by setting F \(\Omega 5 L\) (R \(\Omega 5 L\)) to \(\overline{3} \)\(\Overline{3} : \) Fixed output 1, \(\overline{3} \overline{2} : \) Fixed output 2, \(\overline{3} \overline{3} : \) Fixed output 3)

If it is difficult to calibrate a meter because of large fluctuations of its reading, you may put the inverter out of operation to make its calibration easier.

It is possible to adjust the meter for the data item selected with the parameter FRSL or RRSL. Adjustment levels (a) through (d) shown in the table on the previous page change according to the settings of fixed outputs 1 through 3, as shown in the table below. Use this table as a reference when calibrating the meter(s).

Values adjusted with fixed outputs are put out from the FM (AM) terminal when values in the table are used for operation. For examples of adjustments, see the next page.

Fixed output 1 comes in handy for adjusting items at adjustment level (a) or (c).

Fixed output 2 comes in handy for adjusting items at adjustment level (b).

Fixed output 3 comes in handy for adjusting items at adjustment level (d).

	Meter adjustment				
A discotor and lasted	Fixed output 1	Fixed output 2	Fixed output 3		
Adjustment level	FN5L(RN5L)=30	FN5L(AN5L)=32	FN5L(RN5L)=33		
(a)	F H *2	54%	40%		
(b)	185%	100%	74%		
(c)	150%	81%	60%		
(d)	250%	135%	100%		


^{*1:} The 100% value of input/output power is the product of $\sqrt{3}$ x200V (400V) x inverter's rated current.

Example: Procedure of	calibrating the r	neter connected to the terminal AM to which "output current" is assigned.]		
Key operated	LED display	Operation		
_	0.0	Displays the operation frequency. (Perform during operation stopped.) (When standard monitor display selection \mathcal{F} 7 $\mathcal{C}=\mathcal{D}$ [Output frequency])		
MODE	ЯШН	The first basic parameter "History function (RUH)" is displayed. Press either the \triangle or ∇ key to select " $R\Pi5L$." Pressing the ENTER key allows the reading of parameter setting.		
	AUST			
ENT	2			
\Diamond	32	Set the parameter at \exists $\not\in$ (fixed output for meter calibration 2) by pressing the \triangle key.		
ENT	32⇔RNS L	Press the ENTER key to save the change. Then, R Π 5 L and the set value are displayed alternately.		
\Diamond	яп	Select the AM terminal meter adjustment RR by pressing the Δ key.		
ENT	100	Press the ENTER key to switch to the data display mode.		
$\otimes \otimes$	100	Press either the △ key or the ▽ key to adjust the meter. Adjust the pointer to the graduation to which you want it to point when the inverter passes a current 100% larger than its rated output current. (The meter reading will change at this time but be careful because there will be no change in the inverter's indication). [Hint] It's easier to make the adjustment if you push and hold for several seconds. Setup Setup, before the needle of meter beings to sway, it will take time.		
ENT	100⇔RN	Press the ENTER key to save the change. Then $R\Pi$ and the set value are displayed alternately.		
\bigcirc	AUST	Select the "AM terminal meter adjustment R Π 5 L " by pressing the ∇ key.		
ENT	32	Pressing the ENTER key allows the reading of parameter setting. Return the parameter setting to 2 (output current display).		
	2			
ENT	ANSL⇔∂	Press the ENTER key to save the change. Then, R \(\Pi \) 5 \(\Lambda \) and the set value are displayed alternately.		
MODE	0.0	Press the MODE key three times to return to the running frequency display mode. (When standard monitor display selection F 7 ! [] = [] [Output frequency])		

^{*2:} When $F \cap SL(R \cap SL) = 15$, $17,23 \sim 29,50 \sim 52,74 \sim 75$, fixed output level is 100%.

■ Gradient bias adjustment of analog monitor output

Here is an example of the adjustment of output from 0-20mA \rightarrow 20-0mA, 4-20mA using the FM terminal.



The analog output inclination can be adjusted using the parameter $F\Pi$.

5.17 PWM carrier frequency

: PWM carrier frequency

F 3 12 : Random mode

F3 15 : Carrier frequency control mode selection

Function

- The sound tone of acoustic noise can be changed by adjusting the PWM carrier frequency. This parameter is
 also effective in preventing the motor from resonating with its load machine or its fan cover.
- 2) In addition, this parameter reduces the electromagnetic noise generated by the inverter. Reduce the carrier frequency to reduce electromagnetic noise. Note: Although the electromagnetic noise level is reduced, the magnetic noise of the motor is increased.
- 3) The random mode reduces motor magnetic noise by changing the pattern of the reduced carrier frequency.
- 4) To set the parameter F 3 15 to 2 or 3 has the effect of suppressing voltage serge to the motor. Reduce the carrier frequency to less than 4kHz if the wiring between the inverter and motor is long (20 to 100m as a guida)
- 5) In case of using the sinusoidal filter, set the parameter F 3 15 to 4 or 5.
 This parameter works at 200V-55kW or more and 400V-90kW or more models.

[Parameter setting]

Title	Function	Adjustment range	Default setting
[F	PWM carrier frequency	1.0~ 15.0 kHz (2.5~8.0 kHz) [Note 1]	According to model ⇒ Refer to page K-46.
F312	Random mode	☐:Disabled, /: Enabled	0
F316	Carrier frequency control mode selection	## Discrease carrier frequency automatically Discrease carrier frequency automatically 2:Not decrease carrier frequency automatically, 400V class supported 3:Decrease carrier frequency automatically, 400V class supported 4:Not decrease carrier frequency automatically, with sinusoidal filter 5:Decrease carrier frequency automatically, with sinusoidal filter	1

Note 1: For 200V-55/75kW models and 400V-90kW to 400V-500kW models, the carrier frequency is between 2.5 and 8.0kHz inclusive.

Note 2: If $\mathcal{L}F$ is set at 2.0kHz or above, it cannot be decreased below 2.0kHz during operation. Changes made to decrease $\mathcal{L}F$ below 2.0kHz take effect when operation is restarted after it is stopped.

Note 3: If \mathcal{F} is 1.9kHz or less, you cannot change the setting at 2.0kHz or more. Changes made to increase \mathcal{F} to 2.0kHz or above take effect immediately.

Note 4: If P & (V/f control mode selection) is set to 2, 3, 4, 7, or 8, the inverter sets a lower limit of 2.0kHz for ξ F.

Note 5: If F 3 15=4 or 5 is set, it automatically becomes V/f control (P \(\xi = 0 \)) mode. Moreover, the lower-limit of the career frequency becomes 4kHz.

Note 6: If you change the carrier frequency, you may need to reduce the inverter's continuous output current.

Refer to Section 1.4.4. "Current reduction curve."

Note 8: For the setting $F \ni 15 = 2$ or \ni to take effect, power needs to be turned off and then turned back on. And this parameter is invalidated for the ratings of 90 kW and over.

Note 9: When setting $F \ni f \not \models f$ to $\not \models f$ or $f \not \models f$, be sure to set $f \not \models f$ at 4.0kHz or less.

Note 10: When setting the carrier frequency (£ F) between 1 and 1.9 kHz, you are recommended to set F 5 C 1 below 130%.

5.18 Trip-less intensification

5.18.1 Auto-restart (Restart during coasting)

: Auto-restart control selection

⚠ Warning



· Do not go near motors and equipment.


Motors and equipment that have stopped temporarily after momentary power failure will restart suddenly after recovery. This could result in unexpected injury.

 Attach warnings about sudden restart after a momentary power failure on inverters, motors and equipment for prevention of accidents in advance.

Function

Auto-restart detect the rotating speed and direction of rotation of the motor during coasting or momentary power failure, to ensure that the motor restarts smoothly (Motor speed search function). This parameter also allows commercial power operation to be switched to inverter operation without stopping the motor. During operation, "r t r y" is displayed.

1) Auto-restart after momentary power failure (Auto-restart function)



U_U 5= 1: This function operates after power has been restored following detection of an undervoltage by the main circuits and control power.


Title	Function	Adjustment range	Default setting	Setting value
U u S	Auto-restart control selection	②:Disabled i:At auto-restart after momentary stop ∂:When turning ST on or off 3: i+∂ 4:At start-up	0	/ or ∃

^{*} If the motor is restarted in retry mode, this function will operate, regardless of the setting of this parameter.

^{*} The function ($U_{\omega} S = I, Z, 3, 4$) is activated when the reset of trip or the power is turned on.

^{*} The function ("" 5= 1,3) is activated when an undervoltage is detected in the main circuit.

2) Restarting motor during coasting (Motor speed search function)



U = 5=2: This function operates after the ST-CC terminal connection has been opened first and then connected
 again.

Title	Function	Adjustment range	Default setting	Setting value
U 5	Auto-restart control selection	♂:Disabled 1:At auto-restart after momentary stop ¿:When turning ST on or off 3: 1 + ¿ 4:At start-up	0	₹ or ∄

^{*} To restart the inverter in operation panel operation mode, press RUN key after a power failure.

Operation and application of the auto-restart function

By using retry function F ∃ □ ∃ together, auto restart function can be actuated at the time of tripping.

Application to a crane or hoist

The crane or hoist may have its load moved downward during the above waiting time from input of the operation starting command to the restart of the motor. To apply the inverter to such machines, therefore, set the auto-restart control mode selection parameter U_{u} 5 to "U" (Disabled). And avoid using the retry function.

- At restart, it takes several seconds. for the inverter to check to see the number of revolutions of the motor. For this reason, the start-up takes more time than usual.
- When the auto restart function is selected, this function is actuated also at time of activation of motor and at the first
 operation after the reset of tripping. The operation will restart after the waiting time passes.
- Use this function when operating a system with one motor connected to one inverter. This function may not operate properly in a system configuration with multiple motors connected to one inverter.

5.18.2 Regenerative power ride-through control/Deceleration stop during power failure/Synchronized acceleration/deceleration

: Regenerative power ride-through control
: Non-stop control time/Deceleration time during power failure
: Synchronized deceleration time
: Synchronized acceleration time
: Synchronized acceleration time
: Under voltage detection level
: Regenerative power ride-through control level

• Function
1) Regenerative power ride-through control: When momentary power failure occurs during operation, this

function makes operation continue using the regeneration energy from a motor.

2) Deceleration stop during power failure: When momentary pow

When momentary power failure occurs during operation, this function stops the motor quickly compulsorily. A forcible stop is carried out in F 3 10 (Deceleration time) using the regeneration energy from the motor.

(Deceleration time varies with control.)

After the forced stop, the inverter remains static until you put off the operation command momentarily.

3) Synchronized acceleration/deceleration:

When the inverter is used with textile machines, this function stops more than one textile machine simultaneously in the event of a momentary power failure and it prevents the breakage of yarns around bobbins at the recovery from the

^{*} When F 3.75 (Number of PG input phases) = 1 (single phase) in PG feedback vector control mode (P \(\mu = 7, \(\mu \)), the inverter may trip (\(\mu = 1 \) 3: speed error) if the direction of rotation of the motor does not agree with.

^{*}The function ("" u 5=3) is activated when ST signal turning on or restart after a momentary power failure.

^{*}The function $(U_{IJ} 5 = 4)$ is activated when starting each time.

[Parameter setting]

Title	Function	Adjustment range	Default setting
Uu E Regenerative power ride-through control selection		### Disabled #Power ride-through Discovery ride-thro	a
F 3 10	Non-stop control time/Deceleration time during power failure	<i>D. 1~3 ≥ 0.0</i> sec.	2.0
F317	Synchronized deceleration time	[]. 1~6 [] [] G sec.	2.0
F3 18	Synchronized acceleration time	0.1~6000 sec.	2.0
F625	Under voltage detection level	5 0~ 7 9 %, ₩ 0: Automatic mode	80
F629	Regenerative power ride-through control level	55~100%	75

Note 1: The power ride-through control time when $U \cup E = I$ depends on the setting of $F \ni IB$, and the deceleration time when $U \cup E = B$ depends on the setting of $F \ni IB$. Also, the deceleration time and the acceleration time when $U \cup E = B$ or $A \mid B \mid B$ and that of $A \mid B \mid B$ are pectively.

Note 2: Even if these functions are used, a motor may coast according to load conditions. In this case, use the auto-restart function along with this parameter function.


Note 3: These functions do not operate at the time of torque control.

Note 4: Jog run function doesn't operate at synchronized acceleration/deceleration.

Note 5: Although the setting of *F* 3 / 1/2 can be written when *U* u *L* is set to *l* (non-stop control), it cannot be written when *U* u *L* is set to *d* (momentary power failure slowdown stop).

Note 6: For the parameter *F* 6 *Z* 9, 100% corresponds to 200V (200V class) or 400V (400V class).


■ An example of setting when !! u [= ! [When power is interrupted]



The time for which the operation of the motor can be continued depends on the machine inertia and load conditions. Before using this function, therefore, perform verification tests. Use with the retry function allows the motor to be restarted automatically without being brought to an abnormal stop.


*1: Note: If power is interrupted during deceleration stop, power ride-through control will not be performed.

[If momentary power failure occurs]




*1: Note: If power is interrupted during deceleration stop, power ride-through control will not be performed.


■ An example of setting when $U_{u} \zeta = \overline{c}$



- Even after the recovery from an input power failure, the motor continues slowing down to a stop. If the voltage in the inverter main circuit falls below a certain level, however, control will be stopped and the motor will coast.
- The deceleration time varies according to the setting of F 3 10. In this case, the deceleration time refers to the time elapsed before a motor running at F H (maximum frequency) comes to a full stop.
- If the voltage in main circuit below $F \in \mathcal{Z} S$ (Under voltage detection level) at Non-stop control during power failure, the motor will coast and inverter display is shown " $S \in \mathcal{QP}$ \mathcal{QS} (displayed alternately)". And then, If recovery from the input power failure, the motor continues coasting.
- An example of setting when "U" [=3] (when the function of receiving synchronized acceleration/deceleration signals is assigned to the input terminal S1)
 - F 1.15 (Input terminal function selection 5 (S1)) = 5 € (Synchronized acceleration/deceleration signal)



- If the parameters F 3 17, F 3 18 are set for same acceleration and deceleration time and if synchronized acceleration/deceleration signals set using the input terminal functions (5 2, 5 3) are used, multiple motors can be stopped at about the same time or speed commands can be issued to them at about the same time.
- If a synchronized acceleration/deceleration signal is impressed, the synchronized deceleration function decreases
 the output frequency to 0Hz to decelerate the motor linearly within the time specified with F 3 17. (The S-pattern
 operation function or the braking sequence cannot be used along with this function.)
 When the motor comes to a full stop, the message "STOP" appears on the display panel.
- If the synchronized acceleration/deceleration signal is canceled during synchronized deceleration, the synchronized acceleration function increases the output frequency to the frequency at the start of synchronized deceleration or to the command frequency, whichever is lower, to accelerate the motor linearly within the time specified with F 3 18.
 (The S-pattern operation function, the braking sequence or the auto-tuning function cannot be used along with this function.)
 - When acceleration is started, the message "STOP" on the display panel disappears.
- If a forward/reverse switching command or a stop command is issued during synchronized acceleration or deceleration, synchronized acceleration or deceleration will be canceled.
- An example of setting when $U_U \subseteq U$ Synchronized deceleration if a synchronized acceleration/deceleration signal is impressed or if a power failure occurs, or synchronized acceleration if the synchronized acceleration/deceleration signal is canceled.



^{*1:}Even with $U_{ij}U_{i$

5.19 Dynamic (regenerative) braking - For abrupt motor stop

Pb : Dynamic braking selection

Pbr : Dynamic braking resistance

Pb[P]: Allowable continuous braking resistance

F 5 3 9 : Braking resistance overload time

Function

Dynamic braking is used in the following cases:

1) Need to stop the motor quickly.

2) The inverter trips because of an overvoltage (OP) during deceleration.

3) Fluctuation of load condition causes a regenerative power even at a constant speed such as press machine.

[Parameter setting]

Title	Function	Adjustment range	Default setting
РЬ	Dynamic braking selection	☐:Disabled f:Enabled (bracking resistance overload detect) Z:Enabled (bracking resistance overload not detect)	a
Pbr	Dynamic braking resistance	0.5~ 1000 Ω	According to model ⇒ Refer to page K-46.
PBEP	Allowable continuous braking resistance	0.0 1~600.0 kW	According to model ⇒ Refer to page K-46.
F 6 3 9	Braking resistance overload time	0.1~600.0 sec.	5.0

^{*} Protection levels defined by F & 2 & (Refer to Section 6.14.2).

Note 1: The time set using $F \in \mathcal{F} \mathcal{F} \mathcal{F}$ is the time for which the resistor sustains an overload. (Enter the time elapsed before the inverter trips if a load 10 times as large as the allowable continuous braking resistance specified using $P \in \mathcal{F} P$ is applied.) There is no need to change resistance settings recommended by Toshiba (except DGP resistance setting).


Note 2: If the parameter Pb is set to l or l (regenerative braking selected), the inverter will be set automatically so as to deal with the regenerative energy from the motor by means of a resistor, without taking any action to limit overcurrent. (The same function as $F \ni l \ni l \ni l$)

Note 3: For inverters with ratings of 400V-200kW or more, set P b to 0, because separate dynamic braking units are not included as standard equipment.

All 200V VF-AS1 and 400V VF-AS1 with ratings of up to 160kW have built-in dynamic braking transistors as standard equipment. If the rating of your inverter falls within this range, connect the resistor, as shown in Figure a) below or Figure b) on the next page. If your inverter has a power rating of 200kW or more, connect a resistor, as shown in Figure c).

Connecting an external braking resistor (optional)

a) External braking resistor (with a thermal fuse) (optional)



[Parameter setting]

Title	Function	Adjustment range	Setting value
РЬ	Dynamic braking selection	### Disabled Disable	1


Do not connect an external resistor with a resistance (combined resistance) smaller than the minimum admissible resistance.

For overload protection, be sure to set the parameters Pbr and Pbf properly.

[Parameter setting]

Title	Function	Adjustment range	Setting value	
Pbr	Dynamic braking resistance	0.5~ 1000 Ω	Any value	
Pb[P	Allowable continuous braking resistance	0.0 1~600.0 kW	Any value	
F639	Braking resistance overload time	0. 1~600.0 sec.	Set the parameter to 5.0 for type PBR*- or to any value for other types.	

b) When a using braking resistor without thermal fuse



Note 1: Connection when using an MCCB with a top coil instead of an MC.

Note 2: A depression transformer is required for 400V models but not for 200V models.

[Parameter setting]

Title	Function	Adjustment range	Setting value
РЬ	Dynamic braking selection	☐:Disabled /:Enabled (braking resistance overload detect) ∠:Enabled (braking resistance overload not detect)	t
Pbr	Dynamic braking resistance	0.5~ 1000 Ω	Any value
Pb[P	Allowable continuous braking resistance	0.0 1~600.0 kW	Any value


(When the thermal braking resistor option is not used, be sure to set the parameters Pbr and PbCP properly for overload protection.)

* As a last resort to prevent fire, be sure to connect a thermal relay (Be sure to use bimetals method). Although the inverter has a means of preventing overload and overcurrent to protect the braking resistor, the thermal relay is activated in case the protection function fails to work. Select and connect a thermal relay (THR) appropriate to the capacity (wattage) of the braking resistor.

- Warning -

In the above circuit, the MC in the main circuit is turned off if an inverter's protective function is activated, and consequently no trip message is displayed. The inverter recovers from a trip if it is turned off. So, check the trip history record after turning off the inverter and then on again. ⇒ Refer to Section 8.2.1.

To prevent a trip condition from being cleared by turning off the power and then on again, change the setting of the inverter trip retention selection parameter $F \in \mathcal{G} \subset \mathcal{C}$. \Rightarrow Refer to Section 6.33.2.



Note 1: Connection when using an MCCB with a top coil instead of an MC.

[Parameter setting]

Title	Function	Adjustment range	Setting value
РЬ	Dynamic braking selection	☐:Disabled /:Enabled (braking resistance overload detect) Z:Enabled (braking resistance overload not detect)	o o

^{*} As a last resort to prevent fire, be sure to connect a thermal relay (Be sure to use bimetals method). Although the inverter has a means of preventing overload and overcurrent to protect the braking resistor, the thermal relay is activated in case the protection function fails to work. Select and connect a thermal relay (THR) appropriate to the capacity (wattage) of the braking resistor.

- Warning -

In the above circuit, the MC in the main circuit is turned off if an inverter's protective function is activated, and consequently no trip message is displayed. The inverter recovers from a trip if it is turned off. So, check the trip history record after turning off the inverter and then on again. \Rightarrow Refer to Section 8.2.1.

To prevent a trip condition from being cleared by turning off the power and then on again, change the setting of the inverter trip retention selection parameter $F \in \mathcal{G} \subset \mathcal{C}$. \Rightarrow Refer to Section 6.33.2.

■ Selection of braking resistor option and braking unit

Standard braking resistors are listed in the table below. The usage rate is 3%. (Except for type DGP***)

				Braking resistor		
Inverter type		Model number [Note 2]	Rating	Continuous regenerative braking allowable capacity [Note 1]		
VFAS1-2004PL, 2007PL		PBR-2007	120W -200Ω	90W		
VFAS1-2015PL, 2022PL		PBR-2022	120W -75Ω	90W		
VFAS1-2037PL		PBR-2037	120W - 40Ω	90W		
VFAS1-2055PL		PBR3-2055	240W - 20Ω	96W		
VFAS1-2075PL		PBR3-2075	440W -15Ω	130W		
VFAS1-2110PM		PBR3-2110	660W -10Ω	200W		
VFAS1-2150PM, 2185PM		PBR3-2150	880W -7.5Ω	270W		
VFAS1-2220PM		PBR3-2220	1760W -3.3Ω	610W		
VFAS1-2300PM		PBR3-2220	1760W - 3.3Ω	610W		
VFAS1-2370PM ~2550P		PBR-222W002	2200W - 2Ω	1000W		
VFAS1-2750P		DGP600W-B1	3.4kW - 1.7Ω	3400W		
VFAS1-4007PL ~4022PL		PBR-2007	120W - 200Ω	90W		
VFAS1-4037PL		PBR-4037	120W -160Ω	90W		
VFAS1-4055PL		PBR3-4055	240W - 80Ω	96W		
VFAS1-4075PL		PBR3-4075	440W -60Ω	130W		
VFAS1-4110PL		PBR3-4110	660W - 40Ω	190W		
VFAS1-4150PL, 4185PL		PBR3-4150	880W -30Ω	270W		
VFAS1-4220PL		PBR3-4220	1760W - 15Ω	540W		
VFAS1-4300PL		PBR3-4220	1760W - 15Ω	540W		
VFAS1-4370PL ~4750PL		PBR-417W008	1760W -8Ω	1000W		
VFAS1-4900PC ~4160KPC		DGP600W-B2	7.4kW - 3.7Ω	7400W		
VFAS1-4200KPC, 4220KPC	[Note 3]	PB7-4200K + DGP600W-B3	8.7kW -1.9Ω	8700W		
VFAS1-4280KPC	[Note 3]	PB7-4200K + DGP600W-B4	14kW - 1.4Ω	14000W		
VFAS1-4355KPC, 4400KPC	[Note 3]	PB7-4400K + DGP600W-B3 ×2 (parallel)	17.4kW –0.95Ω	17400W		
VFAS1-4500KPC	[Note 3]	PB7-4400K + DGP600W-B4 ×2 (parallel)	28kW -0.7Ω	28000W		

Note 1: Continuous regenerative braking allowable capacities vary according to the rated capacity and resistance of the resistor for reasons of endurance.

Combined braking resistor (Connected to PA/+, PB terminal of PB7-4□□□)

Note 2: PBR-DDDD, PBR3-DDDD and DGP600W-BD: Braking resistor (Connected to PA/+, PB terminal)

Note 3: PB7-4 $\square\square$: Braking unit (Connected to BU+, BU- terminal)

■ Minimum resistance of connectable braking resistors

The minimum allowable resistance values of the externally connectable braking resistors are listed in the table below.

Do not connect braking resistors with smaller resultant resistance than the listed minimum allowable resistance values.

(For 200kW or greater models, a dynamic braking resistor drive unit (optional separate unit) is needed.)

Inverter	200\	/ Class	400\	' Class
Related output capacity	Resistance of	Minimum allowable	Resistance of	Minimum allowable
(kW)	standard option	resistance	standard option	resistance
0.4	200Ω	50Ω	-	_
0.75	200Ω	50Ω	200Ω	60Ω
1.5	75Ω	35Ω	200Ω	60Ω
2.2	75Ω	20Ω	200Ω	60Ω
3.7/4.0	40Ω	16Ω	160Ω	40Ω
5.5	20Ω	11Ω	80Ω	30Ω
7.5	15Ω	Ω8	60Ω	20Ω
11	10Ω	5Ω	40Ω	20Ω
15	7.5Ω	5Ω	30Ω	13.3Ω
18.5	7.5Ω	3.3Ω	30Ω	13.3Ω
22	3.3Ω	3.3Ω	15Ω	13.3Ω
30	3.3Ω	2.5Ω	13.3Ω	10Ω
37	2Ω	1.7Ω	8Ω	6.7Ω
45	2Ω	1.7Ω	8Ω	5Ω
55	2Ω	1.7Ω	8Ω	5Ω
75	1.7Ω	1.3Ω	8Ω	3.3Ω
90	-	-	3.7Ω	2.5Ω
110	-	-	3.7Ω	1.9Ω
132	-	-	3.7Ω	1.9Ω
160	-	-	3.7Ω	1.9Ω
200	=	-	1.9Ω	1Ω
220	=	-	1.9Ω	1Ω
280	=	-	1.4Ω	1Ω
355	=	-	0.95Ω	0.7Ω
400	=	-	0.95Ω	0.7Ω
500	-	-	0.7Ω	0.7Ω

5.20 Standard default setting

Ł ¥₽ : Factory default setting

Function

This parameter is to set two or more parameters at a time for different commands. Using this parameter, all parameters can be also return to their respective default settings by one operation, and save or set specific parameters individually.

Title	Function	Adjustment range	Default setting
ŁYP	Factory default setting	### Comparison of Comparison o	o

Note 1: This parameter is used to change the settings of other parameters. Therefore, $\mathcal Q$ is always displayed.

Note 2: EYP cannot be set during the inverter operating. Always stop the inverter first and then program. Note 3: When parameter EYP is invoked, the value set previously is displayed on the left side of the parameter.

Note 4: If £ 5P is set to 1B, the optional communication devices DEV002Z, PDP002Z and CCL001Z cannot be used with the inverter. (The personal computer communications software PCM001Z cannot be used, either.) Furthermore, the copy function of the LED extended panel option (RKP002Z) does not work normally, so use only the parameter setting function and the monitoring function.

Note 5: If the power is turned off while the parameter £ \$\mathcal{Y}P\$ is being set, an error (\$\mathcal{E} \mathcal{P} P\$) will occur when the power is turned back on. If the \$\mathcal{E} \mathcal{E} P P\$ error occurs, set \$\mathcal{E} \mathcal{Y}P\$ again.

[Programmed value]

50Hz default setting (£ 4P= 1)

Setting $\mathcal{L} \mathcal{GP}$ at \mathcal{L} causes all the following parameters to be set for operation using a base frequency of 50Hz. (This does not change the settings of any other parameters.)

```
• Maximum frequency F H
                                                 : 50Hz • VI/II input point 2 frequency ₽ 1F ≥
                                                                                                               : 50Hz
• Base frequency 1 u L
                                                 : 50Hz • RR/S4 input point 2 frequency RuF 2
                                                                                                               : 50Hz
• Base frequency 2 F 170
                                                 : 50Hz • RX input point 2 frequency F 2 19
                                                                                                               : 50Hz

    Base frequency 3 F 174

                                                 : 50Hz • Al1 input point 2 frequency F 2 2 5
                                                                                                               : 50Hz

    Base frequency 4 F 178

                                                 : 50Hz • Al2 input point 2 frequency F 2 3 1
                                                                                                               : 50Hz
• Upper limit frequency LL
                                                 : 50Hz • RP/high-speed pulse input point 2 frequency F 2 3 7
                                                                                                               : 50Hz

    Forward speed limit input level F Ч ≥ Б

                                                 : 50Hz • PID deviation upper limit F 3 5 4
                                                                                                               · 50Hz
• Reverse speed limit input level F 4 ≥ 8
                                                 : 50Hz • PID deviation lower limit F 3 5 5
                                                                                                               : 50Hz
• Commercial power/inverter switching frequency F 3 5 5 : 50Hz • Process upper limit F 3 5 7
                                                                                                               : 50Hz

    Point 2 frequency F B 14

                                                 : 50Hz • PID output upper limit F 3 7 []
                                                                                                               : 50Hz
• Automatic light-load high-speed operation frequency F 3 3 0 : 50Hz • Motor rated rotational speed F 4 0 7
                                                                                        :1400~1480min-1 (According to model)
```

60Hz default setting ($E \ \ P = 2$)

Setting $E \ \ P$ at P causes all the following parameters to be set for operation using a base frequency of 60Hz. (This does not change the settings of any other parameters.)

```
    Maximum frequency F H

                                                 : 60Hz • VI/II input point 2 frequency # 1F 2
                                                                                                               : 60Hz
• Base frequency 1 u L
                                                 : 60Hz • RR/S4 input point 2 frequency RuF 2
                                                                                                               : 60Hz
• Base frequency 2 F 170
                                                 : 60Hz • RX input point 2 frequency F 2 19
                                                                                                               : 60Hz

    Base frequency 3 F 174

                                                 : 60Hz • Al1 input point 2 frequency F 2 2 5
                                                                                                               : 60Hz
• Base frequency 4 F 178
                                                 : 60Hz • Al2 input point 2 frequency F 2 3 1
                                                                                                               : 60Hz

    Upper limit frequency #L

                                                 : 60Hz • RP/high-speed pulse input point 2 frequency F 2 3 7
                                                                                                               : 60Hz
• Forward speed limit input level F 4 ₽ 5
                                                 : 60Hz • PID deviation upper limit F 3 5 4
                                                                                                               : 60Hz
• Reverse speed limit input level F 4 ≥ 8
                                                 : 60Hz • PID deviation lower limit F 3 5 5
                                                                                                               : 60Hz
• Commercial power/inverter switching frequency F 3 5 5 : 60Hz • Process upper limit F 3 6 7
                                                                                                               : 60Hz
• Point 2 frequency FB 14
                                                 : 60Hz • PID output upper limit F 3 7 []
                                                                                                               : 60Hz
• Automatic light-load high-speed operation frequency F 3 3 0 : 60Hz • Motor rated rotational speed F 40 7 : :1680~1775min-1 (According to model)
```

Default setting (F 4P=3)

Setting parameter $\xi \, \exists \, P$ to \exists resets all parameters except the following to their default settings.

When this parameter is set to 3, <u>In 11</u> is displayed for a while, then switches back to the original display (<u>IDFF</u> or <u>IDD</u>). Note that this setting also clears all trip history records. Trip history data will be cleared at this time.

Following parameters are designed considering maintenance that they cannot be reset to the factory default setting even if you set the parameter $\xi \not P$ at β . Following parameters are not displayed on the user parameter group $\xi r \ U$ even if their settings are different from their default settings. So please be careful.

Title	Function
RUH	History function
FNSL	FM terminal meter selection
FΠ	FM terminal meter adjustment
AN5L	AM terminal meter selection
RN	AM terminal meter adjustment
F 108	Analog VI/VII voltage/current switching
F 109	Analog Al2 (optional circuit board)
r 103	voltage/current switching
F470	VI/II input bias
F471	VI/II input gain
F472	RR/S4 input bias
F473	RR/S4 input gain
FY7Y	RX input bias
F475	RX input gain
F476	Optional Al1 input bias
FY77	Optional Al1 input gain

	<u>'</u>
Title	Function
F478	Optional AI2 input bias
F479	Optional AI2 input gain
F 5 6 9	Logic output/pulse train output selection (OUT1)
F572	MON1 terminal meter selection
F 5 7 3	MON1 terminal meter adjustment
F 5 7 4	MON2 terminal meter selection
F 6 7 5	MON2 terminal meter adjustment
F58 I	FM voltage/current output switching
F 588	MON1 voltage/current output switching
F 69 1	MON2 voltage/current output switching
F 75 1~ F 782	Quick registration parameter 1~32
F880	Free notes
F899	Network option reset setting
	<u> </u>

Trip clear (Ł 4P=4)

Setting £ 4P to 4 initializes the past four sets of recorded trip history data.

* (The parameter does not change.)

Cumulative operation time clear (E 4P = 5)

Setting £ 4P to 5 resets the cumulative operation time monitor to the initial value (0 [zero] time).

Initialization of type information ($E \ \ P = E$)

When a trip occurs because of a type error ($\mathcal{E} \succeq \mathcal{P}$ is displayed), you can clear the trip by setting $\mathcal{E} \succeq \mathcal{P}$ to \mathcal{E} . This function is used to reformat a control circuit board to adapt it to an inverter, for example, when a circuit board is removed from an inverter to use another inverter for maintenance or for other reasons. This setting clears all type data stored in the inverter.

Save user-defined parameters (£ 4P=7)

Setting £ 47 to 7 causes all the current parameter settings to be stored individually.

Reset of user-defined parameters ($E \ \ P = B$)

Setting $\not\in \mathcal{GP}$ to \mathcal{B} returns all parameters to the settings saved by setting the parameter $\not\in \mathcal{GP} = 7$.

* The above settings 7 and 8 allows you to have your own default parameter settings.

Cumulative fan operation time clear ($E \ \ P=9$)

Setting $\mathcal{L} \mathcal{YP}$ to \mathcal{G} resets the cumulative fan operation time to the initial value (0 [zero] time). Set this parameter when replacing the cooling fan, and so on.

Acceleration/deceleration time setting: 0.01 to 600.0 sec. (£ \$\mathcal{P} = 10)

When £ ½P is set to 13, the acceleration/deceleration time can be set within a range of 0.01 to 600.0 sec.

Acceleration/deceleration time setting: 0.1 to 6000 sec. ($E \ \ P = 11$)

When £ 4 P is set to 11, the acceleration/deceleration time can be set within a range of 0.1 to 6000 sec.

5.21 Searching for all reset parameters and changing their settings

: Automatic edit function

Function

Automatically searches for only those parameters that are programmed with values different from the standard default setting and displays them in the user parameter group $\mathcal{L} \cap \mathcal{U}$. Parameter setting can also be changed within this group.

Note 1: If you reset a parameter to its factory default, the parameter will no longer appear in [], r !!.

Note 2: It may take several seconds to display changed parameters because all data stored in the user parameter group £ r U is checked against the factory default settings. To cancel the parameter group search in process, press the

Note 3: Parameters which cannot be reset to the default setting after setting $\xi \ \mathcal{GP}$ to \mathcal{G} are not displayed.

⇒ Refer to Section 5.20 for details.

■ How to search and reprogram parameters

The operations of search and resetting of parameters are as follows.

The operations of search and resetting of parameters are as follows.		
Key operated	LED display	Operation
_	0.0	Displays the operation frequency (operation stopped). (When standard monitor display selection F 7 $I : G = G$ [Output frequency])
MODE	RUH	The first basic parameter "History function (#UH)" is displayed.
$ \bigcirc \bigcirc$	GrU	Press △ or ▽ key to select ಔ r IJ.
ENT	<i>U</i>	Press the ENTER key to enable the user parameter automatic edit function.
ENT) Or	ЯСС	Searches for parameters that are different in value from the standard default setting and displays those parameters. Press the ENTER key or the \triangle key to change the parameter displayed. (Press the ∇ key to search for parameters in reverse direction.)
ENT	8.0	Press the ENTER key to display the set value.
	5.0	Press the \triangle key and ∇ key to change set value.
ENT	5.0⇔A[[Press the ENTER key to save the changed value. The parameter name and the programmed value will flash on and off alternately.
$\bigcirc (\bigcirc)$	U F (U r)	Use the same steps as those given above to display parameters that you want to search for or change setting with the \triangle key and ∇ key.
$\bigotimes_{i \in \mathcal{I}} \widehat{i}$	GrU	When "Gr U" appears again, the search is ended.
MODE)	Parameter display Fr-F U.G.	A search can be canceled by pressing the MODE key. Press the key once while the search is underway to return to the display of parameter setting mode. After that you can press the MODE key to return to the status monitor mode or the standard monitor mode (display of operation frequency).

5.22 EASY key function

P5EL : Registered parameter F751 ~ F782 :

display selection Quick registration parameter 1~32

F 750 : EASY key function selection

Function

The following three functions can be assigned to the (EASY) key for easy operation by means of a single key.

- Setting monitor mode switching function
- · Shortcut key function
- Operation panel/remote key function

[Parameter setting]

Ĺ	Title	Function	Adjustment range	Default setting
	PSEL	Registered parameter display selection	☐: Standard setting mode at time of activation of motor 1: Quick mode at time of activation of motor 2: Quick mode only	a
	F 150	EASY key function selection	☐: Quick mode/ standard setting mode switching function I:Shortcut key: Pressing for 2 sec. to record the parameter, pressing normally to jump to recorded parameter (first jump to the 1st history) C:Operation panel/remote key: Operation panel by ON S: Monitor peak minimum hold trigger	a

■ Quick mode/standard setting mode switching function (F 750=0)

The EASY key allows you to switch between quick mode and standard setting mode.

The way parameters are read out and displayed varies according to the mode selected.

Quick mode

This mode allows you to previously select parameters (max. 32 parameters) whose settings need to be changed frequently and to read them out only. Eight parameters are selected by default; add or remove parameters as required.

Standard setting mode

Standard setting mode in which all parameters are read out.

[How to read out parameters]

To enter the setting monitor mode, set parameter F 75 \mathcal{Q} to \mathcal{Q} , switch to the setting monitor mode using the EASY key, and then press the (MODE) key.

Press the key or the key to read out parameters in ascending or descending order.

The relation between the parameter and the mode selected is shown below.

P5EL =0

* Standard setting mode at time of activation of motor. Press the (EASY) key to switch to the quick mode.

P5EL = 1

* Quick mode at time of activation of motor. Press the (EASY) key to switch to the standard setting mode.

PSEL =2

- * Quick mode (fixed).
- * How to cancelxk the Quick mode (P 5 E L = 2) setting

 When this parameter is set to 2 (Quick mode), press and hold down the (ENT) key for 5 seconds or more.

[How to select parameters]

Select the desired parameters as parameters 1 to 32 (*F* 75 *1-F* 782). Note that parameters should be specified by communication number. For communication numbers, refer to Table of parameters.

In the quick mode, only parameters registered as parameters 1 to 32 are displayed in order of registration.

By default, parameters are set as shown in the table below.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F 75 I	Quick registration parameter 1	0~999	ዛ <i>ቤ(ጽሀԿ</i>)
F752	Quick registration parameter 2	0~999	15(PE)
F753	Quick registration parameter 3	0~999	! !(F H)
F754	Quick registration parameter 4	0~999	9(A[[)
F 755	Quick registration parameter 5	0~999	10(4EE)
F756	Quick registration parameter 6	0~999	600(ŁHr)
F757	Quick registration parameter 7	0~999	6(F [])
F758	Quick registration parameter 8		
~	~	0~999	333
F781	Quick registration parameter 31		
F782	Quick registration parameter 32	0~999	50(P5EL)

Note: If any number other than communication numbers is specified, it is regarded as 9.9.9 (no function assigned).

Continuous 399: Disabled

■ Shortcut key function (F 750=1)

This function allows you to register, in a shortcut list, parameters whose settings need to be changed frequently so that you can read them out easily in a single operation.

The shortcut is usable in the frequency monitor mode only.

[Operation]

Set the parameter F 75 0 to 1, read out the setting of the parameter you want to register, and press and hold down the EASY key for 2 sec. or more. The registration of the parameter in a shortcut list has been completed. To read out the parameter, just press the EASY key.

■ Operation panel/remote key function (F 750=2)

This function allows you to easily switch control devices (operation panel and terminal board) used to start and stop operation and to set the frequency.

To switch between control device, set the parameter F 75 G to Z, and then select the desired control device, using the EASY key.

[When using the terminal board]

If $[\Pi \Pi G d = G]$, no switching operation is required.

[When using the operation panel]

Turn on the EASY key.

■ Peak hold function (F750=3)

This function allows you to set peak hold and minimum hold triggers for parameters F 709, F 966, F 968, F 970 and F 972, using the EASY key. The measurement of the minimum and maximum values set for F 709, F 966, F 968, F 970 and F 972 starts the instant when you press the EASY key after setting parameter F 750 to 3.

The peak hold and minimum hold values are displayed in absolute values.

6. Extended parameters

Extended parameters are provided for sophisticated operation, fine adjustment and other special purposes. ⇒ Refer to Section 11, Table of parameters.

6.1 Input/output parameters

6.1.1 Low-speed signal

F 100 : Low-speed signal output frequency


Function

When the output frequency exceeds the setting of *F* ! [] an ON signal will be generated. This signal can be used as an electromagnetic brake excitation/release signal.


Through the open collector terminal OUT1 or OUT2 (24Vdc-50mA [max.]).

[Parameter setting]

Title	Function	Adjustment range	Default setting
F 100	Low-speed signal output frequency	0.0~UL Hz	0.0



[Connection diagram (SW1 set to sink logic)]



Output terminal setting

The low-speed signal (ON signal) output function has been assigned to the terminal OUT1 by default. This setting must be changed to invert the polarity of the signal.

[Parameter setting]

Title	Function	Adjustment range	Example of setting
F 130	Output terminal function selection 1(OUT1)	0~255	ዣ(ON signal) or 5 (OFF signal)

Note: To put out signals to OUT2, select the parameter F 13 1.

6.1.2 Putting out signals of arbitrary frequencies

F 10 1 : Speed reach setting frequency

F 102 : Speed reach detection band

Function

When the output frequency becomes equal to the frequency set by $F:\mathcal{C}:\pm F:\mathcal{C}$, an ON or OFF is generated.

[Parameter setting of frequency and detection band]


Title	Function	Adjustment range	Default setting
F 10 1	Speed reach setting frequency	0.0~UL Hz	0.0
F 102	Speed reach detection band	0.0~UL Hz	2.5

[Parameter setting of output terminal selection]


Title	Function	Adjustment range	Example of setting
F 13 1	Output terminal function selection 2 (OUT2)	0~255	8 (RCH (specified speed ON signal)) or 9 (RCH (specified speed OFF signal))

Note: To put out signals to OUT1, select the parameter F 130.

If the detection band value + the set frequency is less than the designated frequency



If the detection band value + the set frequency is more than the designated frequency



6.2 Input signal selection

6.2.1 Priority when forward/reverse run commands are entered simultaneously

F 105 : Priority when forward/reverse run commands are entered simultaneously


Function


This parameter allows you to select the direction in which the motor runs when a forward run (F) command and a reverse run (R) command are entered simultaneously.

- 1) Reverse run
- 2) Deceleration stop

[Parameter setting]

	-31		
Title	Function	Adjustment range	Default setting
F 105	Priority when forward/reverse run commands are entered simultaneously	☐:Reverse run, 1:Stop	1





6.2.2 Assigning priority to the terminal board in the operation panel and operation mode F 106: Input terminal priority selection

Function

This parameter is used to give priority to certain external commands entered from the terminal board in operation panel and operation mode.


For example, when jogging the motor by giving signals externally.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F 106	Input terminal priority selection	☐:Disabled, /:Enabled	O


[#: Deselect (terminal board has no priority)]

Priority is always given to commands (operation commands) entered from the operation panel. To give priority to commands from the terminal board, it is necessary to switch from control panel operation to terminal board operation by sending signals through the terminal board.



[1: Select (terminal board has priority)]

Priority is given to commands entered from the terminal board even in operation panel operation mode.



■ Priority command from terminal board (Operation command)


Jog run : input terminal selection 18/19
DC braking : input terminal selection 22/23

An example of switching to jog run in operation panel operation mode.

[In case that terminals S3 and CC are assigned to jog run]

Assign control terminal S3 ([!4: preset speed 3] in default setting) as the jog run setting terminal.

Title	Function	Adjustment range	Example of setting
FIIT	Input terminal function selection 7 (S3)	0~135	## (Jog run settin g terminal)



6.2.3 Analog input signal switching

F 108 : Analog input VI/VII voltage/current switching


F 109 : Analog input Al2 (optional circuit board) voltage/current switching

• Function

These parameters are used to switch signals to be sent to the analog input terminals VI/II and AI2 (optional).

Parameter setting]

[Farameter Setting	<u> </u>		
Title	Function	Adjustment range	Example of setting
F 108	Analog VI/VII voltage/current switching	☐: Voltage inputI: Current input	0
F 109	Analog input Al2 (optional circuit board) voltage/current switching	∷ Voltage input∴ Current input	0



⇒ For an explanation of input gain and bias adjustments, refer to Section 6.28.

6.3 Terminal function selection

6.3.1 Keeping an input terminal function always active (ON)

F 1 10 , F 127, F 128: Always ON function selection 1~3

Function

This parameter specifies an input terminal function that is always kept active (ON). (Only one function selectable)

[Parameter setting]

- 3	rameter cetting				
	Title	Function	Adjustment range	Default setting	
	F 1 10	Always ON function selection 1	0~135	Inverter with a model number ending with -WN, HN: # -WP: 5	
	F 127	Always ON function selection 2	0~135	0	
Ì	F 128	Always ON function selection 3	0~135	O	

^{*}The selected function is always kept active regardless of the type of logic (positive or negative) in the table of function settings in 7.2.1.

6.3.2 Modifying input terminal functions

F 111 : Input terminal function selection 1 (F) F 117 : Input terminal function selection 7 (S3)

F 112 : Input terminal function selection 2 (R) F 118 : Input terminal function selection 8 (RR/S4)

F ! ! 3 : Input terminal function selection 3 (ST) F ! ! 9 ~ F ! 26 :

F 114 : Input terminal function selection 4 (RES) Input terminal function selection 9~16

F 115 : Input terminal function selection 5 (S1) F 154 ~ F 157 :

F ! 16 : Input terminal function selection 6 (S2) Input terminal function selection 17~20

⇒ For details, refer to Section 7.2.1.

• Function

Use the above parameters to send signals from an external programmable controller to various control input terminals to operate and/or set the inverter.

The desired contact input terminal functions can be selected from 120 types (\mathcal{G} - 135). This gives system design flexibility.

Using the SW3 switch, the function of the RR/S4 terminal can be selected between analog input and contact input. By default, the RR/S4 terminal is set as an analog input terminal (voltage input terminal). To use it as a contact input terminal, therefore, you need to turn the SW3 switch to the S4 position.

■ Setting of contact input terminal function

Terminal symbol	Title	Function	Adjustment range	Default setting
-	F 1 10 [Note 3], F 127, F 128	Always ON function selection 1~3		O
F	FIII	Input terminal function selection 1 (F)		₽ (F)
R	F 1 12	Input terminal function selection 2 (R)	0~135	ሣ (R)
ST	F	Input terminal function selection 3 (ST)	(⇒ Refer to	5 (ST)
RES	FIIY	Input terminal function selection 4 (RES)	Section 11.)	🖁 (RES)
S1	F 1 15	Input terminal function selection 5 (S1)	Occilon 11.)	/ [] (S1)
S2	F 1 15	Input terminal function selection 6 (S2)		1 € (S2)
S3	F 1 1 7	Input terminal function selection 7 (S3)		14 (S3)
The terminal below is operative only when SW3 is in the S4 position.		=	_	
RR/S4	F 1 18	Input terminal function selection 7 (S4)	☐~ / 3 5 [Note 2]	15 (S4)

Note 1: The function that has been selected using F 110, F 12 7and F 128 (always ON function selection 1~3 parameter) are always activated.


Note 2: When using the RR/R4 terminal as a contact input terminal (sink logic), always turn the SW3 slide switch to the S4 position.

Note 3: VFAS1-***-WN, HN


Note 4: VFAS1-***-WP

■ Connection method

1) a-contact input




2) Connection with transistor output



^{*} Interface between programmable controller and inverter

Note: When using a programmable controller with open collector outputs for control, connect it to the P24/PLC terminal, as shown in the figure below, to prevent the inverter from malfunctioning because of current flowing in.

Also, be sure to turn the SW1 slide switch to the PLC position.



Sink logic/source logic input
 Sink logic/source logic (input/output terminal logic) switching is possible.

 \Rightarrow For details, refer to Section 2.3.2.

6.3.3 Using the servo lock function

F ! ! 3 : Input terminal function selection 3 (ST)

F 2 4 0 : Starting frequency setting

Function

As with the operation of a server motor, these parameters allow you to operate the motor at 0Hz by simply issuing an operation signal. These parameters are used to hold the motor at a standstill.

[Parameter setting]


Title	Function	Adjustment range	Example of setting
F 1 13	Input terminal function selection 3 (ST)	0~135	7.0
F240	Starting frequency setting	0.0~ 10.0 Hz	0.0

Note 1: This function is enabled only when parameter $P \not\models$ is set to $\not\ni$ (PG feedback vector control).

Note 2: To activate servo lock, parameter $F \supseteq \Psi G$ (starting frequency setting) needs to be set to G [Hz].

Note 3: These parameters are not intended for position control, and if a load larger than the holding power of the motor is applied, the motor rotates. Keep this in mind.

If parameter *F 113* (for selecting a function for the ST terminal) is set to 70, a servo lock signal is added to the ST signal. In that case, turning on the signal to the ST terminal activates the servo lock function. Note that even when the servo lock function is activated, or the operations can be performed normally by inputting an F or R signal.



Even if the motor is started with servo lock activated, a starting torque of 150% or more can be produced. In such a case, however, the thermal protection level is lowered just as is the case with low-speed operation. Therefore, the following parameters

- [] L [] (Thermal protection characteristic selection)
- £ H r (Motor electronic-thermal protection level 1), F 173, F 177, F 18 1
- F & 0 & (OL reduction starting frequency)
- F & [] 7 (Motor 150%-overload time limit)

need to be adjusted according to the motor.

6.3.4 Modifying output terminal functions

F 130 : Output terminal function selection 1 (OUT1)

F 13 1 : Output terminal function selection 2 (OUT2)

F 132 : Output terminal function selection 3 (FL)

F 133 ~ F 138 : Output terminal function selection 4~9

F 168 ~ F 169 : Output terminal function selection 10, 11

⇒ For details, refer to Section 7.2.2.

6.3.5 Response time of input/output terminals

F 140 : Input terminal 1 response time selection

F 141 : Input terminal 2 response time selection

F 142 : Input terminal 3 response time selection

F 143 : Input terminal 4 response time selection

F 144 : Input terminal 5~12 response time selection

⇒ For details, refer to Section 7.2.3.

The output terminal and the response time can be set with "My function."

⇒ For details, refer to Section 6.39.

6.4 Basic parameters 2

6.4.1 Switching among V/f characteristics 1, 2, 3 and 4 from input terminal

: Input terminal 13~20 response time selection

F 170: Base frequency 2F 176: Manual torque boost 3F 171: Base frequency voltage 2F 177: Thermal protection level 3F 173: Thermal protection level 2F 179: Base frequency voltage 4F 174: Base frequency 3F 180: Manual torque boost 4F 175: Base frequency voltage 3F 181: Thermal protection level 4

Function

Use the above parameters to switch the operation of 4 motors with a single inverter and to select motor V/f characteristics (1 to 4) according to the particular needs or operation mode.

[Switching methods]

Terminals are used for this switching.

Note: The setting of parameter $P \not = (V/f \text{ control mode selection})$ is valid only when V/f1 is selected. If V/f2, V/f3 or V/f4 is selected, V/f control is performed in constant torque mode. Do not switch motors when the parameter $P \not = (V/f \text{ control mode selection})$ is set at 7, 8. For parameters selected when changing V/f characteristics (1 to 4), refer to table on the next page.

Note: Refer to Section 5.8 <u>u</u> <u>L</u> (Base frequency 1) for F 170, F 174 and F 178, Section 5.8 <u>u</u> <u>L</u> <u>u</u> (Base frequency voltage 1) for F 171, F 175 and F 179, Section 5.7 <u>u</u> <u>b</u> (Manual torque boost) for F 172, F 176 and F 180, and Section 5.14 <u>E</u> H_F (Motor electronic thermal protection level 1) for F 173, F 177 and F 181, respectively.


■ Setting of switching terminals

The V/f1, V/f2, V/f3 and V/f4 switching function is not yet assigned to any terminal. Therefore, it is necessary to assign them to unused terminals.

Ex.) Assigning the V/f switching 1 function to S1 and the V/f switching 2 function to S2.

Title	Function	Adjustment range	setting value
F 1 15	Input terminal function selection 5 (S1)	0~135	₽ (V/f switching 1)
F 1 15	Input terminal function selection 6 (S2)	0~135	∃ [(V/f switching 2)

«An example of the connection of terminals: SW1 set to sink logic»



S1-CC	S2-CC	V/f	Parameters selected	
			Base frequency 1	: u L
OFF	OFF		Base frequency voltage 1	:uLu
OFF	OFF	ļ	Manual torque boost 1	: u b
			Thermal protection 1	: <i>E H r</i>
			Base frequency 2	:F 170
ON	OFF	2	Base frequency voltage 2	:F 17 1
ON	OFF	2	Manual torque boost 2	:F 172
			Thermal protection 2	:F 173
		3	Base frequency 3	:F 174
055	ON		Base frequency voltage 3	:F 175
OFF	ON		Manual torque boost 3	:F 176
			Thermal protection 3	:F 177
			Base frequency 4	:F 178
011	ON	4	Base frequency voltage 4	:F 179
ON			Manual torque boost 4	:F 180
			Thermal protection 4	:F 18 1

Note1:V/f switching is not able to change during the inverter running,. Always stop the inverter and then switch.

It is necessary to wait for 0.1 second and over until start up inverter from switch the V/f switching.

Note2:Select V/f1 when using the vector control and the V/f-5 point setting.

Selecting V/f2,.V/f3, or V/f4 disables vector control but enables the V/f constant control.

Note3:By using "My function," torque limits and acceleration/deceleration modes can be switched along with V/f switching.

Note4:With the operation panel or communication, the panel acceleration/deceleration selection (F 5 0 4) can be set.

^{*} This function is active only in operation panel operation mode.

6.5 V/f 5-point setting

 F 190
 : V/f 5-point setting VF1 frequency
 F 196
 : V/f 5-point setting VF4 frequency

 F 191
 : V/f 5-point setting VF1 voltage
 F 197
 : V/f 5-point setting VF4 voltage

F 192 : V/f 5-point setting VF2 frequency F 198 : V/f 5-point setting VF5 frequency
F 193 : V/f 5-point setting VF2 voltage F 199 : V/f 5-point setting VF5 voltage

F 194 : V/f 5-point setting VF3 frequency
F 195 : V/f 5-point setting VF3 voltage

6.6 Speed command switching

6.6.1 Using two types of frequency (speed) commands

F \(\text{I \text{ } d \ } \) : Frequency setting mode selection 1

F200 : Frequency priority selection

F207 : Frequency setting mode selection 2

F208 : Speed command priority switching frequency


Function

These parameters switch two types of frequencies

- · Automatic switching by parameter setting
- · Automatic switching by means of switching frequencies
- Switching with input terminal

1) Switching with input terminal board (F ≥ □ □ = □)

Reference can be switched if the frequency priority switching function is assigned to a terminal.



- A: Selects the command set with parameter F $\Pi \mathcal{Q} d$. Operation frequency command switching terminal OFF
- B: Selects the command set with parameter F 2 0 7. Operation frequency command switching terminal ON

Ex.) When the frequency priority switching function is assigned to terminal S3.


Title	Function	Adjustment range	Example of setting
F 1 17	Input terminal function selection 7 (S3)	0~135	# 대 역(Operation frequency command switching)

«An example of the connection of terminals: SW1 set to sink logic»

		Speed command
S3 -	OFF	Command selected with
cc	ON	Command selected with

[⇒] For details, refer to Section 5.6,5).


2) Automatic switching by means of switching frequencies $(F \supseteq B B = 1)$



A: If the frequency set with F \(\Pi \) d is higher than that set with F \(\Pi \) \(\Pi \) \(\Bar{B} \) \(\cdots \) Priority is given to the

Priority is given to the command set with F \(\Pi\mathbb{G}\) \(\delta\).

B: If the frequency set with F \(\Pi \ \Pi \) d is equal to or lower than that set with F \(\pi \ \Pi \) 8 \\ \tag{20.8} \\ \tag{7.7}.



[Parameter setting]

Title	Function	Adjustment range	Default setting
FNOA	Frequency setting mode selection 1	!:VI/II (voltage/current input) 2:RR/S4 (potentiometer/voltage input) 3:RX (voltage input) 4:Operation panel input enabled (including LED/LCD option input) 5:2-wire RS485 communication input 5:4-wire RS485 communication input 7:Communications option input 8:Optional Al1 (differential current input) 9:Optional Al2 (voltage/current input) 18:Up/Down frequency 1:Optional RP pulse input 12:Optional high-speed pulse input 13: - (Unsupported)	2
F200	Frequency priority selection	0:FN0 d/F 20 7 terminal switching (input terminal function selection 10 4, 10 5) 1:FN0 d/F 20 7 frequency switching (switching with F 20 8)	0
F207	Frequency setting mode selection 2	Same as F $\Pi \square d$ ($1 \sim 13$)	1
F208	Speed command priority switching frequency	0. 1~F H Hz	O. 1

6.7 Operation frequency

6.7.1 Start frequency/Stop frequency

F240 : Start frequency setting
F243 : Stop frequency setting


Function

The frequency set with the parameter $F \ge 40$ is put out as soon as operation is started. Use the $F \ge 40$ parameter when a delay in response of starting torque according to the acceleration/deceleration time is probably affecting operation. Setting the starting frequency to a value from 0.5 to 2.0Hz (max. 5Hz) is recommended. The occurrence of an overcurrent can be suppressed by setting this frequency below the rated slippage of the motor. If 0 speed torque is needed ($P \ge 7$, B), set $F \ge 40$, $F \ge 40$, at 0.0Hz.

- At start up : frequency set with $F \supseteq 4 \square$ is put out immediately.
- At stop : The output frequency drops to 0Hz immediately by the frequency set with F 2 4 3.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F240	Starting frequency setting	0.0 ~ 10.0 Hz	0.1
F243	Stop frequency setting	0.0~30.0 Hz	п.п



Note: Set these parameters so that the start frequency $\boxed{F240}$ is higher than the stop frequency $\boxed{F243}$.

If the $\boxed{F240}$ -set frequency is lower than the $\boxed{F243}$ -set frequency, the reference frequency must be higher than the F243-set frequency to start the motor.

If both $\boxed{F240}$ and $\boxed{F243}$ are set to $\boxed{0.0}$ Hz, the motor will start even if the frequency set is 0.0Hz.

6.7.2 Run/Stop control with frequency setting signals

F241 : Operation start frequency


F242 : Operation start frequency hysteresis

Function

The Run/Stop of operation can be controlled simply with frequency setting signals.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F241	Operation starting frequency	0.0 ~F H	0.0
F242	Operation starting frequency hysteresis	0.0~30.0 Hz	0.0



6.7.3. Frequency setting signal 0Hz dead zone handling function

F 2 4 4 : Frequency command dead band


Function

If the frequency is set to 0Hz by means of an analog signal so that the motor shaft can be locked by sensor vector control (PE=7, B) the frequency may not always be 0Hz because of drift or offset.

In such a case, this parameter allows you to correctly set the operation frequency command to 0Hz. If the operation frequency command is below the frequency setting signal 0Hz insensitive frequency set with $F \ge 44$, parameter $F \ge 44$ will adjust the operation frequency command to 0Hz.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F244	Frequency command dead band	0.0~5.0 Hz	0.0



- Note 1: This function is invalid to preset the speed operation frequency command.
- Note 2: It is effective as frequency instruction is to the frequency reference chosen by F \(\Pi \) \(\frac{1}{2} \) \(\frac{1}{2} \), communication.etc.
- Note 3: The addition and multiplication of the override function is carried out to the frequency in which this function operated.

6.8 DC braking

6.8.1 DC braking

F 2 5 0 : DC braking start frequency

F 2 5 1 : DC braking start frequency

F 252 : DC braking time

253 : Forward/reverse DC braking


priority control

• Function

A large braking torque can be obtained by applying a direct current to the motor. These parameters set the direct current applied to the motor, the application time and the start frequency.

[Parameter setting]


Title	Function	Adjustment range	Default setting
F250	DC braking start frequency	0.0~120.0 Hz	0.0
F251	DC braking current	0~100%	50
F252	DC braking time	<i>□.</i> □~2	1.0
F253	Forward/reverse DC braking priority control	☐:Disabled, I:Enabled	Ü



<DC braking start conditions>

The forward/reverse DC braking priority control function $F \ge 5 \ 3$ recognizes certain conditions such as stop commands from the inverter, and is activated when the output frequency goes down below the DC braking start frequency set with $F \ge 5 \ 3$. In this case, the conditions under which DC braking starts include not only the issue of a start or stop command from the operation panel or an external input device, but also a fall in the reference frequency below the value set with $F \ge 4 \ 3$ (stop frequency setting) or a fall in the output frequency below the operation stop frequency setting $F \ge 4 \ 3$.

[DC braking under normal conditions] (Forward/reverse run DC braking priority control F 2 5 3 = 0 [Disabled])




(1) If F 2 5 0 and F 2 4 3 > reference frequency : DC braking

(2) If $F \supseteq 5 \square$ > reference frequency > $F \supseteq 4 \supseteq 3$: Operation at the command frequency

If F 2 5 0 and F 2 4 3 > reference frequency : DC braking

(3) If an operation command is entered during DC braking : DC braking is discontinued to restart the operation.

[Priority to DC braking during forward/reverse operation] (Forward/reverse run DC braking priority control F 2 5 3= f[Enabled])



- «SW1 set to sink logic»
- (4) During normal forward/reverse run ($F \ge 5 \exists = \square$)
- : Not recognized as a stop command, so that the DC braking is not active.
- (5) If a reverse run (or forward) command is entered during forward run (or reverse) ($F \ge 3 = 1$):

DC braking when the frequency set with $F \ge 50$ decreases below the reference frequency during deceleration.

- (6) If an operation command is entered during DC braking: RUN command has a priority.
- (7) If an operation command is changed from ON to OFF during DC braking, DC braking is discontinued to stop the operation.

6.8.2 Motor shaft fixing control

F254 : Motor shaft fixing control

Function


This function is used to prevent the motor from running unexpectedly after the motor is stopped because it's shaft is not restrained or to preheat the motor.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F254	Motor shaft fixing control	☐:Disabled, I:Enabled	O

If the motor shaft fixing control parameter $F \ge 5$ Y is set at I, DC braking continue at half a braking rate of that set with $F \ge 5$ I to retain the motor after it has come to a full stop by DC braking. To terminate the motor shaft fixing control cut off the standby signal (ST signal).

Note: This function doesn't operate after a DC braking command is entered by control input terminal signal.



- Note 1: If the motor shaft fixing control parameter $F \ge 5 \ Y$ is set at I (enabled) when the output frequency is below the DC braking start frequency $F \ge 5 \ U$ and terminals ST-CC are closed (ON), the DC braking function is activated and the motor shaft fixing control continues regardless of the setting of the DC braking time parameter $F \ge 5 \ Z$.
- Note 2: If a power failure occurs during motor shaft fixing control and the motor starts to a coast, motor shaft fixing control will be canceled. Also, if the inverter trips during motor shaft fixing control and is restored to working order by the retry function, motor shaft fixing control will be canceled.

6.8.3 Function of issuing a 0Hz command during a halt

F 2 5 5 : 0Hz command output selection

Function

This function controls the motor in the zero-speed state at the time of stop. If this function is set up, the 0Hz command will be put out instead of DC braking at the time of a stop, and a motor will be controlled in the setting time stop state. The monitor display serves as ab during this control operation. This function operates only at the time of vector control with a sensor (Pb = 7, B).

Refer to DC braking (Section 6.8.1) for conditions of operation. The position of DC braking is served as an operation which sets the operation frequency command to 0Hz.

[Parameter setting]

arameter settingj					
Title	Function	Adjustment range	Default setting		
F255	0Hz command output selection	 ☐: Standard (DC braking) ☐: 0Hz command	0		
F250	DC braking starting frequency	0.0~120.0 Hz	0.0		
F252	DC braking time	<i>0.0~20.0</i> sec.	1.0		

- Note 1: This function doesn't operate when $F \supseteq S \square = \square \square$
- Note 2: If this function is set up, motor shaft fixing control F 2 5 4 cannot be used.
- Note 3: This function doesn't operate at the time of a torque control.
- Note 4: This function doesn't operate except $P \not\models = 7$, \mathcal{B} of the vector control mode with a sensor. In order to use this function, the option board for PG feedback is required. When expect vector control with a sensor $P \not\models = 7$, \mathcal{B} , this function operate as DC braking mode (It is the same as $F \not\in 5 = \mathcal{G}$ setting).
- Note 5: Since the reference frequency that will suspend the motor abruptly from the state of high rotation if (F 2 5 0) is set up highly, please be careful. A trip may occur according to load conditions.
- Note 6: This parameter has a function similar to the DC braking function, which is activated by a command from the terminal board or an external control device (input terminal function 22 or 23, or command from external control device). To the DC braking function which will be activated if F 25 t (jog run stop pattern) is set to 2 (DC braking), and to the DC braking function which will be activated if F 5 03 (emergency stop pattern) is set to 2 (DC braking), but it issues 0Hz commands instead of DC braking commands.

6.9 Auto-stop in case of lower-limit frequency continuous operation (Sleep/Wake-up function)

F255 : Time limit for lower-limit frequency operation

Function


If operation is carried out continuously at a frequency below the lower-limit frequency ($\xi \xi$) for the period time set $\xi > 5$. the inverter will automatically slow down the motor to a stop.

"L 5 & P" is always displayed on the operation panel. (Blinking alternately)

The auto-stop function will be disabled when the frequency command value reaches over the lower limit frequency ((L,L))+0.2Hz or the operation command is turned to off.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F256	Auto-stop in case of lower-limit frequency continuous operation	<pre>0.0:None 0.1 ~ 600.0 sec.</pre>	0.0



Note: This function is enabled even at the start of operation and during switching between forward and reverse run.

6.10 Jog run mode

F 2 5 0 : Jog run frequency

F25 ! : Jog run stop pattern

F252 : Operation panel jog run mode

Function

Use the jog run parameters to operate the motor in jog mode. Input of a jog run signal generates a jog run frequency output at once, irrespective of the designated acceleration time.

Also, you can choose an operation panel start/stop mode between the ordinary start/stop mode and the jog run start/stop mode.

The jog run function needs to be assigned to an input terminal.

When assigning it to the S3 terminal, set F 117 to 18.

The motor can be operated in jog run mode while the jog run setting terminals are connected (S3-CC: ON).

[Parameter setting]

Title	Function	Adjustment range	Default setting
F260	Jog run frequency	F240~20.0 Hz	5.0
F26 1	Jog run stop pattern	☐:Deceleration stop, I: Coast stop, ≥:DC braking stop	0
F262	Operation panel jog run mode	☐:Disabled, I:Operation panel jog run mode enabled	0


<Examples of jog run (SW1 set to sink logic) >

S3-CC (JOG) ON + F-CC ON: Forward jog run

S3-CC (JOG) ON + R-CC ON: Reverse jog run

(Normal operation frequency signal input + F-CC ON: Forward run, Normal operation frequency signal input + R-CC ON: Reverse run)





- The jog run setting terminal (S3-CC) is enabled when the operation frequency is below the jog run frequency. This connection does not function at an operation frequency exceeding the jog run frequency.
- The motor can be operated in jog mode while the jog run setting terminals are connected (S3-CC: ON).
- Jog run has priority, even when a new operation command is given during operation.
- Even during panel operation ($\mathcal{E}\Pi\mathcal{B}d=1$), the inverter can be switched forcibly to jog run mode by turning on or off the input terminal if parameter $\mathcal{F}H\mathcal{B}$ (input terminal priority selection) is set to \mathcal{F} and the jog run setting function (\mathcal{F} 8, \mathcal{F} 9) is assigned to the input terminal.
- If a forward run command and a reverse run command are entered simultaneously while F !☐ 5 (priority selection (both F-CC and R-CC are ON)) is set to ☐ (reverse run), operation modes are switched as follows: forward jog run → deceleration stop (jog frequency → 0Hz) → reverse jog run. Keep this in mind.
- The jog frequency is not restricted by the upper limit frequency (!!!).

[Setting of jog run setting terminal (S3-CC)]

Assign control terminal S3 ([!4: preset speed 3] in default setting) as the jog run setting terminal.

Title	Function	Adjustment range	Example of setting
F 1 17	Input terminal function selection 7 (S3)	0~135	## (Jog run setting terminal)

Note: During the jog run mode, there is LOW (low speed detection signal) output but no RCH (designated frequency reach signal) output, and PID control does not work.

•When the inverter is in panel jog mode, pressing the (\(\inft\) key displays F J [] [, while pressing the (\(\inft\)) key displays r J [] [.

•When $F \cup G \cup G$ is displayed, the inverter will be placed in forward jog run mode as long as the Run key is held down.


•When $r \cup G \subseteq$ is displayed, the inverter will be placed in reverse jog run mode as long as the RUN key is held down.

•During jog run, the direction of rotation can be changed using the \int and \int keys. Press the \int key to run the motor in the forward direction, or press the \int key to run it in the reverse direction.

•If you press and hold down the (RUN) key for 20 seconds or more, the key failure alarm "E - 17" will be displayed.

The figure below shows the relationship between the operation panel jog run mode and each of the other modes.

Pressing the MODE key, which will move the inverter through each of the modes.



Note1: When the inverter is in operation (RUN key lamp is lit) or when an operation command is issued (RUN key lamp is lit), the inverter cannot be switched to operation panel jog run mode.

Note 2: When parameter F 105 (input terminal priority selection) is set to 1, the inverter does not display any message saying that it is in panel jog run mode.

6.11 Setting frequency via external contact input (Up/Down frequency setting)

F 2 6 4 : Input from external contacts - Up response time

F 2 5 5 : Input from external contacts - Up frequency step

F 2 6 6 : Input from external contacts - Down response time

F257 : Input from external contacts - Down frequency step

F 2 5 8 : Initial Up/Down frequency

F 2 5 9 : Initial Up/Down frequency rewriting

Function

These parameters are used to set the output frequency by means of a contact signal from the external control device.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F264	Input from external contacts - Up response time	0.0 ~ 10.0 s	0.1
F265	Input from external contacts - Up frequency step	<i>□.□ ~ F H</i> Hz	0.1
F266	Input from external contacts - Down response time	<i>□.□</i> ~ 1 <i>□.□</i> s	0.1
F267	Input from external contacts - Down frequency step	<i>□.□ ~ F H</i> Hz	0.1
F268	Initial Up/Down frequency	LL~ULHz	0.0
F269	Initial Up/Down frequency rewriting	☐:Not changed f:Setting of F ☐ E B changed when power is turned off.	1

These functions are operative when parameter $F \Pi \mathcal{G} d$ (frequency setting mode selection 1) is set to $I \mathcal{G}$ or parameter $F \mathcal{F} \mathcal{G} \mathcal{G}$? (frequency setting mode selection 2) is set to $I \mathcal{G}$.

■ Adjustment with continuous signals (Parameter setting example 1)

Set parameters as follows to adjust the output frequency up or down in proportion to the frequency adjustment signal input time:

Panel frequency incremental gradient = F 2 5 5/F 2 5 4 setting time


Panel frequency decremental gradient = F 2 5 7/F 2 5 5 setting time

Set parameters as follows to adjust the output frequency up or down almost in synchronization with the adjustment by the panel frequency command:

$$F264 = F266 = I$$

 $(RCC \text{ (or } F500)/FH) \le (F265/F264 \text{ setting time)}$
 $(dEC \text{ (or } F501)/FH) \le (F267/F266 \text{ setting time)}$

«Sample sequence diagram 1: Adjustment with continuous signals»



■ Adjustment with pulse signals (Parameter-setting example 2)


Set parameters as follows to adjust the frequency in steps of one pulse:

 $F \ge 5 \ \text{H}, F \ge 5 \ \text{B} \le \text{Pulse ON time}$

 $F \ge 5$, $F \ge 5$, T = 1 Frequency obtained with each pulse

* The inverter does not respond to any pulses with an ON time shorter than set with F 2 6 4 or F 2 6 5. 12ms or more of clearing signal is allowed.

«Sample sequence diagram 2: Adjustment with pulse signals»



■ If two signals are input simultaneously

- If a clear single and an up or down signal are input simultaneously, priority will be given to the clear signal.
- If up and down signals are input simultaneously, the frequency will be increased or reduced by the difference between the settings of F 2 5 5 and F 2 5 7. For example, if the F 2 5 5 setting is larger, the frequency will be increased by the value obtained by subtracting the setting of F 2 5 5 from that of F 2 5 7.

■ Setting of the initial Up/Down frequency

To adjust the frequency start at a specified frequency other than 0.0 Hz (default initial frequency) after turning on the inverter, specify the desired frequency using F 2 B 8 (initial Up/Down frequency).

■ Change of the initial Up/Down frequency

To make the inverter automatically save the frequency immediately before it is turned off and start operation at that frequency next time power is turned on, set $F \ge S$ (change of initial Up/Down frequency) to S = S = S (which changes the setting of $S \ge S = S$ when power is turned off).

Keep in mind that the setting of F ≥ 58 is changed each time power is turned off.

■ Frequency adjustment range

The frequency can be set from 0.0 Hz to FH (Maximum frequency). The lower limit frequency will be set as soon as the set frequency clearing function (function number 9.2, 9.3) is entered from the input terminal.

■ Minimum unit of frequency adjustment

If F 702 (Frequency free unit magnification) is set to 1.00, the output frequency can be adjusted in steps of 0.01Hz.

6.12 Jump frequency - jumping resonant frequencies

F270 : Jump frequency 1
F271 : Jumping width 1


F272 : Jump frequency 2

F273 : Jumping width 2
F274 : Jump frequency 3

F 2 75 : Jumping width 3

Function

Resonance due to the natural frequency of the mechanical system can be avoided by jumping the resonant frequency during operation. During jumping, hysteresis characteristics with respect to the jump frequency are given to the motor.



[Parameter setting]

Title	Function	Adjustment range	Default setting
F270	Jump frequency 1	0.0~F H Hz	0.0
F271	Jumping width 1	0.0~30.0 Hz	0.0
F272	Jump frequency 2	0.0~F H Hz	0.0
F273	Jumping width 2	0.0~30.0 Hz	0.0
F274	Jump frequency 3	0.0~F H Hz	0.0
F275	Jumping width 3	0.0~30.0 Hz	0.0

If the upper limit frequency (UL) is within jump frequency range, it is limited to the lowest frequency in the jump frequency range.


If the lower limit frequency (*L L*) is within jump frequency range, it is limited to the highest frequency in the jump frequency range.


Do not overlap upper limit frequency (UL) and lower limit frequency (LL) within jump frequency range.

If they are overlapped, it is operated lowest jump frequency.

Do not overlap two or more jump frequency ranges, or it cannot be operated within normal range.

During acceleration or deceleration, the jumping function is disabled for the operation frequency.





6.13 Preset speed operation frequencies

6.13.1 Preset speed operation frequency 8 to 15

F287 F294 : Preset speed operation frequencies 8 to 15

⇒ For details, refer to Section 5.12.

6.13.2 Forced operation control

F294 : Preset speed operation frequency 15 (Forced operation frequency)

• Function

Forced operation control is used when operating the motor at the specified frequency in case of an emergency. If forced operation control is assigned to the terminal board selection parameter and a forced operation control signal is given, the motor will be operated at the frequency specified with $F \ge 9 \text{ Y}$ (preset speed operation frequency 15). (When the input terminal board selection parameter is set to 5 B or 5 G.)

6.14 Trip-less intensification

6.14.1 Retry function

F 303 : Retry selection (selecting the no. of times)

⚠ Warning



· Stand clear of motors and equipment.

The motor and equipment stop when the alarm is given, selection of the retry function will restart them suddenly after the specified time has elapsed. This could result in unexpected injury.

 Take measures for safety, e.g. attach a cover to the motor, to prevent accidents if the motor suddenly restarts.

• Function

This parameter resets the inverter automatically when the inverter gives a trip. During the retry mode, the motor speed search function operated automatically as required and thus allows smooth motor restarting.

[Parameter setting]

Title	Function	Adjustment range	Default setting
FRAR	Retry selection (selecting the no. of times)	Π: Deselect. 1~ 1Π times	Π

The likely causes of tripping and the corresponding retry processes are listed below.

Cause of tripping	Retry process	Canceling conditions
Momentary power failure Overcurrent Overvoltage Overload	Up to 10 times in succession 1st retry: About 1 sec after tripping 2nd retry: About 2 sec after tripping 3rd retry: About 3 sec after tripping 10th retry: About 10 sec. after tripping	The retry function will be canceled at once if tripping is caused by an unusual event other than momentary power failure, overcurrent, overvoltage or overload. This function will also be canceled if a retry is not successful within the specified number of times.

Trips covered by the retry function

```
      • ### Inverted to Continuous Processing of the Continuous Processing Processin
```

The retry function is disabled in the following unusual events:

```
• ☐ [ R 1, 2, 3: Arm overcurrent at start-up
                                                       • EEP 1, 2, 3: EEPROM error
• EPH 1
              : Input phase failure
                                                       · E - - 2
                                                                      : Main RAM error
• EPHO
                                                       • E r r 3
                                                                      : Main ROM error
               : Output phase failure
• 0 E L
               : Loaded side overcurrent at start time
                                                       • E - - 4
                                                                      : CPU trip
• DH2
               : External thermal error
                                                       · E - - 5
                                                                      : Interruption of operation command from
• UE
               : Low current
                                                                       external control device
• UP 1
               : Voltage drop in main circuit
                                                       •Err5
                                                                      : Gate array fault
                                                       • Err 7
• # E
               : Overtorque
                                                                      : Output current detector error
• EF 1, EF ≥ : Ground fault
                                                       • E - - B
                                                                      : Optional unit error
               : Emergency stop
                                                       · E - 10~26
                                                       • Others (Other than trips covered by the retry function)
```

Protective operation detection relay signals (FLA, FLB, FLC terminal signals) are not sent during use of the retry function. (factory default setting)

A virtual cooling time is provided for overload tripping (GL I, GL Z, GL r).

 \Rightarrow See Section 13.2 for the virtual cooling time.

In this case, the retry function operates after the virtual cooling time and retry time.

In the event of overvoltage tripping ($GPI \sim GPI$), re-tripping may result unless the DC voltage decreases below a predetermined level.

In the event of overheating-caused tripping ($\mathcal{G}H$), re-tripping may result unless the internal temperature decreases below a predetermined level, since the internal temperature detection function of the inverter works.

Even when trip retention selection parameter (FSO2) is set to 1, the retry function is enabled by FSO3 setting. During retry the blinking display will alternate between $r \not\in r \not\subseteq S$ and the monitor display specified by parameter monitor display selection parameter FSO3 SO3

The number of retries will be cleared if the inverter is not tripped for the specified period of time after a successful retry.

"A successful retry" means that the inverter output frequency reaches the command frequency without causing the inverter to re-trip.

At the occurrence of a trip, the rotational speed of the motor is measured and, after the motor is restarted, it's speed is regulated to the speed measured.

6.14.2 Avoiding overvoltage tripping

F 305 : Overvoltage limit operation F 469 : Overvoltage limit constant


F 319 : Regenerative over-excitation upper F 626 : Overvoltage limit operation limit

Function

These parameters are used to automatically control the output frequency and prevent the motor from tripping because of overvoltage due to a rise in the voltage in the DC section during deceleration or constant speed operation. Note that the deceleration time may be prolonged when the overvoltage limiting function is activated.

When operating a motor in automatic torque boost mode or vector control mode (P = 2,3,4,7, or 8) at 200V-55kW or more and 400V-90kW or more models, if $F \ni 0 \ni 5$ set 2 or 3,this function same as $F \ni 0 \ni 5$ set 0.

Overvoltage limit operation level



[Parameter setting]

 r arameter setting				
Title	Function	Adjustment range	Default setting	
F 3 0 5	Overvoltage limit operation	☐:Enabled f:Disabled ∂:Enabled (quick deceleration) ∃:Enabled (dynamic quick deceleration)	2	
F 3 19	Regenerative over-excitation upper limit	1 🖟 🖟 🦟 % [Note]	140	
F469	Overvoltage limit constant	☐:Automatic	0	
F626	Overvoltage limit operation level	100~150 % [Note]	134	

Note: 100% corresponds to an input voltage of 200V for 200V models or to in an input voltage of 400V for 400V models.

If F305 is set to \mathcal{Z} (quick deceleration), the inverter will increase the voltage to the motor (over-excitation control) to increase the amount of energy consumed by the motor when the voltage reaches the overvoltage protection level, and therefore the motor can be decelerated more quickly than normal deceleration.

If $F \ni 0.5$ is set to 3 (dynamic quick deceleration), the inverter will increase the voltage to the motor (over-excitation control) to increase the amount of energy consumed by the motor as soon as the motor begins to slow down, and therefore the motor can be decelerated still more quickly than quick deceleration.

The parameter F319 is used to adjust the maximum energy that the motor consumes during deceleration, and if the inverter is tripped during deceleration because of an overvoltage, specify a larger value. When F305 is set 2 to 3.this function works.

Parameter *F* 453 is able to adjust the filter time constant of the overvoltage limitation.

This parameter is effective at only V/f control mode($P \not\models =0,1,5$).

Parameter F & 2 & serves also as a parameter for setting the regenerative braking level (see section 5.19.).

6.14.3 Output voltage adjustment/Supply voltage correction

: Base frequency voltage 1 (output voltage adjustment)

F 307 : Base frequency voltage selection (supply voltage correction)

• Function

Base frequency voltage 1 (output voltage adjustment)

Base frequency voltage selection (correction of supply voltage)

The F 3 0.7 parameter maintains a constant V/f ratio, even when the input voltage decreases. The torque during low-speed operation is prevented from decreasing.

OSupply voltage correction Maintains a constant V/f ratio, even when the input voltage fluctuates.

OOutput voltage adjustment Limits the voltage at frequencies exceeding the base frequency. Note that no limit is imposed on the output voltage if the supply voltage is not compensated.

[Parameter setting]

Title	Function	Adjustment range	Default setting
uLu	Base frequency voltage 1 (output voltage adjustment)	200V class: 50~330 V 400V class: 50~660 V	200V class: 200 400V class: 400
F307	Base frequency voltage selection (correction of supply voltage)	☐:Without voltage compensation (limitless output voltage) 1: With voltage compensation (limitless output voltage) 2: Without voltage compensation (limited output voltage) 3: With voltage compensation (limited output voltage)	a


If $F \ni G \uparrow$ is set to G or E, the output voltage will change in proportion to the input voltage.

Even if the base frequency voltage ($\underline{u} \ \underline{L} \ \underline{u}$) is set above the input voltage, the output voltage will not exceed the input voltage.


The rate of voltage to frequency can be adjusted according to the rated motor capacity. For example, setting $F \ni 0$ 7 to \exists prevents the output voltage from increasing, even if the input voltage changes when the operation frequency exceeds the base frequency.

When the V/f control mode selection parameter (PE) is set to any number between $Z\sim Y$ or $E\sim B$, the supply voltage is corrected regardless of the setting of $F\supset D$?.


[F 30 7=0: Supply voltage uncorrected, output voltage unlimited]



* The above applies when V/f control mode selection parameter $P \not\models$ is set to \mathcal{G} , \mathcal{I} or \mathcal{G} .




[F 30 7=2: Supply voltage uncorrected, output voltage limited]




*The above applies when V/f control mode selection parameter P \(\mathbb{E} \) is set to \(\mathbb{O} \), \(\mathbb{I} \) or \(\mathbb{E} \).

[F 30 7= 1: Supply voltage corrected, output voltage unlimited]



* Note that a voltage higher than u
otin u is applied at output frequencies over the base frequency u
otin v, even if u
otin u is set below the input voltage.

[F 30 7=3: Supply voltage corrected, output voltage limited]



uLu

Rated voltage

1 the output voltage can be prevented from exceeding the input voltage.

Note: Rated voltage is fixed for 200V class at 200V and 400V class at 400V.

6.14.4 Reverse run prohibition

F 3 1 1 : Reverse run prohibition selection

Function

This function prevents the motor from running in the forward or reverse direction when it receives the wrong operation signal.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F3	Reverse-run prohibition selection	☐:Permit all, /:Prohibit reverse run ⊋:Prohibit forward run	0

Warning!

- If an operation command is entered to rotate the motor in the direction prohibited for the preset speed operation with the mode or forced jog operation, this parameter will cancel the command regardless of operation mode.
- If the motor constant is not set properly while vector control mode or automatic torque boost mode is selected, the motor may turn in the reverse direction. The number of revolutions that correspond to the slip frequency, in these modes, therefore, the stop frequency (F 2 4 3) should be set at the same level as the slip frequency. In sensor vector control mode (P \(\mathbf{E} = 7, \(\mathbf{B} \)), depending on the setting of \(\mathbf{U}_U \(\mathbf{S} \), the motor restarted may rotate in the direction opposite to the prohibited direction regardless of the setting of this parameter.

6.14.5 Output voltage waveform selection

F3 13 : Output voltage waveform selection

• Function

It is an effective function only to the capacity of VFAS1-2550P and above, VFAS1-4900PC and above. The loss of the inverter is reduced a little by setting it to F \mathfrak{F} \mathfrak{F} \mathfrak{F} \mathfrak{F} , when using it with the career frequency raised (only as a guide 4kHz and above. However, some magnetic sounds from the motor is different and use it after confirming whether there is problem in noise.

[Parameter setting]

	arameter cetting				
	Title	Function	Adjustment range	Default setting	
	F313	Output voltage waveform	☐:PWM carrier frequency control 1	n	
		selection	: PWM carrier frequency control 2	u	

6.15 Drooping control

F320 : Drooping gain

F 32 1 : Speed at drooping gain 0%


F 322 : Speed at drooping gain F 320
F 323 : Drooping insensitive torque

F374 Describe sectors (1)

F 3 2 4 : Drooping output filter

Function

When multiple inverters and motors are used to operate a system, the load can distribute to them using this function. These parameters allow you to adjust the frequency range, and also insensitive torque and gain.



[Parameter setting]

Į	Title	Function	Adjustment range	Default setting
Ī	F320	Drooping gain [Note]	0.0~ 10 0.0 %	0.0
	F321	Speed at drooping gain 0%	0.0~320.0 Hz	0.0
ſ	F322	Speed at drooping gain F ∃ ⊋ □	0.0~320.0 Hz	0.0
ſ	F323	Drooping insensitive torque	0~100%	10
	F324	Drooping output filter	[]. 1~2 [] [].[] rad/s	100.0

Note: Drooping gain can be changed within a range of 0.1 to 100.0% during operation. When changing the setting to 0.0 (no drooping) or 0.0, stop operation.

- Drooping control can be performed only when P \(\mathbb{E} \) is set to $\(\frac{3}{3}, \, \frac{4}{3}, \, \ \ 7 \) or <math>\(\frac{8}{3} \)$.
- When torque over the insensitive torque is applied, the frequency is decreased (during power running) or increased (during regenerative braking).
- The drooping function is operative at frequencies over the frequency set with F 3 2 1.
- In the frequency range between the frequencies set with F 3 2 1 and F 3 2 2, the degree of drooping changes according to the magnitude of frequency.
- The error in drooping insensitive torque increases in the frequency range above the base frequency, and it is therefore recommended that these functions be used at frequencies below the base frequency.
- During drooping control, the output frequency is not restricted by the maximum frequency (F H).

The change in frequency at the time of drooping can be calculated, as described below:

```
a) Gain by internal torque reference (Gain1)
```

If internal torque reference (%) \geq 0

Gain1 = (internal torque reference - dead band F323) / 100

Gain1 needs to be set at 0 or a positive number.

If internal torque reference (%) < 0

Gain1 = (internal torque reference + dead band F323) / 100

Gain1 needs to be set at 0 or a negative number.

b) Gain by frequency after acceleration (Gain2)

If F321 < F322

| Frequency after acceleration | \leq Frequency 1 set with $\boxed{F321}$ Gain2 = 0

| Frequency after acceleration | > Frequency 2 set with | F322 | Gain2 = Drooping gain | F320 | / 100

If frequency 1 $\boxed{\textit{F321}}$ <| Frequency after acceleration | \leq Frequency 2 $\boxed{\textit{F322}}$

$$Gain2 = \frac{Drooping gain \boxed{\cancel{F329}}}{100} \times \left\{ \frac{(|Frequency after acceleration| - Frequency 1 \boxed{\cancel{F32!}})}{(Frequency 2 \boxed{\cancel{F322}} - Frequency 1 \boxed{\cancel{F32!}})} \right\}$$

If *F321* ≥ *F322*

| Frequency after acceleration | ≤ Frequency 1 set with F32!

If | Frequency after acceleration | > Frequency 1 F 32 1 Gain2 = Drooping gain F 32 0 / 100

c) Drooping speed

Drooping speed = base frequency $\boxed{\text{u.t.}}$ Note x Gain1 x Gain2

Note: If the base frequency exceeds 100 Hz, count it as 100 Hz.

6.16 Light-load high-speed operation function

F 3 2 B : Light-load high-speed operation F 3 3 5 : Switching load torque during selection

power running

F 3 2 9 : Light-load high-speed learning function

F336

: Heavy-load torque during power

runnina

F 3 3 11 : Automatic light-load high-speed operation frequency

F337

: Heavy-load torque during constant-speed power running

F331: Light-load high-speed operation F338: Switching load torque during switching lower limit frequency

regenerative braking

F 3 3 2 : Light-load high-speed operation

load waiting time

F 3 3 3 : Light-load high-speed operation

load detection time

F 3 3 4 : Light-load high-speed operation heavy load detection time

⇒ For details, refer to Instruction Manual (E6581327) specified in Section 6.42.

6. 17 **Braking function**

F340 : Creeping time 1

F 3 4 4 : Lowering torque bias multiplier F 3 4 5 : Brake release time

F 34 1 : Braking mode selection F 3 4 2 : Load portion torque input

F 3 4 5 : Creeping frequency

selection

F 3 4 7 : Creeping time 2

F 3 4 3 : Hoisting torque bias input

F 3 4 8 : Braking time learning function

Function

These parameters can be used as brake sequences for lifts and similar equipment.

To ensure smooth operation, the motor produces enough torque before the brake is released.


Title	Function	Adjustment range	Default setting
F340	Creeping time 1	0.00~2.50 sec.	D D
F341	Braking mode selection	☐:Disabled !:Forward winding up ☐:Reverse winding up ☐:Horizontal operation	0
F342	Load portion torque input selection	## Disabled #:VIII (voltage/current input) ## RR/S4 (potentiometer/voltage input) ## RX (voltage input) ## F F F F F F E enabled ## S-2-wire RS485 input enabled ## E S485 input enabled ## Communications option input enabled ## Optional AI1 (differential current input)	ч
F343	Hoisting torque bias input (valid only when F 引 せ ご= 4)	-250~250%	100
F344	Lowering torque bias multiplier	0~100%	100
F345	Brake release time	0.00~2.50 sec.	0.05
F346	Creeping frequency	F240~20.0 Hz	3.0
F347	Creeping time2	0.00~2.50 sec.	0.10
F348	Braking time learning function	☐:Disabled 1:Brake signal learning (0 after adjustment)	0

■ Starting procedure

At the run command, the inverter makes the motor produce the torque specified with parameter $F \ni 4 \ni 3$. As soon as a torque output command is issued, a brake release request signal is put out through the brake output terminal. Upon expiration of the brake release time set with $F \ni 4 \ni 5$, the motor starts to accelerate.

■ Stopping procedure

At the stop command, the operation frequency is decreased to the creep frequency set with parameter F 345, and put out the braking request after the creep time 1 set with F 340. And then, the creep frequency is maintained for the creep time set with F 347. While the creep frequency is maintained, the brake release signal is put out through the braking signal output terminal to apply the brake.



Ex.) When using the OUT1 terminal as the brake signal output terminal

Title	Function	Adjustment range	Example of setting
F 130	Output terminal function selection 1 (OUT1)	0~255	68

■ Learning function [F 3 4 8]

Using this function, rough settings can be made automatically and also parameters F 3 4 5, F 3 4 5 and F 3 4 7 can be set automatically.

After the learning function is set, F 3 4 2 will be set automatically to 4 and F 3 4 3 to 100. If necessary, fine adjust the parameter setting manually.

[Learning operation]

Set parameter F 3 4 8 to 1 and enter an operation command to start learning. (The frequency and "£ Un" are displayed alternately.)

Parameter $F \ni 4 \ni 3$ (torque) is set, the brake release timing is calculated, and parameter $F \ni 4 \ni 4 \ni 5$ (release time) is set based on the calculation result. $F \ni 4 \ni 6$ is set automatically according to the motor constant calculated. At the stop of operation, $F \ni 4 \ni 6$ (creep time) are set.

Note1: Learning should be performed under light-load conditions.

Note2: For the braking functions, the pre-excitation time is automatically determined by the inverter from motor-related constants

When the VFAS1-2037PL is used in combination with a Toshiba 4P-3.7kW-60Hz-200V standard motor, the preliminary excitation time is approximately 0.1 to 0.2 seconds.


Depending on the motor used, the preliminary excitation time may be prolonged.

Note 4: If a counterweight is provided, a learning error may occur. If so, make an adjustment manually.

Note 5: Brake learning ($F \ \exists \ \forall \ B = 1$) should be carried out for normal rotation if $F \ \exists \ \forall \ 1$ is set to $\ 1$ (forward winding), or for reverse rotation if $F \ \exists \ \forall \ 1$ is set to $\ 2$ (reverse winding).

■ Torque bias function

Using this function, the load can be started smoothly, by the motor produces enough torque for load portion before the brake is released,



[Selection of external signals]

Voltage signals — RR/S4-CCA - 0~10V (0~250%) 2

RX-CCA - 0~±10V (-250~250%) 3

V//II-CCA - 0~10V (0~250%) /

Current signals — V//II-CCA - 4(0)~20mA (0~250%) /

6.18 Acceleration/deceleration suspend function

F349 : Acceleration/deceleration F352 : Deceleration suspend frequency

suspend function $\boxed{F 353}$: Deceleration suspend time

F 350 : Acceleration suspend frequency
F 35 1 : Acceleration suspend time

• Function

Using these parameters, acceleration or deceleration can be suspended to let the motor run at a constant speed. There are two ways to suspend acceleration or deceleration: suspending it automatically by setting the suspend frequency and time using parameters, and suspending it by means of a signal from an external control device.

These parameters are useful in starting and stopping transfer equipment, textile machines (winders), and so on.

[Parameter setting]

Title	Function	Adjustment range	Setting value
F349	Acceleration/deceleration suspend function	☐:Disabled f:Parameter setting g:Terminal input	0
F350	Acceleration suspend frequency	<i>0.0∼F H</i> Hz	0.0
F351	Acceleration suspend time	<pre>0.0 ~ 10.0 sec.</pre>	0.0
F352	Deceleration suspend frequency	0.0~F H Hz	0.0
F353	Deceleration suspend time	[].[] ~ 1 [].[] sec.	0.0

Note1: The acceleration suspend frequency (F 3 5 Ω) should not be set below the starting frequency (F 2 4 Ω).


Note2: The deceleration suspend frequency ($F \ni 5 \ni 2$) should not be set below the stop frequency ($F \ni 3 \ni 2$).

Note3: If the output frequency is lowered by a stall prevention function, the acceleration suspend function may be activated.


1) To suspend acceleration or deceleration automatically

Set the desired frequency with F350 or F352 and the desired time with F351 or F353, and then set F349 to 1.

When the frequency set is reached, the motor stops accelerating or decelerating to rotate at a constant speed.



2) To suspend acceleration or deceleration by means of a signal from an external control device Set & 3 for the desired external signal input terminal. As long as ON signals are inputted, the motor continues to rotate at a constant speed.




Ex.) When using the RR/S4 terminal as the acceleration/deceleration suspend terminal

Title	Function	Adjustment range	Example of setting
F 1 18	Input terminal function selection 8 (RR/S4)	0~135	60

■ If the stall control function is activated during constant-speed rotation

The frequency drops momentarily as a result of stall control, but the time for which the frequency drops is included in the suspend time.



F 3 5 (Momentary acceleration (deceleration) suspend time) = (t1 + t2 + ts)

■ Stall control

Refers to the inverter's function of automatically changing the operation frequency when it detects an overcurrent, overload or overvoltage. Using the following parameters, you can specify the way, the stall control is performed for each kind of stall.

Overcurrent stall: F & D ! (Stall prevention level 1)

Overload stall : ## : ## (Electronic thermal protection characteristic selection)

Overvoltage stall: F 3 2 5 (Overvoltage limit operation)

Note: Setting the frequency command at the same frequency as the acceleration suspend frequency (F 350) disables the acceleration suspend function.

Similarly, setting the frequency command at the same frequency as the deceleration suspend frequency (F352) disables the deceleration suspend function.

6.19 Commercial power/inverter switching

F 354 : Commercial power/inverter switching output selection

F 355 : Commercial power/inverter switching frequency

F 356 : Inverter-side switching waiting time

F 35 7 : Commercial power-side switching waiting time

F 358 : Commercial power switching frequency holding time

• Function

These parameters are used to specify whether to send a switching signal to an external sequencer (such as an MC) in the event that the inverter trips. The use of an input signal makes it possible to switch between inverter operation and commercial power operation without stopping the motor.

⇒ For details, see Instruction Manual (E6581364) specified in Section 6.42.

[Parameter setting]


Title	Function	Adjustment range	Default setting
F354	Commercial power/inverter switching output selection	☐:Disabled i:Automatic switching in the event of a trip i:Commercial power switching frequency setting i:Commercial power switching frequency setting + automatic switching in the event of a trip [Note1]	a
F355	Commercial power/inverter switching frequency	<i>0~UL</i> Hz	[Note.3]
F356	Inverter-side switching waiting time	0.10~10.00 sec.	According to model ⇒ Refer to page K-46.
F357	Commercial power-side switching waiting time	0.40~10.00 sec.	0.6 ≥
F358	Commercial power switching frequency holding time	0.10~10.00 sec.	2.00

Note1: For trips whose causes are displayed with \mathcal{DLL} , \mathcal{EFL} or \mathcal{E} , switching is not done automatically.

Note2: Braking function F 3 4 1 doesn't operate.

Note3: Inverter with a model number ending with -WN, HN: 5 0.0 -WP: 5 0.0

[Timing chart (example)]



Commercial power switching signal S3-CC ON : Commercial power operation

Commercial power switching signal S3-CC OFF: Inverter operation Note: If ST-CC is opened, switching cannot be operated normally.

Title Function Adjustment range Example of setting F354 Commercial power/inverter switching output selection ∂ or 3 F 355 Commercial power/inverter switching frequency O~UL Hz Power supply frequency etc. According to model F356 Inverter-side switching waiting time 0.10~10.00 sec. ⇒ Refer to page K-46. F357 0.40~10.00 sec. 0.6 2 Commercial power-side switching waiting time F358 Commercial power switching frequency holding time O. 10~ 10.00 sec. 2.00 102 F 1 17 0~135 Input terminal function selection 7 (S3) (Commercial power switching) 46 F 130 Output terminal function selection 1 (OUT1) 0~255 (Commercial power/inverter switching output 1) 48 F 13 1 Output terminal function selection 2 (OUT2) 0~255 (Commercial power/inverter switching output 2)

- Warning

- When switching to commercial power, make sure that the direction in which the motor rotates when operated
 on commercial power agrees with the forward direction when operated via the inverter.
- Do not select any option (F 3 ! !=2) of F 3 !! (reverse rotation prohibition selection) that prohibits forward rotation. Or it becomes impossible to switch to commercial power, because the motor cannot rotate in the forward direction.

6.20 PID control

F 359 : PID control switching F368 : Process lower limit F 360 : PID control feedback control signal selection F 369 : PID control waiting time F 35 1 : Delay filter F 3 70 : PID output upper limit F 362 : Proportional (P) gain F 3 7 1 : PID output lower limit 363 : Integral (I) gain : Process increasing rate F 3 5 4 : PID deviation upper limit (speed type PID control) 755 : PID deviation lower limit F 3 7 3 : Process decreasing rate F 366 : Differential (D) gain (speed type PID control) F 36 7 : Process upper limit F 3 79 : PID output dead band

Function

Using feedback signals (4 to 20mA, 0 to 10V) from a detector, process control can be exercised, for example, to keep the airflow, amount of flow or pressure constant.


[Parameter setting]

Title	Function Adjustment range		Default setting
F359	PID control switching	### Control ### Co	
F360	F 3 5 0 PID control feedback control signal selection PID control feedback control signal selection PID control feedback control signal selection PID control feedback control signal 3:RX (voltage input) 3:RX (voltage input) 4:Optional Al1 (differential current input) 5:Optional Al2 (voltage/current input) 5:PG feedback option		a
F 3 6 1	Delay filter	0.0~25.0	0.1
F362	Proportional (P) gain	0.01~ 100.0	0.10
F 3 6 3	Integral (I) gain	0.0 1~ 100.0	0.10
F364	PID deviation upper limit	LL~UL Hz	*1
F365	PID deviation lower limit	LL~UL Hz	*1
F366	Differential (D) gain	0.00~2.55	0.00
F367	Process upper limit	LL~UL Hz	*1
F368	Process lower limit	LL~UL Hz	LL
F369	PID control waiting time	0~2400 sec.	G
F370	PID output upper limit	LL~UL Hz	*1
F371	PID output lower limit	LL~UL Hz	LL
F372	Process increasing rate (speed type PID control)	0.1~600.0	10.0
F373	Process decreasing rate (speed type PID control)	0.1~600.0	10.0
F379	PID output dead band	0~100	G

^{*1:} Inverter with a model number ending with -WN,HN: 5 @.@ -WP: 5 @.@

[⇒] For details, see instruction Manual(E6581329)specified in Section.

1) External connection



2) Types of PID control interface

Process value (frequency) and feedback value can be combined as follows for the PID control of the VF-PS1.

(1)Process value(frequency setting)	(2) Feedback value
Frequency setting mode selection FIIId/F207	PID control feedback control signal selection F 3 6 0
f:V/III (voltage/current input) 2:RR/S4 (potentiometer/voltage input) 3:RX (voltage input) 4:Operation panel input enabled (including LED/LCD option input) 5:2-wire RS485 communication input 6:4-wire RS485 communication input 7:Communication option input 8:Optional Al1 (differential current input) 9:Optional Al2 (voltage/current input) 10:UP/DOWN frequency 1 I:Optional RP pulse input 12:Optional high-speed pulse input	## Deviation input (no feedback input) ## It VI/II (voltage/current input) ## RE/RS/4 (potentiometer/voltage input) ## RE/RS/4 (potentiometer/voltage input) ## Coptional A11 (differential current input) ## Soptional A12 (voltage/current input) ## PG feedback option

Note 1: About the setting of FITT and F2T7: Do not select the same terminal that is used feedback terminal.

Note 2: The voltage/current changeover of the analog input VI/II and the option Al1 can be set by the parameter F 108 or F 109.

F 108, F 109 0:Voltage input (DC:0~10V) 1:current input (DC:4~20mA)

3) Setting the PID control

In case of controlling the airflow, water flow and pressure, please set the parameter *F 3 5 9* to " t"(Process type PID control operation)

(1)Please set the parameter $\mathcal{A} \in \mathcal{L}$ (Acceleration time), $\mathcal{A} \in \mathcal{L}$ (deceleration time) to the suitable time for the system. (2)Please set the following parameters to place limits to the setting value and the control value.

Placing a limit to the process value: The parameter F 3 & 7 (Process upper limit), F 3 & 8 (Process lower limit) Placing a limit to the PID deviation: The parameter F 3 & 4 (PID deviation upper limit), F 3 & 5 (PID deviation lower limit)

Placing a limit to the PID output: The parameter £3 70 (PID output upper limit), £3 7.1 (PID output lower limit)

Placing a limit to the output frequency: The parameter £1.2 (Upper limit frequency), £1.2 (Lower limit frequency)

4) Adjust PID control gain


Adjust PID control gains according to the process value, the feedback input signal and the item to be controlled. Here are the parameters used to adjust PID control gains.

Title	Function	Adjustment range	Default setting
F362	Proportional (P) gain	0.0 1~ 100.0	0.10
F363	Integral (I) gain	0.0 1~ 100.0	0.10
F366	Differential (D) gain	0.00~2.55	0.00

F352 Proportional (P) gain

The proportional (P) gain set with f362 is the proportional (P) gain obtained by PID control.


A proportional (P) gain, a factor by which the deviation (difference between the process value and the feedback value) is multiplied, is used to perform control in such a way as to make a correction in proportion to the deviation. Although setting this gain high is effective in increasing the response speed, setting it excessively high may cause an unstable operation, such as vibration.



F 3 6 3 Integral (I) gain

The integral (I) gain set with f363 is the integral (I) gain obtained by PID control.


The integral gain reduces the deviation remaining after proportional control to zero (offsetting of residual deviation). Although setting this gain high is effective in reducing the residual deviation, setting it excessively high may cause an unstable operation, such as vibration.



F 3 5 5. Differential (D) gain

The differential (D) gain set with f366 is the differential (D) gain obtained by PID control.

The differential gain increases the speed of response to rapid changes in deviation. If this gain is set excessively high, a phenomenon in which the output frequency greatly fluctuates may occur.




If one of input terminals is assigned input terminal function 52/53 (PID differentiation/integration reset), differential and integral values are always 0 (zero) during the input terminal on.


5) Adjusting the analog command voltage and current


For items which can be adjusted by reference and feedback input, such as voltage/current input (VI/II input),voltage input (RR/S4 input) and voltage input (RX input), adjust scaling factor of the voltage/current if necessary.

When feedback signals are very low, the gain can be increased by this adjustment.

When VI/II used as a voltage input terminal (Default setting)









When RR/S4 used as a voltage input terminal (Default setting)

When RX used as a voltage input terminal (Default setting)





The characteristic of the feedback value can also be reversed by means of a signal from an external device.

Example: To use the S3 terminal as a PID normal/reverse characteristic switching signal input terminal

Title	Function	Adjustment range	Default setting
FIIT	Input terminal function selection7(S3)	0~135	5 4 (positive logic) 5 5 (negative logic)

6) Setting the time elapsed before PID control starts

You can specify a waiting time for PID control to prevent the inverter from starting PID control before the control system becomes stable, for example, after start-up.

The inverter ignores feedback input signals, carries out operation at the frequency determined by the value of processing for the time specified by **F 369** and enters the PID control mode after a lapse of the specified time.

6.21 Stop position control function

F 3 7 5 : V/f control mode selection F 3 7 5 : Number of PG input pulses F 3 7 5 : Selection of number of PG

F 3 6 2 : PID control feedback control input phases

signal selection F 38 : Simple positioning

F 362 : Proportional (P) gain completion range

6.22 Setting motor constants

 F 400
 : Auto-tuning 1
 F 400
 : Motor rated rotational speed (motor nameplate)

 F 400
 : Slip frequency gain
 : Motor constant 1 (torque boost)

 F 400
 : Motor constant 2 (no-load current)

 F 400
 : Motor rated capacity (motor nameplate)
 F 410
 : Motor constant 3 (leak inductance)

 F 400
 : Motor rated current (motor nameplate)
 F 410
 : Motor constant 4 (rated slip)

When selecting automatic torque boost and vector control (i.e., when setting the parameter P_E to Z, Z, Z, Z, Z or Z. By default, Z is set to Z (v/f constant control)), be sure to set every parameter concerned in accordance with the flowchart on the next page.



The inverter is tuned automatically (auto-tuning $F \not G G = 2$) when the inverter is started for the first time after setup. During auto-tuning, which takes about 3 minutes from several seconds as each model, the motor is energized, although it is standing still.

0

Provide cranes and hoists with sufficient circuit protection such as mechanical braking. Without sufficient circuit protection, the resulting insufficient motor torque during tuning could create a risk of machine stalling/falling.

Mandatory

Be sure to set every parameter concerned in accordance with the flowchart on the next page. Failure to do this may cause the inverter not to control the motor properly, and therefore cause the motor not to deliver the desired performance.

[⇒] For details, see Instruction Manual (E6581319) specified in Section 6.42.

Type

Toshiba

standard


motor

Others

No. of motor poles

4P

Other than 4P



	ionoy or the rated			V
not set correctl settings.	d of the motor is ly. Check their	Check the precautions to n setting the auto tuning 1, and if no problem is fine F400 to 2 and start of	parameter to ound, then set	Make necessary settings, as specified in (1) Setting auto-tuning.
or <i>F</i> ∀ 🖟 7, and				End
F 400 to 4 a			or YE	-6
, ,00 ,	· 5	Ent 10		:5
	▼	Ent 2 is disp	played.	
The College Street				
been calculate	parameters have	No I	*4	
F 4 17 Motor				▼
F4 1 1 Motor		F4 [] and F4 d	have been	Parameters F 4 1 1 and
F417 Motor		tuned to the motor of	connected.	F Y 1 ≥ use the value
FY 13 Motor				calculated automatically by the
, , , , ,				
		▼		★
		_l End		End
		Liid		Liid
1:				
	Motor used		T	Tuning required or not

(Yes in flowchart: Tuning required, No: Tuning not required)

* Not required (tuned to factory defaults)

Required

Capacity

Different from the inverter capacity

Different from the inverter capacity

Same as the inverter capacity

Same as the inverter capacity

^{*} When using a long cable (guide: 30m or over), be sure to make auto-tuning 1 (F Ч □ □ = 2).

(1) Setting auto-tuning

This auto tuning function allows you to set the motor constant easily, which needs to be set when operating in auto torque boost mode or vector control mode (P = 2, 3, 4, 7 or 8).

There are two parameters ($F \lor UU$) and $F \lor UU$ described below) for auto tuning. For the steps to be followed when setting these parameters, see the flowchart on the previous page. This section provides an explanation of $F \lor UU$ and $F \lor UU$?

[Parameter setting]

Title	Function	Adjustment range	Default setting
F400	Auto-tuning 1	 ♂:No auto-tuning f:Initialize motor constant (☐ after execution) ♂:Continue operation continued after auto-tuning (☐ after execution) づ:Auto-tuning by input terminal signal(☐ after execution) f:Motor constant auto calculation (☐ after execution) 	a

- F 4 0 0 = 1: Resets F 4 10 (motor constant 1), F 4 1 1 (motor constant 2), F 4 12 (motor constant 3) and F 4 13 (motor constant 4) to their factory default settings (constant of a Toshiba standard four-pole motor with the same capacity as the inverter).
- F Y [] [] = 2: Makes the inverter tune the motor constant, considering how the motor is connected, when it is started for the first time after this setting is made. Connect the motor to the inverter in advance when selecting this setting.
- F 4 0 0 = 3: Makes the inverter only tune the motor constant, unlike F 4 0 0 = 2. Connect the motor to the inverter in advance when selecting this setting.

 This function operates when "ST" signal and "Auto-tuning" signal became active.

(Use this setting if the machine cannot be started as-is after tuning for some reason on the part of the machine.)

F Y D D = Y: If you select this setting after entering the information indicated on the motor nameplate (u L (base frequency), u L u (base frequency voltage), F Y D B (rated current of motor), F Y D T (rated speed of rotation of motor)), the inverter will calculate the motor constant and set the parameters F Y 1 D through F Y 13 automatically.

There is no need to connect the motor when making this setting.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F402	Auto-tuning 2	☐:Disabled 1:Self-cooled motor 2:Forced-air-cooled motor	0

Auto-tuning 2 refers to the function of adjusting the motor constant automatically, while estimating the increase in the motor temperature.

If your inverter is equipped with a self-cooling fan (fan connected directly to the motor shaft), set $F \not\in \mathcal{U} \supseteq \mathcal{U}$ to \mathcal{U} . When using a motor with a cooling fan (forced air-cooling type), set $F \not\in \mathcal{U} \supseteq \mathcal{U}$ to \mathcal{U} .

- Perform auto-tuning 2 along with auto-tuning 1.
- Perform auto-tuning when the motor is cold (temperature equal to the ambient temperature).
 - Precautions on auto-tuning 1
 - (1) The inverter is tuned automatically (auto-tuning 1 F 400 = 2) when the inverter is started for the first time after setup. During auto-tuning 1, which takes about 3 minutes from several seconds, the motor is energized, although it is standing still. Noise may be produced by the motor during auto-tuning 1, which, however, does not indicate that something is wrong with the inverter or the motor.
 - (2) Conduct auto-tuning 1 (F Ч 🖫 🖫 = ₹) only after the motor has been connected and operation completely stopped.
 - If auto-tuning is conducted immediately after operation stops, the presence of a residual voltage may result in abnormal tuning.
 - (3) Usually, auto-tuning terminates into 3 minutes from several seconds as each model. If an error occurs, however, the inverter trips (display \(\xi \xi \xi \)) and no motor constant is set. For these motors, perform manual tuning using (2) described below.
 - (4) It may not be possible to tune automatically special motors such as high-speed motor or high-slip motor. For these motors, perform manual tuning using (2) described below.
 - (5) Provide cranes and hoists with sufficient circuit protection such as mechanical braking. Without sufficient circuit protection, the result of insufficient motor torque during tuning could create the risk of the machine stalling/failing.
 - (6) If auto-tuning is impossible or an auto-tuning error (E \(\mu_n \)) is displayed, perform manual tuning with (2) described below.
 - Precautions on vector control ⇒ Refer to Section 5.6,9).

■ Examples of setting the motor constants

a) Combination with a Toshiba standard motor (4P motor with the same capacity as the inverter)

Inverter: VFAS1-2037PL Motor: 3.7kW-4P-60Hz

1) Set the V/f control mode selection P & at 3 (Sensorless vector control).

2) Set the auto-tuning 1 (F Ч 🗓 🗓) at ⊋. (When the cable length is 30m or over.)

b) Combination with a standard motor other than the above Toshiba motor

Inverter: VFAS1-2037PL Motor: 2.2kW-2P-50Hz

1) Set the V/f control mode selection P + at 3 (Sensorless vector control).

2) Set UL, UL, F405, F406 and F407, as specified on the motor nameplate.

- 3) Set the auto-tuning 1(F \(\frac{1}{12} \) \(\frac{1}{2} \) at \(\frac{1}{2} \).
- 4) Set the auto-tuning 1 (F Y [] []) at 2.

(2) Setting sensorless vector control and manual independently Setting motor constants

Perform all operations in the flowchart on the previous page. If the motor specifications are unknown, enter only the motor capacity ($F \lor 0.5$) and set parameter $F \lor 0.0$ to \lor . After that, run the motor and set other parameters with the following explanation about parameter adjustments as a guide.

Setting motor parameters are necessary when Pt is set at 2, 3, 4, 7 or 8.

(1) Slip frequency gain F 4 [] 1

This parameter is to adjust the slippage of the motor.

Setting this parameter at a larger number can reduce the slippage of the motor. However, setting it at an excessively large number may result in hunting, etc., and thus cause an unstable operation.

(2) Motor constant 1 F 4 1 (Torque boost) (Motor test reports may be useful.)

This parameter is to adjust the primary resistance of the motor. Setting this parameter at a larger value can prevent the drop of the motor torque in low speed ranges due to a voltage drop. However, setting it at an excessively large number may result in large current in low speed range and appearance of an overload trip, etc.

- (3) Motor constant 2 F Y I I (No-load current) (Motor test reports may be useful.) This parameter is to adjust the exciting inductance of the motor. The larger the set value, the more exciting current can be increased. Note that specifying a too large value for the motor constant may cause hunting.
- (4) Motor constant 3 F Ч 1 ₹ (Leak inductance) (Motor test reports may be useful.) This parameter is to adjust the leakage inductance of the motor. The larger the set value, the larger torque the motor can produce in high-speed ranges.
- (5) Motor constant 4 F 4 13 (Rated slip)

This parameter is to adjust the secondary resistance of the motor. The amount of compensation for slip increases with increase in this value.

(6) F 4 5 C (Speed loop proportional gain)

This parameter is to adjust the gain responsive to speed. Specifying a large gain increases the speed of response, but specifying an excessively large gain may result in the occurrence of hunting. If operation is unstable and hunting occurs, operation can be stabilized in most cases by reducing the gain.

(7) F 4 € 2 (Moment of inertia of load)

This parameter is used to adjust the excess response speed. Specifying a large value reduces the amount of overshoot at the completion of acceleration. So, specify a value appropriate to the actual moment of inertia of the load.

6.23 Increasing the motor output torque further in low speed range

F 4 15 : Exciting strengthening coefficient

F 4 15 : Stall prevention factor

The output torque of the motor can adjusted using the parameters described in 6.22 in most cases, but if a finer adjustment is required, use these parameters.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F4 15	Exciting strengthening coefficient	100~130%	100
F4 15	Stall prevention factor	10~250	100

If the torque needs to be increased in low speed range (10Hz or less as a guide)

Perform auto-tuning according to the instructions in 6.22, and if the torque needs to be increased further in low speed range, first increase the slip frequency gain ($F \lor D \lor 1$) to a degree (80% or so as a guide) that hunting of the motor does not occur. Then, increase motor constant 1 ($F \lor D \lor 1$) by 1.1 times the current value as a guide. If the torque needs to be increased even further, increase the exciting current factor ($F \lor D \lor 1$) to a maximum of 130%. $F \lor D \lor 1$ is a parameter that increases the magnetic flux of the motor at low speeds, so specifying a higher value for $F \lor D \lor 1$ increases the no-load current. If the no-load current exceeds the rated current, do not adjust this parameter.

If the motor stalls when operated at frequencies above the base frequency Adjust F 4 f F (stall prevention factor).

If a heavy load is applied momentarily (transiently), the motor may stall before the load current reaches the stall prevention level (F & C 1). In such a case, a motor stall may be avoided by reducing the value of F 4 15 gradually.

6.24 Torque control

⇒ For details, refer to Instruction Manual (E6581331) specified in Section 6.42.

6.24.1 Torque command

: V/f control mode selection F4771: Torque command selection F 2 1 : VI/II input point 1 setting F 2 0 5 : VI/II input point 1 rate FPDE: VI/II input point 2 rate F203 : VI/II input point 2 setting F2 14 : RR/S4 input point 1 rate F 2 10 : RR/S4 input point 1 setting F2 12 : RR/S4 input point 2 setting F 2 15 : RR/S4 input point 2 rate F220 : RX input point 1 rate F 2 16 : RX input point 1 setting F2 18 : RX input point 2 setting F221 : RX input point 2 rate F 2 2 B : Al2 input point 1 setting F42 | : Torque reference filter F230 : Al2 input point 2 setting F 4 5 5 : Torque reference polarity selection F435 : Prohibition of rotation in any direction other than the specified one (F or R) F 725 : Opelation panel torque command

⇒ For details, refer to Instruction Manual (E6581331) specified in Section 6.42.

6.24.2 Speed limits in torque control mode


F 425 : Forward speed limit input selection F 430 : Speed limit (torque=0) center value reference selection

F 427 : Reverse speed limit input selection F 431 : Speed limit (torque=0) center value

F 428 : Reverse speed limit input level F 432 : Speed limit (torque=0) band

[⇒] For details, refer to Instruction Manual (E6581331) specified in Section 6.42.

6.24.3 Selection of tension torque bias input and load sharing gain input



[Parameter setting]

Title	le Function Adjustment range		Default setting
F423	Tension torque bias input selection	☐:Disabled f:VI/II (voltage/current input) Z:RR/S4 (potentiometer/voltage input) ∃:RX (voltage input) 4:Operation panel input enabled (including LED/LCD option input) 5:2-wire RS485 input enabled 5:4-wire RS485 input enabled 7:Communication option input enabled 8:Optional Al1 (Differential current input)	O
F727	Control panel tension torque bias	-250~250%	O
F424	☐:Disabled f:VI/II (voltage/current input) ☐:RR/S4 (potentiometer/voltage input) ☐:RX (voltage input) ☐:RV:Operation paged input enabled (including		9
F728	Control panel load sharing gain	0~250%	100

[Selection of external signals]



6.25 Torque limit

6.25.1 Torque limit switching

F 440 : Power running torque limit 1 F 446 : Power running torque limit 3 selection

F 44 1 : Power running torque limit 1 F 44 7 : Regenerative braking torque

F 4 4 2 : Regenerative braking torque F 4 4 8 : Power running torque limit 4

F 443 : Regenerative braking torque F 449 : Regenerative braking torque limit 1 level

F 444 : Power running torque limit 2 F 454 : Constant output zone torque

F 4 4 5 : Regenerative braking torque


Function

This function is to decrease or increase the output frequency according to the loading condition when the motor torque reaches the limit level. Setting a torque limit parameter at 250% means "Invalid." With this function, you can also select from between limiting the constant output or limiting the constant torque in the constant output zone.

This function is not operate when the parameter P = 0, 1.5 setting.

■ Setting methods

(1) When setting limits to torque, use internal parameters (Torque limits can also be set with an external control device.)



With the parameter $F \ 45 \ 4$, you can select the item that is limited in the constant output zone (somewhat weak magnetic field) from between constant output ($F \ 45 \ 4=1$). When you select the constant torque limit option, you should preferably select the output voltage limit option ($F \ 30 \ 7=3$) with the parameter $F \ 30 \ 7$ (base frequency voltage selection).

[Setting of power running torque]

F 4 4 0 (Power running torque limit 1 selection) : Set at 4 (F 4 4 1)

F44 (Power running torque limit 1) : Set a desirable torque limit level.

[Setting of regenerative torque]

F442 (Regenerative braking torque limit 1 selection) : Set at 4 (F443)

F443 (Regenerative braking torque limit 1) : Set a desirable torque limit level.

[Parameter setting]


Ī	Title	Function Adjustment range		Default setting
ŀ	ritie	FUICUOII	Aujustment range	Delault Setting
	F440	Power running torque limit 1 selection	 ::VI/II (voltage/current input) ≥:RR/S4 (potentiometer/voltage input) 3:RX (voltage input) 4:F 44 1 	ч
I	F441	Power running torque limit 1 level	□.□~249.9 % 250.0 %:Disabled	250.0 %
	F442	Regenerative braking torque limit 1 selection	1:VI/II (voltage/current input) 2:RR/S4 (potentiometer/voltage input) 3:RX (voltage input) 4:F443	ч
I	F443	Regenerative braking torque limit 1 level	0.0~249.9 % 250.0 %:Disabled	250.0 %
Ī	F454	Constant output zone torque limit selection	☐ : Constant output limit I : Constant torque limit	0

Using parameters, four different torque limits can be set for each operating status: power running and regenerative braking. Refer to Section 7.2.1 for the setting for switching from the terminal board.


Power running torque limit $1 - F \lor \lor \lor \lor$ Power running torque limit $2 - F \lor \lor \lor \lor$ Regenerative braking torque limit $2 - F \lor \lor \lor \lor$ Power running torque limit $3 - F \lor \lor \lor \lor$ Regenerative braking torque limit $3 - F \lor \lor \lor \lor$ Power running torque limit $4 - F \lor \lor \lor \lor$ Regenerative braking torque limit $4 - F \lor \lor \lor \lor$

Note: If the value set with F 5 0 1 (stall prevention level) is smaller than the torque limit, then the value set with F 5 0 1 acts as the torque limit.

(2) When setting limits to torque, using external signals



The torque limits can be changed arbitrarily by means of external signals.



[Parameter setting]

٠.	arameter setting				
	Title	Function	Adjustment range	Default setting	
	F440	Power running torque limit 1 selection	#:VI/II (voltage/current input) ≥:RR/S4 (potentiometer/voltage input) 3:RX (voltage input) ザ:チャット	4	
	F442	Regenerative braking torque limit 1 selection	#:VI/II (voltage/current input) 2:RR/S4 (potentiometer/voltage input) 3:RX (voltage input) 4:F443	ч	

In torque control mode, the values set with these parameters limit torque command values.

6.25.2 Torque limit mode selection at acceleration/deceleration

F 45 ! : Acceleration/deceleration operation after torque limit

Function

Using this function in combination with the mechanical brake of the lifting gear (such as a crane or hoist) makes it possible to minimize the delay before the brake starts working, and thus prevents the load from falling because of a decrease in torque.


Moreover, it improves the motor's response during inching operation and keeps the load from sliding down.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F451	Acceleration/deceleration operation after torque limit	### To some state of the state	0


(1) F 45 !=# (In sync with acceleration/deceleration)

The increase in operation frequency is inhibited by the activation of the torque limit function. In this control mode, therefore, the actual speed is always kept in sync with the operation frequency. The operation frequency restarts to increase when torque decreases as a result of the release of the mechanical brake, so the time required for the specified speed to be reached is the sum of the delay in operation of the mechanical brake and the acceleration time.



(2) F 45 != !(In sync with min. time)

The operation frequency keeps increasing, even if the torque limit function is activated. In this control mode, the actual speed is kept in sync with the operation frequency, while torque is held at a limit level when it decreases as a result of the release of the mechanical brake. The use of this function prevents the load from failing and improves the motor's response during inching operation.



6.26 Stall prevention function

6.26.1 Power running stall continuous trip detection time


F 452 : Power running stall continuous trip detection time

Function

A function for preventing lifting gear from failing accidentally. If the stall prevention function is activated in succession, the inverter judges that the motor has stalled and trips.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F452	Power running stall continuous trip detection time	□.□~ 1.□ sec.	0.0



6.26.2 Regenerative braking stall prevention mode selection

F453 : Regenerative braking stall prevention mode selection

Function

A function for preventing lifting gear from stopping in the wrong position. Only the function of preventing a stall by maintaining the current constant during regenerative braking (deceleration stop) is deactivated.

[Parameter setting]

- 2	tameter cetting]			
	Title	Function	Adjustment range	Default setting
	F453	Regenerative braking stall prevention	☐:Stall during regenerative braking	n
	ככרי	mode selection	:Not stall during regenerative braking	u

6.26.3 Stall prevention control switching

F458 : Stall prevention control switching

Function

The operation of the stall prevention control can be switched. Set $F \ 458 = 1$ when the overvoltage trip etc. are lisplayed when acceleration and the deceleration are switched.

This parameter is effective at only V/f control mode(P = 0,1,5).

[Parameter setting]

Title	Function	Adjustment range	Default setting
F468	Stall prevention control switching	: Stall prevention control : Stall prevention control 2	0

6.27 Current and speed control adjustment

6.27.1 Current and speed control gain

F458 ~ F466 : Current and speed control gain

⇒ For details, refer to Instruction Manual (E6581333) specified in Section 6.42.

6.27.2 Prevention of motor current oscillation at light load

F457: Motor oscillation control

Function

When a motor is in unstable with light load, this parameter can change the motor gain to make motor condition stable. First set $F \not\in G$ and check the motor condition. Please set G to G in case motor needs more stable condition. This parameter is effective only in V/F control mode (G) to G).

[Parameter setting]

įi didinotoi sot	91		
Title	Function	Adjustment range	Default setting
F467	Motor oscillation control	0:Disabled 1:Enabled(Low gain) 2:Enabled(Middle gain) 3:Enabled(High gain)	0

6.27.3 Max output voltage modulation rate

F 4 9 5 : Max output voltage modulation rate

• Function

In the case that Inverter output voltage drops and output current exceeds motor rating current at the frequency higher than base frequency, Change this parameter setting and check whether the output current is reduced.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F495	Max output voltage modulation rate	0:Standard 1:100% 2:102.5% 3:105%	0

6.28 Fine adjustment of frequency setting signal


F470: VI/II input biasF475: RX input gainF471: VI/II input gainF475: Optional Al1 input biasF472: RR/S4 input biasF477: Optional Al2 input biasF477: RX input biasF479: Optional Al2 input gain

Function

These parameters are used to fine adjust the relation between the frequency setting signal input through the analog input terminal and the output frequency.

Use these parameters to make fine adjustments after making rough adjustments using the parameters F 20 1-F 23 1.

The figure below shows the characteristic of the frequency setting signal input through the analog input terminal and that of the output frequency.



Bias adjustment of analog input terminals (F 4 70, F 4 72, F 4 74, F 4 75, F 4 78)

To give leeway, the inverter is factory-adjusted by default so that it will not produce an output until a certain amount of voltage is applied to the analog input terminals.

To reduce leeway, decrease the bias of the analog terminal in use.

Note that specifying a too large value may cause an output frequency to be output, even though the operation frequency is 0 (zero) Hz.

Gain adjustment of analog input terminals (F471, F473, F475, F477, F479)

The inverter is factory-adjusted by default so that the operation frequency can reach the maximum frequency, even though the voltage and current to the analog input terminals are below the maximum levels.

To make an adjustment so that the frequency reaches its peak value at the maximum voltage and current, decrease the gain of the analog terminal in use.

Note that specifying a too small value may cause the operation frequency not to reach the maximum frequency, even though the maximum voltage and current are applied.

6.29 Operating a synchronous motor

F498, F499 : PM motor constant 1
F540, F541 : Step-out detection current level/detection time

This parameter is used only when the inverter is used with a synchronous motor. If you intend to use your inverter with a synchronous motor, contact us at the your supplier.

6.30 Acceleration/deceleration 2

6.30.1 Setting acceleration/deceleration patterns and switching

acceleration/deceleration patterns 1, 2, 3 and 4

F500 : Acceleration time 2 F509 : Deceleration S-pattern upper limit adjustment

F501: Deceleration time 2

F502: Acceleration/deceleration 1 pattern

F501: Deceleration time 3

F503 : Acceleration/deceleration 2 pattern F512 : Acceleration/deceleration 3 pattern

F 5 0 4 : Panel acceleration/deceleration selection | F 5 1 3 : Acceleration/deceleration switching frequency 2

F505 : Acceleration/deceleration switching frequency 1 F5 14 : Acceleration time 4
F506 : Acceleration S-pattern lower limit adjustment F5 15 : Deceleration time 4

F507: Acceleration S-pattern upper limit adjustment F5 15: Acceleration/deceleration 4 pattern

F508 : Deceleration S-pattern lower limit adjustment F517 : Acceleration/deceleration switching frequency 3

Function

Four acceleration times and four deceleration times can be specified individually. The selection/switching mode can be selected from the following 3 options:

- 1) Selection by means of parameters
- 2) Switching by means of frequencies
- 3) Switching by means of terminals


[Parameter setting]

Title	Function	Adjustment range	Default setting
F500	Acceleration time 2	☐. /[Note]~ ☐ ☐ ☐ ☐ sec.	According to model
F50 I	Deceleration time 2	☐. /[Note]~ ☐ ☐ ☐ ☐ sec.	According to model
F504	Panel acceleration/deceleration selection	1:Acceleration/deceleration 1 2: Acceleration/deceleration 2 3: Acceleration/deceleration 3 4: Acceleration/deceleration 4	t
F5 10	Acceleration time 3	☐. /[Note]~ ☐ ☐ ☐ ☐ sec.	According to model
F5 1 1	Deceleration time 3	☐. /[Note]~ ☐ ☐ ☐ ☐ sec.	According to model
F5 14	Acceleration time 4	☐. /[Note]~☐☐☐☐ sec.	According to model
F5 15	Deceleration time 4	☐. I[Note]~ ☐ ☐ ☐ ☐ sec.	According to model

Note: The minimum setting of acceleration and deceleration times have been set respectively at 0.1 sec. by default, but they can be changed within a range of 0.01 sec. (setting range:0.01~600.0 sec.) by changing the setting of the parameter £ \$P\$ (default setting).

⇒ For details, refer to Section 5.20.

1) Selection using parameters




Acceleration/deceleration time 1 is initially set as the default. Acceleration/deceleration time 2, 3 and 4can be selected by changing the setting of the $F \subseteq \mathcal{U}$ \mathcal{U} .

Enabled if $[\ \Pi \ \Pi \ d = I \ (operation panel input enabled).$


2) Switching by frequencies - Automatically switching acc/dec times at certain frequencies

Title	Function	Adjustment range	Default setting
F505	Acceleration/deceleration switching frequency 1	0.0~F # Hz	0.0
F5 13	Acceleration/deceleration switching frequency 2	0.0~F # Hz	0.0
F5 17	Acceleration/deceleration switching frequency 3	<i>0.0∼F H</i> Hz	0.0

Note: Regardless of the sequence of input of frequencies, acc/dec times are switched from 1 to 2 at the lowest frequency, from 2 to 3 at the middle frequency and from 3 to 4 at the highest frequency. (For example, if the frequency set with F 5 0 5 is higher than that set with F 5 13, the acc/dec time 1 is selected in the frequency range below the F 5 13-set frequency, while the acc/dec time 2 is selected in the frequency range of the F 5 13-set frequency to the F 5 05-set frequency.)



- (1) Acceleration at the gradient corresponding to acceleration time REE
- (2) Acceleration at the gradient corresponding to acceleration time F 5 0 0
- (3) Acceleration at the gradient corresponding to acceleration time F 5 10
- (4) Acceleration at the gradient corresponding to acceleration time F 5 14
- (5) Deceleration at the gradient corresponding to deceleration time F 5 15
- (6) Deceleration at the gradient corresponding to deceleration time F 5 1 1
- (7) Deceleration at the gradient corresponding to deceleration time F 5 D 1
- (8) Deceleration at the gradient corresponding to deceleration time dEE
- 3) Switching using external terminals Switching the acceleration/deceleration time via external terminals



- Acceleration/deceleration
- to acceleration time R [[
- (2) Acceleration at the gradient corresponding (6) Deceleration at the gradient corresponding to acceleration time F 5 0 0
- to acceleration time F 5 10
- to acceleration time F 5 14
- (1) Acceleration at the gradient corresponding (5) Deceleration at the gradient corresponding to deceleration time F 5 15
 - to deceleration time F 5 1 1
- (3) Acceleration at the gradient corresponding (7) Deceleration at the gradient corresponding to deceleration time F 5 D 1
- (4) Acceleration at the gradient corresponding (8) Deceleration at the gradient corresponding to deceleration time AFF

- Setting parameters
- a) Operating method: Terminal input
 Set the command mode selection [\(\Pi \) \(\Pi
- b) Use the S2 and S3 terminals for switching. (Instead, other terminals may be used.)
 - S2: Acceleration/deceleration switching signal 1
 - S3: Acceleration/deceleration switching signal 2

Title	Function	Adjustment range	Example of setting
F 1 15	Input terminal function selection 6 (S2)	0~135	군 년 (Acceleration/deceleration switching signal 1)
FIIT	Input terminal function selection 7 (S3)	0~135	∠E (Acceleration/deceleration switching signal 2)

■ Acceleration/deceleration pattern

Acceleration/deceleration patterns can be selected individually, using the acceleration/deceleration 1, 2, 3 and 4 parameters.


- 1) Straight acceleration/deceleration
- 2) S-pattern acceleration/deceleration 1
- 3) S-pattern acceleration/deceleration 2

	3) 3-pattern acceleration/deceleration 2			
Title	Function	Adjustment range	Default setting	
F502	Acceleration/deceleration 1 pattern	☐:Straight, 1:S-pattern 1, ☐:S-pattern 2	G	
F503	Acceleration/deceleration 2 pattern	☐:Straight, 1:S-pattern 1, ☐:S-pattern 2	0	
F506	Acceleration S-pattern lower limit adjustment	<i>0</i> ~5 <i>0</i> %	10	
FSOT	Acceleration S-pattern upper limit adjustment	0~50%	10	
F508	Deceleration S-pattern lower limit adjustment	0~50%	10	
F509	Deceleration S-pattern upper limit adjustment	0~50%	10	
F5 12	Acceleration/deceleration 3 pattern	☐:Straight, 1:S-pattern 1, ☐:S-pattern 2	0	
F5 15	Acceleration/deceleration 4 pattern	☐:Straight, 1:S-pattern 1, 2:S-pattern 2	0	

1) Straight acceleration/deceleration


A general acceleration/deceleration pattern.

This pattern can usually be used.



2) S-pattern acceleration/deceleration 1


Select this pattern to accelerate/decelerate the motor rapidly to a high-speed region with an output frequency of 60Hz or more or to minimize the shocks applied during acceleration/deceleration. This pattern is suitable for conveyer machines.



Both the S-pattern lower-limit setting ($F S \mathcal{D} B$, $F S \mathcal{D} B$) and the S-pattern upper limit setting ($F S \mathcal{D} 7$, $F S \mathcal{D} 9$) affect all acceleration/deceleration pattern settings.

3) S-pattern acceleration/deceleration 2

Select this pattern to obtain slow acceleration in a demagnetizing region with a small motor acceleration torque. This pattern is suitable for high-speed spindle operation.



6.31 Pattern operation

F520 : Pattern operation selection

F52 : Pattern operation mode

F522, F531: Number of repetitions of pattern group 1, 2

F523 ~ F530 : Pattern group 1 selection 1~8

F532 ~ F539 : Pattern group 2 selection 1~8

F 5 4 0 ~ F 5 5 4 : Speed 1~15 operation time

Function

These parameters allow you to combine a maximum of 30 operation frequencies, operation time and acceleration/deceleration time (15 combinations of parameters x 2 patterns) for automatic pattern operation by means of the terminal board.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F520	Pattern operation selection	☐:Disabled, f:Enabled (setting in seconds) F:Enabled (setting in minutes)	0
F521	Pattern operation mode	☐:Pattern operation reset when system stops operation 1:Pattern operation continued even after system stops operation	a
F522	Number of repetitions of pattern group 1	1~254, 255:Successive	1
F523~F530	Pattern group 1 selection 1~8	☐:Skip, 1~15	0
F531	Number of repetitions of pattern group 2	1~254, 255:Successive	1
F532~F539	Pattern group 2 selection 1~8	☐:Skip, 1~15	0
F540~F554	Speed 1~15 operation time	□. I-6□□□ (The unit depends on the setting of F52□.) 6□□□:Infinite (depends on the stop trigger entered)	5.0

^{*} Forward/reverse, acc/dec time 1, 2, V/f 1, 2 can be set with F 5 5 0~F 5 75 (Preset speed operation frequency 1~15 operation modes). \Rightarrow For details, refer to Section 5.12.

Note: When the function of auto-restart is active, the time spent for speed search is added to the operation time set for pattern operation. Consequently, the effective operation time sometimes becomes shorter than the settled operation time.

<Basic operating>

<basic operating=""></basic>				
Step	Setting			Parameter
1	Set the pattern operation selection parameter at "Enabled."			(Disabled) (Pattern operation enabled, setting in seconds) (Pattern operation enabled, setting in minutes)
2	Set all necessary operation frequencie In addition, set frequencies for preset speed operation.		F560	 (Preset speed operation frequencies 1~7) 3 4 (Preset speed operation frequencies 8~15) (Preset speed operation mode selection) 5 75 (Preset speed operation frequency 1~15 operation mode)
3	Set the required operation time at each the set operation frequencies. Using $F \subseteq \mathcal{D}$, select the unit of time to be subsected or minute).		F540~F	5 5 4 (Operating time at each speed)
4	Set the sequence of each speed. This sequence following three method: (1) Select a run/stop operation from the pattern operation mode. (2) Select a pattern group, and then so the sequence of each speed. (3) According to the required parameter group, select pattern operation selection 1 or 2 from input terminal function selection F ! ! to F ! Selecting pattern operation continuation signals makes it possition select a start/stop method.	et er ! 26.	→ F522 1) F523 F53 I 2) F532	=## (Patterned operation canceled during stop) Pattern operation is reset by stop/switching operation before operating restarts. = 1 (Patterned operation continued during stop) Pattern operation is started by stop/switching operation. The system stops temporarily on completion of every routine, then proceeds to the next routine. (Number of repetitions of pattern group -F 5 3 @ (Pattern group 1 selection 1~8) (Number of repetitions of pattern group -F 5 3 @ (Pattern group 2 selection 1~8) -F 1 2 6 = 3 8, 3 @ (Pattern operation selection 1) = 4 @, 4 1 (Pattern operation selection 2) = 4 @, 4 3 (Pattern operation continuation signal) = 4 4 9, 4 5 (Pattern operation trigger signal)
5	31			hat you want to display as a status monitor item
	Condition		Marking	Specification
	Pattern and pattern group	P 1.0	7 (A) (B)	(A): Number of the pattern group (B): Number of the pattern
	Pattern group – remaining number of repetitions	n là		Indicates that pattern operation has been performed 123 times.
	Operation preset speed	F !		Frequency reference with preset speed 1 data.
	Remaining time of the current pattern operation	123	34	Current pattern is finished in 1234 sec. Operation time is set for infinity or the system

is waiting for the next step command.

■ Pattern operation switching output (output terminal function: 35, 37)

If the pattern operation switching output function is selected (activated), a signal is put out on completion of all the predetermined patterns of operation. When there is no operation command left to be entered or the pattern operation selection signal changes, the output terminals are turned off.

Terminal symbol	Title	Function	Adjustment range	Example of setting
OUT1	F 130	Output terminal function selection 1	0~255	36 (Pattern operation finished – ON signal) or 37 (Pattern operation finished – OFF signal)

Note: To put out signals to the terminal OUT2, select the parameter *F* 13 1.

Note: •Pattern operation groups should be selected by terminal input.

- If no signal is put out from any pattern operation signal (all terminals are turned off), or after the pattern operation is completed, the system returns to the normal operation mode.
- When two or more pattern group numbers are entered simultaneously, the pattern group operations are
 performed in ascending order and automatically switched to one another. In this case, it may take about
 0.06 seconds to search for each pattern.
- Do not turn on the operation signal in 10 ms after turning on pattern operation selections 1 and 2 when the machine is at rest. Or the normal operation frequency may be output.

	Pattern run operation	
	(1) (2)	(1) : Pattern group 1 in operation (2) : Pattern group 2 in operation
Pattern operation input 1 (S1-CC)	ON	<parameter setting=""></parameter>
Pattern operation input 2 (S2-CC)	ON	F 1 15=3 B (Pattern operation selection 1) F 1 15=4 G (Pattern operation selection 2)
		F 119=10 (Falletti operation selection 2)

6.32 Preset speed mode

F560 ~ F575 : Preset speed operation modes

⇒ For more details, refer to Section 5.12.

6.33 Protection functions

6.33.1 Setting of stall prevention level

FED 1 : Stall prevention level

⚠Warning

Prohibited

 \bullet Do not set the stall prevention level (F § $\ensuremath{\mathcal{G}}$ 1) extremely low.

If the stall prevention level parameter (*F* § 0 1) is set at or below the no-load current of the motor, the stall preventive function will be always active and increase the frequency when it judges that regenerative braking is taking place.

Do not set the stall prevention level parameter (F & 3 1) below 30% under normal use conditions.

Function

This parameter reduces the output frequency by activating a current stall prevention function against a current exceeding the F 5 0 1-specified level.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F60 I	Stall prevention level	0~ 15 4 %, 15 5:Deactivated	150

[Display during the alarm [][]

During an $\mathcal{U}\mathcal{L}$ alarm status, (that is, when there is a current flow in excess of the stall prevention level), the output frequency changes. At the same time, to the left of this value, " \mathcal{L} " is displayed flashing on and off.

Example of display

E 50

6.33.2 Inverter trip record retention

F 6 0 2 : Inverter trip record retention selection

Function


If the inverter trips, this parameter will retain the corresponding trip information. Trip information that has thus been stored into memory can be displayed, even after power has been reset.

[Parameter setting]


Title	Function	Adjustment range	Default setting
F602	Inverter trip record retention selection	#:Clear when power is turned off. #:Retain even after power is turned off.	0

Up to four sets of latest trip records displayed in status monitor mode can be stored into memory.

Data (current, voltage, etc.) displayed in status monitor mode when the inverter is tripped is cleared when power is turned off.



Be sure to select this setting if the main power supply is turned on and off endlessly for reasons of sequence, as shown below, in the event the control power supply backup device fails or not connected.



<Example of a situation in which the main power supply is turned on and off endlessly>
In the example of connection shown above, if the control power supply 4backup device (optional) fails or not connected and becomes incapable of supplying control power, control power is supplied from the inverter's main circuit and operation is continued without interruption. If the inverter is tripped under these circumstances because of a ground fault or overcurrent:

(1) The FL relay is triggered and the main power supply is shut off by the MC.

 \downarrow

- (2) As a result of shutoff by the MC, the voltage in the inverter's main circuit and control circuit drop.
- (3) As a result of a drop in control voltage, the FL relay recovers from a trip.
- (4) The release of the FL relay turns the MC back on.
- (5) Operation is restarted and if the problem causing the inverter to be tripped is not eliminated, the inverter is tripped again, the situation in (1) arises again, and thus the above cycle of operation is repeated endlessly.

6.33.3 Emergency stop

F603 : Emergency stop

F 5 0 4 : Emergency DC braking control time

Function

Emergency stop mode can be selected. At emergency stop, a trip message (" \mathcal{E} ") is displayed. FL relay can be deactivated using the output function selection.

1) Emergency stop by terminal operation

Emergency stop can be performed with the a or b-contact. Assign the emergency stop function to a terminal as described below, and select a stop mode.



2) Emergency stop

 $F \not B \not B \not B = I$: The motor is brought to a stop within the time specified with $d \not E \not E$

F & $\Omega \ni = 2$: DC braking is performed at the current specified with F ≥ 5 1 (DC braking current) for the time specified with F $\leq \Omega \lor 1$ (emergency DC braking control time).

 $F \notin \Omega \ni \exists \exists \exists$: The motor is brought to a stop within the time specified with $F \notin I$ (deceleration time 4).

Use this setting to bring the motor to a stop within time different from the normal deceleration time specified with $d \notin \mathcal{E}$.

3) Selecting the operation of the FL relay

Using the output terminal selection parameter, you can specify whether or not to operate the FL relay.

F 132 (output terminal selection 3) = 10 (default): Operates the FL relay in the event of an emergency stop.

F 132 (output terminal selection 3) = 134: Does not operate the FL relay in the event of an emergency stop.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F603	Emergency stop	☐:Coast stop /:Deceleration stop Z:Emergency DC braking 3:Deceleration stop (deceleration 4)	o o
F 6 0 4	Emergency DC braking control time	0.0~20.0 sec.	1.0
F251	DC braking current	0~100%	50

(Example of terminal assignment): Assigning the emergency stop function to the S3 terminal.

Title	Function	Adjustment range	setting value
E 1 17	Input terminal function selection	n. 136	₽ ☐ (Emergency
F 1 1 1	7(S3)	U~ 133	stop)

Note 1: Emergency stopping via the specified terminal is possible, even during operation panel operation.

Note 2: If F 5 @ 3 = 2 (Emergency DC braking) and DC braking is not required for normal stopping, set the DC braking time F 2 5 2 to 0.0 [s].

4) Emergency stopping from the operation panel is possible

Pressing the STOP key on the operation panel twice enables emergency stop.

- (1) Press the STOP key "E II F F" will blink.
- (2) Press the STOP key again If F 5 Ū 3 (Emergency stop) = Ū~3, the motor makes an emergency stop (or trips) according to the setting.

If "E" is displayed an error detection signal (FL) is issued (FL is activated).

6.33.4 Output phase failure detection

F 5 0 5 : Output phase failure detection mode selection

Function

This parameter detects inverter output phase failure. If the inverter detects an open phase failure, the tripping function and the FL relay will be activated. At the same time, the trip information \mathcal{EPH} will also be displayed.

Detection errors may occur for special motors such as high-speed motors.

F = 0.5 = 0: No tripping

- F & 0 5 = 1: With the power on, the phase failure detection is enabled only at the start of the first operation. The inverter will trip if the inverter detects an open phase failure.
- F & 0 5 = 2: The inverter checks for output phase failures each time it starts operation. The inverter will trip if the inverter detects an open phase failure.
- F & 0 5 = 3: The inverter checks for output phase failures during operation. The inverter will trip if the inverter detects an open phase failure.
- F & 0 5 = 4: The inverter checks for output phase failures at the start of and during operation. The inverter will trip if the inverter detects an open phase failure.
- F § ② 5=5: If the inverter detects an open phase failure in every phase, it does not trip but restarts operation when every phase is reconnected.

The inverter does not check for output phase failures when restarting after a momentary power failure. This function ($F \in G = 5$) doesn't operate at 200V-55kW/75kw and 400V-90kW or more models.

Note: A check for output phase failures is made during auto-tuning 1 (F 400 = 2, 3), regardless of the setting of this parameter F 505.

[Parameter setting]

Į	Title	Function	Adjustment range	Default setting
	F605	Output phase failure detection mode selection	### Discolar Company of the American Company of the	o o

6.33.5 OL reduction starting frequency

F 5 0 5 : OL reduction starting frequency

⇒ For more details, refer to Section 5.14.

6.33.6 Motor 150%-overload time limit

F 6 0 7 : Motor 150%-overload time limit

⇒ For more details, refer to Section 5.14.

6.33.7 Input phase failure detections

F 5 0 8 : Input phase failure detection mode selection

• Function

This parameter detects inverter input phase failure. At the occurrence of a phase failure, the *EPH 1* protection message is displayed.

F & [] B = []: No tripping (Failure signal FL deactivated).

F & 0 8 = 1: This parameter detects inverter input phase failure. If the inverter detects an open phase failure, it trips.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F608	Input phase failure detection mode selection	☐:Disabled, :Enabled	1

Note 1: Setting F 5 0 8 to 0 (input phase failure detection: disabled) may result in a breakage of the capacitor in the inverter main circuit if operation is continued under a heavy load in spite of the occurrence of an input phase failure.

Note 2: When using a single-phase direct current to operate the inverter, disable this function (F & C & = C)

6.33.8 Control mode for low current

F 5 0 9 : Low current detection hysteresis width

F 5 10 : Low current trip selection

F F ! ! : Low current detection current

F 5 12 : Low current detection time

Function

If the current is lower than $F \in I \ I$ level and passes for a time longer than $F \in I \subset I$, the inverter trips. Trip information is displayed as " $U \in I$."

F 5 10=0: No tripping (Failure signal FL deactivated).

A low current alarm can be put out by setting the output terminal function selection parameter.

F & I !! The inverter will trip (the failure signal FL will be activated) if a current below the current set with F & I ! flows for the period of time specified with F & I ?.

Title	Function	Adjustment range	Default setting
F609	Low current detection hysteresis width	1~20 %	10
F 6 10	Low current trip selection	☐: No trip /:Trip	0
F6 ! !	Low current detection current	0~100%	G
F6 12	Low current detection time	0~255 sec.	G .

<Example of operation>


Output terminal function: 26 (UC) Low current detection

F 5 1 □ = □ (No trip)

Ex.) When outputting low current detection signals through output terminal OUT1

Title	Function	Adjustment range	Example of setting
F 130	Output terminal function selection 1(OUT1)	0~255	26

Note: To put out signals to the terminal OUT2, select the parameter F 131.



When $F \in IG = I$ (tripping), the inverter will trip if low current lasts for the period of time set with $F \in IG$. After tripping, the low current signal remains ON.

6.33.9 Detection of output short circuit

F 5 13 : Selection of short circuit detection at starting

• Eunction

Detects a short-circuit on the output side of the inverter.

Title	Function	Adjustment range	Default setting
F6 13	Selection of short circuit detection at starting	### Discrete ### Countries ### Discrete #### Discrete #### Discrete #### Discrete #### Discrete #### Discrete ##### Discrete ##### Discrete ###################################	o

F 5 13 [], 2, 4: Standard —— detecting at starting

1, 3, 5: A check is made once at the first start of operation after the power is turned on or the

Note: If the input voltage is rather high (480V as a guide) or the inverter is used to operate a high-speed motor, set $F \ B \ B \ B \ C \ B \ B \ C \ B \ B \ C \ B$

6.33.10 Overtorque trip

F 5 15 : Overtorque trip selection

F 5 15 : Overtorque detection level during power running

F 5 17 : Overtorque detection level during regenerative braking

F 5 18 : Overtorque detection time

F 5 19 : Overtorque detection hysteresis

Function

Trips the inverter or issues an alarm if the total time for which torque is above the level set with $F \not B \ ! \not B / F \not B \ !
ewline Trips the inverter or issues an alarm if the total time for which torque is above the level set with <math>F \not B \ ! \not B / F \not B \ !
ewline Trips the inverter or issues an alarm if the total time for which torque is above the level set with <math>F \not B \ ! \not B / F \not B \ !
ewline Trips the inverter or issues an alarm if the total time for which torque is above the level set with <math>F \not B \ ! \not B / F \not B \ !
ewline Trips the inverter or issues an alarm if the total time for which torque is above the level set with <math>F \not B \ ! \not B / F \not B \ !
ewline Trips the inverter or issues an alarm if the total time for which torque is above the level set with <math>F \not B \ ! \not B / F \not B / F \not B / F \not B / F \not B$

F S I S = I (Tripping) The inverter will trip (the failure signal FL will be activated) if a torque larger than

 $F \ 5 \ 15$ (during power running) or $F \ 5 \ 17$ (during regeneration) passes for a time longer than the time set with $F \ 5 \ 18$.

Title	Function	Adjustment range	Default setting
F 6 15	Overtorque trip selection	☐:No trip, 1:Trip	O
F 6 1 6	Overtorque detection level during power running	0~250%	150
F6 17	Overtorque detection level during regenerative braking	0~250%	150
F 6 18	Overtorque detection time	0.00~10.00 sec.	0.50
F 6 19	Overtorque detection hysteresis	0~100%	10

Note: Using the output terminal function selection parameter, the inverter can be set so that it outputs overtorque detection signals regardless of the setting of *F § 15*. ⇒ Refer to Section 7.2.2.

<Example of operation>


Output terminal function: 28 Overtorque detection

F 5 15=0 (No trip)

Ex.) When outputting overtorque detection signals through output terminal OUT1

Title	Function	Adjustment range	Example of setting
F 130	Output terminal function selection 1(OUT1)	0~255	28

Note: To put out signals to the terminal OUT2, select the parameter *F* 131.



When F 5 15= 1 (tripping), the inverter will trip if overtorque lasts for the period of time set with F 5 18. In such a case, the overtorque signal remains ON.

6.33.11 Cooling fan control selection

F628 : Cooling fan control selection

Function

With this parameter, you can set the condition of cooling fan so that it operates only when the inverter requires cooling, and thus it can be used for a longer period.

F 6 ≥ B = B: Automatic control of cooling fan, enabled. Operates only when the inverter is in operation.
F 6 ≥ B = I: Automatic control of cooling fan, disabled. The cooling fan always operates when the inverter is energized.

The cooling fan automatically operates whenever the ambient temperature is high, even when the inverter is out of operation.

Title	Function	Adjustment range	Default setting
F620	Cooling fan control selection	☐:Auto, 1:Always ON	O

6.33.12 Cumulative operation time alarm setting

F 6 2 1 : Cumulative operation time alarm setting

Function

This parameter is to make a setting so that the inverter puts out a signal when its cumulative operation time has reached the time set with $F \in \mathcal{Z}$.

* Indication of G. 1 represents 10 hours. Ex.: If 38.5 is displayed, the cumulative operation time is 3850 hours.

Title	Function	Adjustment range	Default setting
F621	Cumulative operation time alarm setting	O. 1~9 9 9.9	5 IO.O

■ Setting of output signal

Ex.) When assigning the cumulative operation alarm signal output function to the OUT2 terminal

Title	Function	Adjustment range	Example of setting
F 13 1	Output terminal function selection 2 (OUT2)	0~255	55 (Negative logic 57)

6.33.13 Abnormal speed detection

F 6 2 2 : Abnormal speed detection time

F623 : Overspeed detection frequency upper band


F 5 2 4 : Overspeed detection frequency lower band

• Function

When use at speed control mode with sensor (PE=7, B), it always monitors the rotational speed of the motor, even when the motor is at rest, and if the speed remains out of the specified limits for the specified length of time, it outputs an error signal.

When use at speed control mode without sensor (P = 3 - 5), it always monitors the estimated rotational speed of the motor.

Title	Function	Adjustment range	Default setting
F622	Abnormal speed detection time	0.0 1~ 100.0 sec.	0.0 1
F623	Overspeed detection frequency upper band	☐.☐: Disabled, ☐. I~∃☐.☐. Hz	0.0
F624	Overspeed detection frequency lower band	□.□: Disabled, □. I~∃□.□. Hz	0.0



Note 1: This function doesn't operate at the time of a torque control.

Note 2: It is advisable to set the parameter F 4 5 1 (Acceleration/deceleration operation after torque limit) to 1 when this function is set.

6.33.14 Overvoltage limit operation

F 6 2 6 : Overvoltage limit operation level

⇒ For more details, refer to Section 6.14.2.

6.33.15 Undervoltage trip

F625 : Undervoltage detection level

F628 : Undervoltage (trip alarm) detection time

Function

This parameter is used for selecting the control mode when an undervoltage is detected. (Invalid, while the inverter stops.) When selecting "tripping enabled," you can also specify the time elapsed before the inverter trips.

F 5 ≥ 7=0: (Disabled) Inverter stops, but does not trip. (FL is not active.)

F 6 2 7= 1: (Enabled) The inverter trips UP 1 if an undervoltage passes for the time set with F 6 2 8 or over. (FL is activated.)

Title	Function	Adjustment range	Default setting
F625	Undervoltage detection level	50~79 %, 80 %: (auto mode)	80
F627	Undervoltage trip selection	☐: Disabled, I: Enabled	O
F628	Undervoltage (trip alarm) detection time	0.0 1~ 10.00 sec.	0.0 3

Note: For F 5 2 5, 100% corresponds to a voltage of 200V (for 200V class) or 400V (for 400V class)

6.33.16 Regenerative power ride-through control level

F629 : Regenerative power ride-through control level

Function

This parameter is used to set the operation level of the regenerative power ride-through control and the deceleration stop. (Refer to Section 5.18.2.)

Title	Function	Adjustment range	Default setting
F629	Regenerative power ride-through control level	55~100%	75

Note1:

Set this parameter at a value of F & 25+5% or more. Or the braking time of regenerative power ride-though control could be extremely shorter. This setting is not necessary if F & 25 is set to & 0 (auto mode).

Note2: When power on or reset operation, the power supply voltage is detected. If the setting value of parameter $F \in \mathcal{Z}$ is too low, the setting value is automatically adjusted to stabilize the performance.

Note3: For F & 2 9, 100% corresponds to a voltage of 200V (for 200V class) or 400V (for 400V class)

6.33.17 Braking answer waiting time

F 6 3 0 : Braking answer waiting time

Function

This parameter is used to set the waiting time for answer from system (Input terminal function setting: System supporting sequence (BA: Braking answer !30, !31). After start of operation, if no answer is received in set time (F630), the inverter trips (F600).

Title	Function	Adjustment range	Default setting
F630	Braking answer waiting time	☐.☐:Disabled☐. I~ I ☐.☐ sec.	0.0

6.33.18 VI/II analog input wire breakage detection level

F533 : VI/II analog input wire breakage detection level

Function

The inverter will trip if the VI/II value remains below the specified value for 0.3 seconds or moreThe message " \mathcal{E} - \mathcal{IB} " is displayed.

 $F \not\subseteq \exists \exists \exists \exists \exists \exists$: Disabled The detection function is disabled.

F & 3 3= 1~ 100 The inverter will trip if the VI/II value remains below the specified value for 0.3 seconds or more.

Title	Function	Adjustment range	Default setting
F633	VI/II analog input wire breakage detection level	☐:None !~ ! ☐ ☐ %	0

6.33.19 Guide to time of replacement

F 6 3 4 : Annual average ambient temperature

Function

You can set the inverter so that it will calculate the remaining useful life of the cooling fan, main circuit capacitor and on-board capacitor from the ON time of the inverter, the operating time of the motor, the output current (load factor) and the setting of F § 3 Y and that it will display and send out an alarm through output terminals when each component is approaching the end of its useful life.

Title	Function	Adjustment range	Default setting
F634	Annual average ambient temperature	f: -10~+10°C Z: +11~+20°C 3: +21~+30°C 4: +31~+40°C 5: +41~+50°C 5: +51~+60°C	3

Note 1: Using F & 3 Y, enter the annual average temperature around the inverter. Be careful not to enter the annual highest temperature.

Note 2: Set *F* 5 3 4 at the time of installation of the inverter, and do not change its setting after the start of use. Changing the setting may cause a part replacement alarm calculation error.

6.33.20 Rush current suppression relay activation time


F 5 3 5 : Rush current suppression relay activation time

• Function

This parameter is used to control the rush current suppressing resistor shorting relay when a direct current is passed or multiple inverters are used with their DC sections connected to each other.

Title	Function	Adjustment range	Default setting
F 6 3 5	Rush current suppression relay activation time	0.0~2.5 sec.	0.0

The rush current suppressing relay is activated on the expiration of the time limit set with parameter $F \delta 35$ after the voltage in the DC section of the inverter has reached the specified level.



6.33.21 Motor thermal protection

F 6 3 7 ~ F 6 3 8 : PTC thermal selection

⇒ For details, refer to Instruction Manual (E6581339) specified in Section 6.42.

6.33.22 Braking resistance overload curve

F 6 3 9 : Braking resistance overload time

⇒ Refer to 5.19 for details.

6.33.23 Selection of a restart condition for the motor stopped with a mechanical brake

F 6 4 3 : Brake-equipped motor restart condition selection

• Function

With this function, the motor can be restarted immediately after a stop if it is operated at a frequency of more than 10Hz (20Hz or less) and stopped with a mechanical brake.


Use this function only when a mechanical brake is used to stop the motor. Using this function for a motor without a mechanical brake, the inverter may be tripped or fail.

Title	Function	Adjustment range	Default setting
	Brake-equipped	☐: Default (no waiting time for frequencies of 10Hz and less)	
F643	motor restart	1: Conditional (no waiting time for frequencies of 20Hz and	0
	condition selection	less)	

The timing chart in the figure below shows how the motor is operated and stopped with a mechanical brake. By default, restart waiting time is set to prevent the inverter from being tripped because of the immediate restart of the motor which started coasting at a frequency of more than 10Hz and stopped (when the ST function is assigned to the S3 terminal, S3 signal is cut off).

This waiting time, however, is not necessary if a mechanical brake is used to stop the motor more reliably. When using a mechanical brake to stop the motor, set this parameter F S H J to I to allow the motor to restart immediately after a stop if it started coasting at a frequency of 20Hz or less and stopped.

<Ex.: When parameter F & 4 3 is set to 1.>



When assigning the ST function to the S3 terminal,

Set $F : I : \mathbb{C}$ to \mathbb{C} (to cancel its factory default setting: $\mathbb{C} = ST$ always active), and Set $F : I : \mathbb{C}$ to \mathbb{C} (to assign the ST function to the S3 terminal).

Note 1: By default, the restart waiting time shown in the figure is set, and the restart of the motor is delayed by the time indicated by the dashed line.

Note 2: If the motor started coasting at a frequency of more than 20Hz, it will restart after the expiration of the waiting time.

6.33.24 Protection against a failure of the control power backup device (optional CPS002Z)

F 5 4 7 : Control power supply backup option failure monitoring

Function

If the control power backup device (optional CPS002Z) fails to supply power for some reason or other for fifteen minutes and over, the inverter will put out an alarm signal or a trip signal depending on the setting.

Leaving this parameter disabled may cause the main power supply to be turned on and off endlessly if something unusual occurs, depending on your sequence etc., so you should set this parameter FEY7 properly when using the optional power backup device.

Title	Function	Adjustment range	Default setting
F647	Control power supply backup option failure monitoring	### : Control power supply not backed up f: Control power supply backed up (alarm in the event of a failure) 2: Control power supply backed up (tripping in the event of a failure)	O

■ F 5 4 7=#: If control power is not backed up with an external backup device:

Select this setting if an external backup device is not connected to the inverter's control terminals +SU and CC.

Note: Even if F & 4 7 is set to @ while control power is backed up, the inverter will cut off the power supply and issue C @FF alarm in the event the backup device fails during operation.

If the backup device is already faulty when it is turned on, it will not be recognized to be faulty even if this setting is selected.

■ F 5 4 7= 1: If control power is backed up with an external backup device (alarm signal output):

If F & Y 7 is set to 1, however, the inverter will cut off the power supply, let the motor coast, and raise a C C F F alarm in the event something unusual (voltage drop) occurs with the power supplied through the +SU and CC terminals.

Once the [### F alarm has been raised, the inverter is not reset even if the control voltage returns to its normal level. To reset the inverter, turn off the main circuit power supply.

■ F 5 4 7=2: If control power is backed up with an external backup device (trip signal output):

This setting trips the inverter in the event something unusual (voltage drop) occurs with the external control power backup device. Trip code *E* - 29 is displayed.


In the event of this trip, unlike ordinary trips, the inverter is held tripped regardless of the setting of $F \in \mathcal{Q} \supseteq$ (inverter trip retention selection).

This setting is effective only when the inverter is used in a standard connection shown in Chapter 2.

If reset the trip, operate with $F \not\subseteq Y ?= 0$ or ! setting.

Note: Be sure to set the parameter $F \in \mathbb{G} \supseteq \mathcal{E}$ to 1 if the main power supply is turned on and off endlessly for reasons of sequence, as shown below, in the event the control power backup device fails.

⇒ For details, refer to section 6.33.2.



6.34 Override

F 5 5 0 : Override addition input selection

F 5 5 ! : Override multiplication input selection

Function

These parameters are used to adjust reference frequencies by means of external input.

Title	Function	Adjustment range	Default setting
F660	Override addition input selection [Hz]	G:Disabled f:VI/II (voltage/current input) ∂:RR/S4 (potentiometer/voltage input) β:RX (voltage input) 4:Operation panel input enabled (including LED/LCD option input) 5:2-wire RS485 input enabled 6:4-wire RS485 input enabled 7:Communication option input enabled 8:Optionl Al1 (differential current input) 9:Optionl Al2 (voltage/current input) 10:Up/Down frequency 1:Optionl RP pulse input 12:Optionl high-speed pulse input 13:Optionl binary/BCD input	a
F66 I	Override multiplication input selection [%]	☐:Disabled f:VI/II (voltage/current input) c:RR/S4 (potentiometer/voltage input) 3:RX (voltage input) 4:F729 5:OptionI Al1	0


The override functions calculate output frequency by the following expression:

Frequency command value
$$\times$$
 (1+ $\frac{\text{Value [\%] selected with F 5 5 !}}{100}$)+Value [Hz] selected with F 5 5 Ω

1) Additive override

In th1is mode, an externally input override frequency is added to operation frequency command.

[Ex.1: RR/S4 (Reference frequency), VI/II (Override input)] [Ex.2:RX (Reference frequency), VI/II (Override input)]



Ex.1:

F 5 5 0 = ! (VI/II input), F 5 5 !=0 (disabled)

Output frequency = Reference frequency + Override (VI/II input [Hz])

Ex.2


F 5 5 0 = 1 (VI/II input), F 5 5 1=0 (disabled)

Output frequency = Reference frequency + Override (VI/II input [Hz])

2) Multiplicative override

In this mode, each output frequency is multiplied by an externally override frequency.

[Ex.1: RR/S4 (Reference frequency), VI/II (Override input)] [Ex.2: RX (Reference frequency), VI/II (Override input)]



Ex.1:

RR/S4 input, (F \geq 10=0, F \geq 11=0.0, F \geq 12=100, A $_{o}$ F \geq =80.0)

VI/II input $(F \ge 0 \ l = 0, F \ge 0.5 = 0, F \ge 0.3 = 1.00, F \ge 0.6 = 1.00)$

⇒ Setting of RR/S4 input: Refer to Section 7.3.1, Setting of VI/II input: Refer to Section 7.3.2.

Output frequency = Reference frequency x {1 + Override (VI/II input [%]/100)}

Ex.2:

F = G = G (Disabled), F = G = G (VI/II input), F = G = G = G (RX input), F = G = G = G = G

RX input $(F \ge 16 = 0, F \ge 17 = 0.0, F \ge 18 = 100, F \ge 19 = 80.0)$

VI/II input (F 2 0 1=0, F 2 0 2=0, F 2 0 3= 10 0, F 2 0 6= 10 0)

⇒ Setting of RX input: Refer to Section 7.3.3, Setting of VI/II input: Refer to Section 7.3.2.

Output frequency = Reference frequency × {1 + Override (VI/II input [%]/100)}

Ex.3:

	Title	Function	Adjustment range	Default setting
l	F729	Operation panel override multiplication gain	- 100~100%	0

Output frequency = Reference frequency × {1 + Override (F 729 setting value [%]/100}

6.35 Adjustment parameters

6.35.1 Pulse train output for meters

F 5 5 9 : Logic output/pulse output selection (OUT1)

F 5 7 7 : Selection of number of pulses

Function

Pulse trains can be sent out through the OUT1-CC output terminals.

To do so, it is necessary to select a pulse output mode and specify the number of pulses.

This function output the pulse is based on F & 7.7 setting when each selection is suitable for the fixed output 1 level (refer to selection 5.16).

Set the SW4 to pulse output (PULS).

Ex.) When operations frequencies (0 to 60Hz) are put out by means of 0 to 10kHz

FH=60.0, F669=1, F676=0, F677=10.00

The pulse will change between 0 and 10kHz according to the operations frequencies between 0 and 60Hz.

⇒ See the circuit diagram shown at the bottom of page B-15.

Title	Function	Adjustment range	Default setting
ccc0	Logic output/pulse output selection	☐:Logic output	п
7003	(OUT1)	1:Pulse output	U
F675			0
		식명:My function monitor 4	
F 5 7 7	Selection of number of pulses	1.00~43.20 kHz	3.84

Note: The pulse length is fixed. Therefore, the duty is variable.

6.35.2 Setting of optional meter outputs

F 6 7 2 ~ F 6 7 5 , F 6 8 8 ~ F 6 9 3 : Meter output settings

⇒ For details, refer to Instruction Manual (E6581341) specified in Section 6.42.

6.35.3 Calibration of analog outputs

F 5 8 1 : FM voltage/current output switching

F682, F683: FM output gradient characteristic and bias adjustment
F685, F686: AM output gradient characteristic and bias adjustment

•Function

Output signals from FM/AM terminals are analog voltage signals. Their standard setting range is from 0 to 10Vdc


The output current from terminal FM can be changed to 0 to 20mAdc (or 4 to 20mAdc) by changing the settings of terminal SW2 and a parameter.


[Parameter setting]


T.	I	A.E. 4.	D (); ;;;
Title	Function	Adjustment range	Default setting
F 6 8 1	FM voltage/current output	☐: Voltage 0~10V output	0
r 0 0 1	switching	1: Current 0~20mA output	U
	EM cutout are dient	☐: Negative gradient	
F682	FM output gradient characteristic	(descending)	1
cna	Characteristic	1: Positive gradient (ascending)	
F 6 8 3	FM bias adjustment	- 10.0~ 100.0%	0.0
	AM output gradient	☐: Negative gradient	
F 6 8 5	characteristic	(descending)	1
	Characteristic	1: Positive gradient (ascending)	
F 6 8 6	AM bias adjustment	- 10.0~ 100.0 %	0.0

Note: To switch to 0-20mAdc (4-20mAdc), set F & 8 1 to 1.

■ FM terminals setting example







The analog output inclination can be adjusted using the parameter $F \, \Pi$

For code data 50 to 64, negative inclination is invalid.

6.36 Operation panel parameter

6.36.1 Prohibition of key operations and parameter settings

F 700 : Parameter write protect selection

F 730 : Operation panel frequency setting prohibition selection

F 734 : Operation panel emergency stop operation prohibition selection

F 735 : Operation panel reset operation prohibition selection

F737 : All key operation prohibition

Function

These parameters allow you to prohibit the operation of the RUN and STOP keys on the operation panel and the change of parameters. Using these parameters, you can also prohibit various key operations.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F700	Parameter write protect selection	☐:Permit, 1:Prohibit	0
F730	Operation panel frequency setting prohibition selection	☐:Permit, 1:Prohibit	0
F734	Operation panel emergency stop operation prohibition selection	☐:Permit, 1:Prohibit	0
F735	Operation panel reset operation prohibition selection	☐:Permit, 1:Prohibit	0
F736	Prohibition of change of [] [] d/F [] d during operation	☐:Permit, 1:Prohibit	1
F737	All key operation prohibition	☐:Permit, 1:Prohibit	0

Note: For the setting of F 73 7 to take effect, the inverter needs to be turned off and turned back on after the setting.

■ Resetting method

1) Canceling the *F* 700 prohibition setting

The setting of only parameter *F* 700 can be changed at any time, even if it is set to 1.

2) Canceling the F 737 prohibition setting

When this parameter is set to 1 (key operation prohibited), press and hold down the (ENT) key for 5 seconds or more. The message $U \cap d \circ D$ appears and this setting is canceled temporarily to enable key operation.

To cancel this setting permanently, change the setting of F 737 directly.

6.36.2 Displaying the rotational speed of the motor or the line speed

F 702 : Frequency free unit display magnification

F703 : Frequency free unit conversion selection

F 705 : Free unit display gradient characteristic

F 706 : Free unit display bias

Function

The frequency or any other item displayed on the monitor can be converted freely into the rotational speed of the motor, the operating speed of the load, and so on. Using these parameters, the units of the amounts of processing and feedback in PID control can also be changed.

The value obtained by multiplying the displayed frequency by the F 702 set value will be displayed as follows:

Value displayed = Monitor-displayed or parameter-set frequency × F 702

1) Displaying the motor speed

To switch the display mode from 60Hz (default setting) to 1800 min⁻¹ (the rotating speed of the 4P motor)



2) Displaying the speed of the loading unit

To switch the display mode from 60Hz (default setting) to 6 m/min⁻¹ (the speed of the conveyer)

Note: This parameter displays the inverter output frequency as the value obtained by multiplying it by a positive number. Even when the actual speed of the motor changes according to the particular changes in load, the output frequency will always be displayed.

Title	Function	Adjustment range	Default setting
F 702	Frequency free unit display magnification	0.00:OFF 0.01~200.0	0.00
F703	Frequency free unit conversion selection	#:All frequencies display free unit conversion #:PID frequencies free unit conversion	0
F 705	Free unit display gradient characteristic	#:Negative gradient (descending) #:Positive gradient (ascending)	1
F706	Free unit display bias	0.00~F	0.00

The $F 7 \square 2$ converts the following parameter settings:

In case of F 703=0

• Free unit Frequency monitor display

Frequency-Related parameters


FM, UL, LL, Ruf2, RIF2, SrI-5r7, F100, F101, F102, F202, F208, F211, F217, F219, F223, F225, F229, F231, F235, F237, F240, F241, F242, F243, F244, F250, F260, F265, F267, F268, F270-F275, F287-F294, F321, F322, F330, F331, F346, F350, F352, F355, F370, F371, F426, F428, F431, F432, F466, F505, F513, F517, F606, F623, F466, F505, F513, F517, F606, F623, F624, F817, F814, F927-F927

In case of F 703 = 1

• Free unit PID control -Related parameters F [(panel frequency), F 2 0 2, R 1 F 2, F 2 0 8, F 2 1 1,

FL (panel trequency), F2U2, F1F2, F2U8, F2 F1 RUF2, F2 F3, F2 F3, F223, F225, F229, F231, F235, F237, F364, F365, F367, F368, F370, F371

■ An example of setting: When FH is BO, and F702 is 10.00



6.36.3 Changing the steps in which the value displayed changes

0 Output frequency 80 (Hz)

F707 : Changing step selection 1 (pressing a panel key once)

F 708 : Change step selection 2 (panel display)

Function

These parameters are used to specify steps in which the command value or standard monitor output frequency displayed on the panel changes each time you press the up or down key to set a frequency on the operation panel.

Note: The settings of these parameters have no effect when the free unit selection (F 702) is enabled.

■ When $F ? \bigcirc ?$ is not $\bigcirc . \bigcirc \bigcirc ?$, and $F ? \bigcirc ?$ is $\bigcirc ?$ (disabled).

Under normal conditions, the panel frequency command value increases in steps of 0.1Hz each time you press the \bigcirc key. If \digamma 7 $\rlap{/}{B}$ 7 is not 0.00, the frequency command value will increase by the value with \digamma 7 $\rlap{/}{B}$ 7 each time you press the \bigcirc key. Similarly, it will decrease by the value set with \digamma 7 $\rlap{/}{B}$ 7 each time you press the \bigcirc key.

In this case, the output frequency displayed in standard monitor mode changes in steps of 0.1Hz, as usual.

■ When F ? @ ? is not @ . @ ?, and F ? @ ? is not @ .

The value displayed on the panel also can be changed in steps.

Output frequency displayed in standard monitor = Internally output frequency × F 108

Title	Function	Adjustment range	Default setting
FIOI	Changing step selection 1 (pressing a panel key once)	□.□□:Disabled □.□ !~F H Hz	0.00
F 708	Changing step selection 2 (panel display)	☐:Disabled 1~255	0

■ Example of setting 1

Set F 7 0 7= 1 0.0 0 [Hz]:

Each time you press the \bigcirc key, Each time the frequency setting $F \not\in$ changes in steps of 10.0Hz: $0.0 \rightarrow 10.0 \rightarrow 20.0 \rightarrow ... \rightarrow 60.0$ [Hz]. This function comes in very handy when operating the load at limited frequencies that change in steps of 1 Hz, 5Hz, 10Hz, and so on.

■ Example of setting 2

Set F 70 7= 1.00 [Hz], F 708= 1:

Each time you press the \bigcirc key, the frequency setting $F \not\subset$ changes in steps of 1 Hz: $0 \to 1 \to 2 \to ... \to 60$ [Hz] and also the value displayed on the operation panel changes in steps of 1. Use these settings to hide decimal fractions. And also the value displayed on the operation panel changes in steps of 1. Use these settings to hide decimal fractions.

6

6.36.4 Changing the standard monitor display

F 7 18 : Standard monitor display selection

F 7 1 1 - F 7 18 : Status monitor 1~8 display selection

These parameters are used to select the item to be displayed when the power turned on and also to change items displayed in status monitor mode. \Rightarrow For details, refer to Section 8.3.

6.36.5 Canceling the operation command

F 7 19 : Operation command clear selection when input terminal function ST (Refer to section 7.2.1) is OFF

Function

You can use this function when driving with the RUN key on the operation panel.

When it turns on again after turning off the input terminal which assigned the standby "ST" function(Refer to 7.2.1) during driving the inverter, the inverter will drive again without pushing the RUN key.

Using this function, the inverter is not driven again unless the RUN key is pushed on after turning on the ST signal.

Title	Function	Adjustment range	Default setting
F719	Operation command clear selection	☐:Clear operation command	,
r 1 13	when standby terminal (ST) is OFF	:Retain operation command	'

6.36.6 Selection of operation panel stop pattern

F 72 1 : Operation panel stop pattern selection

Function

This parameter are used to select a mode in which the motor started by pressing the (RUN) key on the operation panel is stopped when the (STOP) key is pressed.

1) Deceleration stop

The motor stops in the deceleration time set with the parameter $d \in \mathcal{L}$ (or $F \in \mathcal{D}(I, F \in I, I)$).

2) Coast stop

The output of the inverter is cut off. The motor comes to a stop after coasting for a while by inertia. Depending on the load, the motor may keep running for a good long time.

[Parameter setting]

Title	Function	Adjustment range	Default setting
F721	Operation panel stop pattern selection	☐:Deceleration stop /:Coast stop	0

6.36.7 Setting of a torque command in panel operation mode

F725 : Operation panel torque command (reference value in %)

Function

This parameter allows you to set a torque command value when torque is controlled with the operation panel.

Note: This parameter is operative only when F342, F423, F423 and F424 are set to 4. The value set with this parameter is used as the command value (%) for each function.

Operation panel operation: Torque command selection F 4 2 1 is set at 4 (Panel input).

[Parameter setting]

Title	Function	Adjustment range	Default setting
F725	Operation panel torque command	-250~250%	0

[⇒] For details, refer to Instruction Manual (E6581331) specified in Section 6.42.

6.36.8 Torque-related parameters for panel operation

F 727 : Operation panel tension torque bias
F 728 : Operation panel load sharing gain

These parameters are used to specify the torque bias and how to share the load.

⇒ For details, refer to Instruction Manual (E6581331) specified in Section 6.42.

6.37 Tracing functions

 F 740
 : Trace selection
 F 742
 : Trace data 1

 F 741
 : Trace data 2

 F 749
 : Trace data 3

 F 745
 : Trace data 4

Function

These parameters are used to memorize and read out the data collected at the time of tripping or triggering. Up to 4 kinds of data can be selected from 64 kinds of data, and the data collected at 100 consecutive points can be stored in memory as trace data.

Here is the time at which trace data is acquired.

- Tripping: Data collected before the occurrence
- Triggering: Data collected after triggering


Note: To read data on a PC.

Title	Function	Adjustment range	Default setting
F 740	Trace selection	☐:Deselect /:At tripping ∂:At triggering	1
F741	Trace cycle	0:4ms 1:20ms 2:100ms 3:1s 4:10s	2
F742	Trace data 1	0~49	O O
F743	Trace data 2	0~49	1
F744	Trace data 3	0~49	2
F745	Trace data 4	0~49	3


(Note1): For saving trace data, do not disconnect the control power supply or the main circuit power supply during 15 second after inverter tripped.

(Note2): When F 74 I=0 or I setting, set the value of F 5 78 (Constant at the time of filtering) lower than F 74 I setting time (trace cycle time).

1) To acquire trace data at the occurrence of tripping: F 740= I
(Examples of current date output)



2) To acquire trace data at the time of triggering: F 7 4 □ = 2



Ex.) When using the RR/S4 terminal as the tracing back trigger signal terminal

Title	Function	Adjustment range	Example of setting
F 1 18	Input terminal function selection 8 (RR/S4)	0~135	76

Note 1: If the inverter trips when no trigger signal is given, trace data is overwritten with tripping data.

Note 2: Trace data is overwritten each time a trigger signal is given.

[Setup values of F 742~F 745]

Default setting	Communication	Trans (manitar) frantism	Communication
Default setting	No.	Trace (monitor) function	unit at tracing
0	FD00	Output frequency	0.01Hz
1	FD02	Frequency command value	0.01Hz
2	FD03	Output current	0.01%
3	FD04	Input voltage (DC detection)	0.01%
ч	FD05	Output voltage	0.01%
5	FD15	Compensated frequency	0.01Hz
5	FD16	Speed feedback (real-time value)	0.01Hz
7	FD17	Speed feedback (1-second filter)	0.01Hz
8	FD18	Torque	0.01%
9	FD19	Torque command	0.01%
1.1	FD20	Torque current	0.01%
12	FD21	Exciting current	0.01%
13	FD22	PID feedback value	0.01
14	FD23	Motor overload factor (OL2 data)	0.01%
15	FD24	Inverter overload factor (OL1 data)	0.01%
15	FD25	Regenerative braking resistance overload factor (OLr data)	1%
17	FD28	Regenerative braking resistor load factor (% ED)	1%
18	FD29	Input power	0.01kW
19	FD30	Output power	0.01kW
23	FE39	Optional AI2 input	0.01%
24	FE35	RR/S4 input	0.01%
25	FE36	VI/II input	0.01%
26	FE37	RX input	0.01%
27	FE38	Optional Al1 input	0.01%
28	FE40	FM output	0.01%
29	FE41	AM output	0.01%
34	FE76	Integral input power	0.01kWhr
35	FE77	Integral output power	0.01kWhr
45	FE60	My function monitor 1	1c
47	FE61	My function monitor 2	1c
48	FE62	My function monitor 3	1c
49	FE63	My function monitor 4	1c

■ Acquisition of trace data

Trace data is acquired through a communication device. The VF-AS1 supports the protocols listed below.

• RS485 (Standard protocol)

■ Trace data communication number

Communication No.	Function	Minimum setting /readout unit	Setting/readout range	Default setting
E000	Trace data 1~4 pointer	1/ 1	0~99	G G
E100	Data 1 of trace data 1	1/ 1	<i>0~FFFF</i>	0
	Data 2~99 of trace data 1	1/ 1	<i>0~FFFF</i>	0
E199	Data 100 of trace data 1	1/ 1	0~FFFF	0
E200	Data 1 of trace data 2	1/ 1	<i>0~FFFF</i>	0
	Data 2~99 of trace data 2	1/ 1	<i>0~FFFF</i>	0
E299	Data 100 of trace data 2	1/ 1	<i>0~FFFF</i>	0
E300	Data 1 of trace data 3	1/ 1	<i>0~FFFF</i>	0
	Data 2~99 of trace data 3	1/ 1	<i>0~FFFF</i>	0
E399	Data 100 of trace data 3	1/ 1	0~FFFF	0
E400	Data 1 of trace data 4	1/ 1	<i>0~FFFF</i>	0
	Data 2~99 of trace data 4	1/ 1	<i>0~FFFF</i>	0
E499	Data 100 of trace data 4	1/ 1	<i>0~FFFF</i>	0

Ex.) When operation frequency data is acquired through a communication device

Data acquired ($1F Y_{ij}$) h=8000 \Rightarrow 8000×0.01Hz=80.0Hz

■ Relationship between pointer and data

The table below shows the relationship between pointer (E000 set value) and trace data (1 to 4).

Pointer (E000 set value)	8	1	2	~	98	99
Trace data 1 (E100~E199)	E100	E101	E102	~	E198	E199
Trace data 2 (E200~E299)	E200	E201	E202	2	E298	E299
Trace data 3 (E300~E399)	E300	E301	E302	~	E398	E399
Trace data 4 (E400~E499)	E400	E401	E402	~	E498	E499

<Example of setting> If E000 is set to ₽:

(Earliest data) (Latest data)

Trace data 1 E102 ~ E199, E100, E101
Trace data 2 E202 ~ E299, E200, E201
Trace data 3 E302 ~ E399, E300, E301
Trace data 4 E402 ~ E499, E400, E401

Note 1: Use the parameters F 742 through F 745 to specify the types of trace data (1 to 4).

Note 2: Communication numbers E000 is automatically incremented by the inverter when data is traced continuously.

* In ordinary cases, these parameters do not need to be rewritten.

6.38 Integrating wattmeter

F 748 : Integrating wattmeter retention selection

F 749 : Integrating wattmeter display unit selection

Function

At the main power off ,it is selectable whether retention of integral output power values or not. And also, the display unit is selectable.

The integrating wattmeter display can be cleared by external input signal by assignment of the terminal function. Input terminal function 74, 75 (Integrating wattmeter display clear)

Title	Function	Adjustment range	Default setting
F748	Integrating wattmeter retention selection	<pre> ☐: Disabled f: Enabled </pre>	0
F 749	Integrating wattmeter display unit selection	☐: 1 = 1 kWh I: 1 = 10 kWh Z: 1 = 100 kWh ∃: 1 = 1000 kWh H: 1 = 10000 kWh	Accoding to model ⇒ Refer to page K-46.

6.39 Communication function

6.39.1 2-wire RS485/4-wire RS485

FBDD: Communication speed (2-wire RS485)

FRO 1 : Parity (common to 2-wire RS485 and 4-wire RS485)

FB02 : Inverter number (common)

FBD3 : Communications time-out time (common to 2-wire RS485 and 4-wire RS485)

FBD4 : Communications time-out action (common to 2-wire RS485 and 4-wire RS485)

FBD5 : Send waiting time (2-wire RS485)

FBDE : Master/slave setting for Inverter-to-inverter communications (2-wire RS485)

FBD7 : Protocol selection (2-wire RS485)

FBDB : Communication1 time-out condition selection

FB 10 : Frequency point selection

FB 1 1 : Point 1 setting

FB 12 : Point 1 frequency

FB 13 : Point 2 setting

FB 14 : Point 2 frequency

FB20 : Communication speed (4-wire RS485)

FB25 : Send waiting time (4-wire RS485)

FB25 : Inverter-to-inverter communication setting (4-wire RS485)

FB29 : Protocol selection (4-wire RS485)

F B 70 . F B 7 ! : Block write data 1. 2

F B 75 - F B 79 : Block read data 1~5

FBBD : Free notes

Function

These parameters allow you to connect the inverter to a higher-level system (host) and to set up a network for data communications between inverters. They make it possible for the inverter to be linked to a computer and to carry out data communications with other inverters.

<Computer link function>

This function allows the inverter to carry out data communications with a higher-level system (host).

- (1) Monitoring inverter status (such as the output frequency, current, and voltage)
- (2) Sending RUN, STOP and other control commands to the inverter
- (3) Reading, editing and writing inverter parameter settings
- <Inverter-to-inverter communication function>

This function allows you to set up a network that makes it possible to carry out proportional operation of

multiple inverters (without using a computer).

data is sent to the inverter within the specified time, this function trips the inverter ("Err5" is displayed on the display panel) or gives an alarm ("£" is displayed).

to multiple inverters in one session.

Inverter-to-inverter communication function .. Refers to the function that enables the master inverter to send the data selected with a parameter to all slave inverters on the same network. This function allows you to set up a network that makes it possible to carry out synchronized operation or proportional operation (setting of

point frequencies) in an abbreviated manner.

[⇒] For details, see Instruction Manual (E6581315) specified in Section 6.42.

1) 2-wire RS485

The 2-wire RS485 device on the operation panel and the 4-wire RS485 device on the control circuit terminal block are intended for data communications between inverters. To use an optional part for the RS485 device, it should be connected to the communication connector (RJ45) on the operation panel. Through the 2-wire RS485 device and a USB device (optional), the inverter can be linked to a computer.

Here are the parts optionally available for the 2-wire RS485 device.

Optional USB-to-Serial conversion unit (Model: USB001Z)
 Inverter-to-RS485/USB device interconnect cable (Model: CAB0011 (1m), CAB0013 (3m), CAB0015 (5m))
 RS485/USB device-to-computer interconnect cable. Use a commercially available USB1.1 or 2.0 cable. (Type: A-B, Cablelength: 0.25–1.5m)

Optional LED Remote Keypad (Model: RKP002Z)
 Communication cable (Model:CAB0011 (1m), CAB0013 (3m), CAB0015 (5m))

Optional LCD Remote Keypad (Model: RKP004Z)

LCD special cable (Model:CAB0071 (1m), CAB0073 (3m), CAB0075 (5m), CAB00710 (10m))

Note: Do not connect the cable (CAB0011, 0013 or 0015) from the communication device to the optional LCD Remote Keypad. Or the inverter or the optinol LCD Remote Keypad could be damaged.

■ Setting for issuing run/stop commands from an external control device

Title	Function	Adjustment range	Default setting	Example of setting
CUOA	Command mode selection	<i>0~</i> 4	(Terminal input enabled)	∂ (2-wire RS485)

Note: When parameter F 8 0 5 (setting for communications between inverters) is used, the setting [\(\Pi \) 0 d = 2 cannot be used for slave inverters.

■ Setting for issuing speed commands from an external control device

Title	Function	Adjustment range	Default setting	Example of setting
FNOd	Frequency setting mode selection 1	1~13	رَّ (RR/S4 input)	5 (2-wire RS485)

■ Communication parameters (2-wire RS485)

These parameters allow you to change the communication speed, parity check setting, inverter number, communication error trip timer setting, etc. from the operation panel or an external control device.

communication error trip timer setting, etc. from the operation panel of an external control device.

Title	Function	· ·	Adjustment range		
F800	Communication speed (2-wire RS485)	#:9600 bps	#:9600 bps, 1:19200 bps, 2:38400 bps		
F80 :	Parity (common to 2-wire RS485 and 4-wire RS485)	☐:Non parity, 1:Even parity ☐:Odd parity			1
F802	Inverter number (common)	0~247			0
F803	Communications time-out time (common to 2-wire RS485 and 4-wire RS485)	☐:OFF I~ I ☐ ☐ sec.			0
		Setting	2-wire RS485	4-wire RS485	
		0	No action	No action	
		1	Alarm	No action	
I	Communications time-out action *	Ş	Trip	No action	
F804	(common to 2-wire RS485 and 4-wire	3	No action	Alarm	8
	RS485)	4	Alarm	Alarm	
		5	Trip	Alarm	
		<u> </u>	No action	Trip	
		1	Alarm	Trip	
		8	Trip	Trip	
F805	Send waiting time (2-wire RS485)	0.0 1~2.0	nal communio [] sec.	cations	0.00
F806	Master/slave setting for Inverter-to-inverter communications (2-wire RS485)	B:Slave (issues a 0Hz command if something goes wrong with the master) S:Slave (continues operation if something goes wrong with the master) B:Slave (trips for emergency stop if something goes wrong with the master) S:Slave (trips for emergency stop if something goes wrong with the master) S:Master (sends a frequency command) S:Master (sends an output frequency) S:Master (sends an output orque command)			o
F807	Protocol selection (2-wire RS485)	☐:TOSHIB.	A, :MODBL	JS	0

Title	Function	Adjustment range	Default setting
F808	Communication1 time-out condition selection	#:Disconnection detection #:When communication mode enable #:1+Driving operation	0
F8 10	Frequency point selection	☐:Disabled 1:2-wire RS485 ☐:4-wire RS485 ☐:Communication add option	0
F8 ! !	Point 1 setting	0~100%	0
FB 12	Point 1 frequency	0.0~F H Hz	0.0
F8 13	Point 2 setting	0~100%	100
F8 14	Point 2 frequency	0.0-F H Hz	Inverter with a model number ending with -WN, HN: & 0.0 -WP: 5 0.0
F870	Block write data 1	☐:Disabled I:Command information 1 Z:Command information 2 3:Frequency command 4:Terminal board output data 5:Communication analog output E:Rotational speed instruction	а
F871	Block write data 2	Ditto	0
F875	Block read data 1	G:Deselect I:Status information 2:Output frequency 3:Output current 4:Output voltage 5:Alarm information 6:PID feedback value 7:Input terminal board monitor 8:Output terminal board monitor 9:VIII terminal board monitor 10:RR/S4 terminal board monitor 12:Input voltage (DC detection) 13:Speed feedback frequency 14:Torque 15:MY monitor 1 16:MY monitor 2 17:MY monitor 3 18:MY monitor 4 19:Free notes 20:Rotational speed	a
F875	Block read data 2	Ditto	0
F877	Block read data 3	Ditto	0
F878	Block read data 4	Ditto	O
F879	Block read data 5	Ditto	0
F880	Free notes	0~FFFF	0

F880 | Free notes
 0~FF

 *: No action ... No action is taken even if a timeout occurs.

Alarm An alarm goes off if a timeout occurs.

The message "£" blinks at the left end of the operation panel.

Trip The inverter trips when a communication time-over occurs.

The message "Err5" blinks on the operation panel.

Note: Changes to the parameters F 8 0 0 , F 8 0 1 and F 8 0 5 do not take effect until the power is turned off and then on again.

2) 4-wire RS485

The 4-wire RS485 device included as standard equipment, allows you to connect the inverter to a higher-level system (host) and to set up a network for data communications between inverters. It makes it possible for the inverter to be linked to a computer and to carry out data communications with other inverters.

The connector (RJ45) for the 4-wire RS485 device on the control circuit terminal block is used to connect to other inverters.


■ Transmission specifications

Item	Specifications
Interface	Compliant with RS485
Transmission path specification	Half-duplex type [Buss type (terminator resistor required at each end of system)]
Wiring type	Compatible with both 4-wire and 2-wire types
Transmission distance	Up to 500m (overall length of the cable)
Number of connectable	Up to 32 units (including the host computer)
units	Number of inverters that can be connected in a system: Up to 32 units
Synchronization scheme	Asynchronous
Transmission rate	Default: 19200 baud (parameter setting)
Transmission rate	Selectable from 9600/19200/38400 baud
Character transmission	ASCII mode: JIS X 0201 8-bit (ASCII)
Character transmission	Binary code: Binary, 8-bit (fixed)
Stop bit length	Inverter receiving: 1 bit, Inverter sending: 2 bits
Error detection	Parity: Even, Odd, or None selectable by parameter setting; check sum method
Error correction	Not provided
Response monitoring	Not provided
Character transmission format	Reception: 11 bit, Sending: 12 bit (with parity)
Transmission waiting time setting	Possible
Others	Inverter's action at the occurrence of a communication timeout selectable from tripping/raising an alarm/doing nothing →When alarm is selected, "₺" blinks at the left end of the operation panel When tripping is selected, "₺" ⊏ 5" is displayed on the operation panel

■ Example of the connection of inverters linked to a computer

<Independent communication>

Perform computer-inverter connection as follows to send operation frequency commands from the host computer to inverter No. 3:




"Given away": Only the inverter with the selected inverter number conducts data processing. All other inverters, even if they have received the data, give it away and stand by to receive the next data.

: Use the terminal board to branch the cable.

- (1) Data is sent from the host computer.
- (2) Data from the computer is received at each inverter and the inverter numbers are checked.
- (3) The command is decoded and processed only by the inverter with the selected inverter number.
- (4) The selected inverter responds by sending the processing results, together with its own inverter number, to the host computer.
- (5) As a result, only the selected inverter starts operating in accordance with the operation frequency command by communicating independently.

<Broadcast>

When an operation frequency command is broadcasted from the host computer to inverters




- : Use the terminal board to branch the cable.
- (1) Data is sent from the host computer.
- (2) Data from the computer is received at each inverter and the inverter numbers are checked.
- (3) Data with an asterisk (*) in the inverter number position is taken as broadcast data and the command is deciphered and executed.
- (4) To avoid collisions between data, only the inverter with the asterisk (*) replaced with a zero (0) returns data to the host computer.
- (5) As a result, all inverters connected are operated at the operation frequency specified by the command broadcasted.

Note: If an inverter number is assigned to each group of inverters, data can be broadcasted on a group-by-group basis.

- (This function is usable only in ASCII mode. For binary mode, see Instruction Manual (E6581315) specified in Section 6.42.)
- Ex.) When the inverter number *1 is specified, data is broadcasted to inverters Nos. 01, 11, 21, 31, ... 91. At that time, data is returned by the inverter bearing number 01.

■ Inverter-to-inverter communication

When all slave inverters are connected they operat at the same frequency as the master inverter (no setting of point frequencies in this case)



- : Use the terminal board to branch the cable.
- (1) The master inverter transmits frequency command data to its slave inverters.
- (2) The slave inverter calculate a frequency reference from the data received and save the frequency calculated.
- (3) As a result, all slave inverters operate at the same frequency as the master inverter.

Note: The master inverter always sends frequency command data to its slave inverters.

The slave inverters are always on standby so that they can receive an frequency command from the master inverter at anytime.

■ Setting for issuing run/stop commands from an external control device

Title	Function	Adjustment range	Default setting	Example of setting
CUOA	Command mode selection	0~4	(Terminal input enabled)	3 (4-wire RS485)

Note: When parameter $F B \supseteq S$ (setting for communications between inverters) is used, the setting $E \cap G d = S$ cannot be used for slave inverters.

■ Setting for issuing speed commands from an external control device

Title	Function	Adjustment range	Default setting	Example of setting
FNOd	Frequency setting mode selection 1	1~13	₽ (RR/S4 input)	5 (4-wire RS485)

■ Communication parameters (4-wire RS485)

These parameters allow you to change the communication speed, parity, inverter number, communication error trip timer setting, etc. from the operation panel or an external control device.

Title	Function	A	djustment ran	ne	Default setting	
Title	Parity	☐:Non pari		ge	Delault Setting	
F80 I	(common to 2-wire RS485 and 4-wire	:Even parity			1	
, ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	RS485)	∂:Odd pari			,	
F802	Inverter number (common)	0~247			0	
, 000	Communications time-out time					
F803	(common to 2-wire RS485 and 4-wire	₿:OFF			a	
, 003	RS485)	1~ 100 s	ec.			
	110-100)	2-wire 4-wire				
		Setting	RS485	RS485		
		0	No action	No action		
		1	Alarm	No action		
	Communications time-out action *	2	Trip	No action		
F804	(common to 2-wire RS485 and 4-wire	3	No action	Alarm	8	
, , , ,	RS485)	4	Alarm	Alarm		
	110400)	5	Trip	Alarm		
		5	No action	Trip		
		7	Alarm	Trip		
		8	Trip	Trip		
			ection detect			
			ommunication		_	
F808	Communication1 time-out condition selection	enable			O	
		1+Drivin: ج	g operation			
		☐:Disabled	I			
F8 10	Frequency point selection	1:2-wire R	S485		а	
7010	6 10 Frequency point selection		2:4-wire RS485			
		∃:Communication add option				
F8 ! !	Point 1 setting	0~100%			O	
FB 12	Point 1 frequency	<i>□.□~F H</i> Hz			0.0	
F8 13	Point 2 setting	0~100%			100	
					Inverter with a	
					model number	
F8 14	Point 2 frequency	0.0~F H Hz			ending with	
					-WN, HN:	
					<i>60.0</i>	
		8			6 0.0 -WP: 5 0.0	
F820	Communication speed (4-wire RS485)		s, 1:19200 b	ps,		
	, , , , , , , , , , , , , , , , , , ,	⊋:38400 bj	ps		-WP: 5 (3.6) /	
F820 F825	Communication speed (4-wire RS485) Send waiting time (4-wire RS485)	2:38400 bj	ps ault, <i>[].[] 1~2</i>	7.00 sec.	-WP: <i>5 0.0</i>	
	, , , , , , , , , , , , , , , , , , ,	2:38400 bj 0:0:0:Defa 0:Slave (iss	ps ault, [].[] 1~2 sues a 0Hz co	?.[] [] sec. mmand if	-WP: 5 (3.6) /	
	, , , , , , , , , , , , , , , , , , ,	☐:38400 bp ☐:☐:Defa ☐:Slave (iss somethin	ps ault, <i>[].[] 1~2</i>	?.[] [] sec. mmand if	-WP: 5 (3.6) /	
	, , , , , , , , , , , , , , , , , , ,	☐:38400 bj ☐:☐:Defa ☐:Slave (iss somethin master)	ps ault, [].[] 1~2 sues a 0Hz co g goes wrong	mmand if with the	-WP: 5 (3.6) /	
	, , , , , , , , , , , , , , , , , , ,	2:38400 bp ☐.☐ ☐:Defa ☐:Slave (iss somethin master) 1:Slave (cc	ps ault, [].[] 1~2 sues a 0Hz co g goes wrong ontinues opera	R. [] [] sec. mmand if with the	-WP: 5 (3.6) /	
	, , , , , , , , , , , , , , , , , , ,	2:38400 bp 0:0:0:0:0:0efa 0:Slave (iss somethin master) 1:Slave (co somethin	ps ault, [].[] 1~2 sues a 0Hz co g goes wrong	R. [] [] sec. mmand if with the	-WP: 5 (3.6) /	
	Send waiting time (4-wire RS485)	2:38400 bp 0:0:0:Defa 0:Slave (iss somethin master) 1:Slave (co somethin master)	ps ault, [].[] 1~6 sues a 0Hz co g goes wrong ontinues opera g goes wrong	mmand if with the tion if with the	-WP: 5 (3.6) /	
F825	Send waiting time (4-wire RS485) Inverter-to-inverter communication setting	Z:38400 bp ☐:D Defa ☐:Slave (iss somethin master) I:Slave (co somethin master) Z:Slave (triple)	ps ault, ①.① 1~2 sues a 0Hz co g goes wrong ontinues opera g goes wrong ps for emerger	R.D.D sec. mmand if with the tion if with the ncy stop if	-WP: 5 0.0 (0.0 0	
	Send waiting time (4-wire RS485)	2:38400 bp 0:0 0:00 cists comethin master) 1:Slave (co somethin master) 2:Slave (tri somethin	ps ault, [].[] 1~6 sues a 0Hz co g goes wrong ontinues opera g goes wrong	R.D.D sec. mmand if with the tion if with the ncy stop if	-WP: 5 (3.6) /	
F825	Send waiting time (4-wire RS485) Inverter-to-inverter communication setting	2:38400 bp 0:0:0:0:0:0eta 0:Slave (iss somethin master) 1:Slave (co somethin master) 2:Slave (trip somethin master)	ps ault, [].[] 1~[sues a 0Hz co g goes wrong ontinues opera g goes wrong ps for emerge g goes wrong	mmand if with the tion if with the ncy stop if with the	-WP: 5 0.0 (0.0 0	
F825	Send waiting time (4-wire RS485) Inverter-to-inverter communication setting	2:38400 bp 0:0:0:0:0:0eta 0:Slave (iss somethin master) 1:Slave (co somethin master) 2:Slave (trip somethin master)	ps ault, [].[] 1~[sues a 0Hz co g goes wrong ontinues opera g goes wrong ps for emerge g goes wrong sends a freque	mmand if with the tion if with the ncy stop if with the	-WP: 5 0.0 (0.0 0	
F825	Send waiting time (4-wire RS485) Inverter-to-inverter communication setting	2:38400 bp 0:00:00 cpc 0:Slave (iss somethin master) 1:Slave (cc somethin master) 2:Slave (trip somethin master) 3:Master (sc command	ps ault, [].[] 1-2 sues a 0Hz co g goes wrong portinues opera g goes wrong ps for emergeing goes wrong seends a frequent d)	mmand if with the tion if with the ncy stop if with the	-WP: 5 0.0 (0.0 0	
F825	Send waiting time (4-wire RS485) Inverter-to-inverter communication setting	2:38400 bp 0:0 0:0 ciss Somethin master) 1:Slave (co somethin master) 2:Slave (tri somethin master) 3:Master (s command 4:Master (s	ps ault, [].[] 1~[sues a 0Hz co g goes wrong ontinues opera g goes wrong ps for emerge g goes wrong sends a freque	mmand if with the tion if with the ncy stop if with the ncy at frequency)	-WP: 5 0.0 (0.0 0	
F825	Send waiting time (4-wire RS485) Inverter-to-inverter communication setting	2:38400 bj 0:00 csc somethin master) 1:Slave (cc somethin master) 2:Slave (trij somethin master) 3:Master (sc commance 4:Master (s 5:Master (s	ps ault, []. [] 1-c suses a 0Hz co g goes wrong ontinues opera g goes wrong ps for emerge g goes wrong seends a frequently beends an output ps ault [] 1-c suses	e	-WP: 5 0.0 (0.0 0	
F825	Send waiting time (4-wire RS485) Inverter-to-inverter communication setting	2:38400 bj 0:00 csc somethin master) 1:Slave (cc somethin master) 2:Slave (trij somethin master) 3:Master (sc commance 4:Master (s 5:Master (s	ps p	e	-WP: 50:0 (0:00	
F825	Send waiting time (4-wire RS485) Inverter-to-inverter communication setting (4-wire RS485)	2:38400 bp 0:00 constant 3:Slave (iss somethin master) 1:Slave (co somethin master) 2:Slave (trip somethin master) 3:Master (sc command 4:Master (sc 5:Master (sc 6:Master (sc	ps p	e	-WP: 5 0.0 (0.0 0	
F825	Send waiting time (4-wire RS485) Inverter-to-inverter communication setting	2:38400 bp 0:00:00 cissomethin master) 1:Slave (cissomethin master) 2:Slave (tritical cissomethin master) 3:Master (scommanum 4:Master (scommanum 5:Master (scommanum 6:Master (scommanum	ps ault, []. [] 1-c ault, []. [] 1-c ault, []. [] 1-c ault au ong goes wrong ontinues operating goes wrong ps for emerger goes wrong goes wrong sends a frequent at orque sends an output au output d).	e	-WP: 5 0.0 (0.0 0	

Title	Function	Adjustment range	Default setting
F870	Block write data 1	#3:Disabled #5:Command information 1 #2:Command information 2 #3:Frequency command #4:Terminal board output data #5:Communication analog output	a
F871	Block write data 2	Ditto	O
F875	Block read data 1	## Deselect # Status information # Output frequency # Output frequency # Output voltage # Salarm information # PID feedback value # Input terminal board monitor # Output terminal board monitor # Output terminal board monitor # Output terminal board monitor # PIRX serminal board monitor # PIRX terminal board monitor # Input voltage (DC detection) # Speed feedback frequency # Torque # SiMY monitor 1 # MY monitor 1 # MY monitor 3 # MY monitor 4 # PiFree notes	O
F876	Block read data 2	Ditto	O
F877	Block read data 3	Ditto	O
F878	Block read data 4	Ditto	O
F879	Block read data 5	Ditto	O
F880	Free notes	0~FFFF	O

^{*:} No action ... No action is taken even if a timeout occurs.

Note: Changes to the parameters F 8 0 1, F 8 2 0 and F 8 2 5 do not take effect until the power is turned off and then on again.

Alarm An alarm goes off if a timeout occurs.

The message "L" blinks at the left end of the operation panel.

 $[\]mbox{Trip}\;\;$ The inverter trips when a communication time-over occurs.

The message " $\mathcal{E} \sim 5$ " blinks on the operation panel.

6.39.2 Open network option

F576~F594	: For Ethernet Communication option
F784~F789	: MAC address data 1~6
F792~F799	: Device name data 1~8
FB 15	: Address monitor (Modbus plus)
F8 16	: Command selection (Modbus plus)
F8 17	: Number of command (Modbus plus)
F8 18	: Number of monitors (Modbus plus)
F8 19	: Command station (Modbus plus)
F82 !	: Baud rate (Ethernet)
F822	: Baud rate monitor right port (Ethernet)
F823	: Baud rate monitor left port (Ethernet)
F824	: - (Reservation)
F830~F838	: Communication option settings 1 to 7
F841~F848	: Communication option settings 8 to 13
F849	: Disconnection detection extended time
F850	: Disconnection detection extended time
F85 1	: Inverter operation at disconnection
F852	: Preset speed operation selection
F853, F854	: Selection of monitoring

[⇒] For details, refer to Instruction Manual (E6581281, E6581343) specified in Section 6.42.

6.40 My function

F900: Input function target 11~ F977: My function selection

⇒ For details, refer to Instruction Manual (E6581335) specified in Section 6.42.

6.41 Traverse function

 F980 : Traverse selection
 F983 : Traverse step

 F981 : Traverse acceleration time
 F984 : Traverse jump step

: Motor pairs of poles for communication

F982 : Traverse deceleration time

[⇒] For details, refer to Instruction Manual (E6581337) specified in Section 6.42.

6.42 Instruction manuals for optionally available devices and special functions


	For details, refer to the instruction manual for each optional device or function.						
No.	Description	Model	Instruction	Remarks			
INO.	Description	number	Manual No.	Remarks			
1	Light-load high-speed operation function	_	E6581327	_			
2	PID control operation function	_	E6581329	_			
3	Torque control operation function	_	E6581331	_			
4	Current and speed control gain adjustment method	-	E6581333	-			
5	My function	_	E6581335	_			
6	Traverse function	-	E6581337	_			
7	Switching between commercial power and inverter	-	E6581364	-			
8	RS485 communication function	-	E6581315	-			
9	Combination of the VFAS1 and a DC power supply	-	E6581432	-			
10	Expansion I/O card 1 option	ETB003Z	E6581339	Attached to expansion I/O card 1 option			
11	Expansion I/O card 2 option	ETB004Z	E6581341	Attached to expansion I/O card 2 option			
12	PG feedback option	VEC004Z~ VEC007Z	E6581319	Attached to PG feedback option			
13	DeviceNet option	DEV002Z	E6581295	Attached to DeviceNet option			
14	DeviceNet option function	DEV002Z	E6581281	Detailed instruction manual			
15	PROFIBUS-DP option	PDP002Z	E6581279	Attached to PROFIBUS –DP option			
16	PROFIBUS-DP option function	PDP002Z	E6581343	Detailed instruction manual			
17	CC-Link option	CCL001Z	E6581286	Attached to CC-Link option			
18	CC-Link option function	CCL001Z	E6581288	Detailed instruction manual			
19	LCD Remote Keypad	RKP004Z	E6581323	Attached to LCD Remote Keypad			
20	LED Remote Keypad	RKP002Z	E6581277	Attached to LED Remote Keypad			
21	Control power supply backup option	CPS002Z	E6581289	Attached to control power supply backup option			
22	USB-to-Serial conversion unit	USB001Z	E6581282	Attached to USB-to-Serial conversion unit			
23	USB-to-Serial conversion unit	USB001Z	E6581299	Attached in the strage device of USB-to-Serial conversion unit			
24	Optional braking unit PB7	PB7-4200K PB7-4400K	E6581436	For 200kW or more units			
25	Fin outside mounting kit (optional)	FOT***Z	E6581399 E6581400 E6581365	200V-15kW, 400V-18.5kW 200V-18.5~45kW, 400V-22~75kW 200V-55kW~, 400V-90kW~			

7. Operation with external signal

7.1 External operation

The inverter can be freely controlled externally.

Parameters must be differently set depending on the operation method. Make sure of the operation method before setting parameters, and set parameters properly to the operation mode according to the procedure mentioned below.



7.2 Applied operation with input and output signals (operation by terminal board)

7.2.1 Functions of input terminals (in case of sink logic)

Use the above parameters to send signals from an external programmable controller to various control input terminals to operate and/or set the inverter.

The desired contact input terminal functions can be selected from 120 types. This gives system design flexibility. [Control terminal board]



■ Setting of contact input terminal function

Terminal symbol	Title	Function	Adjustment range	Default setting
_	F / / [] [Note 5],	Always ON function selection 1~3		[] (No function is
	F 127, F 128]	assigned)
F	F 111	Input terminal function selection 1 (F)		¿ (Forward run)
R	F 1 12	Input terminal function selection 2 (R)	0~135	닉 (Reverse run)
ST	F 11[] [Note 6], F 113	Input terminal function selection 3 (ST)		Standby
RES	F 1 14	Input terminal function selection 4 (RES)	⇒ Refer to	☐ (Reset)
S1	F 1 15	Input terminal function selection 5 (S1)	Section	1 ☐ (Preset speed 1)
S2	F 1 15	Input terminal function selection 6 (S2)	7.2.1.	1 ₽ (Preset speed 2)
S3	F 1 17	Input terminal function selection 7 (S3)		14 (Preset speed 3)
RR/S4	F 1 18	Input terminal function selection 8 (RR/S4)		15 (Preset speed 4)
LI1~LI8	F 1 19~F 126	Input terminal function selection 9~16		0
B12~B15	F 164~F 167	Input terminal function selection 17~20		0

Note 1:RR/S4 terminal become enable when SW3 is switch to S4.

Note 2: When F 110, F 127 and F 128 (Always ON function selection 1~3) are selected, selected function is generally activated regardless of positive or negative logic.


Note 3: F 119~F 125 is for use of expansion terminal board option unit.

Note 4: F 15 4~F 15 7 is not supported (for options).


Note 5: VFAS1-****-WN. HN Note 6: VFAS1-****-WP

■ Connection method (An example of the connection of terminals: SW1 set to sink logic)


1) In case of positive logic (a-contact) input



2) In case of negative logic (b-contact) input




3) Connection with transistor output




* Interface between programmable controller and inverter

When using an open-collector output type programmable control device to control the operation of a motor, connect cables, as shown in the schematic diagram for sink/source logic (when an external power supply is used) on page B-15. When using the internal power supply of the inverter, connect cables, as shown in the schematic diagram on page B-14. If the programmable control device is turned off with the inverter left on, an incorrect signal will flow into the inverter, as shown in the figure below, because there is a potential difference between the control power supplies. Be sure to provide an interlock so that the programmable controller cannot be turned off when the inverter is on.



■ Example of use- three-wire operation (SW1 set to sink logic)

The three-wire operation function allows you to make the inverter self-hold its operation, without setting up a sequential circuit, so that the inverter can be operated by means of external signals (reset contact signals).



Forward run (F): If you press the Forward (F) button, the motor rotates in the forward direction at the frequency specified with a command.

Reverse run (R): If you press the Reverse (R) button, the motor rotates in the reverse direction at the frequency specified with a command.

HD (S3): If you press the HD (S3) button, the motor decelerates and comes to a stop.

[Parameter setting]

Terminal symbol	Title	Function	Adjustment range	Example of setting
S3	F 1 17	Input terminal function selection 7(S3)	<i>0∼135</i>	5 🛭 (HD operation retention)

■ Table of setting of contact input terminal function

	er setting	contact input terminal function	Paramete	er setting	
Positive logic	Negative logic	Function	Positive logic	Negative logic	Function
O	1	No function is assigned	70	7 /	Servo lock signal
2	3	F: Forward run command	72	73	Simple positioning (positioning loop)
4	5	R: Reverse run command	74	75	Integrating wattmeter display clear
5	7	ST: Standby	76	77	Trace back trigger signal
8	9	RES: Reset	78	79	Light-load high-speed operation prohibitive signal
10	1.1	S1: Preset speed 1	80	8 :	No function assigned
12	13	S2: Preset speed 2	82	83	No function assigned
14	15	S3: Preset speed 3	84	85	No function assigned
15	17	S4: Preset speed 4	86	87	Binary data write
18	19	Jog run	88	89	Up/down frequency (up) *1
20	2!	Emergency stop	90	9 :	Up/down frequency (down) *1
55	23	DC braking	92	93	Up/down frequency (clear)
24	25	Acceleration/deceleration switching 1 *2	94	95	No function assigned
26	27	Acceleration/deceleration switching 2 *2	96	97	No function assigned
28	29	V/f switching signal 1 *2	98	99	Forward/reverse selection
30	3 !	V/f switching signal 2 *2	100	10 1	Run/stop command *3
32	33	Torque limit switching signal 1 *2	102	103	Commercial power/INV switching
34	35	Torque limit switching signal 2 *2	104	105	Frequency reference priority switching
35	37	PID control OFF selection	105	107	VI/II terminal priority
38	39	Pattern operation group 1	108	109	Command terminal board priority
40	41	Pattern operation selection 2	110	111	Permission of parameter editing
42	43	Pattern operation continuation signal	112	113	Speed/Torque switching
44	45	Pattern operation trigger signal	114	115	No function assigned
45	47	External thermal error	1 15	117	No function assigned
48	49	Communication priority cancel	118	113	No function assigned
50	5 /	HD operation retention	120	121	No function assigned
52	53	PID differentiation/integration clear	122	123	Rapidest deceleration command
54	55	PID forward/reverse switching	124	125	Preliminary excitation *4
56	57	Forced continuous operation	126	127	Braking request
58	59	Specified speed operation	128	129	No function assigned
5 C	Б:	Acceleration/deceleration suspend signal	130	13 1	Brake answer back input
62	63	Power failure synchronized signal	132	133	No function assigned
5 Y	<i>65</i>	My function RUN signal	134	135	Traverse permission signal
55	<i>5</i> 7	Auto-tuning signal			
68	69	Speed gain switching			

^{*2:} To switch acceleration/deceleration pattern, V/f pattern, torque limit 1~4, give the following signals to switching functions.

	Switching signal 1	Switching signal 2
Acceleration/deceleration1, V/f 1, torque limit 1	OFF	OFF
Acceleration/deceleration2, V/f 2, torque limit 2	ON	OFF
Acceleration/deceleration3, V/f 3, torque limit 3	OFF	ON
Acceleration/deceleration4, V/f 4, torque limit 4	ON	ON

^{*3:} If 2, 3 (F: Forward run command) or 4, 5 (R: Reverse run command) is assigned at the same time, this function has a priority.

This function should not be used when $F \in \Omega \subseteq S$ is set to $\supseteq S$ or $\subseteq S$. Or the inverter might malfunction.

^{*4:} After the motor slows down and comes to a full stop at a pre-excitation command, the motor is set free momentarily to bring it into a pre-excitation state.

^{*5:} Do not set the function " Permission of parameter editing" into the parameter F 119-F 125 (without option) and 154-F 157. If it is setted, can not reset the setting.

■ Sink logic/source logic

Switching between sink logic and source logic (input/output terminal logic) is possible.


⇒ For details, refer to the Section 2.3.2.

7.2.2 Functions of output terminals (incase of sink logic)


Use the above parameters to send various signals from the inverter to external equipment.

By setting parameters for the OUT1, OUT2 and FL (FLA, FLB and FLC) terminals on the terminal board, you can use 0-255 functions and functions obtained by combining them.

[Control terminal board]



■ How to use



■ Setting of output terminal function

Terminal symbol	Title	Function	Adjustment range	Default setting
OUT1	F 130	Output terminal function selection 1	0~255	্ধ (Low-speed signal)
OUT2	F 13 I	Output terminal function selection 2	0~255	E (Acceleration/decele ration completion)
FL	F 132	Output terminal selection 3	0~255	/ Ū (Failure FL)
OUT3~OUT6 R1~R2	F 133~F 138	Output terminal function selection 4~9	0~255	254
R3, R4	F 168, F 169	Output terminal function selection 10~11	0~255	254

Note1: $F : 133 \sim F : 135$ is for use of expansion terminal board 1 option unit.

Note2: F 135~F 138 is for use of expansion terminal board 2 option unit.

Note3: F 158, F 159 is not supported (for options).

Note4: When use OUT1 terminal for pulse output function, refer to Section 6.35.1.

■ Output terminal function (open collector, relay outputs) setting and detection levels

For the open connector output terminals (OUT1, OUT2) and the relay output terminals (FLA, FLB and FLC). functions can be selected from 0 to 255 functions. The selectable functions and detection levels are listed in the table below.

Up to 7 output terminals can be used if add-on options are used in combination with the inverter, while up to 3 output terminals can be used if no add-on option is used.

<Technical terms>

Light failure

• AlarmAlarm output beyond a certain setting value.

 Pre-alarmAlarm output of the state where the inverter may carry out a trip by continuation.

• Serious failureOutput signal in a serious failure of the protection function of the inverter. (Arm overcurrent (\$\Pi F R I, P, P), Load side overcurrent (\$\Pi F I), Short-circuiting

(EF 1, EF2), Phase failure (EPHD, EPH 1), Abnormal output current detection (Err 7))

......Output signal in a slight failure of the protection function of the inverter.

(Overload (GL(1,2)), overvoltage (GP(1,2,3)), overcurrent during acceleration/deceleration/fixed speed operation (CF, 1, 1P, 2, 2P, 3, 3P))

• Emergency stopOutput signal when the inverter comes into emergency stop.

Stopping manner is set with $F \not\in \mathcal{G} \not\ni$ (emergency stop).

Table of output terminal functions and detection levels

Parameter setting					
Positive	Negative	Function	Operation output specifications (in case of positive logic)		
logic	logic				
0	1	Lower limit frequency (LL)	ON:The running frequency is equal to or higher than the setting of $L \ L$ (Lower limit frequency) OFF:The running frequency is lower than the setting of $L \ L$.		
2	3	Upper limit frequency (UL)	ON:The running frequency is equal to or higher than the setting of #L (Upper limit frequency) OFF:The running frequency is lower than the setting of #L.		
ч	5	Low-speed signal	ON:The running frequency is equal to or higher than the setting of <i>F</i> ! \(\textit{!}\) \(\text{low-speed signal output frequency} \) OFF:The running frequency is lower than the setting of <i>F</i> ! \(\text{l}\) \(\text{l}\) \(\text{l}\).		
5	7	Acceleration/decelerati on completion	ON:The difference between the frequency command and the running frequency is within the setting of <i>F</i> t :: 2. OFF:In acceleration or deceleration.		
8	9	Speed reach signal	ON:The running frequency is in the range of $F : 0 : \pm F : 0 : 2$. OFF:The running frequency is out of the range of $F : 0 : \pm F : 0 : 2$.		
10	1.1	Failure FL (All trips)	ON:Inverter is tripped. OFF:Inverter trip is canceled.		
		Failure FL	ON:Inverter is tripped (except <i>EF</i> and <i>□,E,L</i>)		
12	13	(Except EF, OCL)	OFF:Inverter trip is canceled. (reset)		
14	15	Overcurrent (OC) pre-alarm	ON:Inverter output current is over the F & 0 ! (Stall prevention level) set value. OFF:Inverter output current is under the F & 0 !.		
16	17	Inverter overload (OL1) pre-alarm	ON:A certain rate of inverter overload ("L' !) detection time is over. OFF:The detection time is within a certain limit.		
18	19	Motor overload (OL2) pre-alarm	ON:A certain rate of inverter overload ($G' L Z'$) detection time is over. OFF:The detection time is within a certain limit.		
20	21	Overheat pre-alarm	ON:The temperature of the cooling fin is 95°C or higher inside the inverter. OFF:The temperature drops to 90°C or lower after overheat pre-alarm was on.		
22	23	Overvoltage pre-alarm	Overvoltage control operation or PB operation in progress. ON: PB operation level + 3% (200V class: Approx. 370Vdc, 400V class :Approx. 740Vdc)		
24	25	Undervoltage in main circuit (MOFF) detection	ON:The main circuit voltage is lower than the main circuit undervoltage detection (F & 2 5) level. (200V class: Approx. 170Vdc, 400V class: Approx. 340Vdc)		
26	27	Low current detection	ON: The state that inverter output current is F 6 ! ! set value or larger continued more than F 6 ! 2 set value.		

Paramete Positive logic	er setting Negative logic	Function	Operation output specifications (in case of positive logic)
2 B	23	Over-torque detection	ON:The state that torque component is F 5 15, F 5 17 set value or larger continued more than F 5 18 set value.
30	3 /	Braking resistor overload pre-alarm	ON:A certain rate of braking resister overload trip (\$\overline{U} \subseteq r\) detection time is over. OFF:The detection time is within a certain limit.
32	33	In emergency stop	ON:In emergency stop operation (\mathcal{E} is indicated). OFF:The detection time is within a certain limit.
34	35	In retry	ON:In retry operation (¬ Ł ¬ ⅓ is indicated). OFF:No retry operation is performed.
36	37	Pattern operation switching output	ON:In normal operation or pattern operation has finished. OFF:In pattern operation.
38	39	PID deviation limit	ON:PID deviation is in F 3 6 4 or F 3 6 5 set value.
40	4 /	Run/Stop	ON:Running frequency is output or DC injection breaking (db) is performed.
42	43	Serious failure (OCA, OCL, EF, phase failure, etc.)	ON:Serious failure ($\# ER$, $\# EL$, EF , phase failure, abnormal output, short-circuit) is detected. OFF:Inverter has recovered from serious failure. (Serious failure has been reset)
44	45	Light failure (OL, OC1, 2, 3, OP)	ON:Light failure (GL , GL) is detected. OFF:Inverter has recovered from light failure. (Light failure has been reset)
46	47	Commercial power/inverter switching output 1	Refer to Section 6.19.
48	49	Commercial power/inverter switching output 2	Refer to Section 6.19.
50	5 /	Cooling fan ON/OFF	ON:Cooling fan is in operation. OFF:Cooling fan is off operation.
52	53	In jogging operation (In jog run)	ON:In jog run OFF:In normal operation
54	55	Operation panel/terminal board operation switching	ON:In operation by terminal board. OFF:In operation by operation panel.
5.6	57	Cumulative operation time alarm	ON:Cumulative operation time is beyond the $F \not\in \mathcal{Z}$ I set value. OFF:Cumulative operation time is less than the $F \not\in \mathcal{Z}$ I set value.
58	59	PROFIBUS/DeviceNet/CC- Link communication error	ON:Communication error occurred. OFF:Communication error is canceled (reset).
60	<i>6 1</i>	Forward/reverse switching	OFF:In forward operation. ON:In reverse operation. It output command status while operation is stopped. (When command status is not active, It will be "OFF")
62	63	Ready for operation 1	ON:In operable status or operation can be started with frequency command input as an operation switching answer-back. OFF:In inoperable status.
<i>6</i> 4	65	Ready for operation 2	ON:In operable status or operation can be started with ST and RUN signals and frequency command input. OFF:In inoperable status.
68	59	Brake release (BR)	Output the braking signal according to the brake sequence.
סר	71	In (pre-)alarm status	ON:More than one of alarm, pre-alarm, undervoltage, low current over-torque, poor control power supply, PID deviation limit, abnormal frequency setting or torque limit have occurred or detected. OFF:All the alarms above are canceled.
72	73	Forward speed limit (torque control)	ON:Forward operation speed is $F \not\vdash Z \not\vdash S$ set value or over. OFF:Forward operation speed is less than $F \not\vdash Z \not\vdash S$ set value.
74	75	Reverse speed limit (torque control)	ON:Reverse operation speed is $F \not\in B$ set value or over. OFF:Reverse operation speed is less than $F \not\in B$ set value.
7.5	77	Inverter healthy output	ON and OFF are alternately output at intervals of 1 second.
78	79	RS485 communication error	ON:Communication error occurred. OFF:Communication error is canceled (reset).
80	8:	Error code output 1	
82	83	Error code output 2	
84 86	85 87	Error code output 3 Error code output 4	Output the error code in 6-bit.
88	89	Error code output 5	
90	91	Error code output 6	

Paramete	er setting			
Positive Negative		Function	Operation output specifications (in case of positive logic)	
logic	logic		, , , , , , , , , , , , , , , , , , , ,	
92	93	Specified data output 1		
94	95	Specified data output 2		
9.6	97	Specified data output 3		
98	99	Specified data output 4	Output of the designated data in 7-bit.	
100	10 1	Specified data output 5		
102	103	Specified data output 6		
104	105	Specified data output 7		
106	107	Light load output	ON:Load is equal to F 3 35~F 3 38 set values or less.	
108	109	Heavy load output	ON:Load is larger than F 3 3 5 ~ F 3 3 8 set value.	
1 10	111	Positive torque limit	ON:Positive torque is over the positive torque limit level.	
115	113	Negative torque limit	ON:Negative torque is over the positive torque limit level.	
114	115	Output for external rush suppression relay	ON:External rush suppression relay is actuated.	
118	119	Completion of stop positioning	ON:Stop positioning has been completed.	
120	12.1	L-STOP	ON:Operation at the lower limit frequency is performed continuously.	
155	123	Power failure synchronized operation	ON:Power failure synchronized operation is performed.	
124	125	Traverse in progress	ON:Traverse operation is performed.	
126	127	Traverse deceleration in progress	ON:Traverse deceleration operation is performed.	
128	129	Part replacement alarm	Alarm:The time of replacement of parts is approaching.	
130	13 1	Over-torque pre-alarm	ON: 70% of the F 5 15 or F 5 17 setting level is detected.	
132	133	Frequency command 1/ 2 selection	ON:Frequency command selection 2 is selected.	
134	135	Failure FL (Except emergency stop)	ON:A trip other than emergency stop has occurred.	
555	553	My function output 1	ON:My function output 1 is ON.	
554	225	My function output 2	ON:My function output 2 is ON.	
226	227	My function output 3	ON:My function output 3 is ON.	
228	229	My function output 4	ON:My function output 4 is ON.	
230	23 !	My function output 5	ON:My function output 5 is ON.	
232	233	My function output 6	ON:My function output 6 is ON.	
234	235	My function output 7	ON:My function output 7 is ON.	
236	237	My function output 8	ON:My function output 8 is ON.	
238	239	My function output 9	ON:My function output 9 is ON.	
240	241	My function output 10	ON:My function output 10 is ON.	
245	243	My function output 11	ON:My function output 11 is ON.	
244	245	My function output 12	ON:My function output 12 is ON.	
246	247	My function output 13	ON:My function output 13 is ON.	
248	249	My function output 14	ON:My function output 14 is ON.	
250	25 1	My function output 15	ON:My function output 15 is ON.	
252	253	My function output 16	ON:My function output 16 is ON.	
254	255	Always OFF (for terminal signal tests)	Output signal always OFF	

Note 1: "ON" in positive logic : Open collector output transistor or relay is turned on.

"OFF" in positive logic : Open collector output transistor or relay is turned off.

"ON" in negative logic : Open collector output transistor or relay is turned off.

"OFF" in negative logic : Open collector output transistor or relay is turned on.

Note 2: Alarm output check conditions are as follows.

 $\begin{tabular}{ll} \end{tabular} \begin{tabular}{ll} \end{tabular} \beg$

(2) Low current detected : To be checked during operation command.

(3) Overtorque detected : To be checked always.

■ Sink logic/source logic

Sink logic and source logic (logic of input/output terminal) can be switched to each other.

⇒ For details, refer to Section 2.3.2.

7.2.3 Setup of input terminal operation time

•Function

The input/output terminal operation time setup function is used to extend response time if there is something malfunctioning because of noise or chattering of input relay.

■ Setup of response time

Title	Function	Adjustment range	Default setting
F 140	Input terminal 1 response time selection (F)	2~200 ms	8
FIYI	Input terminal 2 response time selection (R)	2~200 ms	8
F 142	Input terminal 3 response time selection (ST)	2~200 ms	8
F 143	Input terminal 4 response time selection (RES)	2~200 ms	8
F 144	Input terminal 5~12 response time selection	2~200 ms	8
F 145	Input terminal 13~20 response time selection	5~200 ms	8

Setting when vector option unit or expansion terminal board option is used.

Note: Response time is time to receive the terminal signal. The reflection to the inverter output in actual has the delay of several further ms.

7.2.4 Analog input filter

•Function

This function is effective to remove noise from the frequency setting circuit. If operation is unstable because of noise, increase the time constant of the analog input filter.

■ Response time setting


Title	Function	Adjustment range	Default setting
F 2 0 9	Analog input filter	☐:No filter /:Filter approx. 10ms ☐:Filter approx. 15ms ☐:Filter approx. 30ms ☐:Filter approx. 60ms	O

7.3 Setup of external speed command (analog signal)

Function of analog input terminals can be selected from four functions (external potentiometer, 0 to 10Vdc, 4 (0) to 20mAdc, -10 to +10Vdc). The selective function of analog input terminals gives system design flexibility.

⇒ Refer to Section 6.28 for fine adjustment of analog setting signal and output frequency.

[Control terminal board]



■ Setting of analog input terminal functions

Terminal symbol	Title	Function	Adjustment range	Default setting
-	F200	Frequency priority selection	©:F∏@d/F2@7 terminal switching (input terminal function selection f@4, f@5) for the first first for the first fir	G .
	F201	VI/II input point 1 setting	0~100%	0
VI/II	F202	VI/II input point 1 frequency	0.0~F # Hz	0.0
V 1/11	F203	VI/II input point 2 setting	0~100%	100
	A IF 2	VI/II input point 2 frequency	<i>□.□~F H</i> Hz	*1
-	F207	Frequency setting mode selection 2	Same as F \(\iii \ii \ii \) (1 ~ 1 \(\frac{1}{2} \))	1
-	F208	Speed command priority switching frequency	0. I~F H	0.1
All	F209	Analog input filter	☐ (No filter)~ ☐ (Max. filter)	G
	F210	RR/S4 input point 1 setting	0~100%	G
RR/S4	F211	RR/S4 input point 1 frequency	<i>□.□~F H</i> Hz	0.0
10004	F212	RR/S4 input point 2 setting	0~100%	100
	RuF2	RR/S4 input point 2 frequency	0.0~F # Hz	*1
	F216	RX input point 1 setting	- 100~ 100%	O
RX	F217	RX input point 1 frequency	<i>□.□~F H</i> Hz	0.0
KA.	F218	RX input point 2 setting	- 100~ 100 %	100
	F219	RX input point 2 frequency	<i>□.□~F H</i> Hz	*1
Option	F222 ~F231	Al1, Al2 input point setting	For details, see Instruction Manual (E6581341) specified in Section 6.41.	
Оршоп	F234 ~F237	RP/high speed pulse input point setting	For details, see Instruction Mai (E6581319) specified in Sectio	

^{*1:} Inverter with a model number ending with -WN, HN: 60.0 -WP: 50.0

Note 1: Input terminals of AI1 and AI2 are at expansion TB option unit.

Note 2: Input terminals of RP/high speed pulse is at PG feedback device option unit.

7.3.1 Setup by analog input signals (RR/S4 terminal)

If a potentiometer $(1-10k\Omega-1/4W)$ for setting up frequency is connected with the RR/S4 terminal, the inverter can be run and stopped with external commands.


For bringing this function into practice, connect a potentiometer to the terminals of PP, RR/S4 and CC so as to divide the reference voltage (10Vdc) at the terminal PP and to input 0 to 10Vdc of divided voltage between the RR/S4 and CC terminals

If analog voltage signal of 0 to 10Vdc is input between the terminals of RR/S4 and CC, frequency can be set up without connection of a potentiometer.

Title	Function	Adjustment range	Default setting	Example of setting
Enoa	Command mode selection	0~4	[] (Terminal)	[] (Terminal)
FNOd	Frequency setting mode selection 1	1~13	₽ (RR/S4)	¿ (RR/S4)
FNSL	FM terminal meter selection	0~64	0	1
FΠ	FM terminal meter adjustment	-	-	-
F200	Frequency priority selection	0, 1	0	0
F209	Analog input filter	☐ (No filter)~ ☐ (Max. filter)	0	0
F210	RR/S4 input point 1 setting	0~100%	0	0
F211	RR/S4 input point 1 frequency	0.0~F H Hz	0.0	0.0
F212	RR/S4 input point 2 setting	0~100%	100	100
RuF2	RR/S4 input point 2 frequency	0.0~F H Hz	*1	*1

^{*1:} Inverter with a model number ending with -WN, HN: 60.0 -WP: 50.0

«An example of the connection of terminals: SW1 set to sink logic»




7.3.2 Setup by analog input signals (VI/II terminal)

Connect current signal (4 (0) to 20mAdc) or voltage signal (0 to 10Vdc) to the terminal II so that the inverter can be run and stopped with external commands.

Title	Function	Adjustment	Default cetting	Example of setting	
Title	Function	range	Default setting	4 (0)~20mAdc	0~10Vdc
E N D d	Command mode selection	0~4	[] (Terminal)	[] (Terminal)	[] (Terminal)
FNOd	Frequency setting mode selection 1	1~ 13	₽ (RR/S4)	; (VI/II)	; (VI/II)
FNSL	FM terminal meter selection	0~6 Y	G G	1	1
FΠ	FM terminal meter adjustment	-	-	-	-
F 108	Analog V/II voltage/current switching	☐: Voltage input /: Current input	0	1	1
F200	Frequency priority selection	O, 1	G G	0	G .
F201	VIII input point 1 setting	0~100%	0	2 0.0	0.0
F202	VIII input point 1 frequency	<i>□.□~F H</i> Hz	0.0	0.0	0.0
F203	VIII input point 2 setting	0~100%	100	100	100
R 1F2	VIII input point 2 frequency	<i>0.0∼F H</i> Hz	*1	*1	*1
F209	Analog input filter	☐ (No filter)~ ∃ (Max. filter)	0	0	0

^{*1:} Inverter with a model number ending with -WN, HN: 60.0 -WP: 50.0

«An example of the connection of terminals: SW1 set to sink logic»




7.3.3 Setup by analog input signals (RX terminal)

Connect voltage signal (0 to ±10Vdc) to the terminal RX so that the inverter can be run and stopped with external commands.

Title	Function	Adjustment range	Default setting	Example of setting
C N D d	Command mode selection	0~4	☐ (Terminal)	☐ (Terminal)
FNOd	Frequency setting mode selection 1	1~13	₽ (RR/S4)	∃ (RX)
FNSL	FM terminal meter selection	0~64	0	1
FΠ	FM terminal meter adjustment	-	•	-
F200	Frequency priority selection	0, 1	0	0
F209	Analog input filter	☐ (No filter)~ ∃ (Max. filter)	0	0
F216	RX input point 1 setting	- 100~ 100 %	0	0
F217	RX input point 1 frequency	<i>□.□~F H</i> Hz	0.0	0.0
F218	RX input point 2 setting	- 100~ 100 %	100	100
F219	RX input point 2 frequency	<i>□.□~F H</i> Hz	*1	*1

^{*1:} Inverter with a model number ending with -WN, HN: 60.0 -WP: 50.0

«An example of the connection of terminals: SW1 set to sink logic»



^{*:} Regardless of open/closed circuit between R and CC terminals, run and stop operation is controllable.

Switching between forward run and reverse run is controllable by the terminals F/R and RX if reverse run prohibition selection *F* 3 ! ! is properly set up.


⇒ For details, refer to Section 6.14.4.

8. Monitoring the operation status

8.1 Screen composition in the status monitor mode

The status monitor mode is used to monitor the operation status of the inverter.

⇒ For modes available and instructions about how to switch them, refer to section 3.1.



8.2 Monitoring the status

8.2.1 Status monitor under normal conditions

In this mode, you can monitor the operation status of the inverter.

To monitor the inverter when it is normally running, press the MODE key **twice** and the current status is indicated on the LED display.

Setting procedure (EX.: operation at 60 Hz)

	Commun ication No.	Item displayed	Key operated	LED display	Description
*1	-	Standard monitor mode		6 O.O	The output frequency is displayed (during operation). (When standard monitor display selection F 7 III is set to III [Output frequency])
	FE01	Setting monitor mode	MODE	ЯШН	The first basic parameter "History function (###)" is displayed.
	FE01	Status monitor mode (Rotating direction)	MODE	Fr-F	The rotating direction is displayed. (F :Forward run, r :Reverse run)
*2	•	Frequency command value	\bigcirc	6 O.O	The operation frequency command value is displayed. (When F 7 ! != !, Frequency command)
*3	-	Output current	\bigcirc	C 80	The inverter output current (load current) is displayed. (When F 7 12=2, Output current)
*4	-	Input voltage (DC detection)	\Diamond	A 100	The Inverter DC voltage (default setting: unit %) is displayed.(When F 7 13=3, Input voltage) [Note 3]
*5	-	Output voltage	\bigcirc	P 100	The inverter output voltage (default setting: unit %) is displayed.(When F 7 14=4, output voltage)
*6	-	Torque	\bigcirc	9 100	The torque is displayed. (When F 7 15=8 torque)
*7	-	Regenerative braking resistance overload factor (PBrOL data)	\Diamond	r 0	The regenerative braking resistance overload factor is displayed. (When F 7 $!$ E = $!$ E , regenerative braking resistance overload factor)
*8	-	Inverter overload factor (OL1 data)	\Diamond	G 0	The inverter overload factor is displayed. (When F 7 17= 15, inverter overload factor)
*9	ı	Motor overload factor	\Diamond	L 100	The motor overload factor (default setting: unit %) is displayed. (When F 7 $IB = IY$, Motor overload factor)
	FE00	Output frequency	\Diamond	6 0.0	The output frequency is displayed.
		Input terminal information 1	\Diamond	11111111	The ON/OFF status of each of the control signal input terminals (F, R, ST, RES, S1, S2, S3, RR/S4) is displayed in bits.
	FE06	Input terminal information 2	\Diamond	A !!!!	The ON/OFF status of each of the optional control signal input terminals (LI1, LI2, LI3, LI4) is displayed in bits.
		Input terminal information 3	$\langle \rangle$	ь !!!!	The ON/OFF status of each of the optional control signal input terminals (LI5, LI6, LI7, LI8) is displayed in bits.
[Note 4]		Output terminal information 1	\Diamond	0 111	The ON/OFF status of each of the control signal output terminals (OUT1, OUT2, FL) is displayed in bits.
	FE07	Output terminal information 2	\bigcirc	11111111	The ON/OFF status of each of the optional control signal output terminals (OUT3, OUT4, R1, OUT5, OUT6, R2, R3, R4) is displayed in bits.

(Continued overleaf)

	(Continued))			
	Commun ication No.	Item displayed	Key operated	LED display	Description
	FE08	CPU1 version	$\langle \rangle$	J 100	The version of the CPU1 is displayed.
	FE73	CPU2 version	\bigcirc	c 100	The version of the CPU2 is displayed.
[Note 5]	FE10	Past trip 1	\Diamond	0E3⇔1	Past trip 1 (displayed alternately at 0.5-sec. intervals)
[Note 5]	FE11	Past trip 2	\Diamond	0# ⇔2	Past trip 2 (displayed alternately at 0.5-sec. intervals)
[Note 5]	FE12	Past trip 3	$\langle \rangle$	<i>0P3⇔3</i>	Past trip 3 (displayed alternately at 0.5-sec. intervals)
[Note 5]	FE13	Past trip 4	$\langle \rangle$	nErr⇔4	Past trip 4 (displayed alternately at 0.5-sec. intervals)
[Note 6]	FE79	Part replacement alarm information	\Diamond	Π ,,,,	The ON/OFF status of each of the cooling fan, circuit board capacitor, main circuit capacitor or part replacement alarm of cumulative operation time is displayed in bits. ON: { OFF: Cumulative operation time Cooling fan Control circuit board capacitor Cooling fan Control circuit capacitor Cooling fan Cooling fan Control circuit capacitor Cooling fan Cooling f
[Note 7]	FE14	Cumulative operation time	$\langle \rangle$	E 0.10	The cumulative operation time is displayed. (Indication of 0.1 represents 10 hours.)
		Default display mode	MODE [Note 1]	6 O.O	The operation frequency is displayed (during operation).

Note 1: Press the (\(\) keys to change items displayed in the status monitor mode.

Note 2: Contents of status indications of *1, *2, *3, *4, *5, *6, *7, *8, and *9 can be selected from 44 kinds of information.

Contents of status indications that are set up at *F* 7 10 (standard monitor display selection) and *F* 7 11 ~F 7 18 (status monitor 1 to 8 display selection) are displayed.

Unit of current and voltage indications can be changed from % to A (ampere)/V (volt) and vice versa respectively. \Rightarrow Refer to Section 5.15.

- Note 3: Indicated input voltage is DC voltage just after input voltage is rectified multiplied by $1\sqrt{2}$.
- Note 4: The number of bars displayed varies depending on the setting of F 5 5 9 (logic output/pulse train output selection.)

The bar representing the OUT1 terminal is displayed only when logic output function is assigned to it. If $F \in \mathcal{B} = \mathcal{G}$: The bar representing OUT1 is displayed.

If $F \in S = I$: The bar representing OUT1 is not displayed.


Note 5: Past rip records are displayed in the following sequence: 1 (latest trip record) ⇔2⇔3⇔4 (oldest trip record). If there is no trip record, $n \notin r$ is displayed.

Details on past trip record 1, 2, 3 or 4 can be displayed by pressing the **ENT** key when past trip 1, 2, 3 or 4 is displayed. ⇒ For more details, refer to Section 8.2.2.

Note 6: The part replacement alarm is displayed based on the value calculated from the annual average ambient temperature, operation time and load current specified using F 5 3 4.

Use this alarm as a guide only, since it is based on a rough estimation.

Note 7: The cumulative operation time increments only when the machine is in operation.



■ Cumulative operation time

For indication of cumulative operation hours, running hours are counted up when the output frequency monitor reads a frequency other than 0.0Hz. 10 hours is indicated as 0.1 (unit of Indication).

Output terminal 10, 11 (R3, R4)

: Not corresponding

8.2.2 Display of detailed information on a past trip

Details on a past trip (of trips 1 to 4) can be displayed, as shown in the table below, by pressing the (ENT) key when the trip record is selected in the status monitor mode.

Unlike the "Monitor display at tripping" in 8.4.2, details on a past trip can be displayed, even after the inverter is turned off or reset.

	Item displayed	Key operated	LED display	Description
[Note 5]	Past trip 1		0[⇔	Past trip 1 (displayed alternately.)
	Continuous trips	ENT	n 2	The number of time the same trip occurred in succession is displayed. (@ER 1, @ER2, @ER3, @EL Unit: times)
[Note 1]	Output frequency	$\langle \rangle$	6 0.0	The operation frequency when the trip occurred is displayed.
	Status monitor mode (Rotating direction)	$\langle \rangle$	Fr-F	The direction of rotation is displayed. (F:Forward run, -:Reverse run)
	Frequency command value	\bigcirc	6 O.O	The operation frequency command value is displayed. (When F 7 ! != !, Frequency command)
[Note 2]	Output current	\bigcirc	C 80	The inverter output current (load current) is displayed. (When F 7 12=2, Output current)
	Input voltage (DC detection)	\bigcirc	y 100	The inverter DC voltage is displayed. (Default setting unit: %) (When F 7 13=3, Input voltage) [Note 3]
[Note 2]	Output voltage	\bigcirc	P 100	The inverter output voltage is displayed. (Default setting unit: %) (When F 7 14=4, output voltage)
	Input terminal information	\bigcirc	11111111	The ON/OFF status of each of the control signal input terminals (F, R, ST, RES, S1, S2, S3, RR/S4) is displayed in bits.
[Note 4]	Output terminal information	\bigcirc	0 111	The ON/OFF status of each of the control signal output terminals (OUT1, OUT2, FL) is displayed in bits.
[Note 6]	Cumulative operation time	\bigcirc	£ 8.5 6	The cumulative operation time when the trip occurred is displayed. (0.01=1 hour, 1.00=100 hours)
	Past trip 1	MODE	0E 1 ⇔ 1	Press this key to return to past trip 1.

Note 1: Press the or key to change items displayed in the status monitor mode.

Note 2: You can switch between % and A (ampere)/V (volt), using the parameter d 5 P !! (current/voltage unit selection).

Note 3: The input voltage displayed is $1/\sqrt{2}$ times as large as the rectified DC input voltage.

Note 4: The number of bars displayed varies depending on the setting of F & B 9 (logic output/pulse train output selection). The bar representing the OUT1 terminal is displayed only when logic output function is assigned to it.

If F & B 9=0 : The bar representing OUT1 is displayed.

If $F \not\in G : The bar representing OUT1 is not displayed.$

Note 5: If there is no trip record, n Err is displayed.

Note 6: The cumulative operation time increments only when the machine is in operation.

8.3 Changing status monitor function

■ Changing the display format while power is on

The item displayed in the standard monitor mode (*1 on the left side of table on page H-2), for example, operation frequency which is displayed by default in this way: "= $\Omega.\Omega$ " when power is on or " Ω F F" when power is off, can be changed to any item shown on page H-7. This new format, however, will not display an assigned prefix such as ξ or ξ .

• Standard monitor mode ⇒ Standard monitor display selection (F 7 10)

Title	Function	Adjustment range	Default setting
F 709	Standard monitor hold function	☐:Real time 1:Peak hold 2:Minimum hold	0
F710	Standard monitor display selection	©~70 ⇒ Refer to page H-7.	0

Specify how to output the monitored values that are assigned to status monitors 1 through 8.

If $F ? \mathcal{D} \mathcal{G}$ is set to \mathcal{G} , the monitored values selected with $F ? \mathcal{D}$ (standard monitor display selection parameter) are displayed one after another.

For peak hold values and minimum hold values, the minimum values in each operation mode are displayed. When the motor is at a standstill, the values monitored last are held as they were until the motor is started the next time. The maximum and minimum values monitored after power is turned on or after the reset with the EASY key are always displayed no matter whether the motor is in operation or at a standstill.

■ Changing contents of status monitor indication

Regarding contents of status monitor indications appearing in the left column of the table on page H-2, those marked with *2 to *9 can be changed for others. Select a desirable monitor function from among optional monitor functions appearing on page H-7.

*2 Frequency command	⇒ Changeable by status monitor 1 display selection (<i>F</i> 7 1 1).
*3 Output current	\Rightarrow Changeable by status monitor 2 display selection (F 7 12).
*4 Input voltage	⇒ Changeable by status monitor 3 display selection (F 7 13).
*5 Output voltage	⇒ Changeable by status monitor 4 display selection (F 7 14).
*6 Torque	\Rightarrow Changeable by status monitor 5 display selection (F 7 15).
*7 Regenerative braking resistance overload factor	\Rightarrow Changeable by status monitor 6 display selection (F 7 15).
*8 Inverter overload factor	\Rightarrow Changeable by status monitor 7 display selection (F 7 17).
*9 Motor overload factor	⇒ Changeable by status monitor 8 display selection (F 7 18).

Title	Function	Adjustment range	Default setting
F711	Status monitor 1 display selection	☐~7☐ ⇒ Refer to page H-7.	1
F712	Status monitor 2 display selection	Ditto	2
F713	Status monitor 3 display selection	Ditto	3
F714	Status monitor 4 display selection	Ditto	ч
F715	Status monitor 5 display selection	Ditto	8
F716	Status monitor 6 display selection	Ditto	15
F717	Status monitor 7 display selection	Ditto	15
F718	Status monitor 8 display selection	Ditto	14

^{*}If F 7 ! ! to F 7 ! B are set at "B" (Output frequency) the operation frequency is not held in trip status.

[Setup values of monitor indication parameters (F 7 177~F 7 18)]

	Communication No.	Default setting	Item displayed	Marking	Unit (Panel)	Unit (Communication)
	FD00	[]	Output frequency	6 O.O	0.1Hz [note 4]	0.01Hz
	FE02	- 1	Frequency command value	6 D.D	0.1Hz [note 4]	0.01Hz
	FE03	ż	Output current	[0	1% or d 5 P U	0.01%
	FE04	3	Input voltage (DC detection)	y 0	1% or d 5 P U	0.01%
	FE05	4	Output voltage	PO	1% or d 5 P U	0.01%
	FE15	5	Compensated frequency	50.0	0.1Hz [note 4]	0.01Hz
	FE16	5	Speed feedback (real-time value)	0	0.1Hz [note 4]	0.01Hz
	FE17	7	Speed feedback (1-second filter)	Ö	0.1Hz [note 4]	0.01Hz
[Note 5]	FE18	8	Torque	9 0	1%	0.01%
[Note 5]	FE19	9	Torque command	9 0	1%	0.01%
[Note 5]	FE20	11	Torque current	c 0	1%	0.01%
	FE21	12	Exciting current	ΕΟ	1%	0.01%
	FE22	13	PID feedback value	0	0.1Hz [note 4]	0.01Hz
	FE23	14	Motor overload factor (OL2 data)	L 0	1%	0.01%
	FE24	15	Inverter overload factor (OL1 data)	G 0	1%	0.01%
			Regenerative braking resistance			
	FE25	15	overload factor (OLr data)	r O	1%	1%
	FE28	17	Regenerative braking resistance load factor (% ED)	r B	1%	1%
[Note 5]	FE29	18	Input power	h 0	0.1kW	0.01kW
[Note 5]	FE30	19	Output power	H 0	0.1kW	0.01kW
[11010 0]	FE39	23	Optional AI2 input	J D	1%	0.01%
	FE35	24	RR/S4 input	J D	1%	0.01%
	FE36	25	VI/II input	J D	1%	0.01%
	FE37	26	RX input	J D	1%	0.01%
	FE38	27	Optional Al1 input	J D	1%	0.01%
	FE40	28	FM output	8 C	1 /8	0.01%
	FE41	29	AM output	7 C	1	0.01
	(FA65)	31	Communication data output	[Note 3]	[Note 3]	[Note 3]
	FE66	35	Attached to expansion I/O card 1 CPU version	1.10	-	-
	FE67	33	Attached to expansion I/O card 2 CPU version	1.10	-	-
[Note 5]	FE76	34	Integral input power	ь О	Depends on	Depends on
[Note 5]	FE77	35	Integral output power	н О	F749 Depends on	F 749 Depends on
[Note 2]	FE00	50	Signed output frequency	60.0	F 7 4 3 0.1Hz [note 4]	<i>F 7 4 9</i> 0.01Hz
[Note 2]	FE02	51	Signed frequency command value	5 O.O	0.1Hz [note 4]	0.01Hz
[Note 2]	FE15	52	Signed compensated frequency	5 D.O	0.1Hz [note 4]	0.01Hz
[Note 2]	FE16	53	Signed speed feedback (real-time value)	0	0.1Hz [note 4]	0.01Hz
[Note 2]	FE17	54	Signed speed feedback (1-second filter)	Ü	0.1Hz [note 4]	0.01Hz
[Note 2,5]	FE18	55	Signed torque	9 0	1%	0.01%
[Note 2,5]	FE19	56	Signed torque command	9 0	1%	0.01%
[Note 2.5]	FE20	58	Signed torque current	c 0	1%	0.01%
[Note 2]	FE22	59	Signed PID feedback value		0.1Hz [note 4]	0.01Hz
[Note 2]	FE37	60	Signed RX input	J D	1%	0.01%
[Note 2]	FE38	5 !	Signed optional AI2 input	J D	1%	0.01%
	FD50	54	Light-load high-speed load torque monitor 1	L	1%	0.01%
	FD51	65	Light-load high-speed load torque monitor 2	Н	1%	0.01%
	FE31	66	Pattern operation group number	P 1.0	0.1	0.1
	FE32	67	Remaining no. of cycles for which pattern operation is continued	n 123	1	1
	FE33	68	Pattern operation preset speed numbers	FI	1	1
	FE34	69	Remaining time for which pattern operation is continued	123.4	0.1	0.1
	FE71	70	Rated voltage	U400	1	0.1
	FE90	71	Rotational speed	1234	1	1
	FA15	72	Communication reception counter	N 123	1	1
	FA16	73	Communication abnormal counter	n 123	1	1
		74	MON1	0	1%	0.01%
	FE43	17	MONT		1 /0	0.0170

(Continued overleaf)

(Continued)

(commuca)					
Communication No.	Default setting	Item displayed	Marking	Unit (Panel)	Unit (Communication)
FE56	75	RP	0	0.1%	0.01%
FD85	77	COUNT1	1234	1	1
FD86	78	COUNT2	1234	1	1
FD52	79	PID result frequency	60.0	0.1Hz	0.01Hz
FE84	80	Synchronous speed frequency command	60.0	0.1Hz	0.01Hz

Note 1: If any value other than the values in the above table is specified, the number "9 9 9 9" is displayed.

Note 2: If a negative value of signed signal is specified, the negative sign "-" is displayed. When the negative sign "-" is displayed, do not display " 9", " [", ", ", "]". When read through by communications device, the negative sign is affixed only FE18-FE20, FE37 and FE38 values..

Note 3: Data set with FA65-FA79 is displayed.

⇒ For details, refer to Instruction Manual (E6581315) specified in Section 6.42.

Note 4: Unit of display is able to change depends on F 702~F 708 setting.

Note 5: If monitor this item, operate a motor in automatic torque boost mode or vector control mod (P
otin 2, 3, 4, 7 or 8)

8.4 Display of trip information

8.4.1 Trip code display

If the inverter trips, an error code is displayed to suggest the cause. In the status monitor mode, the status when the inverter trip is held.

■ Display of trip information

Error code	Description	Communication/Error code Communication No.:FC90
0E 1	Overcurrent during acceleration	1
002	Overcurrent during deceleration	2
003	Overcurrent during fixed speed operation	3
OC IP	Overcurrent flowing in element during acceleration (Overheat)	37
0C2P	Overcurrent flowing in element during deceleration (Overheat)	38
0C3P	Overcurrent flowing in element during fixed speed (Overheat)	39
0 C R I	U-phase arm overcurrent	5
0CA2	V-phase arm overcurrent	6
0 C R 3	W-phase arm overcurrent	7
OCL	Overcurrent (Loaded side overcurrent at start time)	4
0Cr	Dynamic braking element overcurrent (200V-55kW or larger, 400V-90kW or larger)	36
0 H	Overheating	16
0 H 2	Thermal trip stop command from external device	46
OL I	Inverter overload	13
0 L Z	Motor overload	14
OLr	Dynamic braking resistor overload	15
0P I	Overvoltage during acceleration	10
0P2	Overvoltage during deceleration	11
прэ	Overvoltage during fixed speed operation	12
0 E	Overtorque	32
UC	Low current operation	29
UP I	Undervoltage (main circuit power supply)	30
Ε	Emergency stop	17
EEPI	E E P ROM fault (writing error)	18
EEP2	Initial read error (parameter initialization)	19
EEP3	Initial read error (parameter initialization)	20
EF I EF 2	Ground fault	33 34
EPHO	Output phase failure	9
EPH!	Output phase failure	8
	Input phase failure	o 21
<u>Err2</u>	Inverter RAM fault	22
Err3	Inverter ROM fault	
Err4	CPU fault	23
Err5	Communication time-out error	24 25
<u>Errb</u>	Gate array fault	
<u> </u>	Output current detector error	26 27
Err8	Optional unit fault	
Etn	Tuning error except Etn1~3	40 84
Ebn 1	F 4 10 tuning error	
<u> </u>	F 4 12 tuning error	85
<u> </u>	นไ, นไม, F 405~40 7 setting error	86
<u> </u>	Inverter type error	41
<u>E - 10</u>	Analog input terminal overvoltage	42
<u>E-11</u>	Sequence error	43
E - 12	Encoder error	44

(Continued overleaf)

(Continued)

Error code	Description	Communication/Error code Communication No.:FC90
E - 13	Speed error (Over speed)	45
E - 18	Terminal input error	50
E - 19	Abnormal CPU2 communication	51
E-20	V/f control error	52
E-21	CPU1 fault	53
E-22	Abnormal logic input voltage	54
E-23	Option 1 error	55
E-24	Option 2 error	56
E-25	Stop position retaining error	57
E-26	Internal circuit error	58
E-29	Control power backup undervoltage	61
50UE	Step-out (for PM motors only)	47
n E r r (*)	No error	0

Note: Past trip records (trip records retained or trips that occurred in the past) can be called up.

[⇒] See Section 8.2.1

^(*) This is not a trip code. This code is displayed to show the absence of error when the past trip monitor mode is selected.

8.4.2 Monitor display at tripping

At the occurrence of a trip, the same information as that displayed in the mode described in 8.2.1, "Status monitor under normal conditions," can be displayed, as shown in the table below, if the inverter is not turned off or reset. To display trip information after turning off or resetting the inverter, follow the steps described in 8.2.2, "Display of detailed information a past trip."

■ Example of call-up of trip information

	Commun ication No.	Item displayed	Key operated	LED display	Description
	FC90	Trip information		0P2	Status monitor mode (The code blinks if a trip occurs.) The motor coasts and comes to a stop (coast stop).
	-	Setting monitor mode	MODE	ЯШН	The first basic parameter "History function (RUH) " is displayed.
[Note 3]	FE01	Direction of rotation	MODE	Fr-F	The direction of rotation when the trip occurred is displayed.(F:Forward run, r:Reverse run)
*1	•	Frequency command value	\bigcirc	6 O.O	The operation command value when the trip occurred is displayed.
[Note 4] *2	•	Output current	\bigcirc	C 130	The inverter output current at tripping (load current) is displayed.
[Note 4] [Note 5] *3	1	Input voltage (DC detection)	\bigcirc	9 14 1	The inverter DC voltage at the occurrence of a trip is displayed.
[Note 4] *4	1	Output voltage	\bigcirc	P 100	The inverter output voltage at the occurrence of a trip is displayed.
*5	-	Torque	\Diamond	9 100	The torque when the trip occurred is displayed.
*6	-	Regenerative braking resistance overload factor (PbrOL data)	$\langle \rangle$	r 0	The regenerative braking resistance overload factor at tripping is displayed.
*7	ı	Inverter overload factor (OL1 data)	\bigcirc	G 0	The inverter overload factor at tripping is displayed.
*8	ı	Motor overload factor (OL2 data)	\bigcirc	L 100	The motor overload factor at tripping is displayed.
	FE00	Output frequency	\bigcirc	4 O.O	The output frequency when the trip occurred is displayed.
		Input terminal information 1	\bigcirc	11111111	The ON/OFF status of each of the control input terminals at tripping (F, R, ST, RES, S1, S2, S3, RR/S4) is displayed in bits.
	FE06	Input terminal information 2	\bigcirc	Я !!!!	The ON/OFF status of each of the optional control input terminals at tripping (Ll1, Ll2, Ll3, Ll4) is displayed in bits.
		Input terminal information 3	\bigcirc	ь !!!!	The ON/OFF status of each of the optional control input terminals at tripping (LI5, LI6, LI7, LI8) is displayed in bits.
[Note 6]	FE07	Output terminal information 1	$\langle \rangle$	0 111	The ON/OFF status of each of the control output terminals at tripping (OUT1, OUT2 and FL) is displayed in bits.
	FEU/	Output terminal information 2	\bigcirc	11111111	The ON/OFF status of each of the optional control output terminals (OUT3, OUT4, R1, OUT5, OUT6, R2, R3, R4) is displayed in bits.
	FE08	CPU1 version	\bigcirc	J 100	The version of the CPU1 is displayed.
	FE73	CPU2 version	\bigcirc	c 100	The version of the CPU2 is displayed.
	(Cantinuad				

(Continued overleaf)

	(Continued)			
	Commun ication No.	Item displayed	Key operated	LED display	Description
[Note 7]	FE10	Past trip 1	\Diamond	0€3⇔1	Past trip 1 (displayed alternately at 0.5-sec. intervals)
[Note 7]	FE11	Past trip 2	\Diamond	0н ⇔2	Past trip 2 (displayed alternately at 0.5-sec. intervals)
[Note 7]	FE12	Past trip 3	\Diamond	<i>0P3⇔3</i>	Past trip 3 (displayed alternately at 0.5-sec. intervals)
[Note 7]	FE13	Past trip 4	$\langle \rangle$	nErr⇔4	Past trip 4 (displayed alternately at 0.5-sec. intervals)
[Note 8]	FE79	Part replacement alarm information	\Diamond	nt	The ON/OFF status of each of the cooling fan, circuit board capacitor, main circuit capacitor or part replacement alarm of cumulative operation time is displayed in bits. ON: OFF: Cumulative Cooling fan Control circuit board capacitor Main circuit capacitor
[Note 9]	FE14	Cumulative operation time	\Diamond	E 0.1	The cumulative operation time is displayed. (Indication of 0.1 represents 10 hours.)
	-	Default display mode	MODE)	0P2	Status monitor mode (The code blinks if a trip occurs.) Reverts to the first trip indication.

Note 1: If trouble occurs while the CPU is being initialized after the inverter is turned on or reset, the trip record retaining function does not record it but displays a status monitor item.

- Note 2: Contents of status indications of *1, *2, *3, *4, *5, *6, *7, and *8 can be selected from 44 kinds of information.

 Contents of status indications that are set up at F 7 ! !-F 7 ! B (status monitor 1 to 8 display mode) are displayed.
- Note 3: Items displayed when a trip occurs can be changed by pressing (\infty) or (\infty) key
- Note 4: You can switch between % and A (ampere)/V (volt), using the parameter d 5 P !! (current/voltage unit selection).
- Note 5: The input voltage displayed is $1/\sqrt{2}$ times as large as the rectified DC input voltage.
- Note 6: The number of bars displayed varies depending on the setting of F 5 5 9 (logic output/pulse train output selection). The bar representing the OUT-NO terminal is displayed only when logic output function is assigned to it.
 - If $F \not\in G : G = G$: The bar representing OUT-NO is displayed.
 - If $F \in S = I$: The bar representing OUT-NO is not displayed.
- Note 7: Past rip records are displayed in the following sequence: 1 (latest trip record) ⇔2⇔3⇔4 (oldest trip record). If there is no trip record, n ₹ r r is displayed.
 - Details on past trip record 1, 2, 3 or 4 can be displayed by pressing the (ENT) key when past trip 1, 2, 3 or 4 is displayed. ⇒ For more details, refer to Section 8.2.2.
- Note 8: The time elapsed before an end of part replacement alarm is issued is calculated from the average yearly ambient temperature, operation time and load current entered using F 5 3 4, and it is no more than an estimation, and therefore it should be used for reference purposes only.
- Note 9: The cumulative operation time increments only when the machine is in operation.
- Note 10: At the occurrence of a trip, maximum values are not always recorded and displayed for reasons of detecting time.

8.5 Display of alarm, pre-alarm, etc.

When the inverter alarm, pre-alarm, etc. occurred, the contents are displayed. (Some are not displayed.) Listed below ones can be monitored via communication (FC91). Refer to 13.1 for the other alarms.

Bit	Description	Panel indication
0	Overcurrent pre-alarm	Ε
1	Inverter overload pre-alarm	L
2	Motor overload pre-alarm	L
3	Overheat pre-alarm	Н
4	Overvoltage pre-alarm achieving PBR operation level	Р
5	Main circuit undervoltage detected	NOFF
6	(Reservation area)	-
7	Low current alarm	-
8	Overtorque pre-alarm	-
9	Braking resistor overload pre-alarm	-
10	Cumulative operation time alarm	-
11	PROFIBUS/DeviceNet/CC-Link communication error	Εl
12	RS485 communication error	٤Z
13	(Reservation area)	_
14	Forced deceleration stop because of a momentary power failure	5 t O P
15	Pre-alarm stop because of prolonged lower-limit frequency operation	L56P

Note: For each bit, "0" indicates normal condition and "1" indicates appearance of alarm, etc.

9. Taking measures to satisfy the CE/UL/CSA standards

9.1 How to cope with the CE standard

In Europe, the EMC directive and the low-voltage directive, which took effect in 1996 and 1997, respectively, make it obligatory to put the CE mark on every applicable product to prove that it complies with the directives. Inverters do not work alone but are designed to be installed in a control panel and always used in combination with other machines or systems which control them, so they themselves are not considered to be subject to the EMC directive. However, the CE mark must be put on all inverters because they are subject to the low-voltage directive.

The CE mark must be put on all machines and systems with built-in inverters because such machines and systems are subject to the above directives. It is the responsibility of the manufacturers of such final products to put the CE mark on each one. If they are "final" products, they might also be subject to machine-related directives. It is the responsibility of the manufacturers of such final products to put the CE mark on each one. In order to make machines and systems with built-in inverters compliant with the EMC directive and the low-voltage directive, this section explains how to install inverters and what measures should be taken to satisfy the EMC directive.

We have tested representative models with them installed as described later in this manual to check for conformity with the EMC directive. However, we cannot check all inverters for conformity because whether or not they conform to the EMC direction depends on how they are installed and connected. Applicable EMC standards vary depending on the composition of the control panel in which the inverter is installed, the relationship with other electrical devices installed in the control panel, wiring conditions, equipment layout, and so on, so you should check whether your machine or system complies with EMC standards as a whole. Therefore, please verify for yourself whether your machine or system conforms to the EMC directive.

9.1.1 EMC directive

The CE mark must be put on every final product that includes an inverter(s) and a motor(s). The VF-AS1 series of inverters <u>complies with the EMC directive</u> if an EMC filter recommended by Toshiba is connected to it and wiring is carried out correctly.

The EMC standards are broadly divided into two categories; immunity- and emission-related standards, each of which is further categorized according to the operating environment of each individual machine. Since inverters are intended for use with industrial systems under industrial environments, they fall within the EMC categories listed in Table 1 below. The tests required for machines and systems as final products are almost the same as those required for inverters.

Table 1 (EMC standards)

Category	Subcategory	Product standards	Test standard
Facilities.	Radiated		OIODD44/ENISSO44)
Emission	Conducted	1	CISPR11(EN55011)
	Electrostatic discharge		IEC61000-4-2
	Radiated, radio-frequency, electromagnetic field		IEC61000-4-3
	Electrical fast transient burst	IEC61800-3	IEC61000-4-4
Immunity	Surge]	IEC61000-4-5
	Conducted disturbances, induced by radio-frequency field		IEC61000-4-6
	Voltage dips, short interruptions and voltage variations		IEC61000-4-11

9.1.2 Measures to satisfy the EMC directive

Concrete measures for EMC directive of CE markings are shown below.

■ Models with a built-in EMC filter

(1) 200V class: VFAS1-2004PL~2075PL 400V class: VFAS1-4007PL~4500KPC

The above mentioned models install EMC noise filter inside. So the conducted and radiated noise can be reduced, optional EMC noise filters are not needed.

(If a further noise reduction is required, insert an additional filter described in I-4 on the input side of the inverter.)

		Table 2		tive compliance	
		Requiren			
Inverter type	EMC plate type	PWM carrier frequency [F	Length of motor connecting	Conducted noise IEC61800-3 category C2 (EN55011 classA Group1)	Conducted noise IEC61800-3 category C3 (EN55011 classA Group2)
		(kHz)	cable (m)	(2.1000 : 1 0.000 : 1 0.000 : 1)	(2.1000) 1 0.000/1 0.0002/
VFAS1-2004PL~	EMB4047	4	10		
VFAS1-2015PL	EMP101Z	16	5	Duilt in filter	
VEAC4 2022DI		4	10	Built-in filter	-
VFAS1-2022PL	EMD4007	16	5		
VFAS1-2037PL	EMP102Z	4	10		
VFA51-2037PL		16	5		Built-in filter
VFAS1-2055PL,	EMD4027	4	10]	Built-in filler
VFAS1-2075PL	EMP103Z	16	5]	
VFAS1-4007PL~	EMB4047	4	10		
VFAS1-4022PL	EMP101Z	16	5	Duille in Eller	
VEA 04 4007DI	514B4007	4	10	Built-in filter	-
VFAS1-4037PL	EMP102Z	16	5		
VFAS1-4055PL~	EMB4007	4	10		
VFAS1-4110PL	EMP103Z	16	5		
VEA 04 44 50 DI	EMP104Z	4	10		
VFAS1-4150PL		16	5]	
VEA 04 4405DI		2.5	25		
VFAS1-4185PL		16	25]	
VEAC4 4220DI	EMD4057	2.5	50		
VFAS1-4220PL	EMP105Z	16	25]	
VFAS1-4300PL,	EMD4067	2.5	50		
VFAS1-4370PL	EMP106Z	16	25		
VFAS1-4450PL~	EMP108Z	2.5	50]	Built-in filter
VFAS1-4750PL	EIVIP 1082	16	25		Built-in filler
VFAS1-4900PC	-	2.5	50		
VFAS1-4110KPC	-	2.5	50		
VFAS1-4132KPC	-	2.5	50		
VFAS1-4160KPC	-	2.5	50		
VFAS1-4200KPC	-	2.5	50		
VFAS1-4220KPC	-	2.5	50		
VFAS1-4280KPC	-	2.5	50		
VFAS1-4355KPC, VFAS1-4400KPC,	-	2.5	50		
VFAS1-4500KPC,	-	2.5	50	1	

^{():} An optional regenerative braking unit PB7 is used.

- (2) Use shielded power cables and control signal cables for the input and output lines of the inverter. Route the cables and wires so as to minimize their lengths. Keep a distance between the power cable and the control cable and between the input and output wires of the power cable. Do not route them in parallel or bind them together, instead cross at right angle.
- (3) Install the inverter in an enclosed steel cabinet, it is more effective in limiting the radiation. Using wires as thick and short as possible, earth the control panel securely with a distance kept between the earth cable and the power cable.
- (4) To limit the radiation noise from cables, earth each shielded cable to the EMC plate. It is effective to earth shielded cables in the vicinity of the inverter and filter (within a radius of 10cm from each of them). Inserting a ferrite core in a shielded cable is even more effective in limiting the radiation noise.
- (5) To further limit the radiation noise, insert a zero-phase reactor in the inverter output line and insert ferrite cores in the earth cables of the EMC and cabinet.

[Ex. Countermeasure - inverter wiring]




Fig. 1

■ When an external EMC filter is added

(1) Additional external EMC filters have the further effect of suppressing conduction and radiation noises. Use the recommended EMC noise filter specified in Table 3. This combination of inverter and filter was used when examining the inverter for compliance with the EMC directive.

Table 3 lists noise filters recommended for the inverters.

Table 3 Combinations of inverter and EMC filter

			nations of inverter and EMC filter	
		rements	Conducted noise	Conducted noise
Invertor ture	PWM carrier	Length of motor	IEC61800-3 category C2	IEC61800-3 category C1
Inverter type	frequency [F	connecting cable	(EN55011 classA Group1)	(EN55011 classB Group1)
	(kHz)	(m)		Applicable filters
	` ′	50		EMF3-4012A
VFAS1-2004PL~	3.5~4	100		-
VFAS1-2015PL		20		EMF3-4012A
	4.1~16	50	IEC61800-3 category C2	-
	0.5.4	50		EMF3-4026B
VFAS1-2022PL,	3.5~4	100	EMF3-4026B	-
VFAS1-2037PL	4.1~16	25	EMF3-4026B	EMF3-4026B
	4.1~10	50	EMF3-4026B	-
	3.5~4	50	EMF3-4035C	EMF3-4035C
VFAS1-2055PL	3.5~4	100		-
VI AG 1-2033F L	4.1~16	25	EMF3-4035C	EMF3-4035C
	4.1-10	50		-
	3.5~4	50		EMF3-4046D
VFAS1-2075PL	0.0	100		-
	4.1~16	25		EMF3-4046D
		50		-
	2~4	50		EMF3-4072E
VFAS1-2110PM,		100		-
VFAS1-2150PM	4.1~12	25		EMF3-4072E
		50		-
VEACA CAREDM	2~2.5	50		EMF3-4090F
VFAS1-2185PM,		100		- EMEO 4000E
VFAS1-2220PM	2.6~12	25		EMF3-4090F
		50 50		EMF3-4180H
VFAS1-2300PM~	2~2.5	100		EWF3-4160H
VFAS1-2300FW~ VFAS1-2450PM		25		EMF3-4180H
VI AG1-24301 W	2.6~12	50		LIVII 3-410011
VFAS1-2550P.				
VFAS1-2750P	2.5	100		-
	3.5~4	50		EMF3-4012A
VFAS1-4007PL~	3.34	100		-
VFAS1-4022PL	4.1~16	20		EMF3-4012A
		50		-
	3.5~4	50		EMF3-4026B
VFAS1-4037PL		100		-
	4.1~16	25		EMF3-4026B
		50		-
VEA 04 4055DI	3.5~4	50		EMF3-4035C
VFAS1-4055PL, VFAS1-4075PL		100		- FMF2 4025C
VI /101740/3FL	4.1~16	25 50		EMF3-4035C
	+	50		- EMF3-4046D
	3.5~4	100		EIVIF3-4040D
VFAS1-4110PL	<u> </u>	25		EMF3-4046D
	4.1~16	50		LIVII 3-4040D
	+	100		EMF3-4072E
VFAS1-4150PL.	2~4	300		LIVII 3"4012L
VFAS1-4185PL		100		EMF3-4072E
	4.1~12	200		-
	+	200	LIVII O TOTAL	· · · · · · · · · · · · · · · · · · ·

(Continued overleaf)

1	Cor	ntin	ued

(Continued)				
	Requi	irements	Conducted noise	Conducted noise
las cartar tora	PWM carrier	Length of motor	IEC61800-3 category C2 (EN55011 classA Group1) (EN5501 classA Group1) (EN5501 classA Group1) (EN5501 classA Group1) (EN5501 classA Group1) (EN5300F classA Group1) (EMF3-4090F classA Group2) (EMF3-4092G classA Group2) (EMF3-4092G classA Group2) (EMF3-4180H classA G	IEC61800-3 category C1
Inverter type	frequency [F	connecting cable	(EN55011 classA Group1)	(EN55011 classB Group1)
	(kHz)	(m)	Applicable filters	Applicable filters
	2~4	100	EMF3-4090F	EMF3-4090F
VFAS1-4220PL	2~4	300	EMF3-4090F	-
VFA31-4220FL	4.1~12	100	EMF3-4090F	EMF3-4090F
	4.1~12	200	EMF3-4090F	-
	2~2.5	100	EMF3-4092G	EMF3-4092G
VFAS1-4300PL	2~2.5	300	EMF3-4092G	-
VFAS1-4370PL	2.6~12	100	EMF3-4092G	EMF3-4092G
	2.0~12	200	EMF3-4092G	-
	2~2.5	100	EMF3-4180H	EMF3-4180H
VFAS1-4450PL~	2~2.5	300	EMF3-4180H	-
VFAS1-4750PL	2.6~12	100	EMF3-4180H	EMF3-4180H
	2.0~12	200	EMF3-4180H	-
VFAS1-4900PC~ VFAS1-4132KPC	2.5	100	EMF3-4300I	-
VFAS1-4160KPC~ VFAS1-4280KPC	2.5	100	EMF3-4600J	-
VFAS1-4355KPC~ VFAS1-4500KPC	2.5	100	EMF3-4600J × 2	-

- (2) Use shielded cables for the power and control cables, including filter input cables and inverter output cables. Route the cables and wires so as to minimize their lengths. Keep a distance between the power cable and the control cable and between the input and output wires of the power cable. Do not route them in parallel or bind them together, instead cross at right angle.
- (3) Install the filter and the inverter in an enclosed steel cabinet, it is more effective in limiting the radiation. Earth the cabinet body securely with the thickest and shortest possible electric wire installed away from the power cables.
- (4) Route the EMC filter input and output wires apart from each other.
- (5) To limit the radiation noise from cables, earth each shielded cable to the EMC plate. It is effective to earth shielded cables in the vicinity of the inverter and filter (within a radius of 10cm from each of them). Inserting a ferrite core in a shielded cable is even more effective in limiting the radiation noise.
- (6) To further limit the radiation noise, insert a zero-phase reactor in the inverter output line and insert ferrite cores in the earth cables of the EMC plate and cabinet.

[Ex. Countermeasure - inverter wiring]




Fig. 2

[Operation with external signals]

When using signals from an external control device to operate the inverter, take the measures shown in Figure 3. Ex.) When using the potentiometer and forward run/reverse run terminals




Fig. 3

[Accessories for countermeasure]

□ Recommended shield cable : Showa electric Wire & Cable Co., LTD

Type : CV-S Rating: 600V or less

Cross-sectional area: 2~1000mm²

If it is difficult to procure shielded cables, protect cables with conduit tubes.

□ [Note 1] Recommended shield: SUMITOMO 3M Limited, Electromagnetic wave guard shielding sleeve

Type : DS-5, 7, 10, 14 Type : EMF3 series

 $\hfill \square$ Recommended ferrite core 1 \hfill : TDK Corporation

Type : ZCAT3035-1330

Use the following, as required.

□ Recommended ferrite core : NEC TOKIN Corporation

Type: ESD-R-47D-1

□ Zero-phase reactor : Soshin Electric Co., Ltd.

Type : RC5078 or RC9129

□ High-attenuation radio noise reduction filter : Soshin Electric Co., Ltd.

Type: NF series

9.1.3 Low-voltage directive

□ EMC filter

The low-voltage directive provides for the safety of machines and systems. All Toshiba inverters are CE-marked in accordance with the standard IEC61800-5-1 specified by the low-voltage directive, and can therefore be installed in machines or systems and imported without a problem to European countries.

Applicable standard: IEC61800-5-1

Adjustable speed electrical power drive system


Pollution level: 2

Overvoltage category: 3

9.1.4 Measures to be taken to satisfy the low-voltage directive

When incorporating the inverter into a machine or system, it is necessary to take the following measures so that the inverter satisfies the low-voltage directive.

- (1) <u>Install the inverter in a cabinet and ground the inverter enclosure.</u> When doing maintenance, be extremely careful not to put your fingers into the inverter through a wiring hole and touch a charged part, which may occur depending on the model and capacity of the inverter used.
- (2) Do not connect two or more wires to the main circuit earth terminal of the inverter. If necessary, install an additional earth terminal on the EMC plate on which the inverter is installed and connect another cable to it. (Refer to Fig. 4.) See the table of section 10.1.
- (3) Install a non-fuse circuit breaker on the input side of the inverter.



9.2 Measures to be taken to satisfy the UL/CSA standards

All VF-AS1 series inverters are certified by UL and CSA, and have nameplates with UL and CSA markings.

9.2.1 Caution in installing the inverter

A UL certificate was granted on the assumption that the inverter would be installed in a cabinet. Therefore, install the inverter in a cabinet and if necessary, take measures to maintain the ambient temperature (temperature in the cabinet) within the specified temperature range.

For models designed for 15kW motors or smaller, if the cover on the top of the inverter is removed, the ambient temperature can rise to 50°C in some cases, although the maximum allowable ambient temperature is 40°C. Incidentally, models (with no cover on the top) designed for 18.5 kW motors or larger can be used at ambient temperatures of up to 50°C.

9.2.2 Caution in wiring and rated current

Use the UL conformed cables (Rating 75 °C or more, Use the copper conductors only.) to the main circuit terminals (R/L1, S/L2, T/L3, U/T1, V/T2, W/T3). For FLA, FLB and FLC terminals, the round solderless terminal "V1.25-3" has to be used with UL-certified electric wire.

For instruction in the United States, Integral solid state short circuit protection does not provide branch circuit protection. Branch circuit protection must be provided in accordance with the National Electrical Code and any additional local codes.

For instruction in the Canada, Integral solid state short circuit protection does not provide branch circuit protection.

Branch circuit protection must be provided in accordance with the Canadian Electrical Code and any additional local codes.

⇒ For recommended electric wire sizes, see Tables 5.

UL-certified rated output current is not the same as inverter unit rated current. Refer to Table 5.

9.2.3 Caution as to peripheral devices

Use the UL listed fuses at connecting to power supply.

The UL certification test on this inverter was conducted under the AIC* conditions shown in Table 4 (*: current that flows in the event of a short-circuit in the power supply). Note that AIC currents vary depending on the capacity of the motor used.

Table 4 Power supply short-circuit current and maximum input voltage

Input voltage	Drive motor	Power supply short-circuit and maximum input voltage
1		Suitable For Use On A Circuit Capable Of Delivering Not More Than 5,000A rms
	0.4kW	Symmetrical Amperes, 240 Volts Maximum When Protected by CC Class Fuses.
240V	0.751444 - 07144	Suitable For Use On A Circuit Capable Of Delivering Not More Than 5,000A rms
240V	0.75kW to 37kW	Symmetrical Amperes, 240 Volts Maximum When Protected by J Class Fuses.
	45kW and over	Suitable For Use On A Circuit Capable Of Delivering Not More Than 10,000A rms
	45KW and over	Symmetrical Amperes, 240 Volts Maximum When Protected by J Class Fuses.
	0.75kW to 1.5kW	Suitable For Use On A Circuit Capable Of Delivering Not More Than 5,000A rms
	U.75KVV to 1.5KVV	Symmetrical Amperes, 480 Volts Maximum When Protected by CC Class Fuses.
	2.2kW to 37kW	Suitable For Use On A Circuit Capable Of Delivering Not More Than 5,000A rms
		Symmetrical Amperes, 480 Volts Maximum When Protected by J Class Fuses.
	45kW to 132kW	Suitable For Use On A Circuit Capable Of Delivering Not More Than 10,000A rms
	43KVV 10 132KVV	Symmetrical Amperes, 480 Volts Maximum When Protected by J Class Fuses.
480V	160kW to 220kW	Suitable For Use On A Circuit Capable Of Delivering Not More Than 18,000A rms
400 V	TOOKW to 220KW	Symmetrical Amperes, 480 Volts Maximum When Protected by J Class Fuses.
	280kW	Suitable For Use On A Circuit Capable Of Delivering Not More Than 30,000A rms
	200800	Symmetrical Amperes, 480 Volts Maximum When Protected by T Class Fuses.
	355kW to 400kW	Suitable For Use On A Circuit Capable Of Delivering Not More Than 30,000A rms
	333KW 10 400KW	Symmetrical Amperes, 480 Volts Maximum When Protected by J Class Fuses.
	500kW	Suitable For Use On A Circuit Capable Of Delivering Not More Than 42,000A rms
	JUURVV	Symmetrical Amperes, 480 Volts Maximum When Protected by J Class Fuses.

			-	Table 5	AIC, Fuse a	nd Wire sizes		
Voltage	Applicable		UL	AIC (A)	Fuse class	Input wire sizes of	Output wire sizes of	Earth
class	motor	Inverter model	output current	(Interrupting	and current	power circuit	power circuit	*4
0,000	[kW]		(A) *2, *3	capacity)	(A)	*4	*4	·
	0.4	VFAS1-2004PL	2.5 ([F=4)	AIC 5000A	CC 7Amax.	AWG 14	AWG 14	AWG 14
	0.75	VFAS1-2007PL	4.8 ([F=4)	AIC 5000A	J 15Amax.	AWG 14	AWG 14	AWG 14
	1.5	VFAS1-2015PL	7.8 ([F=4)	AIC 5000A	J 25Amax.	AWG 14	AWG 14	AWG 14
	2.2	VFAS1-2022PL	11.0 ([F = 4)	AIC 5000A	J 25A max.	AWG 12	AWG 12	AWG 14
	3.7/4.0	VFAS1-2037PL	17.5 ([F=4)	AIC 5000A	J 45Amax.	AWG 10	AWG 10	AWG 12
	5.5	VFAS1-2055PL	25.3 ([F=4)	AIC 5000A	J 60Amax.	AWG 8	AWG 8	AWG 10
	7.5	VFAS1-2075PL	32.2 ([F=4)	AIC 5000A	J 70Amax.	AWG 8	AWG 8	AWG 10
200V	11	VFAS1-2110PM	48.3 ([F = 4)	AIC 5000A	J 90Amax.	AWG 4	AWG 4	AWG 10
class	15	VFAS1-2150PM	62.1 ([F=4)	AIC 5000A	J 110Amax.	AWG 4	AWG 4	AWG 10
	18.5	VFAS1-2185PM	74.8 ([F=2.5)	AIC 5000A	J 125Amax.	AWG 3	AWG 3	AWG 8
	22	VFAS1-2220PM	88 ([F=2.5)	AIC 5000A	J 150Amax.	AWG 2	AWG 2	AWG 8
	30	VFAS1-2300PM	114 ([F=2.5)	AIC 5000A	J 200Amax.	AWG 2/0	AWG 2/0	AWG 6
	37	VFAS1-2370PM	143 ([F = 2.5)	AIC 5000A	J 225Amax.	AWG 3/0	AWG 3/0	AWG 6
	45	VFAS1-2450PM	169 ([F=2.5)	AIC 10000A	J 300Amax.	AWG 4/0	AWG 4/0	AWG 6
	55	VFAS1-2550P	221 ([F=2.5)	AIC 10000A	J 350Amax.	AWG 3/0 x 2	AWG 3/0 x 2	AWG 2
	75	VFAS1-2750P	285 ([F=2.5)	AIC 10000A	J 450Amax.	AWG 4/0 x 2	250MCM x 2	AWG 2
	0.75	VFAS1-4007PL	2.1 ([F=4)	AIC 5000A	CC 6Amax.	AWG 14	AWG 14	AWG 14
	1.5	VFAS1-4015PL	3.4 ([F=4)	AIC 5000A	CC 12Amax.	AWG 14	AWG 14	AWG 14
	2.2	VFAS1-4022PL	4.8 ([F=4)	AIC 5000A	J 15Amax.	AWG 14	AWG 14	AWG 14
	3.7/4.0	VFAS1-4037PL	7.6 ([F=4)	AIC 5000A	J 25Amax.	AWG 12	AWG 12	AWG 14
	5.5	VFAS1-4055PL	11.0 ([F=4)	AIC 5000A	J 40Amax.	AWG 10	AWG 10	AWG 12
	7.5	VFAS1-4075PL	14. 0 ([F=4)	AIC 5000A	J 40Amax.	AWG 10	AWG 10	AWG 12
	11	VFAS1-4110PL	21.0 ([F=4)	AIC 5000A	J 60Amax.	AWG 8	AWG 8	AWG 10
	15	VFAS1-4150PL	27.0 ([F=4)	AIC 5000A	J 70Amax.	AWG 6	AWG 6	AWG 10
	18.5	VFAS1-4185PL	34.0 ([F=4)	AIC 5000A	J 70Amax.	AWG 6	AWG 6	AWG 10
	22	VFAS1-4220PL	40.0 ([F=4)	AIC 5000A	J 80Amax.	AWG 6	AWG 6	AWG 10
	30	VFAS1-4300PL	52.0 ([F=4)	AIC 5000A	J 90Amax.	AWG 4	AWG 4	AWG 10
	37	VFAS1-4370PL	65.0 ([F=2.5)	AIC 5000A	J 110Amax.	AWG 3	AWG 3	AWG 8
	45	VFAS1-4450PL	77.0 ([F=2.5)	AIC 10000A	J 150Amax.	AWG 1	AWG 1	AWG 8
	55	VFAS1-4550PL	96.0 ([F=2.5)	AIC 10000A	J 175Amax.	AWG 1/0	AWG 1/0	AWG 6
	75	VFAS1-4750PL	124.0 ([F=2.5)	AIC 10000A	J 225Amax.	AWG 3/0	AWG 3/0	AWG 6
	90	VEA 04 4000 DO	470.0 (5.5. 7.5)	110 100001	1.0504	AWG 1/0 x 2	AWG 1/0 x 2	AWG 2
400V	90	VFAS1-4900PC	179.0 (<i>[F=2.5</i>)	AIC 10000A	J 250Amax.	250 MCM x 2 *1	250 MCM x 2 *1	250 MCM *1
class	110	VFAS1-4110KPC	215.0 ([F=2.5)	AIC 10000A	J 300Amax.	AWG 3/0 x 2	AWG 3/0 x 2	AWG 2
	110	VI AST-4110KFC	213.0 ([[-[.]]	AIC TOUGGA	J JOUAINAX.	250 MCM x 2 *1	250 MCM x 2 *1	250 MCM *1
	132	VFAS1-4132KPC	259.0 ([F=2.5)	AIC 10000A	J 350Amax.	AWG 4/0 x 2	AWG 4/0 x 2	AWG 1
	102	V17/01 4102N 0	200.0 (27 -2.3)	7110 1000071	o oooranax.	250 MCM x 2 *1	250 MCM x 2 *1	250 MCM *1
	160	VFAS1-4160KPC	314.0 ([F=2.5)	AIC 18000A	J 400A max.	300 MCM x 2	300 MCM x 2	AWG 1
	100	V17/01 4100/0 0	314.0 (27 -2:3)	7110 1000071	0 400/1 max.	350 MCM x 2 *1	350 MCM x 2 *1	250 MCM *1
	200	VFAS1-4200KPC	387.0 ([F=2.5)	AIC 18000A	J 500Amax.	AWG 4/0 x 3	AWG 4/0 x 3	AWG 1/0
						350 MCM x 3 *1	350 MCM x 3 *1	250 MCM x 2 *1
	220	VFAS1-4220KPC	427.0 (€ F = ₹.5)	AIC 18000A	J 500Amax.	250 MCM × 3	250 MCM × 3	AWG 2/0
			(/			350 MCM x 3 *1	350 MCM × 3 *1	250 MCM × 2 *1
	280	VFAS1-4280KPC	550.0 ([F=2.5)	AIC 18000A	T 700Amax.	350 MCM × 3	350 MCM × 3	AWG 3/0
	-		.=/	1	-	350 MCM × 3 *1	350 MCM × 3 *1	250 MCM × 2 *1
	355	VFAS1-4355KPC	671.0 ([F=2.5)	AIC 30000A	J 450A x 2 max.	400 MCM × 2 × 2	400 MCM × 4	AWG 4/0
			·	-	-	500 MCM × 2 × 2 *1	500 MCM × 4 *1	500 MCM *1
	400	VFAS1-4400KPC	759.0 ([F=2.5)	AIC 30000A	J 500A x 2 max.	500 MCM x 2 x 2	500 MCM × 4 500 MCM × 4 *1	AWG 4/0 500 MCM *1
					1	500 MCM x 2 x 2 *1 400 MCM x 3 x 2	400 MCM x 4	250 MCM
	500	VFAS1-4500KPC	941.0 ([F=2.5)	AIC 42000A	J 600A × 2 max.	500 MCM × 3 × 2 * 1	500 MCM × 5 *1	500 MCM *1
		l	l	L		JOU WICH A J A Z	JOU WOW A J I	JUU IVICIVI I

^{*1:} This part shows the wiring size with using the Lug terminal.

The Lug terminals are an option.

9.2.4 Caution as to the protection of motors from overload

When using the inverter's thermal protection function to protect the motor from overload, read the instruction manual included with the inverter carefully and set parameters according to the specifications of the motor used.

When using the inverter to control the operation of multiple motors, install an overload relay for each individual motor.

^{*2:} UL output current is different from unit rating output current.

^{*3:} The value of the UL rated output current is applicable when the carrier frequency (ζF) is less than the value shown in the table.

^{*4:} The cables used must be 75°C copper cables within 40°C ambient temperature.

10. Selection of peripheral devices

⚠ Warning



 When using the inverter without the front cover, be sure to place the inverter unit inside a cabinet. If they are used outside the cabinet, it may cause electric shock.



 Be sure to ground every unit. If not, it may cause electric shock or fire on the occasion of failure, short-circuit or electric leak.

10.1 Selection of wiring materials and devices

							Wire size					
				Main	circuit		WITC SIZO		Braking r	esistor/		
Voltage	Applicable		Input te		Output to	rminal	DC terr	minal	Braking		Earth c	able
class	motor	Inverter model	(R, S		(U, V				(optiona			
	[kW]		AWG	mm ²	AWG	mm ²	AWG	mm ²	AWG	mm²	AWG	mm ²
			(*7)	(*8)	(*7)	(*8)	(*7)	(*8)	(*7)	(*8)	(*7)	(*9)
	0.4	VFAS1-2004PL	14	1.5	14	1.5	14	1.5	14	1.5	14	2.5
	0.75	VFAS1-2007PL	14	1.5	14	1.5	14	1.5	14	1.5	14	2.5
	1.5	VFAS1-2015PL	14	1.5	14	1.5	12	1.5	14	1.5	14	2.5
	2.2	VFAS1-2022PL	12	1.5	12	1.5	10	2.5	14	1.5	14	2.5
	3.7/4.0	VFAS1-2037PL	10	4	10	4	8	6	14	1.5	12	4
	5.5	VFAS1-2055PL	8	6	8	6	6	10	14	1.5	10	6
	7.5	VFAS1-2075PL	8	10	8	10	4	16	12	2.5	10	10
200V	11	VFAS1-2110PM	4	16	4	16	3	16	10	4	10	16
class	15	VFAS1-2150PM	4	25	4	25	1	25	8	6	10	16
	18.5	VFAS1-2185PM	3	25	3	25	1/0	35	8	10	8	16
	22	VFAS1-2220PM	2	25	2	25	2/0	35	6	16	8	16
	30	VFAS1-2300PM	2/0	50	2/0	50	4/0	70	4	25	6	25
	37	VFAS1-2370PM	3/0	70	3/0	70	250MCM	95	3	35	6	35
	45	VFAS1-2450PM	4/0	70	4/0	70	300MCM	95	2	50	6	35
	55	VFAS1-2550P	3/0×2	70x2	3/0×2	120	4/0×2	95×2	1/0	50	2	70
	75	VFAS1-2750P	4/0×2	95×2	250MCMx2	70×2	300MCM×2	120×2	1/0	35×2	2	95
	0.75	VFAS1-4007PL	14	1.5	14	1.5	14	1.5	14	1.5	14	2.5
	1.5	VFAS1-4015PL	14	1.5	14	1.5	14	1.5	14	1.5	14	2.5
	2.2	VFAS1-4022PL	14	1.5	14	1.5	14	1.5	14	1.5	14	2.5
	3.7/4.0	VFAS1-4037PL	12	1.5	12	1.5	10	2.5	14	1.5	14	2.5
	5.5	VFAS1-4055PL	10	2.5	10	2.5	8	4	14	1.5	12	2.5
	7.5	VFAS1-4075PL	10	4	10	4	8	6	14	1.5	12	4
	11	VFAS1-4110PL	8	6 10	8	6 10	6	10	14	1.5 2.5	10 10	6 10
	15	VFAS1-4150PL	6		6		4	16	12			
	18.5	VFAS1-4185PL		10	6	10		16	10	2.5	10	10
	22 30	VFAS1-4220PL VFAS1-4300PL	6	10 16	6 4	10 16	4 2	16 25	10 8	4 6	10 10	10 16
	37	VFAS1-4300PL	3	25	3	25	1	35	8	10	8	16
	45	VFAS1-4450PL	1	35	1	35	2/0	50	6	16	8	16
400V	45 55	VFAS1-4450PL	1/0	50	1/0	50	3/0	70	6	16	6	25
	75	VFAS1-4750PL	3/0	70	3/0	70	250MCM	95	3	35	6	35
	90	VFAS1-4900PC	1/0×2	70×2	1/0×2	95	1/0×2	95×2	1/0	35	2	70
	110	VFAS1-4110KPC	3/0×2	95×2	3/0×2	120	2/0×2	120×2	1/0	50	2	95
	132	VFAS1-4132KPC	4/0×2	95×2	4/0×2	150	4/0×2	120×2	4/0	70	1/0	95
	160	VFAS1-4160KPC	300MCM×2	120×2	300MCM×2	95×2	350MCM×2	150×2	4/0	95	1/0	120
	200	VFAS1-4200KPC	4/0×3	150×2	4/0×3	120×2	3/0×3	150×3	300MCM	150	1/0	150
	220	VFAS1-4220KPC	250MCM×3	150×3	250MCM×3	120×2	4/0×3	150×3	300MCM	150	2/0	150
	280	VFAS1-4280KPC	350MCM×3	150×3	350MCM×3	185×2	300MCM×3	150×4	300MCM	150	3/0	120×2
	355	VFAS1-4355KPC	400MCM ×2×2 (*9)	120×2×2 (*9)	400MCM×4	150×3	500MCM×3	185×4	350MCM×2		4/0	120×2
	400	VFAS1-4400KPC	500MCM x2x2 (*9)	150×2×2 (*9)	500MCM×4	185×3	500MCM×4	185×4 (*8)	350MCM×2	185×2	4/0	150×2
	500	VFAS1-4500KPC	400MCM x3x2 (*9)	150×3×2 (*9)	400MCM×5	185×4	500MCM×4	180×4 (*8)			250MCM	

- (*1): The recommended cable size is that of the cable (e.g. 600V class, HIV cable) with continuous maximum permissible temperature of 75°C. Ambient temperature is 40°C or less and the wiring distance is 30m or less.
- (*2): For the control circuit, use shielded wires whose size (cross-section) is 0.75 mm² or more.
- (*3): For the earth cable, use wires larger than the specified ones in size (cross-section).
- (*4): Recommended wire size for an optional braking resistor. Refer to 5.19 for use of external braking resistor.
- (*5): This cable size is conformity to UL508C.
- (*6): This cable size is conformity to IEC60364-5-52.
- (*7): This cable size is conformity to IEC60364-5-54.
- (*8): The recommended cable is 600V class HIV cable with permissible temperature of 90°C.
- (*9): The number refers to a cable composition. For example, in the case of *120x2x2** 120x2x2* Number of cables connected in parallel on the terminal board Number of cables connected to each terminal to each terminal ter

■ Selection of wiring equipment

			Input current[A]			breaker CCB)	Magnetic contactor (MC)	
Voltage class	Applicable motor [kW]		input cu	irrent[A]	Without Reactor	With Reactor	Without Reactor	With Reactor
Class	motor [kwy]		Without Reactor	With Reactor	Rated current [A]	Rated current [A]	(MC Without Reactor Operation Current [A] AC-1	OperationI current [A] AC-1
	0.4	VFAS1-2004PL	3.5	2.1	5	5	25	25
	0.75	VFAS1-2007PL	6.1	3.2	10	5	25	25
	1.5	VFAS1-2015PL	11.5	6.4	15	10	25	25
	2.2	VFAS1-2022PL	15	9.3	20	15	25	25
	3.7/4.0	VFAS1-2037PL	26.0	15.5	30	30	32	25
	5.5	VFAS1-2055PL	35	22. 5	50	40	40	25
	7.5	VFAS1-2075PL	45	34.5	60	40	50	40
200V	11	VFAS1-2110PM	-	53.5	-	75	-	80
class	15	VFAS1-2150PM	-	72	-	100	-	80
	18.5	VFAS1-2185PM	-	77	-	100	-	80
	22	VFAS1-2220PM	-	88	-	125	-	125
	30	VFAS1-2300PM	-	125	-	150	-	125
	37	VFAS1-2370PM	-	140	-	175	-	250
	45	VFAS1-2450PM	-	165	-	200	-	250
	55	VFAS1-2550P	-	200	-	250	-	275
	75	VFAS1-2750P	-	270	-	350	-	350
	0.75	VFAS1-4007PL	3.7	2.1	5	4	25	25
	1.5	VFAS1-4015PL	5.8	3.8	10	6.3	25	25
	2.2	VFAS1-4022PL	8.2	5.7	14	10	25	25
	3.7/4.0	VFAS1-4037PL	14.0	8.7	18	14	25	25
	5.5	VFAS1-4055PL	20.5	12.7	32	25	25	25
	7.5	VFAS1-4075PL	27	16.3	32	25	32	25
	11	VFAS1-4110PL	36.5	21.5	50	30	40	32
	15	VFAS1-4150PL	48	33.5	60	40	50	40
	18.5	VFAS1-4185PL	-	45.5	-	60	-	50
	22	VFAS1-4220PL	-	50	-	60	-	50
	30	VFAS1-4300PL	-	66	-	100	-	80
400\/	37	VFAS1-4370PL	-	84	-	100	-	125
class 200V class	45	VFAS1-4450PL	-	105	-	125	-	125
0.000	55	VFAS1-4550PL	-	120	-	150	-	125
	75	VFAS1-4750PL	-	165	-	200	-	250
	90	VFAS1-4900PC	-	170	-	200	-	250
	110	VFAS1-4110KPC	-	200	-	250	-	275
	132	VFAS1-4132KPC	-	240	-	300	-	315
	160	VFAS1-4160KPC	-	290	-	350	-	350
	200	VFAS1-4200KPC	-	360	-	500	-	500
	220	VFAS1-4220KPC	-	395	-	500	-	500
	280	VFAS1-4280KPC	-	495	-	700	-	700
	355	VFAS1-4355KPC	-	637	-	1000	-	1000
	400	VFAS1-4400KPC	-	709	-	1000	-	1000
	500	VFAS1-4500KPC	-	876	-	1200	-	1600

^{(*1):} Selections for use of the Toshiba 4-pole standard motor with power supply voltage of 200V/400V-50Hz.

^{(*2):} Choose the MCCB according to the power supply capacity.

For comply with UL and CSA standard, use the fuse certified by UL and CSA.

^{(*3):} When using on the motor side during commercial-power supply operation, choose the MC with class AC-3 rated current for the motor rated current.

^{(*4):} Attach surge killers to the magnetic contactor and exciting coil of the relay.

^{(*5):} In the case the magnetic contactor (MC) with 2a-type auxiliary contacts is used for the control circuit, raise the reliability of the contact by using 2a-type contacts in parallel connection.

^{(*6):} For 200V/55kW model and larger and 400V/90kW model and larger, be sure to install a DC reactor.

10.2 Installation of a magnetic contactor

If using the inverter without installing a magnetic contactor (MC) in the primary circuit, use an MCCB (with a power cutoff device) to open the primary circuit when the inverter protective circuit is activated.


If using a braking resistor or braking resistor unit, install a magnetic contactor (MC) or no-fuse breaker with a power cutoff device to the power supply of the inverter, so that the power circuit opens when the failure detection relay (FL) in the inverter or the external overload relay is activated.

■ Magnetic contactor in the primary circuit

To detach the inverter from the power supply in any of the following cases, insert a magnetic contactor (primary-side magnetic contactor) between the inverter and the power supply.

- (1) If the motor overload relay is tripped
- (2) If the protective detector (FL) built into the inverter is activated
- (3) In the event of a power failure (for prevention of auto-restart)
- (4) If the resistor protective relay is tripped when a braking resistor or braking resistor unit is used

When using the inverter with no magnetic contactor (MC) on the primary side, install a no-fuse breaker with a voltage tripping coil instead of an MC and adjust the no-fuse breaker so that it will be tripped if the protective relay referred to above is activated. To detect a power failure, use an undervoltage relay or the like.



Example of connection of a magnetic contactor in the primary circuit

Note on wiring

- When frequently switching between start and stop, do not use the magnetic contactor on the primary side as an on-off switch for the inverter.
 Instead, stop and start the inverter by using terminals F and CC (forward run) or R and CC (reverse run).
- Be sure to attach a surge killer to the exciting coil of the magnetic contactor (MC).

■ Magnetic contactor in the secondary circuit

A magnetic contactor may be installed on the secondary side to switch controlled motors or supply commercial power to the load when the inverter is out of operation.

Note on wiring

- Be sure to interlock the magnetic contactor on the secondary side with the power supply to prevent commercial
 power from being applied to the inverter output terminals.
- When installing a magnetic contactor (MC) between the inverter and the motor, avoid turning the magnetic
 contactor on or off during operation. Turning the magnetic contactor on or off during operation causes a current to
 rush into the inverter which could lead to malfunction.

10.3 Installation of an overload relay

- 1) The VF-AS1 inverter has an electronic-thermal overload protective function. In the following cases, however, an overload relay suitable for the adjustment of the motor electronic thermal protection level (¿ H r) or appropriate to the motor used should be installed between the inverter and the motor.
 - When using a motor with a current rating different to that of the corresponding Toshiba general-purpose motor
 - When operating a single motor with an output smaller than that of the applicable standard motor.

 When operating multiple motors at a time, be sure to install an overload relay for each individual motor.
- 2) When using the VF-AS1 inverter to operate a constant-torque motor, such as the Toshiba VF motor, adjust the protection characteristic of the electronic thermal protection unit ($\mathcal{G} \downharpoonright \Omega$) to the VF motor use.
- 3) It is recommended to use a motor with a thermal relay embedded in the motor coil to give sufficient protection to the motor, especially when it runs in a low-speed range.

10.4 Application and functions of options

Separate type options shown below are prepared for the inverter VF-AS1 (2) DC reactor (200kW models and larger) (DCL) ф-ww-(4) Braking resistor/Braking unit (4) Braking resistor (3) EMC filter for CE No-fuse breaker (MCCB) Magnetic contactor compliance Power supply motor (MC) VF-AS1 IM (5) Motor end surge voltage suppression filter (for 400V (1) Input AC reactor (ACL) models only) (6) Control power supply backup option

Sorts of separate-type options

N1 -	Sorts of separate-type	1		F				
No.	Option name			Function, purp				
(1)	Input AC reactor (ACL)	To be used for improvement of input power-factor of the inverter power source, for reducing higher harmonic or suppressing external surge. The input reactor can be installed when the power capacity is 500 kVA or more and it is 10 times or more as high as the inverter capacity or there are some source distorted wave generation such as a thyristor, etc. and a high capacity inverter connected with the same distribution system.						
					Effect			
		Type of reactor	Power-factor improvement	Harmonic s 200V, 3.7/4.0kW or less	ouppression Other combination	External surge suppression		
	DC reactor(DCL)	Input AC reactor	Effective	Effective	Effective	Effective		
		DC reactor	Very effective	Effective	Very effective	Not effective		
(2)		The DC reactor is superior to the input AC reactor in power-factor improvement. For the inverter system that is required to be high reliable, it is recommended to use the input AC reactor that effectually suppresses external surge together with the DC reactor. 200V/11 to 45kW models and 400V/18.5 to 75kW models come with a built-in DC rector as standard equipment. * If you are using a 200V/55kW model or larger or a 400V/90kW model or larger, be sure to connect a DC reactor. (No DC reactor is required when the inverter is powered from a DC power supply.)						
(3)	EMC Directive compliant noise reduction filter (EMF3-*****)	If EMC filter is installed in proper connection, the inverter has consistency with EMC commands. 200V/0.4kW to 200V/7.5kW models and 400V/0.75 to 400V/500kW models come standard with built-in noise filters. The effectiveness of the built-in filter can, however, be increased by adding an EMC filter.						
(4)	Braking resistor Braking unit	To be used to shorten deceleration time for the reason of frequently operated quick deceleration and suspension or high inertia load. This increases consumption of regenerative energy in dynamic braking. For 200kW more inverter, it requires the braking unit.						
(5)	Motor end surge voltage suppression filter (for 400 V models only)							
(6)	Control power supply backup option	The VF-AS1 supplies control power from the main circuit power supply in it. The optional backup unit is designed to supply control power in the event the main circuit power supply shuts down. The optional backup unit can be used with both 200V and 400V models. Unit type: CPS002Z						

No.	Option name	Function, purpose.
(7)	LED Remote Keypad option (with parameter copy function)	Extention operation panel unit with parameter copy function. Includes LED display, RUN/STOP key, UP/DOWN key, MODE key, ENT key, EASY key, and COPY MODE key. (When using this unit, set as follows: $F \ B \ D \ S$ (common serial transmission waiting time) = $D \ D \ S$ (default setting). Use communication cable No. 10 to connect to the inverter. Panel type: RKP002Z Cable type: CAB0011 (1m), CAB0013 (3m), CAB0015 (5m)
(8)	LCD Remote Keypad option	This LCD operation panel unit can be installed to the inverter unit. Includes LCD display, RUN key, STOP/RESET key, job dial, ESC key, FWD/REV key and F1 to F4 key. Special cable is needed to connect the inverter and LCD panel. Panel type: RKP004Z LCD cable type: CAB0071 (1m), CAB0073 (3m), CAB0075 (5m), CAB00710 (10m)
(9)	USB communication converter unit (for communication with multiple inverters)	More than one inverter can be controlled with a personal computer and so on if this unit is used for connection between inverters and personal computer. Computer link: Since this unit makes it possible to connect inverters with higher-class computer, FA computer, etc., a data communication network can be constructed among multiple inverters. Unit type: USB001Z
(10)	Communication cable	For RS485/USB communication (between inverter and RS485/USB communication conversion unit) Cable type: CAB0011 (1m), CAB0013 (3m), CAB0015 (5m)
(11)	Operation panel	A frequency meter, frequency setup device, RUN/STOP (forward, reverse) switch are built in this operation panel. (Model: CBVR-7B1)
(12)	heat sink outside protrusion option	This allows is heat generated inside panels to be reduced

Selection table of separate-type options (1/2)

Voltage class	Applicable motor [kW]	Inverter model	EMC filter (*1)	DC reactor (DCL)	Dynamic brake drive circuit (GTR7) (*2)	Control power supply backup
	0.4	VFAS1-2004PL	Built-in	Option	Built-in	Option
	0.75	VFAS1-2007PL	Built-in	Option	Built-in	Option
	1.5	VFAS1-2015PL	Built-in	Option	Built-in	Option
	2.2	VFAS1-2022PL	Built-in	Option	Built-in	Option
	3.7/4.0	VFAS1-2037PL	Built-in	Option	Built-in	Option
	5.5	VFAS1-2055PL	Built-in	Option	Built-in	Option
	7.5	VFAS1-2075PL	Built-in	Option	Built-in	Option
	11	VFAS1-2110PM	Option	Built-in	Built-in	Option
200V	15	VFAS1-2150PM	Option	Built-in	Built-in	Option
lass	18.5	VFAS1-2185PM	Option	Built-in	Built-in	Option
	22	VFAS1-2220PM	Option	Built-in	Built-in	Option
	30	VFAS1-2300PM	Option	Built-in	Built-in	Option
	37	VFAS1-2370PM	Option	Built-in	Built-in	Option
	45	VFAS1-2450PM	Option	Built-in	Built-in	Option
	55	VFAS1-2550P	Option	Attached as standard	Built-in	Option
	75	VFAS1-2750P	Option	Attached as standard	Built-in	Option
	0.75	VFAS1-4007PL	Built-in	Option	Built-in	Option
	1.5	VFAS1-4015PL	Built-in	Option	Built-in	Option
	2.2	VFAS1-4022PL	Built-in	Option	Built-in	Option
	3.7/4.0	VFAS1-4037PL	Built-in	Option	Built-in	Option
	5.5	VFAS1-4055PL	Built-in	Option	Built-in	Option
	7.5	VFAS1-4075PL	Built-in	Option	Built-in	Option
	11	VFAS1-4110PL	Built-in	Option	Built-in	Option
	15	VFAS1-4150PL	Built-in	Option	Built-in	Option
	18.5	VFAS1-4185PL	Built-in	Built-in	Built-in	Option
	22	VFAS1-4220PL	Built-in	Built-in	Built-in	Option
	30	VFAS1-4300PL	Built-in	Built-in	Built-in	Option
	37	VFAS1-4370PL	Built-in	Built-in	Built-in	Option
	45	VFAS1-4450PL	Built-in	Built-in	Built-in	Option
	55	VFAS1-4550PL	Built-in	Built-in	Built-in	Option
	75	VFAS1-4750PL	Built-in	Built-in	Built-in	Option
			1	Attached as		
V00V	90	VFAS1-4900PC	Built-in	standard Attached as	Built-in	Option
class	110	VFAS1-4110KPC	Built-in	standard	Built-in	Option
	132	VFAS1-4132KPC	Built-in	Attached as standard	Built-in	Option
	160	VFAS1-4160KPC	Built-in	Attached as standard	Built-in	Option
	200	VFAS1-4200KPC	Built-in	Attached as standard	Option	Option
	220	VFAS1-4220KPC	Built-in	Attached as standard	Option	Option
	280	VFAS1-4280KPC	Built-in	Attached as standard	Option	Option
	355	VFAS1-4355KPC	Built-in	Attached as standard	Option	Option
	400	VFAS1-4400KPC	Built-in	Attached as standard	Option	Option
	500	VFAS1-4500KPC	Built-in	Attached as standard	Option	Option

^{(*1):} For the types and effects of EMC filters, refer to section 9.1.

^{(*2):} An optional braking resistor is required for every model of any capacity (see Selection table of separate-type options (2/2)).

Selection	table of sepa	arate-type options	(2/2)				
Voltage class	Appli-cable motor [kW]	Inverter model	Input AC reactor (ACL)	DC reactor (DCL) (*6)	Braking resistor (*1)	Motor end surge voltage suppression filter (*4)	Control power supply backup
	0.4	VFAS1-2004PL	PFL-2005S	DCL-2007	PBR-2007		
	0.75	VFAS1-2007PL	PFL-20055	DCL-2007	PBR-2007		
l	1.5	VFAS1-2015PL	DEI 20110	DOI 0000	DDD 0000	1	
	2.2	VFAS1-2022PL	PFL-2011S	DCL-2022	PBR-2002	R-2002	
	3.7/4.0	VFAS1-2037PL	PFL-2018S	DCL-2037	PBR-2037		
	5.5	VFAS1-2055PL	PFL-2025S	DCL-2055	PBR3-2055		
	7.5	VFAS1-2075PL	PFL-2050S	DCL-2110	PBR3-2075		
200V	11	VFAS1-2110PM	PFL-20505		PBR3-2110		
class	15	VFAS1-2150PM			PBR3-2150	-	
ciass	18.5	VFAS1-2185PM	PFL-2100S		PBR3-2150		
	22	VFAS1-2220PM		Built-in	PBR3-2220		
	30	VFAS1-2300PM	PFL-2150S		PBR3-2220		
	37	VFAS1-2370PM	FFL-21303				
	45	VFAS1-2450PM	PFL-2200S		PBR-222W002		
	55	VFAS1-2550P	PFL-2300S				
	75	VFAS1-2750P	PFL-2400S	Attached as standard	DGP600W-B1 [DGP600W-C1]		CPS002Z
	0.75	VFAS1-4007PL		DCL-2007			
	1.5	VFAS1-4015PL	DEI 10100	(*5)	PBR-2007	MSF-4015Z	
	2.2	VFAS1-4022PL	PFL-4012S	DCL-2022		MOE 40077	
	3.7/4.0	VFAS1-4037PL	1	(*5)	PBR-4037	MSF-4037Z	
	5.5	VFAS1-4055PL		DCL-4110	PBR3-4055	MOE 40757	
	7.5	VFAS1-4075PL	PFL-4025S		PBR3-4075	MSF-4075Z	
	11	VFAS1-4110PL			PBR3-4110	14507	
	15	VFAS1-4150PL	PFL-4050S	DCL-4220		MSF-4150Z	
	18.5	VFAS1-4185PL		Built-in	PBR3-4150	MSF-4220Z	
	22	VFAS1-4220PL					
	30	VFAS1-4300PL			PBR3-4220	MSF-4370Z MSF-4550Z	
	37	VFAS1-4370PL	PFL-4100S		PBR-417W008		
	45	VFAS1-4450PL					
	55	VFAS1-4550PL	PFL-4150S				
	75	VFAS1-4750PL	FFL-41303			MSF-4750Z	
	90	VFAS1-4900PC	PFL-4300S			MSL-4215T	
	110	VFAS1-4110KPC	FFL-43003			MOL 4044T	1
400V class	132	VFAS1-4132KPC	PFL-4400S		DGP600W-B2 [DGP600W-C2]	MSL-4314T	
	160	VFAS1-4160KPC					
	200	VFAS1-4200KPC	PFL-4600S		PB7-4200K(*2) DGP600W-B3	MSL-4481T	
	220	VFAS1-4220KPC			[DGP600W-C3]		
	280	VFAS1-4280KPC	PFL-4800S	Attached as standard	PB7-4200K(*2) DGP600W-B4 [DGP600W-C4]	-B4 -C4] MSL-4759T -B3	
	355	VFAS1-4355KPC	PFL-4450S	1	PB7-4400K(*2) DGP600W-B3 ×2(parallel)		
	400	VFAS1-4400KPC	×2(parallel)		x2(parallel) [DGP600W-C3 x2(parallel)]	MSL-41188T	
	500	VFAS1-4500KPC	PFL-4613S x2(parallel)		PB7-4400K(*2) DGP600W-B4 ×2(parallel) [DGP600W-C4 ×2(parallel)]		

^{(*1):} Model in square brackets is fitted with top cover.

^{(*2):} To use a 400V/200kW inverter or larger in combination with an external braking resistor (DGP600 series), a braking unit (PB7) with a built-in braking resistor drive circuit is also needed.

^{(*3):} The options are selected based on the premise that 600V HIV insulated wires (continuous allowable temperature: 75°C) are used.

^{(*4):} Each MSF-***Z model is composed of a reactor, a resistor and a capacitor, and as a guide, use a cable 300m or less in length to connect the inverter to the motor.

Each MSL-****T model is an output-dedicated surge suppression reactor, and as a guide, use a cable 100m or less in length (or 50m or less for a shielded cable) to connect the inverter to the motor, although allowable cable lengths vary according to the input voltage.)

^{(*5):} These reactors are usable for each of 200V class and 400V class.

^{(*6):} Be sure to connect DC reactor to 200V-55kW or more or 400V-90kW or more inverter. (Not necessary for DC power input.)

When a 200V-55kW or more inverter or 400V-90 to 280kW inverter is replaced with new one, the reactor (model: DCL-****) used with the current inverter can be used as-is with the new inverter. In such cases, therefore, you do not need to purchase any reactors in this table.

10.5 Optional internal devices

Here are the internal devices optionally available. There are two types of optional devices: Add-on type and Plug-in type.

■ Table of optional devices

	Option name	Function, purpose	Model	Type of installation
sion nal	(1) Expansion I/O card1 option (Logic input/output + PTC input)	Used to extend input and output	ETB003Z	Add-on
Expansion terminal function	(2) Expansion I/O card2 option (Function of the above optional card 1 + Analogue input/output + Pulse input)	terminals.	ETB004Z	Add-on
ation	(3) CC-Link communication option	Used to connect to a CC-Link network for control.	CCL001Z	Add-on
Sommunication function	(4) DeviceNet communication option	Used to connect to a DeviceNet network for control.	DEV002Z	Add-on
Com	(5) PROFIBUS-DP communication option	Used to connect to a PROFIBUS-DP network for control.	PDP002Z	Add-on
_	(6) PG feedback option (Push-pull 12V)		VEC004Z	Plug-in
Other function	(7) PG feedback option (Push-pull 15V)	Used to issue motor pulse train rate commands or used for sensor	VEC005Z	Plug-in
Other f	(8) PG feedback option (Push-pull 24V)	vector control.	VEC006Z	Plug-in
	(9) PG feedback option (RS422-5V)		VEC007Z	Plug-in

■ Functions of Add-on type options

(1) Expansion I/O card1 option (Logic input/output + PTC input)

Function	Description			
Multifunction programmable contact	No-voltage contact input (24Vdc-5mA or less)	No-voltage contact input (24Vdc-5mA or less)		
input (4 points)	Sink logic input (at a common voltage of 24V)	Source logic input		
	ON: Less than 10Vdc	ON: 11Vdc or more		
	OFF: 16Vdc or more	OFF: Less than 5Vdc		
Multifunction programmable open	Driving current: Max. 50mA when an external po	ower source is used		
collector output (2 points)	Max. 20mA when the internal p	ower source is used		
	Driving voltage: 12V (min) to 30V (max)			
Multifunction programmable relay	1C contact configuration			
contact output	output 250Vac-2A (cosφ=1), 250Vac-1A (cosφ=0.4), 30Vdc-1A			
External thermal trip input	nal trip input Resistance between TH+ and TH-			
	Error: Approx. 70Ω or less or approx. 3kΩ or mo	or: Approx. 70Ω or less or approx. 3kΩ or more		
Recovery from error: Approx. 1.6k Ω				
24V power output	4V power output 24Vdc - 60mA max			
-10V power output	V power output -10Vdc -10mA			
Contact input common terminal Common terminals for contact input				

(2) Expansion I/O card2 option (Function of optional card 1 + Analogue input/output + Pulse input)


Function	Description		
Multifunction programmable contact	No-voltage contact input (24Vdc-5mA or less)		
input (4 points)	Sink logic input (at a common voltage of 24V) Source logic input		
	ON: Less than 10Vdc	ON: 11Vdc or more	
	OFF: 16Vdc or more	OFF: Less than 5Vdc	
Multifunction programmable open	Driving current: Max. 50mA when an external p	ower source is used	
collector output (2 points)	Max. 20mA when the internal p	ower source is used	
	Driving voltage: 12V (min) to 30V (max)		
Multifunction programmable relay	1C contact configuration		
contact output	250Vac-2A (cosφ=1), 250Vac-1A (cosφ=0.4),	30Vdc-1A	
Differential current input	Current input: 20mA or less		
	Voltage input: Differential voltages 5V or less, -10V or more, +10V or		
Analog input	Current input: 20mA or less		
	Voltage input: 0V to 10V		
Monitor output	Voltage output: -10V to 10V, 0V to 10V		
	Current output: 0mA to 20mA		
Pulse train input	Input pulse specifications		
	Voltage: Max. 5V Current: Max. 15mA	Frequency: Max. 30kHz	
	Duty: 50±10%		
External thermal trip input	Resistance between TH+ and TH-		
	Error: Approx. 70Ω or less or approx. $3k\Omega$ or more		
	Recovery from error: Approx. 1.6kΩ		
24V power output	24Vdc - 60mA max		
-10V power output	-10Vdc -10mA		
Contact input common terminal	Common terminals for contact input		

■ Functions of Plug-in type options


	PG feedback option (6) (7) (8)	PG feedback option (9)	
Model	VEC004Z, VEC005Z, VEC006Z	VEC007Z	
Sensor vector control operation	Speed control operation: Zero-speed - 150% torque Speed control range: 1:1000 (1000ppr PG) Torque control operation: Torque control accuracy ±10% Torque control range: -100% to +100%		
PG method	Complementary method, open collector method	Line drive method	
PG cable length	Max. 100m (complementary method)	Max. 30m	
PG supply power	VEC004Z: 12V-160mA VEC005Z: 15V-150mA VEC006Z: 24V-90mA	5V-160mA	
Maximum pulse input frequency 300kHz or less * If a two-phase open collector is used, a study ne details, refer to the operating manual for the optic Pulse duty: 50±10%		ű	
Pulse input voltage	12Vdc to 24Vdc	Line driver (LTC485 or equivalent)	
Recommended encoder	Manufacturer: Sumtak Corporation Model: IRS360 series Supply voltage: 10.8 to 26.4V Output method: Complementary output	Manufacturer: Sumtak Corporation Model: IRS320 series Supply voltage: 5V Output method: Line driver method	
Wiring of Cable type: Twisted-pair shielded cable Conductor resistance: Conductor resistance (Ω/m) x cable length (m) x 2 x current consumption (A V _D (V): 1.0V (VEC004Z, VEC006Z, VEC006Z), 0.3V (VEC007Z) Applicable cable: 0.2 to 0.75mm² * When a power cable 0.2 mm² in cross sectional area is used, the encoder cable length shot Max. 30m (VEC004Z, VEC005Z, VEC006Z) Max. 10m (VEC007Z) Recommended cable: Kuramo Electric KVC-36SB, Furukawa Electric ROVV-SB			

■ How to install

Add-on type devices and insertion type devices are installed in different ways. Install them correctly, as shown in the figures below.



Depending on the capacity, the installation of an Add-on type device may increase the depth of the inverter.



10.6 Connection of a DC power supply and other electric units

Besides a three-phase commercial power supply, a single-phase 200V power supply (5.5kW or less) and a DC power supply can be connected to the VFAS1 inverter.

When connecting each of these units, keep in mind the points described in the following sections.

10.6.1 Connection of a single-phase 200V power supply

The table below shows which model to select when operating a three-phase induction motor, using a single-phase 200V power supply (200-240V, 50/60Hz).

Input power	Applicable motor (kW)	Inverter type
Single phase	0.4	VFAS1-2007PL
200~240V	0.75	VFAS1-2015PL
50/60Hz	1.5	VFAS1-2022PL
	2.2	VFAS1-2037PL
	3.7	VFAS1-2055PL
	5.5	VFAS1-2075PL

Note: Set the parameter $F \not B \not B \not B$ to $\not B$ (input phase failure detection mode selection: disabled).

10.6.2 When using the inverter along with a DC power supply

Keep the following in mind when connecting a DC power supply to the VFAS1 (PA/+ and PC/- terminals).

Note 1: An optional initial charger (MCR-2550) is needed for middle- and large-capacity models.

Note 2: 200V-75kW and 400V-110kW or more models are needed to change the connecting for the cooling fan.

Note 3: A DC reactor does not need to be connected to the inverter.

⇒ For details about use in combination with a DC power supply, refer to the instruction manual (E6581432) specified in section 6.42.

Voltage class	Inverter model	Initial charger (optional)	Change to connection of cooling fan power supply	DC reactor
	VFAS1-2004PL~ VFAS1-2150PM	No required	No required	No required
200V class	VFAS1-2185PM~ VFAS1-2550P	MCR-2550×1	No required	No required
	VFAS1-2750P	MCR-2550×2 (parallel)	Required	No required
	VFAS1-4007PL~ VFAS1-4185PL	No required	No required	No required
	VFAS1-4220PL~ VFAS1-4900PC	MCR-2550×1	No required	No required
	VFAS1-4110KPC	MCR-2550×1	Required	No required
400V class	VFAS1-4132KPC~ VFAS1-4220KPC	MCR-2550×2 (parallel)	Required	No required
	VFAS1-4280KPC	MCR-2550x3 (parallel)	Required	No required
	VFAS1-4355KPC, VFAS1-4400KPC	MCR-2550×4 (parallel)	Required	No required
	VFAS1-4500KPC	MCR-2550x5 (parallel)	Required	No required

Note: Set the parameter $F \in \mathcal{D} B$ to \mathcal{D} (input phase failure detection mode selection: disabled).


■ Power consumed by the fans

VFAS1	Power consumed by the fans
2750P, 4110KPC~4160KPC	700VA
4200KPC~4280KPC	1300 VA
4355KPC, 4400KPC	1900 VA
4500KPC	2500 VA


■Connecting fans for a separate power supply

In order to remove the link between the fans and the transformer power supply and relocate it at terminals RO, SO, TO, connectors X1 and X4 must be crossed as indicated on the diagrams below.


VFAS1-2750P, 4110KPC~4160KPC



VFAS1-4200KPC~4280KPC



VFAS1-4355KPC, 4400KPC, 4500KPC



11. Table of parameters

*3 Sensorless vector/vector with sensor (e:Effective, -:Ineffective)	Reference	3.2	sensor : Any setting of $P = 7$, B Sensorless vectorivector with sensor (• Effective : Ineffective)		Reference	5.1	5.2	5.3	5.4	5.5	က ဟ်
ffective,	V/f *1	•	-ffective	///		•	•	•	•	•	•
ensor (∙:E	PM control *2	•	<i>B</i> sensor (•:F	Σd	control	•	•	•	•	•	•
ctor with s	control Torque control	•/•	of $PE = 7,t$	control	Torque control	•/•	•	-	•/•	•/•	
s vector/ve	Speed Torq	•/•	ny setting	Vector control	Speed	•/•	•/•	•/•	•/•	•/•	•/•
Sensorles	Write during running	Enabled	Sensor: A		Write during running	-	Disabled	Disabled	Disabled	Disabled	Disabled
*	Default setting	0	Vector with		Default setting	-	0	0	0	0	0
	Minimum setting unit (Panel/Communi cation)	0.1/0.01	1 = 2, 3, 4/	Minimum	setting unit (Panel/Communi cation)	1/1	1/1	1/1	1/1	1/1	1/1
	Adjustment range	7.5 ~ F H Hz	*2: PM control : $P_L = S_L =$		Adjustment range		0:Disabled 1:Automatic setting 2:Automatic setting (during acceleration only)	0:Disabled 1:Automatic torque boost + auto-tuning 1 2:Sensorless vector control 1+ auto-tuning 1	O'Disabled 1:Frequency setting by means of voltage 1:Frequency setting by means of current 3:Voltage/current switching from external terminal 4: Frequency setting on operation panel and operation by means of terminals 5: Frequency setting and operation on operation panel	O:Terminal input enabled 1:Operation panel input enabled (including LED/LCD option input) 2:2-wire RS485 communication input 3:4-wire RS485 communication input 4:Communication option input	1:VIII (voltage/current input) 2:RR/S4 (potentiometer/voltage input) 2:RR/S4 (potentiometer/voltage input) 4:Operation panel input enabled (including LED/LCD option input) 5:2-wire RS485 communication input 6:4-wire RS485 communication input 6:4-wire RS485 communication input 9:Optional AI1 (differential current input) 9:Optional AI1 (differential current input) 11:Optional RP pulse input 12:Optional RP pulse input 12:Optional Ingi-speed pulse input 13:-(Unsupported option)
		Operation frequency of operation panel	.F=0, 1,5		Function	History function	Automatic acceleration/deceleration	Automatic torque boost	Automatic function setting	Command mode selection	Frequency setting mode selection 1
ameter	Communi cation No.		y setting c	Commin	cation No.		0000	0001	0040	0003	0004
1. User parameter	Title	34	*1: V/f : Any setting of $P E = D$, 2. Basic parameter [1/4]		Title	нпн	80.1	RU∂	вич	P0u3	Fnad

2. Basic parameter [2/4]	rameter [2/	(4]				Sensorles	ss vector/ve	ctor with se	ənsor (●:Ei	fective, -	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)
	Commini			Minimum			Vector control	control			
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed	Torque control	PM	\/ \	Reference
			0:Constant torque characteristics				-/-	-/-		•	
			1:Voltage decrease curve				-/-	+		•	
			2:Automatic torque boost				-/•	<u>,</u>			
ċ			3:Sensorless vector control 1 (speed)		(:	-/•	, '			ı
T U	0015	V/f control mode selection	4:Sensorless vector control 2 (speed/torque)	1/1	0	Disabled	-/•	-/·			5.6
			5.V/T 5-point setting				'	÷,		•	
			6:PM control					÷,	•		
			7:PG feedback control				• •	÷ ÷			
qn	0016	Manual torque boost 1	0.10 Cleedback vector connot	0.1/0.1	*1	Enabled	•	-	•	•	5.7
-1	0014		25.0~500 Hz	0.1/0.01	£*	Disabled	•/•	•/•	•	•	5.8
חלח	0409	Base frequency voltage 1	200V class:50~330V	1/0/1	٠,4	Disabled	•/•	•/•	•	•	5.8
N U	0011	Maximum fragilancy	30 0-500 0Hz	1/0/01	0 08	Disabled	9/0	-/-	•	•	2
1111	0012	Upper limit frequency	00.01.000.01.00	0.1/0.01	8.00	Frabled	,	,	•	•	
J -	200	= 1 ==	20.00	0.1/0.01	9 0	Enabled	2/3			٠,	5 6
7,00	0000	Lower IIIIII II equericy	0.0~µ ∟ ⊓∠	0.1/0.01	0.0	Ellabled	•/•		•	•	
H.C.	6000	Acceleration time 1	0.1~6000 sec.	0.1/0.1 *2	٠,1	Enabled	•/•	-	•	•	
SEC	0010	Deceleration time 1	0.1~6000 sec.	0.1/0.1 *2	*1	Enabled	•/•	-	•	•	5.2
80FZ	0213	RR/S4 input point 2	0.0∼ <i>F H Hz</i>	10.0/1.0	€*	Enabled	•/•		•	•	5. 11
C31 8	0204	VI/II ipput point 2 frequency	7 H 7 J ~ U	0 1/0 01	٤*	Polyton	•/•		•		7 11
3 11 11	4070	VI/II III pui poi it 2 il equello y		0.1/0.01	2	Lilabida		-	•	•	-
5-1	0018	Preset speed operation frequency 1	<i>LL-UL</i> Hz	0.1/0.01	0.0	Enabled	•/•	-	•	•	5. 12
5-5	0019	Preset speed operation frequency 2	7 <i>1 - 1</i> 17 Hz	0.1/0.01	0.0	Enabled	•/•	,	•	•	5. 12
5-3	0020	Preset speed operation frequency 3	77 -77 Hz	0.1/0.01	0.0	Enabled	•/•		•	•	5. 12
5.4	0021	Preset speed operation frequency 4	77 -77 Hz	0.1/0.01	0.0	Enabled	•/•		•	•	5. 12
5 - 5	0022	Preset speed operation frequency 5	77 -77 Hz	0.1/0.01	0.0	Enabled	•/•		•	•	5.12
5.6	0023	Preset speed operation frequency 6	77 -77 Hz	0.1/0.01	0.0	Enabled	•/•		•	•	5. 12
5-7	0024	Preset speed operation frequency 7	77 -77 Hz	0.1/0.01	0.0	Enabled	•/•		•	•	5. 12
ي ع	8000	Forward run/reverse run selection (operation panel	0.Forward run 1.Reverse run 2.Forward run (Forward/reverse switchable on operation	1/1	0	Enabled	•/•	•/•	•	•	5. 13
		operation)	panel) 3:Reverse run (Forward/reverse switchable on oneration panel)								
*1: Default	values vary	*1: Default values vary depending on the capacity. See the table of K-46.	⇒ See the table of K-46.								

^{22.} Changing the parameter F 4 P enables to set to 0.01 sec. (adjustment range: 0.01–600.0 sec.).

*3. Inverter with a model number ending with -WN, HN: 60.0 -WP: 50.0

Sensorless vector/vector with sensor (•:Effective, -:Ineffective)		Reference	5. 14				5 14	<u>t</u>				5. 15	5. 16	5. 16	5. 16	5. 16	5. 17	5. 18.1	5. 18. 2	5. 19	5. 19	0,7
ffective,		V/f	•				•	•				•	•	•	•	•	•	•	•	•	•	
ensor (∙:E		control	•				•	•				•	•	•	•	•	•	•	•	•	•	
ctor with s	control	Torque control	•/•				77					•	•/•	•/•	•/•	•/•	•/•	•/•	-/-	•/•	•/•	,
s vector/ve	Vector control	Speed control	•/•					•				•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	,
Sensorles		Write during running	Enabled				Fnahlad	L and a				Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Disabled	Disabled	Disabled	Disabled	
	. , -	Default setting	100				c	>				0	0	*4	2	*	*3	0	0	0	£*	
	Minimum	setting unit (Panel/Communi cation)	1/1				1/1					1/1	1/1	1/1	1/1	1/1	0.1/0.1	1/1	1/1	1/1	0.1/0.1	
		Adjustment range	10~100%	Setting Motor type Overload OL stall protection	d) o	1 Standard (protect) (stall)	Motor × (not protect)	3 × (not protect) (stall)	o (protect) x (not stall)	5 c (protect) c (stall)	or protectly	0:%, 1:A (ampere)/V (volt)	0~76 *1		0~76 *1	-	1.0~16.0kHz (2.5~8.0kHz) *2	0:Disabled 1:Af auto-restart after momentary stop 2:When turning ST on or off 3:1+2 4:At start-up	O'Disabled 1:Power ride-through 1:Power ride-through 3:Synchronized deceleration/acceleration (synchronized acceleration/acceleration signal) 4:Synchronized deceleration/acceleration (synchronized acceleration/acceleration acceleration signal) 4:Synchronized deceleration signal	0:Disabled 1:Enabled (braking resistance overload detect) 2:Enabled (braking resistance overload not detect)	0.5∼1000Ω	
[4]	-	Function	Motor electronic thermal protection level 1			14 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	Electronic mermal	selection			40000	Selection	FM terminal meter selection	FM terminal meter adjustment	AM terminal meter selection	AM terminal meter adjustment	PWM carrier frequency	Auto-restart control selection	Regenerative power ride-through control	Dynamic braking selection	Dynamic braking resistance	Allowable continuous
rameter [3,	Communi	cation No.	0090				0017	3				0701	9000	9000	0490	0671	0300	0301	0302	0304	0308	
2. Basic parameter [3/4]		Title	Ł Hr				0 70					9598	F7151	ЬП	15 <i>UB</i>	88	47	500	טינ	90	Pbr	0

*1: ⇒ For the adjustment range, see the table on page K-39.
*2: Por 2004/55/75kW models and 400Y-90kW to 400V-50kW models, the carrier frequency is between 2.5 and 8.0kHz inclusive.
*2: Default values vary depending on the capacity. → See the table of K-46.
*4: Default setting value is adjusted for connection of frequency meters "QS60T". (Between FM and CCA: Approx. 3.6V) (Between AM and CCA: Approx. 3.6V)

Basic para	Basic parameter [4/4]	4]				Sensorles	s vector/ve	ctor with se	ensor (∙:E	ffective,	Sensorless vector/vector with sensor (e:Effective, -:Ineffective)
	Communi			_			Vector control	control	i		
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default Write during setting running	Write during running	Speed	Torque	PM	V/f	Reference
483	2000	Factory default setting	15.0 Hz default setting 2:60 Hz default setting 3:Factory default setting 3:Factory default setting 4.Tip clear 5:Cumulative operation time cleared 6:Initialization of type information 7:Save user-defined parameters 8:Reset of user-defined parameters 9:Cumulative han operation time record clear 10:Acceleration/deceleration time setting 0.01 sec600.0 sec. sec6000sec.	1,1	0	Disabled	*	•,•	•	•	5. 20
7350	0020	Registered parameter display selection	0:Standard setting mode at time of activation of motor 1:Quick mode at time of activation of motor 2:Quick mode only	1/1	0	Enabled	•/•	•/•	•	•	5. 22
<u>.</u> 9	,	Extended parameters	Set detailed parameters shown in the following pages.				•/•	•/•	•	•	,
$\mathcal{L}_{r}U$		Automatic edit function					•/•	•/•	•	•	4.2

Sensorless vector/vector with sensor (•:Effective, -:Ineffective)	Poference	Releience	6. 1. 1	6. 1. 2	6. 1. 2	Sensorless vector/vector with sensor (e:Effective, -:Ineffective)	Reference	6. 2. 1	6. 2. 2	*	6. 2. 3	6. 2. 3
ffective, .	//#	//	•	•	•	ffective, .	V/f	•	•	•	•	•
ensor (∙:E	PM	control	•	•	•	ensor (∙:El	PM control	•	•	•	•	•
ctor with se	control	control	•/•	•/•	•/•	ctor with se	control Torque control	*	•/•	•/•	•/•	•/•
s vector/ve	Vector control	control	•/•	•/•	•/•	s vector/ve	Speed Torque control	•,	•/•	•/•	•/•	•/•
Sensorles	Write during	running	Enabled	Enabled	Enabled	Sensorles	Write during running	Disabled	Disabled	Disabled	Disabled	Disabled
•			0.0	0.0	2.5		Default setting	-	0	0	0	0
•	Minimum setting unit	(Panel/Communi cation)	0.1/0.01	0.1/0.01	0.1/0.01		Minimum setting unit (Panel/Communi cation)	1/1	1/1	1/1	1/1	1/1
	Adjustment range	Adjustment range	0.0~ <i>UL</i> Hz	0.0∼ <i>U.</i> L Hz	0.0∼ <i>UL</i> Hz		Adjustment range	0:Reverse run 1:Stop	0:Disabled 1:Enabled	87 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 - 1 -	0:Voltage input 1:Current input	0:Voltage input 1:Current input
ırs	Fination	ranction	Low-speed signal output frequency	Speed reach setting frequency	Speed reach detection band	stion	Function	Priority when forward/reverse run commands are entered simultaneously	Input terminal priority selection	Unsupported	Analog VI/VII voltage/current switching	Analog AI2 (optional circuit board) voltage/current switching
Extended parameter [1] Frequency signal	Communi	No.	0100	0101	0102	[2] Input signal selection	Communi cation No.	0105	0106	0107	0108	0109
Extended parameters In Frequency signal	Tiflo	enne	0013	1013	2013	[2] Input s	Title	5013	8013	1013	8013	F 18 9 0109

Sensorless vector/vector with sensor (•:Effective, -:Ineffective) Vector control	Reference	6.3.1	7.2.1	7.2.1	7.2.1	7.2.1	7.2.1	7.2.1	7.2.1	7.2.1	7.2.1	7.2.1	7.2.1	7.2.1	7. 2. 1	7. 2. 1	7. 2. 1			6.3.1	7.2.2	7.2.2	7.2.2	7.2.2	7.2.2	7.2.2	7.2.2	7.2.2	7.2.2
ffective,	V/f	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ensor (∙:E	PM control	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
control	Torque	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
s vector/vector wi	Speed	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
Sensorles	Write during running	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
	Default setting	£*	2	4	9	8	10	12	14	16	0	0	0	0	0	0	0	0	0	0	4	9	10	254	254	254	254	254	254
Minimum	setting unit (Panel/Communi cation)	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1
	Adjustment range	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~255 *2	0~255 *2	0~255 *2	0~255 *2	0~255 *2	0~255 *2	0~255 *2	0~255 *2	0~255 *2
selection	Function	Always ON function selection 1	Input terminal function selection 1 (F)	Input terminal function selection 2 (R)	Input terminal function selection 3 (ST)	Input terminal function selection 4 (RES)	Input terminal function selection 5 (S1)	Input terminal function selection 6 (S2)	Input terminal function selection 7 (S3)	Input terminal function selection 8 (RR/S4)	Input terminal function selection 9 (LI1)	Input terminal function selection 10 (LI2)	Input terminal selection 11 (LI3)	Input terminal selection 12 (LI4)	Input terminal selection 13 (LI5)	Input terminal selection 14 (LI6)	Input terminal selection 15 (LI7)	Input terminal selection 16 (LI8)	Always ON function selection 2	Always ON function selection 3	Output terminal function selection 1 (OUT1)	Output terminal function selection 2 (OUT2)	Output terminal function selection 3 (FL)	Output terminal function selection 4 (OUT3)	Output terminal function selection 5 (OUT4)	Output terminal function selection 6 (R1)	Output terminal function selection 7 (OUT5)	Output terminal function selection 8 (OUT6)	Output terminal function selection 9 (R2)
3 Terminal function selection	communi cation No.	0110	0111	0112	0113	0114	0115	0116	0117	0118	0119	0120	0121	0122	0123	0124	0125	0126	0127	0128	0130	0131	0132	0133	0134	0135	0136	0137	0138
[3] Termir	Title	0113	1111	2113	E113	4114	5113	8113	6117	8113	6113	6150	1511	£ 155	F 123	F 124	F 125	F 125	F 127	108	F 130	1813	2813	E 133	h E ! 3	5813	8 13B	F 137	8813

Ξ,																										_
Sensorless vector/vector with sensor (•:Effective, -:Ineffective)		Reference	7.2.3	7.2.3	7.2.3	7.2.3	7.2.3	7.2.3	7.2.1	7.2.1	7.2.1	7.2.1	7.2.2	7.2.2	6.4.1	6.4.1	6. 4. 1	6. 4. 1	6. 4. 1	6. 4. 1	6. 4. 1	6. 4. 1	6. 4. 1	6. 4. 1	6.4.1	6. 4. 1
ffective,		VÆ	•	•	•	•	•	٠	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ensor (∙:Ef	i	control	•	•	•	•	•	٠	•	•	•	•	•	•												
ctor with se	control	Torque control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	-	-	-	-	-	-	-	-	-	-		
s vector/ve	Vector contro	Speed	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•												
Sensorles		Default Write during setting running	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Enabled	Enabled	Disabled	Disabled	Enabled	Enabled	Disabled	Disabled	Enabled	Enabled
	. , -	Default setting	8	8	8	8	8	8	0	0	0	0	254	254	*4	*3	*3	100	*4	*3	*3	100	*4	*3	*3	100
	Minimum	setting unit (Panel/Communi cation)	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0.1/0.01	1/0.1	0.1/0.1	1/1	0.1/0.01	1/0/1	0.1/0.1	1/1	0.1/0.01	1/0.1	0.1/0.1	1/1
		Adjustment range	2~200ms	2~200ms	2~200ms	2~200ms	2~200ms	5~200ms	0~135 *1	0~135 *1	0~135 *1	0~135 *1	0~255*2	0~255 *2	25.0~500 Hz	50~330V/660V	0.0~30.0%	10~100%	25.0~500 Hz	20~330V/660V	0.0~30.0%	10~100%	25.0~500 Hz	20~330\/660\	0.0~30.0%	10~100%
[4] Terminal response time setup		Function	Input terminal 1 response time selection (F)	Input terminal 2 response time selection (R)	Input terminal 3 response time selection (ST)	Input terminal 4 response time selection (RES)	Input terminal 5~12 response time selection	Input terminal 13~20 response time selection	Input terminal selection 17(B12)	Input terminal selection 18(B13)	Input terminal selection 19(B14)	Input terminal selection 20(B15)	Output terminal function selection 10 (R3) *5	Output terminal function selection 11 (R4) *5	Base frequency 2	Base frequency voltage 2	Manual torque boost 2	Thermal protection level 2	Base frequency 3	Base frequency voltage 3	Manual torque boost 3	Thermal protection level 3	Base frequency 4	Base frequency voltage 4		Thermal protection level 4 10
al respons	Communi	cation No.	0140	0141	0142	0143	0144	0145	0164	0165	0166	0167	0168	0169	0170	0171	0172	0173	0174	0175	0176	0177	0178	0179	0180	0181
[4] Termina		Title	8613	1613	2413	Eh1 3	hh! 3	5413	491 J	591 3	991 3	1814	8913	6913	0113	1114	2113	EL1 3	h11 d	5113	9613	6613	8613	6613	08/3	F 18 1 0181 Thermal

*1: ⇒ For the adjustment range, see the table on page K-41.

2: ⇒ For the adjustment range, see the table on page K-43.

3: Default values vary depending on the capacity. ⇒ See the table of K-46.

4: Inventer with a model number ending with -WN, HN: 60.0 -WP: 50.0

*5: Unsupported option

Sensorless vector/vector with sensor (•: Effective, -: Ineffective)		Reference	5.6	5.6	5.6	5.6	5.6	5.6	5.6	5.6	5.6	5.6
ffective,		V/f	•	•	•	•	٠	•	•	•	•	•
ensor (∙:E		PM control	-	-	-	-	-	-	-	-	-	-
ctor with s	control	Torque control			٠				٠		٠	
s vector/ve	Vector control	Speed	-							-		
Sensorles		Write during running	0.0 Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
		Default setting	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0
	Minimum	setting unit (Panel/Communi cation)	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01
		Adjustment range	0.0∼ <i>F H</i> Hz	0.0~100.0%	0.0~ <i>F H</i> Hz	0.0~100.0%						
		Function	V/f 5-point setting VF1 frequency	V/f 5-point setting VF1 voltage	V/f 5-point setting VF2 frequency	V/f 5-point setting VF2 voltage	V/f 5-point setting VF3 frequency	V/f 5-point setting VF3 voltage	V/f 5-point setting VF4 frequency	V/f 5-point setting VF4 voltage	V/f 5-point setting VF5 frequency	V/f 5-point setting VF5 voltage
[5] V/f 5-point setting	Commini	cation No.	0190	0191	0192	0193	0194	0195	0196	0197	0198	0199
[5] V/f 5-p		Title	6813	. 6; u	2813	E51 4	h61 d	F 195	981 3	1814	8613	£ 133

٠		_	1			<u> </u>		Γ						
Sensorless vector/vector with sensor (.Effective, -:Ineffective)		Reference	6.6.1	7.3.2	7.3.2	7.3.2	5. 11	*2	*2	6.6.1	6.6.1	7.2.4	7.3.1	7.3.1
ffective,		V/f	•	•	•	•	•	-	-	•	•	•	•	•
ensor (∙:E		PM	•	•	•	•	•		-	•	•	•	•	•
ector with s	Vector control	Torque control		•/•	-	•/•		•/•	•/•	-		•/•	•/•	
ss vector/ve	Vector	Speed	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
Sensorle	Write during	running	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Disabled	Enabled	Enabled	Enabled	Fnabled
		Default setting	0	0	0.0	100	l*	0	100	1	0.1	0	0	0.0
	Minimum	setting unit (Panel/Communi cation)	1/1	1/1	0.1/0.01	1/1	0.1/0.01	1/0.01	1/0.01	1/1	0.1/0.01	1/1	1/1	0.1/0.01
		Adjustment range	0.F fl B d l F 2 B 7 terminal switching (input terminal function selection 104, 105) 1.F fl fl d l F 2 B 7 trequency switching (switching with F 2 B B)	0~100%	0.0∼ <i>F H Hz</i>	0~100%	0.0∼ <i>F H</i> Hz	0~250% (for torque control etc.)	0~250% (for torque control etc.)	Same as <i>F II IJ d</i> (1~13)	0.1~ <i>F H</i> Hz	0:No filter 1:Filter approx. 10ms 2:Filter approx. 15ms 3:Filter approx. 30ms 4:Filter approx. 60ms	0~100%	0.0 ≥ F W Hz
[6] Speed/torque reference gain/bias setup [1/2]		Function	Frequency priority selection	VI/II input point 1 setting	VI/II input point 1 frequency	VI/II input point 2 setting	VI/II input point 2 frequency	VI/II input point 1 rate	VI/II input point 2 rate	Frequency setting mode selection 2	Speed command priority switching frequency	Analog input filter	RR/S4 input point 1 setting	RR/S4 input point 1 frequency
torque refe	Commini	cation No.	0200	0201	0202	0203	0204	0202	0206	0207	0208	0209	0210	0211
[6] Speed,		Title	6653	1021	F 202	F203	8 152	F205	F 205	1023	8023	£203	F 2 10	1100
		ı	•										_	

[|] F-c i i | u211 | RR/54 input point 1 frequency | 0.0-F /H Hz | This parameter moves to a fundamental parameter | This parameter moves | This parameter move

K-8

	П		П	
y	1	J	4	

_																											_
Sensorless vector/vector with sensor (•:Effective, -:Ineffective)		Reference	7.3.1	5. 11	*1	*1	7.3.3	7.3.3	7.3.3	7.3.3	*	*1	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	£*	£*	£*	£*	
fective,		V/f	•	•			•	•	•	•			•	•	•	•			•	•	•	•	•	•	•	•	
ınsor (∙:Ei		PM	•	•			•	•	•	•			•	•	•	•			•	•	•	•	•	•	•	•	
ctor with se	control	Torque	•/•		•/•	•/•	•/•		•/•		•/•	•/•	•/•		•/•		•/•	•/•	•/•		•/•		1	-	1	-	
ss vector/ve	Vector control	Speed	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	
Sensorles		Default Write during setting running	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	
		Default setting	100	*4	0	100	0	0.0	100	*4	0	100	0	0.0	100	*4	0	100	0	0.0	100	*4	0	0.0	100	*4	
	Minimum	setting unit (Panel/Communi cation)	1/1	0.1/0.01	1/0.01	1/0.01	1/1	0.1/0.01	1/1	0.1/0.01	1/0.01	1/0.01	1/1	0.1/0.01	1/1	0.1/0.01	1/0.01	1/0.01	1/1	0.1/0.01	1/1	0.1/0.01	1/1	0.1/0.01	1/1	0.1/0.01	
		Adjustment range	0~100%	0.0∼F # Hz	0~250% (for torque control etc.)	0~250% (for torque control etc.)	-100~100%	2.0.0 ⊬ H Hz	-100~100%	0.0∼ <i>F H</i> Hz	-250~250% (for torque control etc.)	-250~250% (for torque control etc.)	-100~100%	0.0∼F # Hz	-100-100%	0.0∼ <i>F H</i> Hz	-250~250% (for torque control etc.)	-250~250% (for torque control etc.)	0~100%	0.0∼F ⅓ Hz	0~100%	0.0∼ <i>F H</i> Hz	0~100%	0.0∼ <i>F H</i> Hz	0~100%	0.0∼ <i>F H</i> Hz	pr
ference gain/bias setup [2/2]		Function	RR/S4 input point 2 setting	RR/S4 input point 2 frequency	RR/S4 input point 1 rate	RR/S4 input point 2 rate	RX input point 1 setting	RX input point 1 frequency	RX input point 2 setting	RX input point 2 frequency	RX input point 1 rate		AI1 input point 1 setting	Al1 input point 1 frequency	Al1 input point 2 setting	Al1 input point 2 frequency	Al1 input point 1 rate	Al1 input point 2 rate	AI2 input point 1 setting	AI2 input point 1 frequency	AI2 input point 2 setting	AI2 input point 2 frequency	RP/high speed pulse input point 1 setting	RP/high speed pulse input point 1 frequency	RP/high speed pulse input point 0~100% 2 setting	RP/high speed pulse input point $\begin{vmatrix} 0.0 \sim F \ H \ A \end{vmatrix}$	moves to a fundamental parameter
[6] Speed/torque reference ga	Commini	cation No.	0212	0213	0214	0215	0216	0217	0218	0219	0220	0221	0222	0223	0224	0225	0226	0227	0228	0229	0230	0231	0234	0235	0236	0237	This parameter moves to
(e] Speec		Title	51 2 J	BURG	F0 14	E5 12	81 Z J	6721	B1 23	6121	6223	1551	5523	F 2 2 3	トララメ	6523	F225	6227	6523	6523	F230	1623	h € ∂ 3	5 E Z 3	5E23	1653	This

Sensorless vector/vector with sensor (e:Effective, -:Ineffective) Reference 6.7.2 6.7.2 6.7.1 6.7.1 6.7. * • • control Μ Torque control Vector control Speed •/ • Enabled Enabled Write during Enabled Enabled Enabled running setting Default 0.0 0.0 0.0 setting unit (Panel/Communi 0.1/0.01 0.1/0.01 0.1/0.01 0.1/0.01 Minimum cation) Adjustment range 0.0~F H Hz 0.0~30.0Hz 0.0~30.0Hz 0.0~5.0Hz Frequency command dead band Operation start frequency hysteresis Starting frequency setting Operation start frequency Stop frequency setting Function [7] Operation frequency Communi cation 0240 0242 0243 0244 <u>.</u> 5454 F243 F244 Title

[8] DC braking	raking					Sensorles	ss vector/ve	ctor with se	ensor (∙:E	ffective,	Sensorless vector/vector with sensor (e:Effective, -:Ineffective)
	Communi			Minimum			Vector control	control	i		
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed	Torque control	control	V/f	Reference
6523	0250	DC braking start frequency	0.0~120.0Hz	0.1/0.01	0.0	Enabled	•/•		•	•	6.8.1
F251	0251	DC braking current	0~100%	1/1	20	Enabled	•/•	-	•	•	6.8.1
F252	0252	DC braking time	0.0~20.0 sec.	0.1/0.1	1.0	Enabled	•/•		•	•	6.8.1
E523	0253	Forward/reverse DC braking priority control	0:Disabled, 1:Enabled	1/1	0	Enabled	•/•	-	•	•	6.8.1
F254	0254	Motor shaft fixing control	0:Disabled, 1:Enabled	1/1	0	Enabled	•/•		•	•	6.8.2
F 255	0255	0Hz command output selection	0:Default (DC braking) 1:0Hz command	1/1	0	Enabled	-/•				6.8.3
F 258	0256	Time limit for lower-limit frequency operation	0.0:Disabled 0.1~600.0 sec.	0.1/0.1	0.0	Enabled	•/•	•/•	•	•	6.9
iggol [6]	[9] Jogging operation	c				Sensorles	ss vector/ve	ctor with se	ensor (∙:E	ffective,	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)
	Communi			Minimum			Vector control	control	i		
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed	Torque control	PM	V/f	Reference
F250	0560	Jog run frequency	F ご 4 🗓 ~20.0Hz	0.1/0.01	2.0	Enabled	•/•	-	•	•	6. 10
F281	0261	Jog run stop pattern	0:Deceleration stop 1:Coast stop 2:DC braking stop	1/1	0	Disabled	•/•	-	•	•	6. 10
F 2 B 2	0262	Operation panel jog run mode	0:Disabled 1:Operation panel jog run mode enabled	1/1	0	Enabled	•/•	-	•	•	6. 10
4353	0264	Input from external contacts - UP response time	0.0~10.0 sec.	0.1/0.1	0.1	Enabled	•/•		•	•	6. 11
F 2 5 5	0265	Input from external contacts - UP frequency step	0.0~ <i>F H</i> Hz	0.1/0.01	0.1	Enabled	•/•		•	•	6. 11
F 255	0266	Input from external contacts - DOWN response time	0.0~10.0 sec.	0.1/0.1	0.1	Enabled	•/•	-	•	•	6. 11
F267	0267	Input from external contacts - DOWN frequency step	0.0~ <i>F H</i> Hz	0.1/0.01	0.1	Enabled	•/•	,	•	•	6. 11
8923	0268	Initial UP/DOWN frequency	7.7 ~ <i>1</i> .7 Hz	0.1/0.01	0.0	Enabled	•/•	-	•	•	6. 11
F259	0269	Initial up/down frequency rewriting	0:Not changed 1:Setting of F 2 5 8 changed when power is turned off	1/1	1	Enabled	•/•	-	•	•	6. 11
[10] Jum	[10] Jump frequency					Sensorles	ss vector/ve	ctor with se	ensor (∙:E	ffective,	Sensorless vector/vector with sensor (•: Effective, -: Ineffective)
	Communi			Minimum			Vector control	control	i		
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed	Torque control	control	V/f	Reference
F270	0270	Jump frequency 1	0.0~F <i>H</i> Hz	0.1/0.01	0.0	Enabled	•/•	-	•	•	6. 12
F271	0271	Jumping width 1	0.0~30.0Hz	0.1/0.01	0.0	Enabled	•/•	-	•	•	6. 12
5070	0272	Jump frequency 2	0.0∼ <i>F H</i> Hz	0.1/0.01	0.0	Enabled	•/•		•	•	6. 12
7 (-)	0273	Jumping width 2	0.0~30.0Hz	0.1/0.01	0.0	Enabled	•/•		•	•	6. 12
	0274	Jump frequency 3	0.0∼ F H Hz	0.1/0.01	0.0	Enabled	•		•	•	6. 12
7 ()	0275	Jumping width 3	0.0~30.0Hz	0.1/0.01	0.0	Enabled	•/•		•	•	6. 12

	e e									(e)		e e			2	L		2
	Reference	5. 12	5. 12	5. 12	5. 12	5. 12	5. 12	5. 12	5. 12	-:Ineffectiv		Reference	5.17	5. 18.1	5. 18. 2	6.14.1	5. 19	
	V/f	•	•	•	•	•	•	•	•	ffective,		\/\	•	•	•	•	•	•
	PM control	•	•	•	•	•	•	•	•	ensor (∙:E		control	•	•	•	•	•	•
ontrol	Torque control	-	-	-						ctor with se	control	Torque control	•/•	•/•	-/-	•/•	•/•	•/•
Vector control	Speed	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)	Vector control	Speed	•/•	•/•	*	•/•	•/•	•/•
Write during	running	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Sensorles		Write during running	Enabled	Disabled	Disabled	Enabled	Disabled	Disabled
	Default setting	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0			Default setting	*2	0	0	0	0	2
Minimum	setting unit (Panel/Communi cation)	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01	0.1/0.01		Minimum	setting unit (Panel/Communi cation)	0.1/0.1	1/1	1/1	1/1	1/1	1/1
	Adjustment range	רו <i>-חו</i> Hz	רו <i>-חו</i> Hz	רו <i>-חו</i> Hz	רך- <i>ח</i> ך Hz	רך- <i>ח</i> ך Hz	רך- <i>ח</i> ך Hz	77 ~77 HZ	7 - 17 Hz			Adjustment range	1.0~16.0kHz (2.5~8.0kHz) *1	0:Disabled, 1:At auto-restart 2:ST ON/OFF switching, 3:1+2, 4:Starting	O:Disabled, 1:Power ride-through Sucederation stop during power failure Synchronized deceleration/acceleration (synchronized acceleration/deceleration signal) Synchronized deceleration/deceleration (synchronized deceleration/acceleration ignathonized acceleration/deceleration ignathonized acceleration/deceleration ignathonized acceleration/deceleration	0:Deselect, 1-10 times	0:Disabled 1:Enabled (braking resistance overload detect) 2:Enabled (braking resistance overload not detect)	O:Enabled 1.0 Disabled 2. Enabled (quick deceleration) 3. Enabled (dynamic quick deceleration) 3. Enabled (dynamic quick deceleration) 4. O Disabled 4. O Disabled 5. Tabled (dynamic quick deceleration) 5. Enabled (dynamic quick deceleration) 5. Tabled (dynamic quick deceleration) 6. Tabled (dynamic quick deceleration) 7. Tabled
Communi	Function	Preset speed operation frequency 8	Preset speed operation frequency 9	Preset speed operation frequency 10	Preset speed operation frequency 11	Preset speed operation frequency 12	Preset speed operation frequency 13	Preset speed operation frequency 14	Preset speed operation frequency 15 (Forced operation frequency)	12] Tripless intensification setup [1/2]		Function	PWM carrier frequency	Auto-restart control selection	Regenerative power ride-through control	Retry selection	Dynamic braking selection	7.5 0305 Overvoltage limit operation 21:
Communi	cation No.	0287	0288	0289	0530	0291	0292	0293	0294	less intens	Commin	cation No.	0300	0301	0302	0303	0304	0305
	Title	1823	£288	6823	F290	1623	5623	F533	F 2 9 4	[12] Tripl		Title	13	800	unc	F303	P.b	F 3 0 5

[12]	Tripless i	intensifica	ation setup [2/2]				Sensorless	vector/	vector with se	ensor (∙:El	fective,	-:Ineffective)	
Title	CO S	mmuni ation	Function	Adjustment range	Minimum setting unit (Panel/Communi	Default '	Write during running	Vector	control	PM	\/\	Reference	
	_				cation)))	control	control				

				Minimum				Vector control			
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed	Torque control	PM	\/ /	Reference
1883	0307	Base frequency voltage selection (correction of supply voltage)	O:Without voltage compensation (limitless output voltage) 1:With voltage compensation (limitless output voltage) 2:Without voltage compensation (limited output voltage) 3:With voltage compensation (limited output voltage)	1/1	0	Disabled		Parameter is changeable, but fixed to "with voltage compensation" intermally. When £ 3\bar{2}7 is set to 0 or 1, fixed at 1 intermally. When £ 3\bar{2}7 is set to 2 or 3, fixed at 3 intermally.	out fixed to n" internally. r 1, fixed at r 3, fixed at	•	6. 14. 3
799	0308	Dynamic braking resistance	0.5~1000Ω	0.1/0.1	*	Disabled	•/•	•/•	•	•	5. 19
6396	0309		0.01~600.0kW	0.01/0.01	*1	Disabled	•/•	•/•	•	•	5. 19
63 18	0310	Non-stop control time/deceleration time during power failure	0.1~320.0 sec.	0.1/0.1	2.0	Enabled *3/ Disabled	•/•	-/-	•	•	5. 18. 2
1183	0311	Reverse-run prohibition selection	0:Permit all, 1:Prohibit reverse run 2:Prohibit forward run	1/1	0	Disabled	•/•	•/•	•	•	6. 14. 4
F3 12	0312	Random mode	0:Disabled, 1:Enabled	1/1	0	Disabled	•/•	•/•	•	•	5. 17
E1 E3	0313	Output voltage waveform selection *4	0:PWM carrier frequency control 1 1:PWM carrier frequency control 2	1/1	0	Disabled	•/•	•/•	•	•	6. 14. 5
818	0316	Carrier frequency control mode selection	O'Not decrease carrier frequency automatically L'boerseas carrier frequency automatically 2.Not decrease carrier frequency automatically, 400V class supported 2.Subcrease carrier frequency automatically, 400V class supported 2.Not decrease carrier frequency automatically, 400V class supported 4.Not decrease carrier frequency automatically, with sinusoidal filter 5.Decrease carrier frequency automatically, with sinusoidal filter 5.Decrease carrier frequency automatically, with sinusoidal filter	1/1	-	Disabled	•/•	•/•	•	•	5. 17
F3 17	0317	Synchronized deceleration time (time elapsed between start of deceleration to stop)	0.1~6000 sec.	0.1/0.1 *2	2.0	Enabled	•/•	-/-	•	•	5. 18. 2
8183	0318	Synchronized acceleration time (time elapsed between start of acceleration to achievement of specified speed)	0.1~6000 sec.	0.1/0.1 *2	2.0	Enabled	•/•	-/-	•	•	5. 18. 2
61 63	0319	Regenerative over-excitation upper limit	100~160%	1/1	140	Disabled	•/•	•/•		•	6. 14. 2
*2. Changi	s parameter	moves to a fundamental paramet	This parameter moves to a fundamental parameter. *1: Default values vary depending on the capacity. ⇒ See the table of K-46.	ity. ⇒ See the	table of K	-46.					

2. Changing the parameter £ yP enables to set to 0.01 sec. (adjustment range: 0.01-600.0 sec.).
 3. Although the setting can be written into memory if U L is set to 1 (power ride-through control), it cannot be written if U L is set to 2 (deceleration stop during a power failure).
 4: F ∃ 1 ∃ is available for VFAS1-2550p, VFAS1-4900PC and above.
 (13) Drooping control

[13] Dro	oping contro	[13] Drooping control				Sensorles	ss vector/ve	ctor with se	ensor (∙:Ef	fective, -	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)
	Commini			Minimum			Vector control				
Title	cation No.	Function	Adjustment range	setting unit Default Write during (Panel/Communi setting running cation)	Default Netting		Speed Torque control		PM	//	rol V/f Reference
F 320	0320	Drooping gain	0.0~100.0% (Enabled if P £ =3, 4, 7 or 8)	0.1/0.1	0.0	Enabled *1	•/•				6. 15
1 2E 1	0321	Speed at drooping gain 0%	0.0~320.0Hz (Enabled if P \(\nabla = 3, 4, 7 \text{ or 8} \)	0.1/0.01	0.0	Enabled	•/•				6. 15
F 322	0322	Speed at drooping gain F 3 2 0	drooping gain F ∄ ♂ 🗗 0.0~320.0Hz (Enabled if P ≿ =3, 4, 7 or 8)	0.1/0.01	0.0	Enabled	•/•	-			6.15
F 353	0323	Drooping insensitive torque	ig insensitive torque $0\sim100\%$ (Enabled if $PL=3$, 4, 7 or 8)	1/1	10	Enabled	•/•	-			6.15
				, 00							

ve)		9																			
-:Ineffecti		Reference	6.15	*	*	*	٠,	*	*	*	٠,	*1	*	*	6.17	6. 17	6. 17	6. 17	6.17	6. 17	6. 17
ffective,		\/\	-	•		•	•	•	•	•	•	•	•	•	-			٠			
ensor (∙:E	Md	control		•		•	•	•	•	•	•	•	•	•		-	1	-			
ctor with s	control	Torque control		1												,	1	-		·	
Sensorless vector/vector with sensor (•:Effective, -:Ineffective)	Vector control	Speed control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	<u>.</u>
Sensorles	Write during	running	Enabled	Disabled	Disabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Disabled	Enabled	Enabled	Enabled	Enabled	Disabled
	Default	setting	100.0	0	0	*2	40.0	0.5	1.0	0.5	90	100	92	20	0	0	4	100	100	0.05	3.0
	Minimum	(Panel/Communi cation)	0.1/0.1	1/1	1/1	0.1/0.01	0.1/0.01	0.1/0.1	0.1/0.1	0.1/0.1	1/0.01	1/0.01	1/0.01	1/0.01	0.01/0.01	1/1	1/1	1/0.01	1/0.01	0.01/0.01	0.1/0.01
		Adjustment range	$0.1 \sim 200.0 \text{ rad/s (Enabled if } PL = 3, 4, 7 \text{ or 8)}$	O'Disabled Hitligh-speed operation speed set automatically (Power running at F command: Increase) 2.High-speed operation speed set automatically (Power running at R command: Increase) 3.High-speed operation speed set with £ 330 (Power running at F command: Increase) 4.High-speed operation speed set with £ 330 (Power running at R command: Increase)	0:No learning, 1:Forward run learning 2:Reverse run learning	30.0∼ <i>U</i> Ł Hz	2.0∼ <i>U.L.</i> Hz	0.0~10.0 sec.	0.0~10.0 sec.	0.0~10.0 sec.	-250~250%	-250~250%	-250-250%	-250~250%	0.00~2.50 sec.	0: Disabled, 1:Forward winding up 2:Reverse winding up, 3:Horizontal operation	O'Disabled 1:V/III (voltage/current input) 2.RR/54 (potentiometer/voltage input) 3.RX (voltage input) 4.F 3 4' gatabled 5.2-wire R5485 communication input 6.4-wire R5485 communication input 7.Communications option input enabled 8.Optional A1I (differential current input)	-250~250%	0~100%	0.00~2.50 sec.	アンタパ~20.0 Hz
t [1/2]		Function	Drooping output filter	Light-load high-speed operation selection	Light-load high-speed learning function	Automatic light-load high-speed operation frequency	Light-load high-speed operation switching lower limit frequency	Light-load high-speed operation load waiting time	Light-load high-speed operation load detection time	Light-load high-speed operation heavy load detection time	Switching load torque during power running	Heavy-load torque during power running	Heavy-load torque during constant power running	Switching load torque during regenerative braking	Creeping time 1	Braking mode selection	Load portion torque input selection	Hoisting torque bias input (valid only when $\vec{F} \vec{3} \vec{4} \vec{c} = \vec{4}$)	Lowering torque bias multiplier	Brake release time	Creeping frequency
[14] Functions for lift [1/2]	Communi	cation No.	0324	0328	0329	0330	0331	0332	0333	0334	0335	0336	0337	0338	0340	0341	0342	0343	0344	0345	0346
[14] Fun		Title	435 H	F 3 2 B	F329	533B	1 EE 3	5883	F 3 3 3	4883	5 E E 3	F335	F 337	8883	634B	1 483	5342	E h E J	44E3	F345	575

_								
Sensorless vector/vector with sensor (•:Effective, -:Ineffective)		Reference	6. 17	6. 18	6. 18	6. 18	6. 18	6. 18
fective,		V/f		•	•	•	•	•
ensor (∙:Ef		PM		•	•	•	•	•
ctor with se	control	Torque control		-	-	-		
ss vector/ve	Vector control	Speed control	•/•	•/•	•/•	•/•	•/•	•/•
Sensorles		Default Write during setting running	0 Enabled	0 Disabled	Enabled	Enabled	0.0 Enabled	Enabled
		Default setting	0	0	0.0	0.0	0.0	0.0
	Minimum	setting unit (Panel/Communi cation)	1/1	1/1	0.1/0.01	0.1/0.1	0.1/0.01	0.1/0.1 0.0 Enabled
		Adjustment range	O:Disabled 1:Brake signal learning (0 after adjustment)	0:Disabled, 1:Parameter setting, 2:Terminal input	ZH <i>H J∼</i> 0′0	0.0~10.0 sec.	0.0∼ <i>F H</i> Hz	0.0~10.0 sec.
t [2/2]		Function	Braking time learning function	Acceleration/deceleration suspend function	Acceleration suspend frequency 0.0~F H Hz	Acceleration suspend time	Deceleration suspend frequency	Deceleration suspend time
14] Functions for lift [2/2]	Commini	cation No.	0348	0349	0320	0351	0352	0353
[14] Func		Title	8483	6483	F350	15E1	F355	F353

[15] Con	[15] Commercial/inverter swi	erter switching function				Sensorles	ss vector/ve	ctor with se	ensor (∙:Ef	fective, .	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)
	Commini			Minimum			Vector control	control			
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Default Write during setting running	Speed Torque control	Torque	PM	V/f	Reference
4 3 E 3	0354	Commercial power/inverter switching output selection	0:Disabled 1:Automatic switching in the event of a trip 2:Commercial power switching frequency setting 3:Commercial power switching frequency setting + automatic switching in the event of a trip	1/1	0	Disabled	•/•	•/•	•	•	6. 19
5 5 E 3	0355	Commercial power/inverter switching frequency	zH 7 <i>n-</i> 0	0.1/0.01		Enabled	•/•	•/•	•	•	6. 19
8 S E 3	9320	Inverter-side switching waiting 0.10~10.00 sec. time	0.10~10.00 sec.	0.01/0.01	*1	Enabled	•/•	•/•	•	•	6. 19
£ 3E 3	0357	Commercial power-side switching waiting time	0.40~10.00 sec.	0.01/0.01	0.62	Enabled	•/•	•/•	•	•	6. 19
F358	0358	Commercial power switching	0.10~10.00 sec.	0.01/0.01 2.00 Enabled	2.00	Enabled	•/•	•/•	•	•	6. 19

*7: Default values vary depending on the capacity. ⇒ See the table of K-46. *2: Inverter with a model number ending with -WN, HN: 60.0 -WP: 50.0

[16] PID control [1/2]

Sensorless vector/vector with sensor (•: Effective, -: Ineffective)

	Commini			Minimum			Vector control				
Title	cation No.	Function	Adjustment range	setting unit Default Write during (Panel/Communi setting running cation)	Default Netting	Write during running	Speed Torque control	Torque control	PM	V/f	Reference
6353	0359	PID control switching	0:No PID control Throcess type PID control (temp./pressure, etc.) operation 2:Speed type PID control (potentiometer, etc.) operation 3:Stop retaining P control 4.Dancer control	1/1	0	Disabled	•/•	,	•	•	*1, *2
*1: → For	⇒ For details, refer to Inst	! ⊱	uction Manual (F6581319) specified in Section 6.42 **2: \Rightarrow For details, refer to Instruction Manual (F6581329) specified in Section 6.42	to Instruction	Manual (F6	3581329)	S ni beilipen	Section 6.4	.2.		

neffective)	Reference	*1, *2	*2	*1, *2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2	*2
fective, -: In	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ensor (∙:Eff	PM	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Sensorless vector/vector with sensor (•:Effective, -:Ineffective)	control Torque control	1		-						-			-	ı	
ss vector/ve	Speed Torque control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
Sensorles	Default Write during setting running	Disabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled
	Default setting	0	0.1	01.0	0.10	0.09	0.09	00'0	0.09	0.0	0	0.09	0.0	10.0	10.0 Enabled
	Minimum setting unit (Panel/Communi cation)	1/1	1/1	0.01/0.01	0.01/0.01	0.1/0.01	0.1/0.01	0.01/0.01	0.1/0.01	0.1/0.01	1/1	0.1/0.01	0.1/0.01	0.1/0.1	0.1/0.1
	Adjustment range	O:Deviation input (no feedback input) 1.7.///////////////////////////////////	0.0~25.0	0.01~100.0	0.01~100.0	zH 7 <i>[</i>]~7.7	zH 7 <i>n~</i> 7 7	0.00~2.55	zH 7 <i>[</i>]~7.7	zH 7 <i>∏~</i> 7.7	0~2400 sec.	zH 7 <i>[</i>]~7.7	ZH 7 <i>∏~</i> 7.7	0.1~600.0	0.1~600.0
£	Function	PID control feedback control signal selection	Delay filter	Proportional (P) gain	Integral (I) gain	PID deviation upper limit	PID deviation lower limit	Differential (D) gain	Process upper limit	Process lower limit	PID control waiting time	PID output upper limit	PID output lower limit	Process increasing rate (speed type 0.1~600.0 PID control)	Process decreasing rate (speed 10.1~600.C type PID control)
[16] PID control [2/2]	Communi cation No.	0360	0361	0362	0363	0364	0365	9980	0367	0368	6980	0320	0371	0372	0373
[16] PID	Title	8 3 8 0	13E 1	F 38 2	F 3E 3	4 3E 4	5 3E 3	53E3	£ 3E 1	F 35 8	£3£3	01E 4	118	51E3	E1E3

*2: ⇒ For details, refer to Instruction Manual (E6581329) specified in Section 6.42. *1: ⇒ For details, refer to Instruction Manual (E6581319) specified in Section 6.42.

[17] Spe	ed feedbaci	[17] Speed feedback/positioning control				Sensorles	ss vector/ve	ector with se	ensor (∙:Ef	ffective,	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)
	Commin			Minimum		-	Vector control	control			
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	running	Speed Torque control	Torque	PM control	V/f	Reference
F375	0375	Numb	12~9999	1/1	200	Disabled	•/-	•/-		-	*1
3183	Selection phases	Selection of number of PG input 2:Two-phase input 2:Two-phase input 3:Two-phase input (Ir	1:Single-phase input 2:Two-phase input 3:Two-phase input (Inversion of polarity)	1/1	2	Disabled -/•	•/-	•/-	1	-	*
11E3		0377 PG disconnection detection	0:Disabled 1:Enabled (with filter) 2:Enabled (Detection of momentary power failure)	1/1	0	Disabled -/•	•/-	•/-	i		*
8183	0378	Number of RP terminal input oulses	12~9999	1/1	200	Disabled	•/•	•/•	•	•	*2
6181	0379	PID output dead band	0~100%	1/1	0	Enabled	•/•	•/•	•	•	*3
1863	0381	Simple positioning completion range	1~4000	1/1	100 Enabled	Enabled	•/-	-	1	-	٠,

[&]quot;: \Rightarrow For details, refer to Instruction Manual (E6881319) specified in Section 6.42. "2: \Rightarrow For details, refer to Instruction Manual (E6881329) specified in Section 6.42. "3: \Rightarrow For details, refer to Instruction Manual (E6881329) specified in Section 6.42.

[18] Moto	[18] Motor constant					Sensorles	s vector/ve	Sensorless vector/vector with sensor (•: Effective, -: Ineffective)	ensor (∙:E	ffective, -	Ineffective)
	Commun	· -		Minimum	, thinefor	edinib otial Ministra	Vector control	control	DM		
Title	cation No.	Function	Adjustment range	Setting unit (Panel/Communi cation)	setting	running	Speed	Torque	control	Vf Constant	MfConstant Reference
			0:No auto-tuning 1:Initialize motor constant (0 after execution) 2:Continue operation continued after auto-tuning (0								
0054	0400	Auto-tuning 1	after execution)	1/1	0	Disabled	•	•/•			6. 22
)	3.Auto-tuning by input terminal signal 4:Motor constant auto calculation (0 after								
			execution)								
1054	0401	Slip frequency gain	0~150%	1/1	20	Enabled	-/•				6. 22
			0:Disabled								
50h4	0402	Auto-tuning 2	1:Self-cooled motor 2:Forced air-cooled motor	1/1	0	Disabled	•	•/•			6. 22
5043	0405	Motor rated capacity (motor name plate)	0.10~630.0kW	0.01/0.01	*	Disabled	•/•	•/•			6. 22
8043	0406	Motor rated current (motor name plate)	0.1~2000A	0.1/0.1	*1	Disabled	•/•	•/•			6. 22
604	0407	Motor rated rotational speed (motor name plate)	100~60000min-1 *2	1/1	*1	Disabled	•/•	•/•			6. 22
01 64	0410	Motor constant 1 (torque boost)	0.0~30.0%	0.1/0.1	*1	Enabled	•/•	•/•			6. 22
11143	0411	Motor constant 2 (no load current)	10~90%	1/1	*1	Disabled	•/•	•/•		-	6. 22
21 43	0412	Motor constant 3 (leak inductance)	0~200(×0.1%)	1/1	*1	Disabled	•/•	•/•			6. 22
E1 hd	0413	Motor constant 4 (rated slip)	0.1~25.0%	0.1/0.1	*1	Disabled	•/•	•/•		-	6. 22
51 h d	0415	Exciting strengthening coefficient	100~130%	1/1	100	Disabled	•/•	•/•		-	6. 23
91 64	0416	Stall prevention factor	10~250	1/1	100	Disabled	•/•	•/•			6. 23
*1. Default	values var	*1. Default values vary depending on the capacity -> See the table of K-46	the table of K-46								

[19] Torque control [1/2]

Sensorless vector/vector with sensor (•: Effective, -: Ineffective) Reference 6.24.3 <u>*</u> V/F Constant PM control Torque control • · : /ector contr Speed control Enabled Enabled Enabled Write during running Default setting 3 0 0 setting unit (Panel/Communi Minimum cation) 7 7 7 4:Operation panel input enabled (including LED/LCD option input)
5:2-wire RS485 communication input 6:4-wire RS485 communication input 7:Communications option input applications option input applications option input an 2:RR/S4 (potentiometer/voltage input) 3:RX (voltage input) 0:Disabled, 1~8 (same as F Կ근립) Adjustment range :VI/II (voltage/current input) $F \not+ Q \not> 3$ Tension torque bias input
selection (torque control)0:Disabled, 1-8 (same as
1:E > For details, refer to Instruction Manual (E6581331) specified in Section 6.42. 0~1000ms Torque command selection Torque reference filter Function Communi cation 0420 0421 ģ 8420 1243 Title

	Ī		Ī
 J	И	J	4

	[19] Torque control [2/2]	2/2]				Sensorles	ss vector/ve	ctor with s	ensor (•:E	ffective,	Sensorless vector/vector with sensor (•: Effective, -: Ineffective)
Comm	ini			Minimum			Vector control	control	i		
cation No.	_	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed	Torque control	control	V/f Constant	WfConstart Reference
0424	4	Load sharing gain input selection	0.Disabled, 1~8 (same as $F \Psi_c \mathcal{D}$)	1/1	0	Enabled		•/•	٠		6. 24. 3
0425		Forward speed limit input selection	O:Disabled 1:V/I/I (voltage/current input) 2:RR/S4 (potentiometer/voltage input) 3:RX (voltage input) 4:F 4 Z E enabled	1/1	0	Enabled		•/•		,	*
04	0426	Forward speed limit input level	0.0~ <i>U.</i> L Hz	0.1/0.01	*2	Enabled		•/•			٠,
90	0427	Reverse speed limit input selection	0:Disabled 1:VIII (voltage/current input) 2:RX/S4 (potentiometer/voltage input) 3:RX (voltage input) 4:주 낙구용 enabled	1/1	0	Enabled		•/•	ı	,	*
04	0428	Reverse speed limit input level	ZH 7 <i>∏</i> ~0:0	0.1/0.01	*2	Enabled		•/•			٠,
90	0430	Speed limit (torque = 0) center value reference selection	0: Disabled 11: VIII (voltage/current input) 2: RKN/S4 (potentiometer/voltage input) 3: RX (voltage input) 4: F 4 3 1' enabled	1/1	0	Enabled	1	•/•	ı	i	*
70	0431	Speed limit (torque = 0) center value	0.0∼ <i>F H Hz</i>	0.1/0.01	0.0	Enabled		•/•	٠	-	١.
04	0432	Speed limit (torque = 0) band	0.0∼F # Hz	0.1/0.01	0.0	Enabled		•/•			*1
04	0435	Prohibition of rotation in any direction other than the specified one (F or R)	0: Disabled 1:Enabled	1/1	0	Enabled		•/•	•	•	١.
etails	⇒ For details, refer	to Instru	ction Manual (E6581331) specified in Section 6.42. *2: Inverter with a model number ending with	idel number en	ding with	-WN, HN: 60.0	60.0 -WF	-WP: 50.0	g.•) acade	e, it of it.	-WN, HN: 60.0 -WP: 50.0
<u> </u>	7/1			100		Selisolies	os vectorive	CIOI WILL S	1.001101	- וופכוואפי	III cili coti ve)
Cog	Communi cation No.	Function	Adjustment range	Minimum setting unit (Panel/Communi cation)	Default setting	Write during running	Speed Torque control	Torque control	PM	V/f Constant	WfConstant Reference
l	ĺ		1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1		Ī	I	Ī			l	

	WitConstant Reference	- 6. 25. 1	- 6. 25. 1	- 6. 25. 1	- 6. 25. 1	- 6. 25. 1
	PM control	•	•	•	•	•
Vector control	Torque control	•/•	•/•	•/•	•/•	•/•
Vector	Speed	•/•	•/•	•/•	•/•	•/•
	Default Write during setting running	Enabled	250.0 Enabled	Enabled	250.0 Enabled	250.0 Enabled
	Default setting	4	250.0	4	250.0	250.0
Minimum	setting unit (Panel/Communi cation)	1/1	0.1/0.01	1/1	0.1/0.01	0.1/0.01
	Adjustment range	1:VIVII (voltage/current input) TRRVS4 (potentiometer/voltage input) 3:RX (voltage input) 4:F 4 4 1	0.0~249.9%, 250.0:Disabled	1:VIVII (voltage/current input) STRNS4 (potentiometer/voltage input) 3:RX (voltage input) 4:F 4 4 3	0.0~249.9%, 250.0:Disabled	0.0~249.9%, 250.0:Disabled
	Function	Power running torque limit 1 selection	Power running torque limit 1 level	Regenerative braking torque limit 1 selection	Regenerative braking torque limit 1 level	Power running torque limit 2
Commini	cation No.	0440	0441	0442	0443	0444
Commini	Title	Ohhd	1 443	2443	Ehhj	hhhj

[20] Torque limit [2/2]			Minimum		Sensorles	s vector/vector w	ctor with s	ensor (∙:E	ffective, -	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)
Communi cation No.	c	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed	Torque	PM control	VifConstart	Reference
0445 Regenerative braking torque limit 2 level	Ф	0.0~249.9%, 250.0:Disabled	0.1/0.01	250.0	Enabled	•/•	•/•	•		6. 25. 1
0446 Power running torque limit 3		0.0~249.9%, 250.0:Disabled	0.1/0.01	250.0	Enabled	•/•	•/•	•		6. 25. 1
0447 Regenerative braking torque limit 3 level	l	0.0~249.9%, 250.0:Disabled	0.1/0.01	250.0	Enabled	•/•	•/•	•		6. 25. 1
0448 Power running torque limit 4 level		0.0~249.9%, 250.0:Disabled	0.1/0.01	250.0	Enabled	•/•	•/•	•	-	6. 25. 1
0449 Regenerative braking torque limit 4 level		0.0~249.9%, 250.0:Disabled	0.1/0.01	250.0	Enabled	•/•	•/•	•	-	6. 25. 1
Acceleration/deceleration operation after torque limit		0:In sync with acceleration/deceleration 1:In sync with min. time	1/1	0	Disabled	•/•	-	•		6. 25. 2
0452 Power running stall continuous trip detection time		0.0~1.0 sec.	0.1/0.1	0.0	Enabled	•/•	-	•	•	6. 26. 1
0453 Regenerative braking stall prevention mode selection		0:Stall during regenerative braking 1:Not stall during regenerative braking	1/1	0	Enabled	•/•	-	•	•	6. 26. 2
0454 Constant output zone torque limit selection		0:Constant output limit 1:Constant torque limit	1/1	0	Disabled	•/•	•/•	•	-	6. 25. 1
Torque reference polarity selection		O:It is interchangeable so far. (When reversing reverses the polarity.)	1/1	0	Disabled	•	•/•	•		*
PCC POGOTA action makes at makes of categories		Messiel (FORDADA) securities of the Control of the		=	-					

*1: \Rightarrow For details, refer to Instruction Manual (E6581331) specified in Section 6.42

Sensorless vector/vector with sensor (•:Effective, -:Ineffective)		#Constant Reference	*1	*1	+	*	*1	*	*1	*1	6.27.2	6.26.3
ffective, -		V/f Constant	-								•	•
ensor (∙:E		PM control			-	•		•	•	-	-	
ector with s	Vector control	Torque control	•/•	-	-	-	-	-	-	-	-/-	-/-
ss vector/v	Vector	Speed control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	-/-	-/-
Sensorle		Default Write during setting running	Disabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Disabled	Disabled
		Default setting	0	12	100	32	12	100	32	0.0	0	0
	Minimum	setting unit (Panel/Communi cation)	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1
		Adjustment range	0.0~1000	1~9999	1~9999	0~100	1~9999	1~9999	0~100	0.0~F 爿 Hz	0:Disabled Erlanblad(Low gain) 2:Enabled(Middle gain) 3:Enabled(High gain)	0: Stall prevention control 1 1: Stall prevention control 2
imeters [1/2]		Function	Current control proportional gain 0.0~1000	Speed loop proportional gain	Speed loop stabilization coefficient	Moment of inertia of load 1	Second speed loop proportional gain	Second speed loop stabilization coefficient	Moment of inertia of load 2	Speed PI switching frequency	Motor oscillation control	Stall prevention control switching
[21] Adjustment parameters	Commini	cation No.	0458	0460	0461	0462	0463	0464	0465	0466	0467	0468
[21] Adjus		Title	8543	0963	1943	2943	E9h4	h9h4	5943	9943	1943	8943

^{*1:} \Rightarrow For details, refer to Instruction Manual (E6581333) specified in Section 6.42. *2: \Rightarrow Settings vary from unit to unit. Even if £ 9P is set to $\vec{3}$, no change is made to these values.

Sensorless vector/vector with sensor (•: Effective, -: Ineffective)		//fConstant Reference	6.14.2	6. 28	6. 28	6. 28	6. 28	6. 28	6. 28	6. 28	6. 28	6. 28	6. 28	6.27.3	6. 29	6. 29	
ffective, -		V/f Constant	•	•	•	•	•	•	•	•	•	•	•	•	-	-	
ensor (∙:E		PM control		•	•	•	•	•	•	•	•	•	•	•	•	•	
ector with s	control	Torque control	-/-	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•			
ss vector/ve	Vector control	Speed	-/-	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•			
Sensorles		Write during running	Disabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Disabled	Disabled	Disabled	
		Default setting	0	*2	*2	*2	*2	*2	*1	*1	*1	*1	*1	0	10.0	10.0	
	Minimum	setting unit (Panel/Communi cation)	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0.1/0.1	0.1/0.1	
		Adjustment range	0: Automatic, 1~1000ms	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0.Standard 2.102.5% 3.105.6	0~100%	0~100%	unit. Even if Ł YP is set to 3, no change is made to these values.
meters [2/2]		Function	Overvoltage limit constant	VI/II input bias	VI/II input gain	RR/S4 input bias	RR/S4 input gain	RX input bias	RX input gain	Optional AI1 input bias	Optional AI1 input gain	Optional AI2 input bias	Optional AI2 input gain	Max output voltage modulation rate	PM motor constant 1 (d axis inductance)	PM motor constant 2 (q axis inductance)	
[21] Adjustment parameters [2//	Commini	cation No.	0469	0470	0471	0472	0473	0474	0475	0476	0477	0478	0479	0495	0498	0499	ngs vary fro
[21] Adjus		Title	59h d	ロヒカメ	トトアル	2143	ELHY	かいたよ	5143	9143	ところよ	8164	5124	5643	8643	66h3	*1: ⇒ Settings vary from unit to

[22] Acce	[22] Acceleration/deceleration	celeration 2 [1/2]				Sensories	s vector/ve	ector with so	ensor (∙:E	ffective,	Sensoriess vector/vector with sensor (•: Effective, -: Ineffective)
	Commini			Minimum			Vector control	control			
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed	Torque control	PM control	ViConstant	Reference
F 500	0020	Acceleration time 2	0.1~6000 sec.	0.1/0.1 *2	٠,	Enabled	•/•	-	•	•	6. 30. 1
1054	0501	Deceleration time 2	0.1~6000 sec.	0.1/0.1 *2	*1	Enabled	•/•		•	•	6.30.1
5053	0502	Acceleration/deceleration 1 pattern	0:Straight, 1:S-pattern 1, 2:S-pattern 2	1/1	0	Enabled	•/•		•	•	6. 30. 1
F233	6050	Acceleration/deceleration 2 pattern	0:Straight, 1:S-pattern 1, 2:S-pattern 2	1/1	0	Enabled	•/•		•	•	6. 30. 1
F504	0504	Panel acceleration/deceleration 1 Selection 3.Acceleration/deceleration 3 Selection 4.Acceleration/deceleration 3 4.Acceleration/deceleration 3	1:Acceleration/deceleration 1 2:Acceleration/deceleration 2 3:Acceleration/deceleration 3 4:Acceleration/deceleration 4	1/1	1	Enabled	•/•	-	•	•	6. 30. 1
F505	9090	Acceleration/deceleration switching frequency 1	0.0∼ <i>F H</i> Hz	0.1/0.01	0.0	Enabled	•/•		•	•	6. 30. 1
F508	9090	Acceleration S-pattern lower limit adjustment	%05-0	1/1	10	Enabled	•/•	1	•	•	6. 30. 1
F 5 0 7	2090	Acceleration S-pattern upper limit adjustment	%05~0	1/1	10	Enabled	•/•		•	•	6. 30. 1
F508	8090	Deceleration S-pattern lower limit adjustment	%05~0	1/1	10	Enabled	•/•		•	•	6. 30. 1

T: Default values vary depending on the capacity, \Rightarrow See the table of K-46. 2: Changing the parameter £ 4 P enables to set to 0.01 sec. (adjustment range: 0.01–600.0 sec.).

_												
Sensorless vector/vector with sensor (•:Effective, -:Ineffective)		WfCanstart Reference	6. 30. 1	6. 30. 1	6.30.1	6. 30. 1	6. 30. 1	6.30.1	6.30.1	6. 30. 1	6. 30. 1	
ffective,		V/F Constant	•	•	•	٠	٠	•	•	•	•	
ensor (∙:E		PM control	•	•	•	•	•	•	•	•	•	
ctor with s		Torque control										
ss vector/ve	Vector control	Speed	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	
Sensorles		Default Write during setting running	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	
		Default setting	10	*1	١.	0	0.0	٠,	٠,	0	0.0	
	_	setting unit (Panel/Communi cation)	1/1	0.1/0.1 *2	0.1/0.1 *2	1/1	0.1/0.01	0.1/0.1 *2	0.1/0.1 *2	1/1	0.1/0.01	
		Adjustment range	0~20%	0.1~6000 sec.	0.1~6000 sec.	0:Straight, 1:S-pattern 1, 2:S-pattern 2	0.0∼ <i>F H Hz</i>	0.1~6000 sec.	0.1~6000 sec.	0:Straight, 1:S-pattern 1, 2:S-pattern 2	0.0~ <i>F H H</i> z	on the capacity. \Rightarrow See the table of K-46. enables to set to 0.01 sec. (adjustment range: 0.01~600.0 sec.).
[22] Acceleration/deceleration 2 [2/2]	-	Function	Deceleration S-pattern upper limit adjustment	Acceleration time 3	Deceleration time 3	Acceleration/ deceleration 3 pattern	Acceleration/deceleration switching frequency 2	Acceleration time 4	Deceleration time 4	Acceleration/ deceleration 4 pattern	Acceleration/deceleration switching frequency 3	*!: Default values vary depending on the capacity, \Rightarrow See the table of K-46. *2: Changing the parameter E 4 P enables to set to 0.01 sec. (adjustment $r_{\rm s}$
eration/d	Jummoo	cation No.	6090	0510	0511	0512	0513	0514	0515	0516	0517	values va าg the paเล
[22] Acce		Title	F503	B1 54	1151	F5 15	F 2 13	h1 5 d	5151	F5 15	F151	*1: Default *2: Changir

[23] Pattern operation [1/3]

_																				
Sensorless vector/vector with sensor (•: Effective, -: Ineffective)		Reference	6.31		6. 31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31
ffective,		V/FConstant	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ensor (∙:E	i	control	•		•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ctor with s	control	Torque control							-			-		-	-				-	
s vector/ve	Vector contro	Speed	•/•		•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
Sensorles		Write during running	Disabled		Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
•		Default	0		0	1	0	0	0	0	0	0	0	0	1	0	0	0	0	0
	Minimum	setting unit (Panel/Communi cation)	1/1		1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1
		Adjustment range	0:Disabled 1:Enabled (setting in units of seconds) 2:Enabled (setting in units of minutes)	0:Pattern operation reset when system stops	operation 1.Pattern operation continued even after system stops operation	1~254, 255:Successive	0:Skip, 1~15	1~254, 255:Successive	0:Skip, 1~15											
n [1/3]		Function	Pattern operation selection		Pattern operation mode	Number of repetitions of pattern group 1	Pattern group 1 selection 1	Pattern group 1 selection 2	Pattern group 1 selection 3	Pattern group 1 selection 4	Pattern group 1 selection 5	Pattern group 1 selection 6	Pattern group 1 selection 7	Pattern group 1 selection 8	Number of repetitions of pattem group 2	Pattern group 2 selection 1	Pattern group 2 selection 2	Pattern group 2 selection 3	Pattern group 2 selection 4	Pattern group 2 selection 5
[23] Pattern operation [1/3]	Communi	cation No.	0520		0521	0522			0525		0527			0230	0531	0532	0533		0535	0536
[23] Patte		Title	F520		F 5 2 1	F555	F253	F504	525 <i>3</i>	F528	F527	825J	F553	£230	1853	F535	£ 233	7534	5853	9E54

	11
J	Ц
	J

Sensorless vector/vector with sensor (•:Effective, -:Ineffective)	Reference	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	6.31	5. 12	5. 12	5. 12	5. 12	5. 12	5. 12	5. 12	5. 12	5. 12	5. 12
ffective,	VifConstant	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ensor (∙:E	PM control	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ctor with se	control control								-		-	-		-	-	-	-	-	-	-	1		-	-	-	-	-	-	
s vector/ve	Speed Torque control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
Sensorles	Write during running	Disabled	Disabled	Disabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
•	Default \setting	0	0	0	5.0	2.0	2.0	2.0	5.0	2.0	5.0	5.0	2.0	5.0	5.0	5.0	5.0	2.0	5.0	0	0	0	0	0	0	0	0	0	0
	Minimum setting unit (Panel/Communi cation)	1/1	1/1	1/1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1
	Adjustment range	0:Skip, 1~15	0:Skip, 1~15	0:Skip, 1~15	0.1~6000 (The unit depends on the setting of F G G G .) 6000:Infinite (depends on the stop trigger entered)	Ditto	Ditto	Ditto	Ditto	Ditto	Ditto	Ditto	Ditto	Ditto	Ditto	Ditto	Ditto	Ditto	Ditto	0:Preset speed operation with no mode 1:Preset speed operation with mode	U.Foward run +1:Reverse run +2:Acceleration/deceleration switching signal 1 +2:Acceleration/deceleration switching signal 2 +8:V/f switching signal 1 +16:V/f switching signal 2 +3:Torque limit switching signal 1 +64:Torque limit switching signal 2 +64:Torque limit switching signal 2	Ditto							
ion [2/3]	i Function	Pattern group 2 selection 6	Pattern group 2 selection 7		Speed 1 operation time	Speed 2 operation time	Speed 3 operation time		Speed 5 operation time	9					Speed 11 operation time			Speed 14 operation time	Speed 15 operation time	Preset speed operation mode selection	Preset speed operation frequency 1 operation mode	Preset speed operation frequency 2 operation mode	Preset speed operation frequency 3 operation mode	Preset speed operation frequency 4 operation mode	Preset speed operation frequency 5 operation mode	Preset speed operation frequency 6 operation mode	Preset speed operation frequency 7 operation mode	Preset speed operation frequency 8 operation mode	Preset speed operation frequency 9 operation mode
[23] Pattern operation [2/3]	Communi cation No.	0537	0538	0539	0540	0541	0542	0543	0544	0545	0546	0547	0548	0549	0220	0551	0552	0553	0554	0990	0561	0562	0563	0564	0565	0566	0567	0568	0569
[23] Patte	Title	F537	F538	5539	8540	1 224	545d	E h S d	7544	F545	F548	F547	8 h S d	6754	£520	F 55 1	F555	E553	F554	£580	1881	F 5 8 2	£ 2 5 3	h954	F585	F555	1953	£558	£883

Sensorless vector/vector with sensor (•:Effective, -:Ineffective)	Vector control PM MCarsant Reference control control Control MCarsant Reference Control Con		- 5.12	5.	· · ·	и и и ии и и	м м м м м • • • • •	が	• • • • • • • • • • • • • • • • • • •	/• • • 5.12 /• • • 5.12 /• • • 5.12 /• • • 5.12 /• • • 5.12 /• • • 5.12 /• • • 5.12 /• • • 5.12 /• • • 5.12 /• • • 5.12 /• • • 5.12 /• • • 6.12 /ector control read	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-
8 8				•/• pə	•/• pə	•/• pə	•/• pəl	orless vector/	ds o	•/• pa	•/• pə	•/• pə	•/• pə	•/• pə	•/• pə	•/• pə	•/• pə	_	•/• pə	•/• pə	•/• pa	•/• pə	•/• pə						
L	Default Write during setting	0 Disabled	0 Disabled	0 Disabled	0 Disabled	0 Disabled	0 Disabled	Sens	Default Write during setting	0 Enabled	0 Enabled	0 Enabled	0 Enablec	0 Enabled			0 Enabled			0 Enabled	0 Enabled	0 Enablec	0 Enabled	0 Enabled					
Ministra	setting unit De (Panel/Communi se cation)	1/1	1/1	1/1	1/1	1/1	1/1		Minimum setting unit De (Panel/Communi se cation)	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	0.1/0.1	
	Adjustment range	Ditto	Ditto	Ditto	Ditto	Ditto	Ditto		Adjustment range	0: Manual setting (F 5 7 7~F 5 8 \varOmega Enabled) 1: BOOTP 2: DHCP	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0~255	0: Prohibit 1: Permit	0.0~60.0sec.	option.(planning)
n [3/3]	Function				eed operation frequency on mode		Preset speed operation frequency 15 operation mode	function	Function	P address setting method	Data1		Data3				Data3			Data2 (Data3		Data1	Data2 (Data3	Data4	IO scan permission	Communication time-out (Modbus)	1.⇒This function is for Etherenet communication option (planning)
[23] Pattern operation [3/3]	Communi cation No.	0250	0571	0572	0573	0574	0575	[24] Communication function	Communi cation No.	0576	0577	0578	0579	0580	0581	0582	0583	0584	0585	0586	0587	0588	0589	0690	0591	0592	0593	0594	function is
[23] Pati	Title	0153	1153	2153	E153	4653	515J	[24] Con	Title	8183	6653	8151	F579	F580	F581	F585	F583	F 584	F585	F585	F587	F588	£883	£530	F591	285J	E 8 8 3	F594	1:⇒This

	11	1	
Į	4	Ц	

Sensorless vector/vector with sensor (•:Effective, -:Ineffective)	Reference	کواوا واارد کواوا واارد	6. 33. 1	6. 33. 2	6. 33. 3	6. 33. 3	6. 33. 4	5. 14	5. 14	6. 33. 7	6. 33. 8	6. 33. 8	6. 33. 8	6.33.8	6. 33. 9	6. 33. 10	6. 33. 10	6. 33. 10	6. 33. 10	6. 33. 10	6. 33. 11	6. 33. 12
fective, -	VEConstant	VII CUI BUILL	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ensor (∙:Ef		control	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ector with se	Vector control	control		•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
ss vector/ve	Vector	control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
Sensorle	Write during	running	Enabled	Enabled	Disabled	Enabled	Disabled	Enabled	Enabled	Disabled	Enabled	Enabled	Enabled	Enabled	Disabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled
	Default	setting	150	0	0	1.0	0	0.9	300	1	10	0	0	0	0	0	150	150	0.50	10	0	610.0
	Minimum setting unit	(Panel/Communi cation)	1/1	1/1	1/1	0.1/0.1	1/1	0.1/0.01	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/0.01	1/0.01	0.01/0.01	1/0.01	1/1	0.1/0.1
	epaes triemtsiiibA	Adjustifieri range	10~164%, 165:Deactivated	0:Clear when power is turned off 1:Retain even after power is turned off	0:Coast stop 1:Deceleration stop 2:Emergency DC braking 3:Deceleration stop (deceleration 4)	0.0~20.0 sec.	0:Deselect 1-74 starting (only one time after power is turned on) 2-44 starting (each time power is turned on) 3:During operation 4-44 starting + during operation 5:Output cut-off detection enabled	0.0~60.0Hz	10~2400 sec.	0:Disabled 1:Enabled	1~20%	O:No trip 1:Trip	0~100%	0~255 sec.	O:Each time (standard pulse) 1:Only one time affer power is turned on 2:Each time (short pulse) 3:Only one time affer power is turn on (short pulse) pulse) 4:Each time (Extremely shot-time pulse) 5:Only one time affer power is turn on (Extremely shot-time pulse)	O:No trip 1:Trip	0~250%		0.00~10.00 sec.		0:Auto 1:Always ON	0.1~999.9 (x100h)
ions [1/2]	Finction	רמוכוסו	Stall prevention level	Inverter trip record retention selection	Emergency stop	Emergency DC braking control time	Output phase failure detection mode selection		nit		Low current detection hysteresis width	Low current trip selection	rent detection current	Low current detection time	Selection of short circuit detection at starting	Overtorque trip selection	Overtorque detection level during power running	Overtorque detection level during regenerative braking	Overtorque detection time	Overtorque detection hysteresis	Cooling fan control selection	Cumulative operation time alarm setting
[25] Protection functions [1/2	Communi	No.	0601	0602	090	0604	0605	9090	2090	8090	6090	0610	0611	0612	0613	0615	0616	0617	0618	0619	0620	0621
[25] Prote	Title	ם ב	1091	5033	F883	4093	F 6 0 5	F505	F803	8093	£803	66 10	1194	E8 15	F8 13	5194	51 93	6617	8193	£8 13	F620	F521

Sensorless vector/vector with sensor (.Effective, -:Ineffective)	Reference	6. 33. 13	6. 33. 13	6. 33. 13	6.33.15	6.14.2	6. 33. 15	6. 33. 15	6. 33. 16	6. 33. 17	5. 14	6. 33. 18	6. 33. 19	6. 33. 20	*	*	5. 19	6. 29	6. 29	6. 33. 23	6. 33. 24
ffective,	V/FConstant	•	•	•	•	•	•	•	•		-	•	•	•	•	•	•	-	-	•	•
ensor (∙:E	PM control	•	•	•	•	•	•	•	•			•	•	•	•	•	•	•	•	•	•
ector with s	control Torque control	•/•	•/•	•/•	•/•	-	•/•	•/•	•/•	-		•/•	•/•	•/•	•/•	•/•	•/•	-		•/•	•/•
ss vector/ve	Speed Torque control	•/•	•/•	•/•	•/•	•/•	• /•	•/•	•/•	•/•		•/•	•/•	•/•	•/•	•/•	•/•			•/•	•/•
Sensorle	Write during running	Enabled	Enabled	Enabled	Disabled	Disabled	Disabled	Disabled	Disabled	Enabled	Disabled	Enabled	Enabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled	Disabled
	Default setting	0.01	0.0	0.0	80	134	0	60.0	92	0.0	0	0	3	0.0	0	0	2.0	100	0.0	0	0
	Minimum setting unit (Panel/Communi cation)	0.01/0.01	0.01/0.01	0.01/0.01	1/1	1/1	1/1	0.01/0.01	1/1	0.1/0.1	1/1	1/1	1/1	0.1/0.1	1/1	1/1	0.1/0.1	1/1	0.1/0.1	1/1	1/1
	Adjustment range	0.01~100.0 sec.	0.00:Disabled, 0.01~30.0Hz	0.00:Disabled, 0.01~30.0Hz	50~79%, 80: (auto mode)		0:Disabled 1:Enabled	0.01~10.00 sec.	25~100%	0.0:Disabled, 0.1~10.0 sec.	0:Standard (150%-60 sec.) 1:Estimation of temperature	0:None 1~100%	2.+11.+10-+10°C 2.+11.+20°C 3.+21.+40°C 5.+41.+60°C 6.+51.+60°C	0.0~2.5 sec.	O:Deselect 1:Select	0:Deselect 1:Select	0.1~600.0 sec.	10~150	0.0:Not detect 0.1~25.0	0:Default (no waiting time for frequencies of 10Hz and less) 1:Conditional (no waiting time for frequencies of 20Hz and less)	O:Control power supply not backed up 1:Control power supply backed up (alarm in the event of a failure) 2:Control power supply backed up (tripping in the event of a failure) event of a failure)
ions [2/2]	Function	Abnormal speed detection time	Overspeed detection frequency upper band	eed detection frequency		evel	Undervoltage trip selection	Undervoltage (trip alarm) detection time	Regenerative power ride-through control level	Braking answer waiting time		VI/II analog input wire breakage detection level	Annual average ambient temperature (calculation for part replacement alarms)	Rush current suppression relay activation time			Braking resistance overload time (10 times of rated torque)	Step-out detection current level (for PM motors)	Step-out detection time (for PM motors)	Brake-equipped motor restart condition selection	Control power supply no power supply no power supply no power supply no power supply backup (**Control power supply backup power supply power supply backup power supply power supply backup power supply backup power supply power supply power supply backup power supply backup power supply backup power supply backup power supply power supply backup power supply backu
[25] Protection functions [2/2]	Communi cation No.	0622	0623	0624	0625	0626	0627	0628	0629	0630	0631	0633	0634	0635	0637	0638	0639	0640	0641	0643	0647
[25] Prote	Title	£855	F853	F624	F625	F525	F627	F528	F523	F830	1 693	F633	4634	5693	1833	F638	£833	0h93	1 493	£ 6 4 3	F 6 4 7

	i		ī	7
ı		J	ı	4

Sensorless vector/vector with sensor (•.Effective, -:Ineffective)	Vector control	Adjustment range setting unit Default Write during Speed Torque PM WiConstant Reference control control addition	by continuater/voltage input) Itage/current input) Itage input Itage input) Itage input	ed, 1:VI/II, 2:RR/S4, 3:RX, 4:F 729, 1/1 0 Enabled •/• - • • 6.34	output 1/1 0 Disabled •/• • • 6.35.1	c
Sensor		ult Write duri	Enable	Enable	Disable	Fnahlad
			0	0	0	6
	Minimun	setting ur (Panel/Comr. cation)	1/1		1/1	1/1
		Adjustment range	O'Disabled 1:VIII (votage/current input) 2:RRX54 (potentiomater/votage input) 3:RX (vottage input) 4:Operation panel input enabled 4:Operation panel input enabled 5:2-wire RS485 input enabled 7:Communications option input) 9:Optional Al1 (differential current input) 9:Optional Al2 (voltage/current input) 10:UPIOOWN frequency 11:Optional RP pulse input 12:Optional High-speed pulse input	0:Disabled, 1:VI/II, 2:RR/S4, 3:RX, 4:F 729, 5:Optional Al1	0:Logic output 1:Pulse output	0_6/1 *1
		Function	Override addition input selection	Override multiplication input selection	Logic output/pulse output selection (OUT1)	AM terminal meter selection
	iuni	cation No.	0990	0661	6990	0670
[26] Override	Commun	. g ~				

Ins parameter moves to a rundamental parameter.
*1: ⇒ For the adjustment range, see the table on page K-39.

[27] Meter output [1/2]		(2)				Sensorles	ss vector/ve	ector with s	ensor (•:F	:ffective,	Sensorless vector/vector with sensor (•: Effective, -: Ineffective)
Comming				Minimum			Vector control	control			
cation Function No.	Function	_	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Default Write during setting running	Speed	Torque control	control	V/FConstant	Reference
0671 AM terminal meter adjustment		adjustment		1/1		Enabled	•/•	•/•	•	•	5. 16
0672 MON1 terminal me		terminal meter selection	0~26 *1	1/1	4	Enabled	•/•	•/•	•	•	*2
0673 MON1 terminal meter adjustment		ter	-	1/1		Enabled	•/•	•/•	•	•	*2
0674 MON2 terminal me		terminal meter selection	0~76 *1	1/1	5	Enabled	•/•	•/•	•	•	*2
0675 MON2 terminal meter adjustment	MON2 terminal me adjustment	ster	1	1/1		Enabled	•/•	•/•	•	•	*2
0676 Pulse output function selection	Pulse output funct	ion selection	0~49 *1	1/1	0	Enabled	•/•	•/•	•	•	6.35.1
0677 Selection of numb	Selection of numb	on of number of pulses	1.00~43.20kHz	0.01/0.01	3.84	Enabled	•/•	•/•	•	•	6.35.1
0678 Constant at the tir		nt at the time of filtering	4msec, 8msec~100msec	1/1	64	Enabled	•/•	•/•	•	•	5. 16
0681 FM voltage/current output switching	FM voltage/currer switching	nt output	0:Voltage 0~10V output 1:Current 0~20mA output	1/1	0	Disabled	•/•	•/•	•	•	6. 35. 3
0682 FM output gradient characteristic		nt	0:Negative gradient (descending) 1:Positive gradient (ascending)	1/1	1	Enabled	•/•	•/•	•	•	6.35.3
0683 FM bias adjustment	FM bias adjustm	ent	-10.0~100.0%	0.1/0.1	0.0	Enabled	•/•	•/•	•	•	6.35.3

This parameter moves to a fundamental parameter.

↑: ⇒ For the adjustment range, see the table on page K-39.

↑: ⇒ For details, refer to Instruction Manual (E6581341) specified in Section 6.42.

_				_						
Sensorless vector/vector with sensor (•:Effective, -:Ineffective)	Reference	5. 16	6.35.3	6.35.3	*2	7*	*2	*2	7*	*2
fective, .	Wf Constant	•	•	•	•	•	•	•	•	•
ensor (∙:Ef	PM control	•	•	•	•	•	•	•	•	•
ector with s	control Torque control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
ss vector/ve	Speed Torq	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
Sensorles	Write during running	Enabled	Enabled	Enabled	Disabled	Enabled	Enabled	Disabled	Enabled	Enabled
	Default setting	0	1	0.0	1	1	0.0	1	1	0.0
	Minimum setting unit (PaneVCommuni cation)	7,	1/1	0.1/0.1	1/1	1/1	0.1/0.1	1/1	1/1	0.1/0.1
	Adjustment range	0:No filter 1:Filter approx 10ms 2:Filter approx 10ms 3:Filter approx 30ms 4:Filter approx 30ms 5:Filter approx 60ms 6:Filter approx 120ms 6:Filter approx 250ms 7:Filter approx 50ms 8:Filter approx 50ms	0:Negative inclination (downward slope) 1:Positive inclination (upward slope)	-10.0~100.0%	0:Voltage -10~10V output 1:Voltage 0~10V output 2:Current 0~20mA output	0:Negative inclination (downward slope) 1:Positive inclination (upward slope)	-10.0~100.0%	0:Voltage -10~10V output 1:Voltage 0~10V output 2:Current 0~20mA output	0:Negative inclination (downward slope) 1:Positive inclination (upward slope)	-10.0~100.0%
[2]	Function	FM output filter	AM output gradient characteristic	AM bias adjustment	MON1 voltage/current output switching	MON1 output gradient characteristic	MON1 bias adjustment	MON2 voltage/current output switching	MON2 output gradient characteristic	MON2 bias adjustment
[27] Meter output [2/2]	Communi cation No.	0684	0685	9890	0688	6890	0690	0691	0692	0693
[27] Mete	Title	h893	5893	3833	8893	6893	0693	1893	2693	F833

This parameter moves to a fundamental parameter.
⁴1: ⇒ For the adjustment range, see the table on page K-39.
*2: ⇒ For details, refer to Instruction Manual (E6581341) specified in Section 6.42.

[28] Oper	ation panel	[28] Operation panel parameters [1/3]				Sensorles	ss vector/ve	ector with s	ensor (∙:E	ffective,	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)
	Communi			Minimum			Vector control	control			
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed	Torque control	PM	V/f Constant	Reference
8013	0020	Parameter write protect selection	0:Permit 1:Prohibit	1/1	0	Enabled	•/•	•/•	•	•	6. 36. 1
RUSP	0701	Current/voltage unit selection	0:%, 1:A (ampere)/V (volt)	1/1	0	Enabled	•/•	•/•	•	•	5. 15
5013	0702	Frequency free unit display magnification	0.00:OFF, 0.01~200.0	0.01/0.01	0.00	Enabled	•/•	•/•	•	•	6.36.2
E013	6020	Frequency free unit conversion selection	0:All frequencies display free unit conversion 1:PID frequencies free unit conversion	1/1	0	Enabled	•/•	•/•	•	•	6.36.2
5013	9020	Free unit display gradient characteristic	0:Negative inclination (downward slope) 1:Positive inclination (upward slope)	1/1	-	Enabled	•/•	•/•	•	•	6. 36. 2
F 705	9020	Free unit display bias	0.00~ <i>F H</i> Hz	0.01/0.01	0.00	Enabled	•/•	•/•	•	•	6.36.2
F 20.3	2020	Changing step selection 1	0.00:Disabled, 0.01∼F / Hz	0.01/0.01	0.00	Enabled	•/•	•/•	•	•	6.36.3
F 708	0708	Changing step selection 2	0:Disabled, 1~255	1/1	0	Enabled	•/•	•/•	•	•	6.36.3
£109	6020	Standard monitor hold function	0:Real time, 1:Peak hold, 2:Minimum hold	1/1	0	Enabled	•/•	•/•	•	•	8.3
6710	0710	Standard monitor display selection	0~80 *1	1/1	0	Enabled	•/•	•/•	•	•	8.3
1111	0711	Status monitor 1 display selection	Ditto	1/1	1	Enabled	•/•	•/•	•	•	8.3
2113	0712	Status monitor 2 display selection	Ditto	1/1	2	Enabled	•/•	•/•	•	•	8.3
E113	0713	Status monitor 3 display selection	Ditto	1/1	3	Enabled	•/•	•/•	•	•	8.3
h1 L d	0714	Status monitor 4 display selection	Ditto	1/1	4	Enabled	•/•	•/•	•	•	8.3
5113	0715	Status monitor 5 display selection	Ditto	1/1	8	Enabled	•/•	•/•	•	•	8.3
3113	0716	Status monitor 6 display selection	Ditto	1/1	16	Enabled	•/•	•/•	•	•	8.3
6113	0717	Status monitor 7 display selection	Ditto	1/1	15	Enabled	•/•	•/•	•	•	8.3
8113	0718	Status monitor 8 display selection	Ditto	1/1	14	Enabled	•/•	•/•	•	•	8.3
8113	6120	Operation command clear selection when standby terminal (ST) is OFF		1/1	1	Enabled	•/•	•/•	•	•	6. 36. 5
1213	0721	Operation panel stop pattern selection	0:Deceleration stop 1:Coast stop	1/1	0	Enabled	•/•	•/•	•	•	6. 36. 6
5213	0725	Operation panel torque command	-250-250%	1/0.01	0	Enabled		•/•	-	-	6.36.7
1213	0727	Operation panel tension torque bias	-250-250%	1/0.01	0	Enabled	-	•/•	-	-	6.36.8
8213	0728	Operation panel load sharing gain	0~250%	1/0.01	100	Enabled		•/•	-	-	6.36.8
6213	0729	Operation panel override multiplication gain	-100~100%	1/0.01	0	Enabled	•/•		•	•	6.34
This p	arameter m	This parameter moves to a fundamental parameter.	. *1: ⇒ For the adjustment range, see the table on page K-39	page K-39.							

Prunction	[20] Opt	zoj operation pariet paramet	parameters [2/3]		Minimum		Sellsolle	Vector control	Vector control		יבכה אם,	·IIIeIIective
1/1 0 Enabled ** ** ** * * * * * * * * * * * * * *	Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed	Torque	PM	VifConstant	Reference
1/1 0 Enabled o'.	0813	0230	Operation panel frequency setting prohibition selection	0:Permit 1:Prohibit	1/1	0	Enabled	•/•	•/•	•	•	6. 36. 1
1/1 0 Enabled •/• •/• •/• • • • 6. The control of	£ {	0734	Operation panel emergency stop operation prohibition selection	O:Permit 1:Prohibit	1/1	0	Enabled	•/•	•/•	•	•	6. 36. 1
1/1 1 Enabled 0/0 0/	57	0735	Operation panel reset operation prohibition selection	0:Permit 1:Prohibit	1/1	0	Enabled	•/•	•/•	•	•	36.
Tit 0 Enabled """""""""	r-	0736	Prohibition of change of ど	0: Permit 1: Prohibit	1/1	-	Enabled	•/•	•/•	•	•	36.
14. 1 Enabled •/• •/• •/• • • • • • • • • • • • • •	6737	0737	All key operation prohibition	0:Permit 1:Prohibit	1/1	0	Enabled	/•	•/•	•	•	6. 36. 1
Total total trianger	8748	0740	Trace selection	0:Deselect, 1:At tripping, 2:At triggering	1/1	1	Enabled	•/•	•/•	•	•	
1/1 0 Enabled •/• •/• •/• • • • • • • • • • • • • •	126	0741	Trace cycle	0:4ms, 1:20ms, 2:100ms, 3:1s, 4:10s	1/1	2	Enabled	•/•	•/•	•	•	6.37
d setting mode switching 1/1 2 Enabled	546 J	0742	Trace data 1	0~49	1/1	0	Enabled	•/•	•/•	•	•	6.37
d setting mode switching for 2 sec. to record the first jump to story) um hold trigger 1/1 (AU4) Enabled 1/2 (AU4) Enabled 1/3 (ACC) Enabled 1/4 (ACC) Ena	E 143	0743	Trace data 2	0~49	1/1	1	Enabled	•/•	•/•	•	•	6.37
1/1 3	としてみ	0744	Trace data 3	0~49	1/1	2	Enabled	•/•	•/•	•	•	6. 37
d setting mode switching 1/1	5745	0745		0~49	1/1	3	Enabled	•/•	•/•	•	•	
d setting mode switching for 2 sec. to record the for 3 sec. to record the for 4 sec. to record the for 5 sec. to record the for 6 sec. to record the for 7 sec. to record	8714	0748		0:Disabled 1:Enabled	1/1	0	Enabled	•/•	• /•	•	•	
tor 2 sec. to record the figure and parameter (first jump to jump to de parameter (first jump to jump tigger j	5hl 3	0749	Integrating wattmeter display unit selection	1:1=10kWh 1:1=10kWh 2:1=10bkWh 2:1=10bkWh 4:1=1000kWh	1/1	.2	Enabled	•/•	•/•	•	•	6.38
1/1 (AU4) Enabled 6/6 6/6 6/6 6/6 6/6 6/6 6/6 6/6 6/6 6/	B 25 B	0750	EASY key function selection	O:Quick mode/standard setting mode switching function 1:Shortcut key,Pressing for 2 sec. to record the parameter, pressing normally to jump to recorded parameter (first jump to the 1st history) 2:Operation panel/remote key;Operation panel by ON 3:Monitor peak minimum hold trigger	1/1	0	Disabled	•,	• ,	•	•	5. 22
1/1 (pt) (pt) (pt) (pt) (pt) (pt) (pt) (pt)	1513	0751	Quick registration parameter 1	0~999 *1	1/1	40 (AU4)	Enabled	•/•	•/•	•	•	
1/1 (FH) Enabled •/• •/• • 5. 1/1 (ACC) Enabled •/• •/• • 5. 1/1 (ACC) Enabled •/• •/• • 5.	5 /	0752	Quick registration parameter 2	0~999 *1	1/1	15 (pt)	Enabled	•/•	•/•	•	•	
1/1 (ACC) Enabled •/• •/• • 5. 1/1 (dEC) Enabled •/• •/• • 5.	51	0753	Quick registration parameter 3	0~999 *1	1/1	11 (FH)	Enabled	•/•	•/•	•	•	
1/1 (dEC) Enabled •/• •/• • 5.	4563	0754	Quick registration parameter 4	0~999 *1	1/1	9 (ACC)	Enabled	•/•	•/•	•	•	
	£ 755	0755	Quick registration parameter 5	0~999 *1	1/1	10 (dEC)	Enabled	•/•	•/•	•	•	

The communication number of the parameter is used for this setting.
 Default values vary depending on the capacity. ⇒ See the table of K-46.

Adjustment range ration setting the following setting running Speed Torque control cation) 1/1 (FM) Enabled % % % % % % % % % % % % % % % % % % %	Default (HI) Write during speed (Control) PM (Consent output) Wilconsent control con	[28] Operation panel parameters [3/3]
Panel/Ommun Setting Tunning Control	Panel/Communi Setting Tunning Control Control	Communi cation Function
(FM) Enabled o'-	1/1 (FM) Enabled	No.
FM Enabled ** ** ** ** ** ** **	1/1 (FM) Enabled o'• o'• o'• o' o' 1/1 999 Enabled o'• o'• o'• o'• o' 1/1 999 Enabled o'•	0756 Quick registration parameter 6 0~999 *1
999 Enabled	1/1 999 Enabled 1/2 1/4	0757 Quick registration parameter 7 0~999 *1
999 Enabled 9/9	1/1 999 Enabled 1/2 1/3 999 Enabled 1/4 1/	0758 Quick registration parameter 8 0~999 *1
999 Enabled	1/1 999 Enabled	Quick registration parameter 9
999 Enabled	1/1 999 Enabled	Quick registration parameter 10
999 Enabled 9' 9' 9' 9' 9' 9' 9' 9	1/1 999 Enabled	Quick registration parameter 11
999 Enabled	1/1 999 Enabled	Quick reg
999 Enabled 9/9	1/1 999 Enabled 1/2 0.0 0.0 0.0 1/2 999 Enabled 1/2 0.0 0.0 0.0 1/3 999 Enabled 1/2 0.0 0.0 0.0 1/4 999 0.0 0.0 0.0 0.0 0.0 1/4 999 0.0 0.0 0.0 0.0 0.0 1/4 999 0.0 0.0 0.0 0.0 0.0 0.0 1/4 999 0.0 0.0 0.0 0.0 0.0 0.0 1/4 999 0.0 0.0 0.0 0.0 0.0 0.0 0.0 1/4 999 0.0	
999 Enabled 9' 9' 9' 9' 9' 9' 9' 9	1/1 999 Enabled	0764 Quick registration parameter 14 0~999 *1
999 Enabled 9'	1/1 999 Enabled	
999 Enabled 9/9	1/1 999 Enabled 1/2 0.4 0.4 0.4 0.5 1/1 999 Enabled 1/2 0.4 0.5 1/2 999 Enabled 1/2 0.4 0.5 1/3 999 Enabled 1/2 0.4 0.5 1/4 999 0.4 0.4 0.5 1/4 999 0.4 0.4 0.5 1/4 999 0.4 0.4 0.5 1/4 999 0.4 0.4 0.5 1/4 999 0.4 0.4 0.5 1/4 999 0.4 0.4 0.5 1/4 999	Quick reg
999 Enabled 9/0	1/1 999 Enabled 1/2 9/2	
999 Enabled 9'0 9'0 9'0 9'0 9'0 9'0 9'0 9'0 9'0 9'0	1/1 999 Enabled	Quick registration parameter 18
999 Enabled 9'• 9'• 5' 999 Enabled 9'• 9'• 5' 999 Enabled 9'• 9'• 5' 999 Enabled 9'• 9'• 6' 999 Enabled 9'• 6'• 6' 999 Enabled 9'• 6' 999 Enabled 9'• 6' 999 Enabled 9'• 6' 999 Enabled 9'• 6'	999 Enabled 9'• 9'• 5' 999 Enabled 9'• 9'• 5' 999 Enabled 9'• 9'• 5' 999 Enabled 9'• 9'• 6' 50 999 Enabled 9'• 9'• 6' 50 60 60 60 60 60 60 60 60 60	Quick registration parameter 19
999 Enabled 9,0 9,0 9,0 9,0 9,0 9,0 9,0 9,0 9,0 9,0	999 Enabled 9,	Quick registration parameter 20
999 Enabled 9,0 9,0 9,0 9,0 9,0 9,0 9,0 9,0 9,0 9,0	1/1 999 Enabled 1/2 9/2	Quick registration parameter 21
999 Enabled 9,0 9,0 9,0 9,0 9,0 9,0 9,0 9,0 9,0 9,0	1/1 999 Enabled 6/6 6/6 6/6 6/6 6/6 6/6 6/6 6/6 6/6 6/	Quick registration parameter 22
999 Enabled 9,0 9/0 6 9/0 9/0 9/0 9/0 9/0 9/0 9/0 9/0 9/0 9/0	1/1 999 Enabled 6/6 6/6 6/6 6/6 6/6 6/6 6/6 6/6 6/6 6/	Quick registration parameter 23
999 Enabled 9'• 9'• 9'• 9' 999 Enabled 9'• 9'• 6' 999 Enabled 9'• 6'• 6' 999 Enabled 6'• 6'• 6'• 6'• 6'• 6'• 6' 999 Enabled 6'• 6'• 6'• 6'• 6'• 6'• 6'• 6' 999 Enabled 6'• 6'• 6'• 6'• 6'• 6'• 6'• 6' 999 Enabled 6'• 6'• 6'• 6'• 6'• 6'• 6'• 6' 999 Enabled 6'• 6'• 6'• 6'• 6'• 6'• 6'• 6'• 6'• 6'•	1/1 999 Enabled */* */* * * * 5. 1/1 999 Enabled */* */* * * * 5. 1/1 999 Enabled */* */* * * * 5. 1/1 999 Enabled */* */* * * * * 5. 1/1 999 Enabled */* */* * * * * 5. 1/1 999 Enabled */* */* * * * * 5. 1/1 999 Enabled */* */* * * * * 5. 1/1 999 Enabled */* */* * * * * * * *	Quick registration parameter 24
999 Enabled 9/9 6/9 6/9 6/9 6/9 6/9 6/9 6/9 6/9 6/9	1/1 999 Enabled 6/• 6/• 6 • 6 5. 1/1 999 Enabled 6/• 6/• 6 • 6 5. 1/1 999 Enabled 6/• 6/• 6 • 6 5. 1/1 999 Enabled 6/• 6/• 6 • 6 5. 1/1 999 Enabled 6/• 6/• 6 • 6 5. 1/1 999 Enabled 6/• 6/• 6 • 6 5. 1/1 999 Enabled 6/• 6/• 6 • 6 5. 1/1 (PSEL) Enabled 6/• 6/• 6 • 6 5.	Quick registration parameter 25
999 Enabled 9/• 9/• • 5. 50 50 Formula 9/• 9/• 6/• 5.	1/1 999 Enabled 6/• 6/• 6 6/• 6/• 6/• 1/1 999 Enabled 6/• 6/• 6/• 6/• 6/• 6/• 6/• 6/• 6/• 6/•	3 Quick registration parameter 26
999 Enabled (a) *** *** **	1/1 999 Enabled s/• s/• s 5. 1/1 999 Enabled s/• s/• s 5. 1/1 999 Enabled s/• s/• s 5. 1/1 999 Enabled s/• s/• s s 5. 1/1 999 Enabled s/• s/• s s 5. 1/1 PSEL Enabled s/• s/• s s 5. 1/2 PSEL Enabled s/• s/• s s s s s s s s s	0777 Quick registration parameter 27 0~999 *1
999 Enabled 9/• 9/• • 5. 999 Enabled 9/• 9/• • 5. 999 Enabled 9/• 9/• 6 5. 50 50 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6 6	1/1 999 Enabled 6/• 6/• • 6 5 1/1 999 Enabled 6/• 6/• • 6 5 1/1 50 Enabled 6/• 6/• • 6 5 1/1 (PSEL) Enabled 6/• 6/• 6 6 5	Quick registration parameter 28
999 Enabled 9/• 6/• • • • 5 . 999 Enabled 9/• 6/• • • • 5 . 50 50 Enabled 9/• 6/• • • 5 .	1/1 999 Enabled 6/• 6/• • 65 1/1 999 Enabled 6/• 6/• 6 • 65 1/1 (PSEL) Enabled 6/• 6/• 6 • 65	0779 Quick registration parameter 29 0~999 *1
99 Enabled e/e e/e e 5. (PSEL) Enabled e/e e/e e 5.	1/1 899 Enabled s/• e/• • 5. 1/1 (PSEL) Enabled s/• e/• • 5.	Quick reg
50 Enabled •/• •/• • • • 5.	1/1 (PSEL) Enabled •/• •/• • • • • • • 5.	0781 Quick registration parameter 31 0~999 *1
	tting.	0782 Quick registration parameter 32 0~999 *1

[29] Con	[29] Communication function	function [1/4]			Minimim		Sensorle	ss vector/vector w	ector with s	ensor (∙:E	ffective,	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)
Title	Communi cation No.	Function		Adjustment range	setting unit (Panel/Communi cation)	Default \setting	Write during running	Speed	Torque	PM control	V/FConstant	Reference
£ 784	0784	Ď	Data1	0~255	1/1	0	*1	•/•	•/•	•	•	*2
F 785	0785	Ď	Data2	0~255	1/1	0	٠,1	•/•	•/•	•	•	*2
38L J	9820	MAC address Da	Data3	0~255	1/1	0	*1	•/•	•/•	•	•	*2
1813	2820	2	Data4	0~255	1/1	0	٠,	•/•	•/•	•	•	*2
8813	0788	<u> </u>	Data5	0~255	1/1	0	٠,4	•/•	•/•	•	•	*2
F 789	0789	Dě	Data6	0~255	1/1	0	*1	•/•	•/•	•	•	*2
F 192	0792	٥	Data1	0000~FFFF	1/1	0	*1	•/•	•/•	•	•	*2
F 193	0793	<u>ה</u>	Data2	0000~ FFFF	1/1	0	*1	•/•	•/•	•	•	*2
F 194	0794	Dř	Data3	0000~ FFFF	1/1	0	*1	•/•	•/•	•	•	*2
F 795	0795	Device name Da	Data4	0000~ FFFF	1/1	0	*1	•/•	•/•	•	•	*2
F 795	0796		Data5	0000~ FFFF	1/1	0	*1	•/•	•/•	•	•	*2
1814	2620	Ď	Data6	0000~ FFFF	1/1	0	*1	•/•	•/•	•	•	*2
861 J		Ď	Data7	0000~ FFFF	1/1	0	*1	•/•	•/•	•	•	*2
F 799	0799	Dě	Data8	0000~ FFFF	1/1	0	*1	•/•	•/•	•	•	*2
F800	0800	Communication speed (2-wire RS485)	I (2-wire	0.9600 bps 1.19200 bps 2.38400 bps	1/1	1	Enabled	•/•	•/•	•	•	6. 39. 1
1083	0801	Parity (common to 2-wire RS485 and 4-wire RS485)		0:Non parity 1:Even parity, 2:Odd parity	1/1	1	Enabled	•/•	•/•	•	•	6. 39. 1
E805	0802	Inverter number (common)	mon)	0~247	1/1	0	Enabled	•/•	•/•	•	•	6. 39. 1
£883	£080	Communications time-out time (common to 2-wire RS485 and 4-wire RS485)	out time 485 and	0:OFF, 1~100 sec.	1/1	0	Enabled	•/•	•/•	•	•	6. 39. 1
4083	0804	Communications time-out action (common to 2-wire RS485 and 4-wire RS485)	out action 485 and	8~0	1/1	8	Enabled	•/•	•/•	•	•	6. 39. 1
5083	5080	Send waiting time (2-wire RS485)	vire	0.00:Default, 0.01~2.00 sec.	0.01/0.01	00.0	Enabled	•/•	•/•	•	•	6. 39. 1
8083	9080	Master/slave setting for inverter-to-inverter communications (2-wire RS485)		O. Slave (issues a OHz command if something goes wrong with the master) 1. Slave (continues operation if something goes wrong with the master) 2. Slave (tips for emergiagnery stop if something goes wrong with the master) 3. Master (sends a frequency command) 5. Master (sends a rotque command) 5. Master (sends a outque trequency) 6. Master (sends a outque command)	1/1	0	Enabled	•/•	•/•	•	•	6. 39. 1
F807	0807	Protocol selection (2-wire RS485)		0:TOSHIBA 1:MODBUS	1/1	0	Enabled	•/•	•/•	•	•	6. 39. 1
*4. This paramoter	romater ic	חיים סיים										

[29] Con	[29] Communication functi	on function [2/4]				Sensorle	ss vector/ve	ctor with s	ensor (∙:E	ffective, -	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)
	Communi			Minimum			Vector control	control	i		
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed control	Torque control	PM	Wf Constant	Reference
8083	8080	Communication1 time-out condition selection	O:Disconnection detection 1:When communication mode enable 2:1+Driving operation	1/1	0	Enabled	•/•	•/•	•	•	*
6183	0810	Frequency point selection	0:Disabled 1-12-wire RS485 2-4-wire RS485 3:Communication add option	1/1	0	Enabled	•/•	ı	•	•	6. 39. 1
1181	0811	Point 1 setting	0-100%	1/1	0	Enabled *2	•/•		•	•	6. 39. 1
2183	0812	Point 1 frequency	0.0∼ F # Hz	0.1/0.01	0.0	Enabled *2	•/•	-	•	•	6. 39. 1
FB 13	0813	Point 2 setting	0~100%	1/1	100	Enabled *2	•/•		•	•	6. 39. 1
F8 14	0814	Point 2 frequency	0.0~F H Hz	0.1/0.01	60	Enabled *2	•/•		•	•	6. 39. 1
FB 15	0815	Address monitor (Modbus puls)	1~64	1/1	1	*5	•/•	•/•	•	•	£*
8183	0816	Command selection (Modbus puls)	0: Prohibit 1: Permit	1/1	0	Enabled	•/•	•/•	•	•	£*
1183	0817	Number of command (Modbus puls)	8~0	1/1	0	Enabled	•/•	•/•	•	•	*3
8183	0818	Number of monitors (Modbus puls)	0~8	1/1	0	Enabled	•/•	•/•	•	•	£*
6183	0819	Command station (Modbus puls)	0~64	1/1	0	Enabled	•/•	•/•	•	•	£,
6883	0820	Communication speed (4-wire RS485)	0:9600 bps 1:19200 bps 2:38400 bps	1/1	-	Enabled	•/•	•/•	•	•	6. 39. 1
1283	0821	Baud rate (Ethernet)	O:Automatic detection 1:10Mbps Full 3:10Mbps Full 4:100Mbps Full 4:100Mbps Half	1/1	0	Enabled	•/•	•/•	•	•	*
585	0822	Baud rate monitor right port (Ethernet)	0.Automatic detection 1:10Mbps Full 2:10Mbps Half 3:100Mbps Full 4:100Mbps Half	1/1	1	*5	•/•	•/•	•	•	*4
£853	0823	Baud rate monitor left port (Ethernet)	0.Automatic detection 1:10 Mbps Full 3:10Mbps Half 3:100Mbps Full 4:100Mbps Half	1/1	1	\$*	•/•	•/•	•	•	*4
h283	0824	(Reservation)	\$ \$ \$ \$	1/1	0	Enabled	•/•	•/•	•	•	*
*1: ⇒ For c	*1: ⇒ For details, refer to Instru	r to Instruction Manual (E6581315	ction Manual (E6581315) specified in Section 6.42. "2: Effective when a command value is sent by communication.	mmand value	is sent by	communic	ation.				

72: Effective when a commany value is sent by communication.
*4: This function is for Etherenet communication option (planning). ⇒ rol orderists, their on instruction Maintal (Ecoo 1515) specified in Section 25: ⇒ This function is for Modbus plus communication option (planning).
 This parameter is read only.

nmunicat	[29] Communication function [3/4]				Sensorles	s vector/ve	ctor with s	ensor (∙:E	ffective, .	Sensorless vector/vector with sensor (•: Effective, -: Ineffective)
cation No.	Communi cation No.	Adjustment range	Minimum setting unit (Panel/Communi cation)	Default setting	Write during running	Speed Torque control	control Torque control	PM control	VfConstant	Reference
0825	Send waiting time (4-wire RS485)	0.00:Default, 0.01~2.00 sec.	0.01/0.01	00:0	Enabled	•/•	•/•	•	•	6. 39. 1
0826	Inverter-to-inverter communication setting (4-wire RS485)	O:Slave (issues a OHz command if something goes wrong with the master) 1:Slave (continues operation if something goes wrong with the master) 2:Slave (trips for emegaency stop if something goes wrong with the master) 3:Master (sends a frequency command) 5:Master (sends a routput frequency) 5:Master (sends a noutput torque command) 6:Master (sends a noutput torque command)	1/1	0	Enabled	•	•/•	•	•	6. 39. 1
0829	Protocol selection (4-wire RS485)	0:TOSHIBA 1:MODBUS	1/1	0	Enabled	•/•	•/•	•	•	6. 39. 1
0	Communication option setting 1	2~0	1/1	0	Enabled	•/•	•/•	•	•	*1
0831	Communication option setting 2	2 1 1 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2 2	1/1	0000	Enabled	•/•	•/•	•	•	*1
0832	Communication option setting 3	<i>ქ ქ ქ ქ ~</i> 0000	1/1	0000	Enabled	•/•	•/•	•	•	*1
0833	Communication option setting 4	<i>±</i> ± ± ± ± 0000	1/1	0000	Enabled	•/•	•/•	•	•	*1
0834	Communication option setting 5	ララナー	1/1	0000	Enabled	•/•	•/•	•	•	*1
0835	Communication option setting 6	ラ	1/1	0000	Enabled	•/•	•/•	•	•	*1
9	Communication option setting 7	<i>슄 슄 슄 ኅ</i> ~0000	1/1	0000	Enabled	•/•	•/•	•	•	*1
0837	Communication option setting 8	0000 ~ F F F F	1/1	0	Enabled	•/•	•/•	•	•	* *
0838	Communication option setting 9	LLL 00000	1/1	0	Enabled	•/•	•/•	•	•	
- 0	Communication option setting 10		1/1	0000	Enabled	•/•	•/•	•	•	- *
0842	Communication option setting 11	1 1 1 1 1 00000 1 1 1 1 1 1 1 1 1 1 1 1	1/1	0000	Enabled	/	/	•	•	*
2 -	Communication option setting 12	1 1 1 2 0000 2 2 2 2 3 3 0000	1/4	0000	Enabled	,	/-	•	•	*
0845	Communication option setting 13	0000~FFFF	1/1	0000	Fnabled	,	/	•	•	*
0846	Communication option setting 15	00000 F F F F	1/1	0000	Fnabled	•/•	•/•	•	•	*
0847	Communication option setting 16	± ± ± ± ~0000	1/1	0	Enabled	•/•	•/•	•	•	*
0848	Communication option setting 17	0000~FFF	1/1	0	Enabled	•/•	•/•	•	•	*1
0849	Communication2 time-out condition selection	0:Disconnection detection 1:When communication mode enable 2:1+Driving operation	1/1	0	Enabled	•/•	•/•	•	•	*1
0820	Disconnection detection extended time	0.0~100.0 sec.	0.1/0.1	0.0	Enabled	•/•	•/•	•	•	+
0851	Inverter operation at disconnection	O:Inverter stop, communication command, frequency mode open (by $\mathcal{L} \Pi \mathcal{U}_d$, $\mathcal{L} \Pi \mathcal{U}_d$) 1:None (continued operation) 2:Deceleration stop 3:Coast stop 4:Network error ($\mathcal{E}_r \sim \mathcal{B}$ trip) 5:Preset speed operation (by $\mathcal{E} \mathcal{B} \mathcal{E}_d \mathcal{E}_d$ setting) 5:Preset speed operation (by $\mathcal{E} \mathcal{B} \mathcal{E}_d \mathcal{E}_d$ setting)	1/1	0	Enabled	•/•	•/•	•	•	*
0852	Preset speed operation selection	0:None 1~15:Preset speed operation (by parameter setting)	1/1	0	Enabled	•/•	•/•	•	•	*
e.	1: \Rightarrow For details, refer to Instruction Manual (E6581281	uction Manual (E6581281, E6581343) specified in Section 6.42.								

	ī	1	Ī	7
J	u	J	I,	

Sensorless vector/vector with sensor (•: Effective, -: Ineffective)		Reference	*	*	*		6. 39. 1	6. 39. 1	6. 39. 1	6. 39. 1	6. 39. 1	6. 39. 1	6. 39. 1	6. 39. 1	*	
ffective,		V/f Constant	•	•	•		•	•	•	•	•	•	•	•	•	
ensor (∙:E		PM control	•	•	•		•	•	•	•	•	•	•	•	•	
ector with s	control	Torque control	•/•	•/•	•/•		• <u></u>	•/•	*	•/•	•/•	•/•	•/•	•/•	•/•	
ss vector/ve	Vector control	Speed control	•/•	•/•	•/•		*	•/•	.	•/•	•/•	•/•	•/•	•/•	•/•	
Sensorle		Write during running	Enabled	Enabled	Enabled		Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Disabled	
		Default setting	0	0	2		0	0	0	0	0	0	0	0	0	
	Minimum	setting unit (Panel/Communi cation)	1/1	1/1	1/1		1,1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	
		Adjustment range	0~255	0~255	112 Poles, 2:4 Poles 3:6 Poles, 4:8 Poles 5:10 Poles, 6:12 Poles 7:14 Poles, 8:16 Poles	0:Disabled 1:Command information 1 2:Command information 2	3:Frequency command 4:Terminal board output data 5:Communication analog data 6:Rotational speed instruction	Ditto	O'Deselect 1.Status information 2.Output frequency 2.Output frequency 3.Output current 4.Output voltage 5.Alarm information 6.E.D I bedback value 7.Input terminal board monitor 9.V/I/I terminal board monitor 9.V/I/I terminal board monitor 1.F.X ferminal board monitor 1.F.X ferminal board monitor 12.Input voltage (DC detection) 13.Speed feedback frequency 14.Torque 15.MY monitor 1 15.MY monitor 2 17.MY monitor 3 18.MY monitor 3 18.MY monitor 3 18.MY monitor 4 19.Free notes	Ditto	Ditto	Ditto	Ditto	0~6 6 6 6	0:None 1:Reset option circuit board and inverter	*1: \Rightarrow For details, refer to Instruction Manual (E6581281, E6581343, E6581476) specified in Section 6.42.
[29] Communication function [4/4]		Function	Communication option station address monitor	Communication option speed switch monitor DeviceNet/CC-Link	Motor pairs of poles for communication		Block write data 1	Block write data 2	Block read data 1	Block read data 2	Block read data 3		Block read data 5	Free notes	Network option reset setting	er to Instruction Manual (E6581281
munication	Communi	cation No.	6280	0854	0856		0870	1280	0875	9280	2280	0878	6280	0880	6680	letails, refe
[29] Com		Title	E583	F854	F855	!	10 10 10 10 10 10 10 10 10 10 10 10 10 1	1183	5875	5683	F833	F818	6183	F880	F839	*1: ⇒ For c

Sensorless vector/vector with sensor (e:Effective, -:Ineffective)		///Constant Reference	2	
ffective, .		VfConstart	•	
nsor (∙:E		PM control	•	
ector with se	control	Torque control	••	
ss vector/ve	Vector contro	Speed	•/•	
Sensorles		Write during running	Disabled	
		Default setting	0	
	Minimum	setting unit (Panel/Communi cation)	7-	
		Adjustment range	l'input terminal function number Debsellect 1: F terminal 3:ST terminal 4:RES terminal 5:SS terminal 6:SS terminal 7:SS terminal 7:SS terminal 10:LL2 terminal 11:LL3 terminal 11:LL3 terminal 12:LL4 terminal 12:LL4 terminal 12:LL5 terminal 12:LL5 terminal 12:LL5 terminal 12:LL5 terminal 12:LL5 terminal 13:LL5 terminal 14:LES terminal 17:BL2 terminal 17:BL3 terminal 17:BL3 terminal 17:BL3 terminal 17:BL4 terminal 18:BL3 terminal 18:BL3 terminal 18:BL3 terminal 18:BL3 terminal 18:BL3 terminal 18:BL3 terminal 10:C-BL5 terminal 20:BL5 termin	tion Manual (E6581335) specified in Section 6.42.
		Function	Input function target 11	to Instruction Manual (E6581335
[30] My function [1/5]	Communi	cation No.	0060	etails, refer
[30] My fu		Title	F 9 0 0	*1: ⇒ For details, refer to Instruct

[30] My f	[30] My function [2/5]	5]				Sensorle	ss vector/v	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)	ensor (∙:E	ffective,	:Ineffective)
	Communi			Minimum			Vector control	control			
Title	cation No.	Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed	Torque control	PM control	V/fConstant	Reference
F 9 0 1	0901	Input function command 12	1.5T (move) 2.5TN 2.5TN 2.5TN 2.5TN 2.5TN 2.5TN 3.7AND (logical product) 4.7ANDN 3.7EO (equal) 3.7EO (equal) 3.7EO (equal) 4.1TT (less than) 1.1T (less than) 1.4.7ADUB (absolute) 1.7COUNTR 2 (counter 1) 1.7COUNTR 2 (counter 2) 1.8:HOLD (hold) 1.9:SET (seet) 2.1CLR 2.2CRESET (reset) 2.2TR	1/1	0	Disabled	•/•	•/•	•	•	2-
£305	0902	Input function target 12	Same as F 900	1/1	0	Disabled	•/•	•/•	•	•	*1
F303	6060	Input function command 13	Same as <i>F 9 0.1</i>	1/1	0	Disabled	•/•	•/•	•	•	*1
4063	0904	Input function target 13	Same as F 900	1/1	0	Disabled	•/•	•/•	•	•	*1
F905	9060	Output function assigned object 1	Same as F 900	1/1	0	Disabled	•/•	•/•	•	•	*
F905	9060	Input function target 21	Same as F 900	1/1	0	Disabled	•/•	•/•	•	•	*1
F907	2060	Input function command 22	Same as F g 🖟 /	1/1	0	Disabled	•/•	•/•	•	•	*
8063	8060	Input function target 22	Same as F 900	1/1	0	Disabled	•/•	•/•	•	•	*1
6063	6060	Input function command 23	Same as <i>F 9 🛭 !</i>	1/1	0	Disabled	•/•	•/•	•	•	*
0163	0910	Input function target 23	Same as F 900	1/1	0	Disabled	•/•	·/•	•	•	*1
1181	0911	Output function assigned object 2	Same as F 900	1/1	0	Disabled	•/•	•/•	•	•	*1
5161	0912	Input function target 31	Same as F 900	1/1	0	Disabled	•/•	•/•	•	•	*
F3 13	0913	Input function command 32	Same as <i>F 9 0.1</i>	1/1	0	Disabled	•/•	•/•	•	•	*1
68 14°	0914	Input function target 32	Same as F 9 $\!$	1/1	0	Disabled	•/•	•/•	•	•	*
*1: ⇒ For c	details, refe	*1: \Rightarrow For details, refer to Instruction Manual (E6581335) specified in Section 6.42.) specified in Section 6.42.								

€							_						_																_				_		
Sensorless vector/vector with sensor (•:Effective, -:Ineffective)		Reference	*1	*1	*	*1	*1	*	*	*	*	*1	*1	*	*1	*1	*1	*1	*1	*	*1	*1	*1	*1	*1	*1	*1	*	*1	*	*	*	*	*	*1
ffective,		V/fConstant	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
sensor (∙:E	N	control	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
ector with s	control	Torque control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
ss vector/ve	Vector control	Speed control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
Sensorle	Maito dining	write during running	Disabled	Disabled	Disabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled
	11.040	Setting	0	0	0	0.00	0.00	0.00	0.00	0.00	0.0	0.0	0.0	0.0	0.0	0.01	0.01	0.01	0.01	0.01	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
	Minimum	setting unit (Panel/Communi cation)	1/1	1/1	1/1	0.01/0.01	0.01/0.01	0.01/0.01	0.01/0.01	0.01/0.01	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.1/0.1	0.01/0.01	0.01/0.01	0.01/0.01	0.01/0.01	0.01/0.01	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1
		Adjustment range	Same as F 9 0 1	Same as F 900	Same as F 9 \Box \Box	0.00~200.0%	0.00~200.0%	0.00~200.0%	0.00~200.0%	0.00~200.0%	0.0~500.0Hz	0.0~500.0Hz	0.0~500.0Hz	0.0~500.0Hz	0.0~500.0Hz	0.01~600.0sec	0.01~600.0sec	0.01~600.0sec	0.01~600.0sec	0.01~600.0sec	0~9999 times	0~9999 times	Same as F 900	Same as <i>F 9 🛭 1</i>	Same as F 9 III	Same as <i>F 9 🛭 1</i>	Same as F 900	Same as F 9 Ω	Same as F 900	Same as <i>F 9 0.</i> /	Same as F 9 Ω Ω	Same as <i>F 9 🛭 1</i>		Same as F 9 \Box \Box	Same as F 900
1]		Function	Input function command 33	Input function target 33	Output function assigned object 3	My output percent data 1	My output percent data 2	My output percent data 3	My output percent data 4	My output percent data 5	My output frequency data 1	My output frequency data 2		My output frequency data 4	My output frequency data 5	-		My output time data 3	My output time data 4	My output time data 5	No. of times of My output data 1	No. of times of My output data 2	Input function target 41	Input function command 42	Input function target 42	Input function command 43	Input function target 43	Output function assigned object 4	Input function target 51	Input function command 52	Input function target 52	Input function command 53	Input function target 53	Output function assigned object 5	Output function target 61
[30] My function [3/5]	Communi	cation No.	0915	0916	0917	0918	0919	0920	0921	0922	0923	0924	0925	0926	0927	0928	0929	0830	0931	0932	0933	0934	0935	0936	0937	0938	0939	0940	0941	0942	0943	0944	0945	0946	0947
[30] My fu		Title	5163	F9 18	1181	8161	F3 13	0263	1263	£355	E263	6354	F 925	F 9 2 6	1253	F 928	F 9 2 9	F 930	1663	£835	F833	7534	5863	9863	1663	£838	6863	0463	1 454	2463	E 4 6 3	hh63	5454	8483	6883

^{1:} \Rightarrow For details refer to the Instruction Manual (E6581335) for this parar

Sensorless vector/vector with sensor (e:Effective, -:Ineffective)		Reference	*1	*1	*1	*1	۲*	*1	*1	٠,1	*1	*1	*	*	*
ffective,		Vif Constant	•	•	•	•	•	•	•	•	•	•	•	•	•
ensor (∙:E		PM control	•	•	•	•	•	•	•	•	•	•	•	•	•
ector with s	control	Torque control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
ss vector/ve	Vector control	Speed	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
Sensorle		Write during running	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Enabled	Disabled
		Default setting	0	0	0	0	0	0	0	0	0	0	0	0	0
	Minimum	setting unit (Panel/Communi cation)	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1	1/1
		Adjustment range	Same as <i>F 9 🛭 1</i>	Same as F 900	Same as <i>F 9 \mathcal{D}_1</i>	Same as F 900	Same as F 900	Same as F 9 Ω	Same as F 9 0 1	Same as F 9 Ω	Same as <i>F 9 0.1</i>	Same as F 9 Ω	Same as $F g \varOmega g$	0.Disabled 1.1V/III 2.RR/54 3.RX 4.Optional A1+, Optional A11- 5.Toptional A12 6.Internal memory	(0.D)sables of the control of the c
5]		Function	Input function command 62	Input function target 62	Input function command 63		Output function assigned object 6	Input function target 71	d 72	Input function target 72	Input function command 73	ion target 73	Output function assigned object 7	Analog input function target 11	Analog function assigned object
[30] My function [4/5]	Commini	cation No.	0948	0949	0980		0952	0953	0954	9960	9560	2960	8560	6960	0961
[30] My f		Title	8463	F349	F950	1583	£385	F353	F954	F355	F956	F 357	8583	£353	F 9 6 1

 $^*\text{1:} \Rightarrow \text{For details}, \text{ refer to Instruction Manual (E6581335) specified in Section 6.42.}$

$_{\odot}$	[30] My function [5/5]					Sensorle	ss vector/v	ector with s	sensor (•:E	-tective, -	Sensorless vector/vector with sensor (•:Effective, -:Ineffective)
, mu	iun			Minimum			Vector control	control	i		
cation No.		Function	Adjustment range	setting unit (Panel/Communi cation)	Default setting	Write during running	Speed control	Torque control	control	V/fConstant	Reference
0962	2	Analog input function target 21	0:Disabled 1:V/III 2:RRVS4 3:RX	1/1	0	Enabled	*/•	•/•	•	•	*
		-	4:Optional Al1+, Optional Al1- 5:Optional Al2 6:Internal memorv2								
ő	0964	Analog function assigned object 21		1/1	0	Disabled	•/•	•/•	•	•	*
ő	0965	Monitor output function target 11	2000~2099;FD00~FD99 3000~3099;FE00~FE99	1/1	2000	Enabled	•/•	•/•	•	•	*
ő	9960	Monitor output function command 11	0:Normal monitor, 1:Max. value, 2:Min. value	1/1	0	Enabled	•/•	•/•	•	•	*
ő	2960	Monitor output function target 21	2000~2099;FD00~FD99 3000~3099;FE00~FE99	1/1	2000	Enabled	•/•	•/•	•	•	*
ő	8960	Monitor output function command 21	0:Normal monitor, 1:Max. value, 2:Min. value	1/1	0	Enabled	•/•	•/•	•	•	*
ő	6960	Monitor output function target 31	2000-2099;FD00-FD99 3000-3099;FE00-FE99	1/1	2000	Enabled	•/•	•/•	•	•	*
ő	0260	Monitor output function command 31	0:Normal monitor, 1:Max. value, 2:Min. value	1/1	0	Enabled	•/•	•/•	•	•	*
ö	0971	Monitor output function target 41	2000~2099;FD00~FD99 3000~3099;FE00~FE99	1/1	2000	Enabled	•/•	•/•	•	•	*
0	0972	Monitor output function command 41	0:Normal monitor, 1:Max. value, 2:Min. value	1/1	0	Enabled	•/•	•/•	•	•	*
0	0973	Virtual input terminal selection 1	0~135 *2	1/1	0	Disabled	•/•	•/•	•	•	*1
0	0974	Virtual input terminal selection 2	0~135 *2	1/1	0	Disabled	•/•	•/•	•	•	*1
0	0975	Virtual input terminal selection 3		1/1	0	Disabled	•/•	•/•	•	•	*1
ö	976	Virtual input terminal selection 4	0~135 *2	1/1	0	Disabled	•/•	•/•	•	•	*1
ő	2260	My function selection	0:Disabled 1:My function + permission signal 2:My function always ON	1/1	0	Disabled	•/•	•/•	•	•	*
4	ile refe	*1: - For details refer to lostruction Manual (E6581335	rdion Manual (ERSR1335) snacified in Saction 6.42 **2. — For the adjuistment range see the table on nage K.44	ant range see	aldet adt	У орси по	-41				

[31] Travenirse function

Sensorless vector/vector with sensor (•:Effective, -:Ineffective)

	00000			Minimum			Vector control	control			
Title	cation No.	Function	Adjustment range	setting unit Default M (Panel/Communi setting cation)	Default setting	Write during running	Speed control	Torque control	PM control	V/f Constant	PM VfCansant Reference
6883	0860	Traverse selection	0:Disabled 1:Enabled	1/1	0	Disabled	•/•	-	•	•	*
1863	0981	Traverse acceleration time	0.1~120.0 sec.	0.1/0.1	25.0	Enabled	•/•	-	•	•	*
₹885	0982	Traverse deceleration time	0.1~120.0 sec.	0.1/0.1	25.0	Enabled	•/•	-	•	•	*1
E863	0983	Traverse step	0.0~25.0%	0.1/0.1	10.0 E	Enabled	•/•	-	•	•	*1
7984	0984	Traverse jump step	0.0~20.0%	0.1/0.1	10.0 Enabled	Enabled	•/•		•	•	*1

 $^{^*1}$: \Rightarrow For details, refer to Instruction Manual (E6581337) specified in Section 6.42.

S	[Contents of monitor displays]				•	Sellsoliess v	ector/vector	Sensoriess vector/vector with sensor (•: valid, -: Invalid)	• valid, - I	(pila)
Communi ation No.	Function	Unit (Commun ication)	Monitor output selection	Trip retention	Meter output selection	Speed	Torque control	PM control	V/f	Reference
Š	Standard monitor		0113			*				
ıts c	Contents of status monitor display									
۵	Pattern operation group selection		at a pattern operation	0		•/•		•	•	
Žά	Number of times to repeat current pattern	1	at a pattern operation	0		•/•	,	•	•	
g, g	Pattern operation - number of preset speeds	٢	at a pattern operation	0	,	•/•		•	•	
호형	Remaining time of current pattern operation	-	at a pattern operation	0		•/•		•	•	
Š	Status (rotation direction)		Pixed	0	-	•/•	•/•	•	•	
Š	Status monitor 1		1114			*				
Š	Status monitor 2	-	2114			۰. ۱				
Š	Status monitor 3		F113			* 1				
Š	Status monitor 4		F714			* 1				
Š	Status monitor 5		F715			*				0
Š	Status monitor 6		F 7 15			* 1				8.2.1
છ	Status monitor 7	-	F717			* 1				
Š	Status monitor 8		F7:18			*				
0	Output frequency monitor	0.01Hz	when tripped	when tripped		•/•	•	•	•	
⊆ .	Input terminal information		Fixed	0	'	•/•	•/•	•	•	
₽.	Input terminal information (optional)	-	Fixed	0		•/•	•/•	•	•	
_	Input terminal information (optional)		Fixed	0		•/•	•/•	•	•	
FE07 O	Output terminal information		Fixed	0		•/•	•/•	•	•	
-	Output terminal information (optional)		Fixed	0		•/•	•/•	•	•	
FE08 CF	CPU1 version	_	Fixed	×		•/•	•/•	•	•	
FE73 CF	CPU2 version		Fixed	×		•/•	•/•	•	•	
FE10 Pa	Past trip 1	-	Fixed	×	-	•/•	•/•	•	•	
ď	Past trip 2		Pixed	×	-	•/•	•/•	•	•	
FE12 Pa	Past trip 3	,	Fixed	×		•/•	•/•	•	•	
Ą	Past trip 4	-	Fixed	×		•/•	•/•	•	•	
FE79 Pa	Part replacement alarm information	-	Fixed	×	-	•/•	•/•	•	•	
FF14 Ci	Cumulative operation time	1h	Fixed	×		•/•	•/•	•	•	

ivaliu)	Reference																4.00	ς, α 2 κ	?														
. valu, .	V/f	•	•	•	•	•	•	-		•*2		•*2	•*2	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Total	PM control	•	•	•	•	•	•			•	-			•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Toron Control	control	•/•		•/•	•/•	•/•	•/•	•/-	•/-	•/•	•/•	•/•	-/•		•/•	-/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	-/•	-/•	•/•	•/•	•/•	·•
0	control	•/•	•/•	•/•	•/•	•/•	•/•	•/-	•/-	•/•		•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•
	Trip retention	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	×	×	×	×	×	×	×	×	×	×	×	×	×
Unit	(Communicat ion)	0.01Hz	0.01Hz	0.01%	0.01%	0.01%	0.01Hz	0.01Hz	0.01Hz	0.01%	0.01%	0.01%	0.01%	0.01Hz	0.01%	0.01%	1%	1%	0.01kW	0.01kW	0.01%	0.01%	0.01%	0.01%	0.01%	0.01	0.01	0.01%	-	0.01%	0.01%	-	
	Function	Output frequency	Frequency command value	Output current	Input voltage (DC detection)	Output voltage	Compensated frequency	Speed feedback (real-time value) *1	Speed feedback (1-second filter) *1	Torque	Torque command	Torque current	Exciting current	PID feedback value	Motor overload factor (OL2 data)	Inverter overload factor (OL1 data)	Regenerative braking resistance overload factor (OLr data)	Regenerative braking resistor load factor (% ED)	Input power	Output power	Optional AI2 input	RR/S4 input	VI/II input	RX input	Optional A11 input	FM output	AM output	Fixed output 1	Communication data output	Fixed output 2	Fixed output 3	Attached to expansion I/O card 1 CPU version	Attached to expansion I/O card 2 CPU version
onitor output	Communicati on No.	FE00	FE02	FE03	FE04	FE05	FE15	FE16	FE17	FE18	FE19	FE20	FE21	FE22	FE23	FE24	FE25	FE28	FE29	FE30	FE39	FE35	FE36	FE37	FE38	FE40	FE41					FE66	FE67
Monitor	Option No.	0	1	2	3	4	2	9	7	8	6	11	12	13	14	15	16	17	18	19	23	24	25	26	27	28	29					32	33
se output	Communicati on No.	FD00	FD02	FD03	FD04	FD05	FD15	FD16	FD17	FD18	FD19	FD20	FD21	FD22	FD23	FD24	FD25	FD28	FD29	FD30	FE39	FE35	FE36	FE37	FE38	FE40	FE41	FE51	FA51 *3	FE50	FE52		
FM/AM/pulse output Monitor output	Option No.	0	1	2	3	4	5	9	7	8	6	11	12	13	14	15	16	17	18	19	23	24	25	26	27	28	29	30	31	32	33	-	

1: Estimated speed is output it titlete is to the treatback. It used as purse input comments with the treatback operation, incurrently.

*2: Reference data

*3: Communication no. FA51 is used for FM, FA52 for AM, FA53 for MON1 and FA54 for MON2 and pulse output, respectively,

⇒ For details, refer to Section 5.16; [Terminal FM-related parameters].

⇒ For monitor indications, refer to Section 8.3; [Set up values of monitor indication parameters].

Monitor FM	//AM/pulse	Monitor FM/AM/pulse output function selection (2/3)]	on selection	(2/3)]			Ø	ensorless vecto	Sensorless vector/vector with sensor (•: valid, -: invalid)	ensor (•: valid,	-: invalid)
FM/AM/pu	FM/AM/pulse output	Monitor output	output	:	Unit						
Option No.	Communicati on No.	Option No.	Communicati on No.	Function	(Communicat Trip retention ion)	Trip retention	Speed control	Torque control	PM control	V/f	Reference
8	FE76	8	FE76	Integral input power	Depends on F 7 4 9	×	•/•	•/•	•	•	
35	FE77	32	FE77	Integral output power	Depends on ドア49	×	•/•	•/•	•	•	
45	0006 *3 0671 *4			Gain display	-		•,	•,	•	•	
46	FE60	-		My function monitor 1 (Output of unsigned value)	-	×	•/•	•/•	•	•	
47	FE61			My function monitor 2 (Output of unsigned value)	1	×	•/•	•/•	•	•	
48	FE62			My function monitor 3 (Output of signed value) *2	1	×	•/•	•/•	•	•	
49	FE63		-	My function monitor 4 (Output of signed value) *2	1	×	•/•	•/•	•	•	
20	FD00	20	FE00	Signed output frequency *5	0.01Hz	0	•/•	•/•	•	•	
51	FD02	51	FE02	Signed frequency command value *5	0.01Hz	0	•/•	-	•	•	
52	FD15	52	FE15	Signed compensated frequency *5	0.01Hz	0	•/•	•/•	•	•	
53	FD16	53	FE16	Signed speed feedback (real-time value)*5	0.01Hz	0	•/-	•/-	-	-	
54	FD17	54	FE17	Signed speed feedback (1-second filter) *5	0.01Hz	0	•/-	•/-	-		5.16
22	FD18	22	FE18	Signed torque *5	0.01%	0	•/•	•/•	•	•*1	8.3
26	FD19	99	FE19	Signed torque command *5	0.01%	0	-	•/•	-	-	
28	FD20	28	FE20	Signed torque current *5	0.01%	0	•/•	•/•	-	• *1	
29	FD22	69	FE22	Signed PID feedback value *5	0.01	0	•/•	-	•	•	
09	FE37	09	FE37	Signed RX input *5	0.01%	×	•/•	•/•	•	•	
61	FE38	61	FE38	Signed optional AI1 input *5	0.01%	×	•/•	•/•	•	•	
62	FE51	-		Signed fixed output 1	-	×	•/•	•/•	•	•	
63	FE50	-		Signed fixed output 2	-	×	•/•	•/•	•	•	
64	FE52	-		Signed fixed output 3	-	×	•/•	•/•	•	•	
		64	FD50	Light-load high-speed load torque monitor 1	0.01%	×	•/•	•/•	•	•	
-		92	FD51	Light-load high-speed load torque monitor 2	0.01%	×	•/•	•/•	•	•	
		99	FE31	Pattern operation group number	0.1	×	•/•	-	•	•	
		67	FE32	Remaining no. of cycles for which	-	>	•/•	,	•	•	
1		5	- 102	pattern operation is continued	-	۲	2 /2		•	•	
		68	FE33	Pattern operation preset speed numbers	1	×	•/•	-	•	•	
•	•	69	FE34	Remaining time for which pattern operation is continued	0.1	×	•/•	1	•	•	
*1. Reference data		*2. An absolut	o si enlev et	becliffe value is outful for pulse train outful of 48 and 49	*3. Comminic	*3. Communication no for EM output		Comminication	*4. Communication no for AM output	fourt	

*5: If a negative value is specified, the negative sign "" is displayed. When read through by communications device, the negative sign is affixed only FE18-FE20, FE37 and FE38 values. \Rightarrow For monitor indications, refer to Section 8.3; [Set up values of monitor indication parameters]. *4: Communication no. for AM output *3: Communication no. for FM output *2: An absolute value is output for pulse train output of 48 and 49. ⇒ For details, refer to Section 5.16; [Terminal FM-related parameters]. *1: Reference data

1														1
-: invalid)	, -	Keterence					5.16	8.3						
nsor (•: valid,	****	V/†	•	•	•	•	•	•	•	•	•	•	•	
or/vector with se		PM control	•	•	•	•	•	•	•	•	•	•	•	
Sensorless vector/vector with sensor (•: valid, -: invalid)		lorque control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•			
S		(Communicat Inp retention Speed control ion)	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	
		Irip retention	×	×	×	×	×	×	×	×	×	×	0	
	Unit	(Communicat ion)	0.1	1	1	1	0.01%	0.01%	0.01%	1	1	0.1/0.01	0.1/0.01	
(3/3)]	:	Function	Rated voltage	Rotational speed	Communication option Reception counter	Communication option Abnormal counter	MON1	MON2	RP	COUNT1	COUNT2	PID result frequency	Synchronous speed Frequency command	7. F. 40. TEL
Monitor FM/AM/pulse output function selection (3/3)]	Monitor output	Communicati on No.	FE71	FE90	FA15	FA16	FE43	FE44	FE56	FD85 (FD86	FD52	FE84	T I a si con a L
utput functi	Monito	Option No.	0/	1.4	7.5	23	74	92	92	<i>LL</i>	82	6/	08	
/AM/pulse o	lse output	Communicati on No.					FE43	FE44	FE56					0 -1 1
[Monitor FM	FM/AM/pulse output	Option No.					74	75	9/					the Contractor of the Contractor

 \Rightarrow For details, refer to Section 5.16; [Terminal FM-related parameters]. \Rightarrow For monitor indications, refer to Section 8.3; [Set up values of monitor indication parameters].

[Input termi	inal functic	[Input terminal function setting (1/2)]			Senso	orless vector/	Sensorless vector/vector with sensor (•: valid, -: invalid)	nsor (∙: valid, -	: invalid)
Positive Negative logic	Negative logic	Function	Speed control	Torque control	PM control	V/f	1=0003	1=901 3	Reference
0	1	No function is assigned	•/•	•/•	•	•		-	
2	3	F: Forward run command	•/•	•/•	•	•	•		
4	2	R: Reverse run command	•/•	•/•	•	•	•	,	
9	7	ST: Standby	•/•	•/•	•	•	١.		
8	6	RES: Reset	•/•	•/•	•	•	*2		
10	11	S1: Preset speed 1	•/•		•	•	•		
12	13	S2: Preset speed 2	•/•	-	•	•	•		
14	15	S3: Preset speed 3	•/•	-	•	•	•		
16	17	S4: Preset speed 4	•/•	-	•	•	•		
18	19	Jog run	•/•	-	•	•	•	•	
20	21	Emergency stop	•/•	•/•	•	•	*2	,	
22	23	DC braking	•/•		•	•	•	•	
24		Acceleration/deceleration switching 1	•/•		•	•	•		
56	27	Acceleration/deceleration switching 2	•/•		•	•	•		
28	29	V/f switching signal 1	•/•		•	•	•		
30	31	V/f switching signal 2	•/•		•	•	•		
32	33	Torque limit switching signal 1	•/•	•/•	•	•	•		
34	32	Torque limit switching signal 2	•/•	•/•	•	•	•	,	7 2 4
36	37	PID control OFF selection	•/•		•	•	•		1.5.7
38	39	Pattern operation selection 1	•/•		•	•	•		
40	41	Pattern operation selection 2	•/•		•	•	•		
42	43	Pattern operation continuation signal	•/•		•	•	•		
44	45	Pattern operation trigger signal	•/•		•	•	•		
46	47	External thermal error	•/•		•	•	•		
48	49	Communication priority cancel	•/•		•	•	•		
90	51	Holding of HD operation (stop of three-wire operation)	•/•	-	•	•	•		
52		PID differentiation/integration reset	•/•	-	•	•	•		
54	22	PID forward/reverse switching	•/•		•	•	•		
26	22	Forced continuous operation	•/•		•	•	•		
28	69	Specified speed operation	•/•		•	•	•		
09	61	Acceleration/deceleration suspend signal	•/•		•	•	•	,	
62	63	Power failure synchronized signal	•/•	-	•	•	•		
64	65	My function RUN signal	•/•	•/•	•	•	•		
99		Auto-tuning signal	•/•	-	•	•	•		
89	69	Speed gain switching	•/•		•	•	•		
*1: Valid any time	ıv time								

^{*1:} Valid any time *2: Independent of $\vec{L} \; \vec{H} \; \vec{G} \; \vec{d}$, and all command are valid.

Input term	inal funct	Input terminal function setting (2/2)]			Sens	orless vector/	Sensorless vector/vector with sensor (•: valid, -: invalid)	sor (•: valid, -	: invalid)
Positive logic	Negative logic	Function	Speed control	Torque control	PM control	\/\f	1=0003	f 105=1	Reference
20	71	Servo lock signal	•/•		•	•	•	-	
72	73	Simple positioning (positioning loop)	•/•		•	•	•		
74	22	Integrating wattmeter display clear	•/•		•	•	•		
9/	2.2	Trace back trigger signal	•/•		•	•	•		
78	62	Light-load high-speed operation prohibitive signal	•/•	-	•	•	•		
98	87	Binary data write	•/•	•/•	•	•	•		
88	88	Up/Down frequency (up)*1	•/•		•	•	•		
06	91	Up/Down frequency (down)*1	•/•		•	•	•		
95	63	Up/Down frequency (clear)	•/•		•	•	•		
94	92	Dancer Correction OFF	•/•		•	•	•		
86	66	Forward/reverse selection	•/•	•/•	•	•	•		
100	101	Run/Stop command	•/•	•/•	•	•	•		7.2.1
102	103	Commercial power/INV switching	•/•		•	•	•		
104	105	Frequency reference priority switching	•/•		•	•	•		
106	107	VI/II terminal priority	•/•		•	•	•		
108	109	Command terminal board priority	•/•	•/•	•	•	•		
110	111	Parameter editing enabling	•/•	•/•	•	•	•		
112	113	Speed/Torque switching	•/•	•/•	-	-	*2	-	
122	123	Rapidest deceleration command	•/•	-	•	•	•	-	
124	125	Preliminary excitation	•/•	•/•	•	•	•		
126	127	Braking request	•/•		•	•	•		
130	131	Brake answer back input	•/•	-	•	•	•	-	
134	135	Traverse permission signal	•/•		•	•	•		

**: The deceleration/deceleration time depends on the RLL/dEL setting, unless switching between acceleration and deceleration is performed.

*2: Dependent on [] [] [] d.

Output ter	rminal fun	[Output terminal function setting (1/3)]		Sensorless v	Sensorless vector/vector with sensor (•: valid, -: invalid)	ı sensor (∙: vali	d, -: invalid)
Positive logic	Negative Iogic	Function	Speed control	Torque control	PM control	V/f	Reference
0	1	П	•/•	•/•	•	•	
2	3	UL	•/•	•/•	•	•	
4	2	LOW	•/•	•/•	•	•	
9	7	Acceleration/deceleration completion	•/•	-	•	•	
8	6	Specified speed arrival	•/•	•/•	•	•	
10	11	Failure FL (all trip)	•/•	•/•	•	•	
12	13	Failure FL (except for EF, OCL, EPHO and OL2)	•/•	•/•	•	•	
14	15	Overcurrent pre-alarm	•/•	•/•	•	•	
16	17	Inverter overload pre-alarm	•/•	•/•	•	•	
18	19	Motor overload pre-alarm	•/•	•/•	•	•	
20	21	Overheat pre-alarm	•/•	•/•	•	•	
22	23	Overvoltage pre-alarm	•/•	•/•	•	•	
24	25	Main circuit undervoltage alarm	•/•	•/•	•	•	
26	27	Low current alarm	•/•	•/•	•	•	
28	58	Overtorque alarm	•/•	•/•	•	•	
30	31	Braking resistor overload pre-alarm	•/•	•/•	•	•	
32	33	In emergency stop	•/•	•/•	•	•	
34	32	In course of retry	•/•	•/•	•	•	
36	37	Pattern operation switching output	•/•	-	•	•	
38	39	PID deviation limit	•/•	-	•	•	7.2.2
40	41	Run/Stop	•/•	•/•	•	•	
42	43	Serious failure (OCA, OCL, EF, phase failure, etc.)	•/•	•/•	•	•	
44	45	Light failure (OL, OC1, 2, 3, OP)	•/•	•/•	•	•	
46	47	Commercial/INV switching output 1 (for inverter operation output)	•/•		•	•	
48	49	Commercial/INV switching output 2 (for commercial operation output)	•/•		•	•	
20	51	Cooling fan ON/OFF	•/•	•/•	•	•	
52	23	In Jog run	•/•	-	•	•	
54	22	Panel operation/terminal board operation switching	•/•	•/•	•	•	
26	22	Cumulative operation time alarm	•/•	•/•	•	•	
28	69	PROFIBUS/DeviceNet/CC-Link communication error	•/•	•/•	•	•	
09	61	Forward/reverse run	•/•	•/•	•	•	
62	63	Ready for operation 1	•/•	•/•	•	•	
64	92	Ready for operation 2	•/•	•/•	•	•	
89	69	Braking release signal	•/•		•	•	
70	71	In (pre-)alarm status	•/•	•/•	•	•	
72	73	Forward speed limit (torque control)		•/•		-	
74	75	Reverse speed limit (torque control)		•/•		-	

lid, -: invalid)	Reference																				722	4:4:											ı							
sensor (●: va	V/f	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	-	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
Sensorless vector/vector with sensor (•: valid, -: invalid)	PM control	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	-	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	
Sensorless v	Torque control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	-/-	-/-	•/•	•/•	•/•	-/-	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	+	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	-/-
	Speed control	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	-/-	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•,	•/•	•/•	•/•	•/•	•/•	•/•	•/•	•/•	-/-
Output terminal function setting (2/3)]	Function	Inverter healthy output	RS485 communication error	Error code output 1 (6-bit output)	Error code output 2 (6-bit output)	Error code output 3 (6-bit output)	Error code output 4 (6-bit output)	Error code output 5 (6-bit output)	Error code output 6 (6-bit output)	Designated data output 1 (7-bit output)	Designated data output 2 (7-bit output)	Designated data output 3 (7-bit output)	Designated data output 4 (7-bit output)	Designated data output 5 (7-bit output)	Designated data output 6 (7-bit output)	Designated data output 7 (7-bit output)	Light load signal	Heavy load signal	Positive torque limit	Negative torque limit	Output for external rush suppression relay	Completion of stop positioning (for simple positioning)	L-STOP	Power failure synchronized operation	Traverse motion	Traverse deceleration in progress	Part replacement alarm	Overtorque pre-alarm	Operation frequency command 1/2 selection	Failure FL (except emergency stop)	Motor oscillation contro1 (VFA7 Compatibility)	My function output 1	My function output 2	My function output 3	My function output 4	My function output 5	My function output 6	My function output 7	My function output 8	My finaction quitaint 0
minal func	Positive Negative logic	77	29	81	83	85	87	88	91	93	92	6	66	101	103	105	107	109	111	113	115	119	121	123	125	127		131	133	135	165	223	225	227	229	231	233	235	237	000
[Output ter	Positive logic	9/	78	80	82	84	98	88	06	92	94	96	86	100	102	104	106	108	110	112	114	118	120	122	124	126	128	130	132	134	164	222	224	226	228	230	232	234	236	238

10	1	ľ	1
•	Л	v	1

Output ter	rminal func	[Output terminal function setting 3/3]		Sensorless	Sensorless vector/vector with sensor (•: valid, -: invalid)	וsensor (●: valic	d, ∹ invalid)
Positive logic	Negative Iogic	Function	Speed control	Speed control Torque control PM control	PM control	V/f	Reference
240	241	My function output 10	•/•	•/•	•	•	
242	243	My function output 11	•/•	•/•	•	•	
244	245	My function output 12	•/•	•/•	•	•	
246	247	My function output 13	•/•	•/•	•	•	700
248	249	My function output 14	•/•	•/•	•	•	7:7:
250	251 N	My function output 15	•/•	•/•	•	•	
252	253	My function output 16	•/•	•/•	•	•	
254	255	255 Always OFF (for terminal signal tests)	•/•	•/•	•	•	

Standard default settings cl	ttings classi	fied by inve	assified by inverter model (capacity)	capacity)											
Inverter type		Base frequency voltage F 7 F 7 F 7	4 @WWW	PW	Dynamic braking resistance P b r	Allowable continuous braking resistance	Inverter side switching waiting time F355	Motor rated capacity F 4 0 5	Motor rated current F 405	Motor rated rotational speed F 40 7	Motor constant 1 (torque boost) F Y 1 (1)	Motor constant 2 (no load current) F 4 1 1	Motor constant 3 (leak inductance) £ 4 1,2	Motor constant 4 (rated slip) £ 4 13	Display unit selection for integral output power
VFAS1-2004PL	8:0	082	0.01	0.21	2000	0.12	7.50	0.40	0.5	0891	3.8	19	021	19.9	O
VFAS1-2007PL	8.0	230	0.01	0.51	2000	0.12	7.50	0.75	3.4	0691	7.3	45	001	11.9	O
VFAS1-2015PL	0.9	230	0.07	12.0	0.57	0.12	7.50	1.50	5.5	0691	1.1	5 %	ΩL	11.9	0
VFAS1-2022PL	0.9	230	0.07	12.0	75.0	0.12	7.50	2.20	8.9	0891	5.9	1 5	Gι	5.57	O
VFAS1-2037PL	0.9	230	0.07	12.0	0.07	0.15	7.9.0	3.70	8.41	0691	4.9	38	08	11.3	1
VFAS1-2055PL	D'h	230	0.01	0.51	0.02	0.24	0.87	5.50	0.15	0811	3.9	ьE	Oι	58€	,
VFAS1-2075PL	O'h	230	10.0	12.0	15.0	0.44	0.87	7.50	28.2	0611	3.4	33	20	3.89	1
VFAS1-2110PM	3.0	082	0.07	12.0	0.07	0.55	1.0.1	1.1.0	9.0%	0611	5.8	12	03	58€	1
VFAS1-2150PM	3.0	230	0.07	12.0	7.5	0.88	1.0.1	15.0	54.5	0611	2.5	7.2	09	68.€	1
VFAS1-2185PM	3.0	230	30.0	0. h	7.5	0.88	1.37	18.5	0.89	0511	5.5	63	a.	81.5	1
VFAS1-2220PM	3.0	230	30.0	0.4	3.3	1.75	1.37	0.22	0.08	0511	5.4	12	Oι	81.5	,
VFAS1-2300PM	3.0	230	30.0	0.4	3.3	1.75	1.37	30.0	0.801	5461	5.5	92	Oι	90'€	,
VFAS1-2370PM	3.0	230	30.0	O.P	5.0	2.20	1.37	37.0	0.461	0511	8.1	92	O L	81.5	2
VFAS1-2450PM	8:€	230	30.0	0.4	5.0	2.20	1.37	0.5 h	0.031	0511	1.7	92	09	81.5	Ç
VFAS1-2550P	3.0	230	30.0	5.5	5.0	2.20	1.87	5.5.0	0.961	1755	9.1	h2	Oι	05.2	2
VFAS1-2750P	0.5	230	6.0.0	2.5	1.7	3.40	7.37	15.0	0.852	1775	1.5	58	05	6E'I	2
VFAS1-4007PL	0.8	*2	0.07	12.0	2000	0.12	7.50	27.0	1.7	0691	7.3	45	001	11.9	O
VFAS1-4015PL	0.9	*2	0.07	12.0	2000	0.12	7.50	1.50	3.1	0691	7.1	5 %	09	1119	0
VFAS1-4022PL	0.9	*2	0.01	0.51	2000	0.12	7.50	2.20	4.5	0891	5.3	1 h	ΩL	199	C
VFAS1-4037PL	0.9	*2	0.01	12.0	150.0	0.12	7.90	3.70	7.4	0691	4.9	38	Oι	1119	,
VFAS1-4055PL	0.4	*2	0.07	12.0	80.0	0.24	0.87	5.50	10.5	0611	3.9	34	O'L	68.€	1
VFAS1-4075PL	a.p	*2	0.07	12.0	50.0	0.44	7.8.0	7.50	14.1	0611	3.4	33	01	68∙€	,
VFAS1-4110PL	3.0	*2	0.07	12.0	40.0	0.55	1.0.1	1.1.0	50.3	130	5.8	7.2	23	3.83	1
VFAS1-4150PL	3.0	*2	10.0	12.0	30.0	0.88	1.0.1	15.0	27.3	130	2.5	72	50	3.83	1
VFAS1-4185PL	3.0	*2	30.0	4.0	30.0	0.88	1.37	18.5	34.0	1750	2.5	72	סר	2.78	,
VFAS1-4220PL	3.0	*2	30.0	4.D	15.0	1.75	1.37	22.0	40.0	1750	7.℃	72	۵L	5.78	,
VFAS1-4300PL	3:0	*2	30.0	4:0	15.0	1.75	1.37	30.0	54.0	1745	6	25	ΩL	3.05	,
VFAS1-4370PL	3.5	*2	30.05	<i>0:5</i>	8.0	1.75	1.3.1	3.7.5	0.1.0	1.150	89.	67	D)	81.5	ا ن
VFAS1-4450PL	J. (1)	*2	3.00		9.0	0'.'	1.5.1	45.0	0.08	1.50	i	90	20	81.5	υr
VFAS1-4550PL		7.	30.0	9.0	9.0	1.10	1.51	55.0	28.0	5 5 7	0.	5 F	01	05.5	v
VFAS1-4750PL	2:0	*2	5 0.0	4:0	8.0	1.75	1.3.1	15.0	129.0	11.15	1.5	28	50	1.39	ا ن
VFAS1-4900PC	O:O	*2	50.0	2.5	3.7	7.40	1.37	90.0	153.0	1775	1.3	25	20	1.39	~
VFAS1-4110KPC	5.0	*2	60.0	2.5	3.7	7.40	1.37	1.10.0	183.0	1775	1.5	21	30	1.39	5
VFAS1-4132KPC	5.0	*2	60.0	2.5	7.7	7.40	1.37	132.0	0.11.5	1755	7.0	20	40	1.94	5
VFAS1-4160KPC	1.5	*2	60.0	2.5	7.7	7.40	1.3.7	150.0	0.1 62	1755	9.0	20	0.5	h67	5
VFAS1-4200KPC	1.5	*2	60.0	2.5	1.9	8.70	1.37	200.0	333.0	1755	0.6	20	40	1.94	5
VFAS1-4220KPC	1.5	*2	60.0	2.5	1.9	8.70	1.37	220.0	371.0	1765	0.6	20	40	1.94	5
VFAS1-4280KPC	0.1	*2	60.0	2.5	1.4	14.00	1.37	280.0	46 4.0	1765	0.6	20	40	1.94	2
VFAS1-4355KPC	0:1	*2	60.0	2.5	0.9	17.40	1.37	355.0	6 14.0	1755	0.6	20	30	467	Ę
VFAS1-4400KPC	0.7	*2	50.0	2.5	0.7	28.00	7.3.1	400.0	69 1.0	1755	0.6	20	30	1.94	Ü
VFAS1-4500KPC	0.5	*2	50.0	2.5	0.7	28.00	1.37	500.0	830.0	1765	0.5	20	30	1.94	£
*1: Factory default settings when the base frequency (ω \underline{L}) is set at 60Hz (50Hz)	settings whe	on the base	frequency (u.L.) is set	at 60Hz (50		Inverter with	a model	number end	*2: Inverter with a model number ending with $\ $ -WN, HN: $\ $ 4 $\ $ $\ $	194 :NH	J -WP: 400	00		

12. Specifications

12.1 Models and their standard specifications

1) 5	Standard specif	ications	s (smal	l/mediu	m capa	acity typ	es)									
	Item							Specif	ication							
Volt	age class							200V	class							
App	licable motor (kW)	0.4	0.75	1.5	2.2	3.7/4.0	5.5	7.5	11	15	18.5	22	30	37	45	
App	licable motor (HP)	0.5	1	2	3	5	7.5	10	15	20	25	30	40	50	60	
	Туре								\S1-							
	Form	2004PL	2007PL	2015PL	2022PL	2037PL	2055PL	2075PL	2110PM	2150PM	2185PM	2220PM	2300PM	2370PM	2450PM	
70	Output capacity (kVA) [Note 1]	1.1	1.8	3.0	4.2	6.7	10	13	21	25	29	34	46	55	67	
Rating	Output current (A) [Note 2]	3.0 (3.0)	4.8 (4.5)	8.0 (8.0)	11 (10.5)	17.5 (16.6)	27.5 (25.0)	33 (33)	54 (49)	66 (64)	75 (66)	88 (75)	120 (88)	144 (120)	176 (140)	
	Output voltage		Thre	ee-phase	200V~2	240V (Th	e maxim	um outp	ut voltag	e is equ	al to the	input sup	oply volta	age.)		
	Overload current rating						150%	-1 minut	e, 165%-	-2 sec.						
Elec	Dynamic braking circuit					Е	Built-in dy	/namic b	raking dı	rive circu	uit					
Electrical braking	Dynamic braking resistor					A			g resisto Refer to		al)					
Su	Voltage-frequency	Three-phase 200~240V-50/60Hz [Note 3]														
Power supply	Allowable fluctuation	Voltage + 10% - 15% [Note 4] Frequency ±5%														
Pro	tective method			IP2	20 Enclo	sed type	(JEM10	30)			IP00 0	Open typ	e (JEM1	030) [N	lote 5]	
Co	oling method							Forced a	ir-cooled	t						
Coc	ling fan noise (dBA)	43	43	43	55	55	56	58	60	60	60	60	64	64	64	
Col	or							RAL	7016							
EM	C filter				Built-in				Basic	filter (Not	complies	with the	European	EMC Dir	ective)	
DC	reactor		E	xternal [OC react	or (optio	n)				-	Built-in	-			

	Item							Sp	ecificati	on						
Volt	age class							40	00V clas	ss						
App	icable motor (kW)	0.75	1.5	2.2	3.7/4.0	5.5	7.5	11	15	18.5	22	30	37	45	55	75
App	icable motor (HP)	1	2	3	5	7.5	10	15	20	25	30	40	50	60	75	100
	Туре								VFAS1-							
	Form	4007PL	4015PL	4022PL	4037PL	4055PL	4075PL	4110PL	4150PL	4185PL	4220PL	4300PL	4370PL	4450PL	4550PL	4750PL
ZD.	Output capacity (kVA) [Note 1]	1.8	3.1	4.4	8.0	11	13	21	25	31	37	50	60	72	88	122
Rating	Output current	2.3	4.1	5.8	10.5	14.3	17.6	27.7	33	41	48	66	79	94	116	160
9	(A) [Note 2]	(2.3)	(4.0)	(4.6)	(8.6)	(13)	(17)	(25)	(32)	(37)	(38)	(53)	(60)	(75)	(93)	(120)
	Output voltage		Th	ree-pha	se 380V	~480V ((The ma	ximum c	utput vo	oltage is	equal to	the inp	ut suppl	y voltag	e.)	
	Overload						15	0%-1 mi	nute 16	55%-2 s	20					
	current rating						10	0 /0 1 1111	nuto, re	70 70 2 3						
σ⊞	Dynamic						Built-ir	n dynam	ic brakir	na drive	circuit					
ra ect	braking circuit															
Electrica braking	Dynamic braking							ernal bra								
_=	resistor							⇒ Ratii	ng: Refe	r to 5.19	9.					
Power	Voltage-frequenc y						Thr	ee-phas	e 380~4	180V-50	/60Hz	[Note 3]				
wer pply	Allowable fluctuation	Voltage + 10% - 15% [Note 4] Frequency ±5%														
Pro	tective method			IP2	0 Enclos	ed type	(JEM10	30)			IPO	0 Open	type (JE	EM1030) [Note	5]
Co	oling method							Force	ed air-co	ooled						
Coo	ling fan noise (dBA)	43	43	43	55	56	56	58	60	60	60	64	64	64	64	64
Col	or							F	RAL7016	3					•	
EM	C filter								Built-in							
DC	reactor			Extern	nal DC re	eactor (d	option)						Built-in			
Not	e 1: Capacity is	s calcu	lated a	at 220V	for the	200V	model	s and a	at 440\	for th	e 400\	/ mode	ls.			

- Note 1: Capacity is calculated at 220V for the 200V models and at 440V for the 400V models. Note 2: Rated output current when the PWM carrier frequency (parameter [F) is 4kHz or less.
 - The values between parentheses refer to rated output currents when set to 12kHz.
 - ⇒ Refer to 1.4.4 "Current reduction curve" for details.
- Note 3: If you are using a 200V-15kW or 400V-2.2kW inverter and the ambient temperature is 40°C or more, decrease the PWM carrier frequency to 8kHz. Setting F § 3 I to I enables you to protect the overload caused by ambient temperature described in page A-23.
 - An external power supply backup available (optional) (Type: CPS002Z)
- Note 4: ±10% when the inverter is used continuously (load of 100%).
- Note 5: Models, 200V-18.5kW or more and 400V-22kW or more, do not have wiring port covers. They have large openings, but there is no space to bend the external cables inside the unit.

2) Standard specifications (large capacity types) [Note 1]

	Item	Sper	cification								
Volt	age class	200	DV class								
App	licable motor (kW)	55	75								
App	licable motor (HP)	75	100								
	Type	V	FAS1-								
	Form	2550P	2750P								
20	Output capacity (kVA) [Note 2]	84	109								
Rating	Output current (A)	221	285								
	Output voltage	Three-phase 200V~240V (The maximum ou	tput voltage is equal to the input supply voltage.)								
	Overload current rating	150%-1 min	ute, 165%-2 sec.								
bra	Dynamic braking circuit	Built-in dynamic	braking drive circuit								
Electrical braking	Dynamic braking resistor		ing resistor (optional) : Refer to 5.19.								
SUE	Voltage-frequency [Note 3] Allowable	Three-phase 2	Three-phase 200~240V-50/60Hz								
wer oply	Allowable fluctuation	Voltage + 10% - 15%	[Note 4] Frequency ±5%								
Pro	tective method	IP00 Open type	(JEM1030) [Note 5]								
Co	oling method	Forced	d air-cooled								
Coc	oling fan noise (dBA)	61	72								
Со	lor	RA	AL7016								
ΕM	IC filter	External f	filter (optional)								
DC	reactor	Attache	d DC reactor								

	Item					Specif	ication								
Volt	age class					400V	class								
App	licable motor (kW)	90	110	132	160	200	220	280	355	400	500				
App	licable motor (HP)	125	150	200	250	300	350	450	550	600	700				
	Туре					VFA	S1-								
	Form	4900PC	4110KPC	4132KPC	4160KPC	4200KPC	4220KPC	4280KPC	4355KPC	4400KPC	4500KPC				
70	Output capacity (kVA) [Note 2]	136	164	197	239	295	325	419	511	578	717				
Rating	Output current (A)	179	215	259	314	387	427	550	671	759	941				
	Output voltage		Three-pha	se 380V~48	0V (The ma	ximum outp	ut voltage is	equal to the	input supp	ly voltage.)					
	Overload current rating				15	0%-1 minute	e, 165%-2 se	ec.							
Electrical braking	Dynamic braking circuit	Built-ii	n dynamic b	raking drive	circuit		External	dynamic bra	king circuit	(optional)					
trical	Dynamic braking resistor						g resistor (op efer to 5.19								
Sup	Voltage-frequency [Note 3] Allowable	[Note 6] Three-phase 380-440V-50Hz Three-phase 380-480V-60Hz													
plv plv	Allowable fluctuation	Voltage + 10% - 15% [Note 4] Frequency ±5%													
Pro	tective method				IP00 C	pen type (JI		Note 5]							
Co	oling method					Forced a	ir-cooled								
Coc	ling fan noise (dBA)	61	72	73	73	76	76	76	76	76	78				
Co						RAL									
EM	C filter					Bui	lt-in								
DC	reactor					Attached I	OC reactor								

Note 1: For 200V-55kW, 400V-90kW or larger model, be sure to install DC reactor.

However, this is unnecessary for DC input specifications.

- Note 2: Capacity is calculated at 220V for the 200V models and at 440V for the 400V models.
- Note 3: An external power supply backup available (optional) (Type: CSP002Z)
- Note 4: ±10% when the inverter is used continuously (load of 100%).
- Note 5: Models, 200V-18.5kW or more and 400V-22kW or more, do not have wiring port covers. They have large openings, but there is no space to bend the external cables inside the unit.
- Note 6: Three-phase 380~480V-50/60Hz for 4900PC

3) Common specification

3) (ommon specification											
<u> </u>	Item	Specification										
	Control system	Sinusoidal PWM control										
	Output voltage adjustment	Main circuit voltage feedback control. (Switchable between automatic adjustment/fix/control off)										
	Output frequency range	Setting between 0.01 to 500Hz. Default max. frequency is set to 0.01 to 60Hz. Maximum frequency adjustment (30 to 500Hz)										
	Minimum setting steps of frequency	0.01Hz: operation panel input (60Hz base), 0.03Hz: analog input (60Hz base, 11 bit/0 to 10Vdc)										
	Frequency accuracy	Analog input: ±0.2% of the maximum output frequency (at 25±10°C) Digital input: ±0.01%±0.022Hz of the output frequency										
l _		V/f constant, square reduction torque control, automatic torque boost, vector calculation control, base										
Control specification	Voltage/frequency characteristics	frequency adjustment 1, 2, 3, and 4 (25 to 500Hz), V/f 5-point arbitrary setting, torque boost adjustment										
0		(0 to 30%), start frequency adjustment (0 to 10Hz), stop frequency adjustment (0 to 30Hz)										
spe		3kΩ potentiometer (possible to connect to 1 to 10kΩ-rated potentiometer)										
£.	Frequency setting signal	0 to 10Vdc (input impedance Zin: $30k\Omega$) 0 to ± 10 Vdc (Zin: $22k\Omega$)										
8		4 to 20mAdc (Zin: 22κΩ)										
9	Terminal board base	The characteristic can be set arbitrarily by two-point setting. Compliant with 6 types of input; analog input										
	frequency	(RR, VI/II, RX, AI1, AI2), and pulse input. (*AI1, AI2, pulse input: optional)										
	Frequency jump	3 places. Setting of jump frequency and width.										
	Upper and lower limit	Upper limit frequency: 0 to max. frequency, lower limit frequency: 0 to upper limit frequency										
	frequencies											
	PWM carrier frequency	200V-45kW or less, adjustable between 1.0 to 16kHz for 400V-75kW or less										
		200V-55kW or less, adjustable between 2.5 to 8kHz for 400V-90kW or more										
	PID control	Adjustment of proportional gain, integral time, differential time and delay filter										
	Torque control	Voltage command input specification: DC 0 to ±10V										
	Acceleration/deceleration	0.01 to 6000 sec. Selectable from among acceleration/deceleration. times 1, 2, 3 and 4. Automatic										
	time	acceleration/deceleration function. S-pattern acceleration/deceleration 1 and 2 pattern adjustable.										
	DC braking	Adjustment of braking start frequency (0 to 120Hz), braking (0 to 100%) and braking time (0 to 20 sec.).										
		With emergency stop braking function and motor shaft fix control function.										
	Forward run/reverse run	With F-CC closed to forward run, with R-CC closed to reverse run, with both closed to reverse run. With										
	[Note 1]	ST-CC opened to coast stop. Emergency stop by panel operation or terminal board.										
	Jog run [Note 1]	Jog mode, if selected, allows jog operation from the operation panel Jog run operation by terminal board is possible by setting the parameters.										
	[Note 1]	By changing the combination of open/close between S1, S2, S3, RR/S4-CC, set frequency + 15-speed										
	Preset speed operation [Note 1]	operation.										
0	[Selectable between acceleration/deceleration time, torque limit and V/f by set frequency.										
oer:	Retry	Capable of restarting after a check of the main circuit elements in case the protective function is										
atic	*	activated. Max. 10 times selectable arbitrarily. Waiting time adjustment (0 to 10 sec.)										
n s	Soft stall	Automatic load reduction control at overloading. (Default: OFF) The cooling fan will be stopped automatically to assure long life when uppecessary										
pe	Cooling fan ON/OFF	The cooling fan will be stopped automatically to assure long life when unnecessary. Key prohibition selectable between STOP key only, MODE key only, etc. All key operations can be										
Operation specifications	Operation panel key operation ON/OFF control	prohibited.										
atic	Regenerative power	Possible to keep the motor running using its regenerative energy in case of a momentary power failure.										
ns	ride-through control	(Default: OFF)										
	Auto-restart operation	Possible to restart the motor in coasting in accordance with its speed and direction. (Default: OFF)										
	Simplified pattern	Possible to select each 8 patterns in 2 groups from 15-speed operation frequency. Max. 16 types of										
	operation	operation possible. Terminal board operation/repeat operation possible.										
	Commercial inverter switching	Possible to switch operation by commercial power source or inverter										
	Light-load high-speed	Increases the operating efficiency of the machine by increasing the rotational speed of the motor when it										
	operation	is operated under light load.										
		When two or more inverters are used to operate a single load, this function prevents load from										
	Drooping function	concentrating on one inverter due to unbalance.										
	Override function	External input signal adjustment is possible to the operation frequency command value.										
		Stall prevention, current limit, overcurrent, overvoltage, short circuit on the load side, ground fault on the										
Pro	Protective function	load side [Note 5], undervoltage, momentary power failure (15ms or more), non-stop control at										
tec	Frotective function	momentary power failure, overload protection, arm overload at starting, overcurrent on the load side at										
ŧive		starting, overcurrent and overload at dynamic braking resistance, overheat, emergency stop										
Protective function	Electronic thermal	Switchable between standard motor/constant torque VF motor, adjustment of overload protection and										
즚	characteristic	stall prevention level.										
n	Reset	Reset by 1a contact closed (or 1b contact opened), or by operation panel. Or power source OFF/ON.										
	l	This function is also used to save and clear trip records.										

(Continued overleaf)

(Continued)

	İ	tem	Specification							
		Alarms	Stall prevention during operation, overload limit, overload, undervoltage on power source side, DC circuit undervoltage, setting error, in retry, upper limit, lower limit.							
		Causes of failures	Overcurrent, overvoltage, overheat, short circuit on the load side, ground fault on the load side, inverter overload, arm overcurrent at starting, overcurrent on the load side at starting, CPU error, EEPROM error, RAM error, ROM error, communication error, (dynamic braking resistor overcurrent/overload), (emergency stop), (undervoltage), (low current), (overtorque), (motor overload), (input phase failure), (output phase failure) The items in the parentheses are selectable.							
Display function	4-digit and 7-segme nt LED	Monitoring function	Operation frequency, operation frequency command, forward run/reverse run, output current, DC voltage, output voltage, compensated frequency, terminal board input/output information, CPU version, past trip history, cumulative operation time, speed feedback, torque, torque command, torque current, exiting current, PID feedback value, motor overload factor, inverter overload factor, PBR overload factor, PBR load factor, input power, output power, peak output current, peak DC voltage, RR/S4 input, VI/II input, RX input, Al1 input, Al2 input, FM output, AM output, expansion I/O card option CPU version, integral input power, integral output power, communication option reception counter, communication option abnormal counter							
		Free unit display	Display of optional units other than output frequency (motor speed, line speed, etc), current ampere/% switch, voltage volt/% switch							
		Automatic edit function	Searches automatically parameters that are different from the standard default setting parameters. Easy to find changed parameters.							
		User default setting	User parameter settings can be saved as default settings. Allows to reset the parameters to the user-defined parameter settings.							
	LED	Charge display	Displays main circuit capacitor charging.							
Inpu		minal input	Possible to select positive logic or negative logic with programmable input/output terminal function menu. [Note 1] [Note 2] (Default setting: positive logic)							
Sink	/source sw	ritching	Possible to switch between minus common (CC) and plus common (P24) for control terminal. (Default setting: minus common (CC))							
	Failure de	etection signal	1c contact output (250Vac-2A-cosΦ=1, 250Vac-1A-cosΦ=0.4, 30Vdc-1A)							
	Low spee signal ou [Note 2]	ed/speed reach tput	Open collector output (24Vdc, max. 50mA, output impedance: 33Ω)							
output signa	Upper/lov frequency [Note 2]	wer limit y signal output	Open collector output (24Vdc, max. 50mA, output impedance: 33Ω)							
ignal	meter/	or frequency or ammeter	Analog output. 1mAdc full-scale DC ammeter or 7.5Vdc-1mA voltmeter							
		in frequency	Open collector output (24Vdc, max. 50mA)							
Con	nmunication	n function	RS-485 standard 2-channel equipped (connector: modular 8P) CC-Link, DeviceNet and PROFIBUS-DP are optional.							
Environments	Use envii	ronments	Indoor use. Altitude: 3000m or less (current reduction necessary if 1000m or more.) Place not exposed to direct sunlight and free of corrosive and explosive gases.							
ð	Ambient 1	temperature	-10 to +60°C (Remove the upper cover if 40°C or more, max. 60°C) [Note 4]							
3		emperature	-25 to +70°C							
ent	Relative I		20 to 93% (free from condensation)							
S	Vibration		5.9m/s ² {0.6G} or less (10 to 55Hz) (Compliant with JIS C60068-2-6)							
			A CONTRACTOR OF THE CONTRACTOR							

- Note 1: 16 contact input terminals (of which 8 are options) are programmable contact input terminals, and they make it possible to arbitrarily select from 136 types of signals.
- Note 2: Programmable ON/OFF output terminals make it possible to arbitrarily select from 150 types of signals.
- Note 3: Programmable analog output terminals make it possible to arbitrarily select from 55 types of signals.
- Note 4: When using inverters where the ambient temperature will rise above 50°C, remove the upper cover and operate each inverter at a current lower than the rated one.
 - (200V-55kW or lager and 400V-90kW or larger models dose not need remove the upper cover)
- Note 5: This function protects inverters from overcurrent due to output circuit ground fault.


12.2 Outside dimensions and weight

■ Outside dimensions and weight

Voltage	Applicable	Applicable					Dime	nsions	(mm)					Approx.
class	motor	motor	Inverter type	W	Н	D	W1	H1	W2	H2	НЗ	H4	Drawing	weight
Class	(kW)	(HP)		VV	П	U	VVI	П	VVZ	П2	пэ	П4		(kg)
	0.4	0.5	VFAS1-2004PL											
	0.75	1	VFAS1-2007PL	130	230	152	114	220	-	-	-	-	Α	3
	1.5	2	VFAS1-2015PL											
	2.2	3	VFAS1-2022PL	155	260	164	138	249			_	-	В	4
	3.7/4.0	5	VFAS1-2037PL	155	260	104	130	249	-	-	-	-	ь	4
	5.5	7.5	VFAS1-2055PL	175	295	164	158	283	-	-	-	-	С	5.5
	7.5	10	VFAS1-2075PL	210	295	191	190	283	-	-	-	-	D	7.5
	11	15	VFAS1-2110PM	230	400	191	210	386					Е	14
200V	15	20	VFAS1-2150PM	230	400	191	210	300	-	-	-	-		14
200 V	18.5	25	VFAS1-2185PM	240	420	212	206	403	_	_	_	-	F	21
	22	30	VFAS1-2220PM	240	420	212	200	403	-	-	-	-	Г	21
	30	40	VFAS1-2300PM											
	37	50	VFAS1-2370PM	320	550	242	280	525	-	-	-	-	Н	41
	45	60	VFAS1-2450PM											
		75	VEA 04 0550D	040	680	070	050	050	000	75	450	00		59
	55	75	VFAS1-2550P	310	(920)	370	250	650	320	75	150	30	J	(87)
	75	100	VFAS1-2750P	350	782 (1022)	370	298	758	360	72	150	30	К	72 (103)
	0.75	1	VFAS1-4007PL											
	1.5	2	VFAS1-4015PL	130	230	152	114	220	-	-	-	-	Α	3
	2.2	3	VFAS1-4022PL	1										
	3.7/4.0	5	VFAS1-4037PL	155	260	164	138	249	-	-	-	-	В	4
	5.5	7.5	VFAS1-4055PL	475	005	404	450	000					_	
	7.5	10	VFAS1-4075PL	175	295	164	158	283	-	-	-	-	С	5.5
	11	15	VFAS1-4110PL	210	295	191	190	283	-	-	-	-	D	8
	15	20	VFAS1-4150PL	230	400	191	240	386	_			-	Е	13
	18.5	25	VFAS1-4185PL	230	400	191	210	300	-	-	-	-		16
	22	30	VFAS1-4220PL	240	420	212	206	403	-	-	-	-	F	21
	30	40	VFAS1-4300PL	240	550	242	206	529	_			-	G	29
	37	50	VFAS1-4370PL	240	330	242	200	329	-	-	-	-	G	29
	45	60	VFAS1-4450PL											
	55	75	VFAS1-4550PL	320	630	290	280	605	-	-	-	-	- 1	48
	75	100	VFAS1-4750PL											
400V	90	125	VFAS1-4900PC	310	(680 (920)	370	250	650	320	75	150	30	J	59 (89)
	110	150	VFAS1-4110KPC	350	782 (1022)	370	298	758	360	72	150	30	К	74 (108)
	132	200	VFAS1-4132KPC	330	950 (1190)	370	285	920	340	75	150	30	L	82
	160	250	VFAS1-4160KPC	430	950 (1190)	370	350	920	440	75	150	30	М	(118) 104 (161)
	200	300	VFAS1-4200KPC		950									134 (194)
	220	350	VFAS1-4220KPC	585	(1190)	370	540	920	598	75	150	30	N	136
	280	450	VFAS1-4280KPC	1	l	l	l					l		(204)
	355	550	VFAS1-4355KPC	l	1150									260
	400	600	VFAS1-4400KPC	880	(1390)	370	418	1120	890	75	150	30	0	
	400	000	VITAG 1-440UNPC	<u> </u>	` ′								<u> </u>	(370)
	500	700	VFAS1-4500KPC	1108	1150 (1390)	370	533	1120	1120	75	150	30	Р	330 (462)

Note: Value in () includes attached DC reactor.

■ Outline drawing



12

Fig. F

Fig. E






Fig. I Fig. J








Fig. O




Fig. P

13. Before making a service call - Trip information and remedies

13.1 Trip causes/warnings and remedies

When a problem arises, diagnose it in accordance with the following table.

If it is found that replacement of parts is required or the problem cannot be solved by any remedy described in the table, contact your supplier.

[Trip infor	mation]								
Error code	Description	Possible causes	Remedies						
0C I *0C IP	Overcurrent during acceleration	 The acceleration time Rf f is too short. The Vf setting is improper. A restart signal is input to the rotating motor after a momentary stop, etc. A special motor (e.g. motor with a small impedance) is used. Manual torque boost value (υ b) is large. 	 Increase the acceleration time #££. Check the Vf parameter setting. Use £u 5 (Auto-restant) and £u £ (Regenerative power ride-though control). Increase the carrier frequency £F. Decrease u b setting value. Decrease F £ £ I (stall prevention level) to 130 as a guide. Increase £ F (carrier frequency) setting value if it is set at lower value (2kHz or less). 						
002 *002	Overcurrent during deceleration	•The deceleration time d E [is too short. (in deceleration)	•Increase the deceleration time $ d otin otin$						
0C3 *0C3P	opecu	The load fluctuates abruptly. In load is in an abnormal condition.	Reduce the load fluctuation. Check the load (operated machine).						
Causes of	[1P,0[2P, originate from other than those ed above.	A main circuit elements is defective. Overheat protection is activated.	Make a service call. Check operation of cooling fan. Check cooling fan control mode parameter F 6 2 0.						
*0 C R I	U-phase arm short-circuit	•A main circuit elements is defective (U-phase).	Make a service call.						
*0 C R 2	V-phase arm short-circuit	•A main circuit elements is defective (V-phase).	Make a service call.						
*0 C R 3	W-phase arm short-circuit	•A main circuit elements is defective (W-phase).	Make a service call.						
001	Loaded side overcurrent at start time	The insulation of the output main circuit or motor is defective. The motor has too small impedance. The drive circuit board in the inverter was damaged.	Check the cables and wires for defective insulation. Selection of short circuit detection at starting parameter F & I 3. If this error message appears when a motor is not connected to the inverter, the inverter itself may be faulty, so make a service call.						
	Dynamic braking element overcurrent (200V-55kW or larger, 400V-90kW or larger)	 PB-PC/+ circuit is shorted. A resistor with resistance smaller than the minimum allowable resistance is connected. Parameter P b was set to f or ≥ without connecting regenerative brake or with wire disconnected (with dynamic braking). 	*Check the impedance wiring for the resistor, etc. *Make a service call. *Check if regenerative brake is connected. If regenerative brake is not necessary, set.						
ОН	Overheating	The cooling fan does not rotate. The ambient temperature is too high. The vent is blocked up. A heat generating device is installed close to the inverter. The thermistor in the unit is disconnected.	Restart the operation by resetting the inverter after it has cooled down enough. The fan requires replacement if it does not rotate during operation. Secure sufficient space around the inverter. Do not place any heat generating device near the inverter. Make a service call.						
045	Thermal trip stop command from external device	An input signal is impressed at control input terminal PTG for optional add-on cards. A thermal trip command (input terminal function: 45 or 47) is issued by an external control device.	•The motor is overheated, so check whether the current flowing into the motor exceeds the rated current.						

^{*} In the event one of the error codes £ [1P to £ 3P and £ R 1 to £ R 3 appears, in which case a main circuit component has most probably failed, the only way to reset the inverter is to turn power off and back on. (Continued overleaf)

(Continued)

Error	Description	Possible causes	Remedies	
OL I	Inverter overload	Rapid acceleration is operated. The DC braking amount is too large. The V/f setting is improper. A restart signal is input to the rotating motor after a momentary stop, etc. The load is too large.	•Increase the acceleration time # £ £ . •Reduce the DC braking amount F ≥ 5 1 and the DC braking time F ≥ 5 2. •Check the Vf parameter setting. •Use U ∪ 5 (Auto-restart) and U ∪ € (Regenerative power ride-though control). •Use an inverter with a larger rating.	
0 L Z	Motor overload	The V/f parameter is improperly set. The motor is locked up. Cow-speed operation is performed continuously. An excessive load is applied to the motor during operation.	•Check the V/f parameter setting. •Check the load (operated machine). •Check the @L fl setting and adjust F 5 @5 according to the sustainable overload in the motor low-speed range. •Reduce the DC braking amount F 2 5 1 and the DC braking time F 2 5 2.	
OLr	Dynamic braking resistor overload	Rapid deceleration is operated. Dynamic braking is too large.	•Increase the deceleration time $d \in \mathcal{E}$. •Increase the capacity of dynamic braking resistor (wattage) and adjust PBR capacity parameter $Pb \in P$.	
0P I	Overvoltage during acceleration	The input voltage fluctuates abnormally. (1)The power supply has a capacity of 500kVA or more. (2)A power factor improvement capacitor is opened and closed. (3)A system using a thyrister is connected to the same power distribution line. A restart signal is input to the rotating motor after a momentary stop, etc.	•Insert a suitable input reactor. •Use "□□ 5 (Auto-restart) and "□□ [(Regenerative power ride-though control).	
0P2	Overvoltage during deceleration	 •The deceleration time d E ℓ is too short (regenerative energy is too large). •The dynamic braking resistor has a considerably large resistance. •P b (Dynamic braking resistor) is OFF. Overvoltage limit operation F 305 is OFF. •The input voltage fluctuates abnormally. (1)The power supply has a capacity of 500kVA or more. (2)A power factor improvement capacitor is opened and closed. (3)A system using a thyrister is connected to the same power distribution line. 	 Increase the deceleration time d E E. Install a dynamic braking resistor. Decrease dynamic braking resistance. (Also reset the P b r.) Set dynamic braking mode parameter P b properly. Set overvoltage limit operation F 3 0 5 properly. Insert a suitable input reactor. 	
0P3	Overvoltage during fixed speed operation	The input voltage fluctuates abnormally. (1)The power supply has a capacity of 500kVA or more. (2)A power factor improvement capacitor is opened and closed. (3)A system using a thyrister is connected to the same power distribution line. The motor is in a regenerative state because the load causes the motor to run at a frequency higher than the inverter output frequency.	•Insert a suitable input reactor. •Install a dynamic braking resistor.	
*0 E	Overtorque	Overtorque reaches to a detection level during operation. Stall prevention operation was performed continuously for a length of time longer than that set with F 45 Z.	Check system error. Check whether the motor is overloaded or the brake is engaged.	
*U[Low current	•The output current decreased to a low-current detection level during operation.	Check the suitable detection level for the system (F 5 1 1). Make a service call if the setting is correct.	
*UP 1	Voltage drop in main circuit	 The input voltage (in the main circuit) is too low. Momentary power failure occurs because undervoltage continues longer than undervoltage detection time F 5 2 8. 	•Check the input voltage. •To cope with a momentary stop due to undervoltage, enable $U \cup F$ (Regenerative power ride-through control), $U \cup F$ (auto-restart control), and $F \cap F \cap F$ (Undervoltage detection time).	

^{*}Presence or absence of parameter trip can be selected. (Continued overleaf)

(Continue	Continued)				
Error code	Description	Possible causes	Remedies		
Ε	Emergency stop	•Inverter is stopped by panel operation during automatic or remote operation. •A stop command (input terminal function: 2 0 or 2 1) is issued by an external control device.	•Reset the inverter.		
EEPI	EEPROM error	•A data writing error occurs.	•Turn off the inverter, then turn it again. If it does not recover from the error, make a service call.		
EEP2	Initial read error	*Some internal data is corrupted. *Power was turned off while £ 4P was being set.	Make a service call. Set L YP again. If the inverter does not recover from the error, make a service call.		
EEP3	Initial read error	 Some internal data is corrupted. 	Make a service call.		
EF 1	Ground fault	A current leaked from an output cable or the motor to ground.	•Check the cable and the motor for ground faults.		
* EPHO	Output phase failure	A phase failure occurred in the output line of the main circuit.	Check the main circuit output line, motor, etc. for phase failure. Select output phase failure detection parameter F 5 0 5.		
EPH I	Input phase failure	A phase failure occurred in the input line of the main circuit.	•Check the main circuit input line for phase failure.		
Err2	Main unit RAM fault	•The control RAM is defective.	Make a service call.		
Err3	Main unit ROM fault	•The control ROM is defective.	•Make a service call.		
Erry	CPU fault	•The control CPU is defective.	•Make a service call.		
Err5	Interruption of operation command from external control device	•A normal communication was not possible for the time or longer set by F 8 0 3.	Check the remote control device, cables, etc.		
Errb	Gate array fault	Main gate array is defective.	•Make a service call.		
Errl	Output current detector error	•The main output current detector is defective.	Make a service call.		
Err8	Optional unit fault	•An optional device has failed. (such as a communication device [add-on option])	Check the connection of optional board(s). Refer to instructions of options concerned specified in Section 6.42.		
Etn	Tuning error	The capacity of the motor connected is 2 notches or more smaller than the inverter capacity. The motor connected is not a three-phase inductive motor. Tuning is performed while the motor is running.	Make sure that a motor is connected. Make sure that the motor is at standstill. Perform auto-tuning 1 again and if the error persists, perform tuning manually.		
Etni	Tuning detection error	Some of FY 10, FY 11(*2), FY 12 and FY 13(*2) were not to be detected during auto tuning. The capacity of the motor connected is 2 notches or more smaller than the inverter capacity. The motor connected is not a three-phase inductive motor. Tuning is performed while no motor is connected. The cables connecting the inverter to the motor are too long; they are more than 30m in length. Tuning is performed while the motor is running.	Make sure that a motor is connected. Make sure that the motor is at standstill. Perform auto-tuning 1 again and if the error persists, perform tuning manually.		
EtnZ	Motor constant value error	■ Some detection values of F 4 1 13 . F 4 1 1 (*2), F 4 1 2 and F 4 1 3 (*2) were beyond the limits of normal value. ■ The capacity of the motor connected is 2 notches or more smaller than the inverter capacity. ■ The motor connected is not a three-phase inductive motor. ■ The cables connecting the inverter to the motor are too long; they are more than 30m in length. ■ Tuning is performed while the motor is running.	Make sure that the motor is at standstill. Perform auto-tuning 1 again and if the error persists, perform tuning manually.		

^{*}Presence or absence of parameter trip can be selected.
(Continued overleaf)

(Continued)

(Continue	Description	Possible causes	Remedies	
code	2 cccription	Some items indicated on the motor	Make sure that all items on the motor nameplate	
Etn3	Motor constant setting error	nameplate are not entered correctly. *Base frequency UL *Base frequency voltage 1 uL u *Motor rated capacity F 405 *Motor rated current F 405 *Motor rated speed F 407	are entered correctly.	
ЕЕЧР	Inverter type error	•Is circuit board (or main circuit/drive circuit board) replaced?	•When board has been replaced, input \$\mathcal{B}\$ for \$\mathcal{E} \mathcal{B} P\$.	
E - 10	Analog input terminal overvoltage	Overrated voltage is applied to analog input.	Apply voltage within the rated voltage.	
E - 11	Sequence error	•The signal from system is not inputted into input terminals. •The input terminal function (130, 131) is not set up. •A value other than 0.0 is specified for F B 30, although the brake answer function is not used.	Please check if the sequence is normal or not. Please set 130 or 131 as the input terminal to use. Please set up 0.0, when you do not use system-supporting sequence.	
E - 12	Encoder error	Disconnection of encoder circuit. The encoder is not connected correctly.	*Check connection of encoder. Connect encoder correctly. *Check whether the setting of F 3 7 6 matches the phase-A and phase-B connections of the encoder.	
E - 13	Speed error (Over speed)	Speed error (Inverter error, Encoder error) Over speed by overvoltage limit operation Using braking function in not connect a motor	*Check the setting of F & Z Z ~ F & Z Y *Check connection of encoder. *In the case of overvoltage limit operation, install a dynamic braking resistor. *Operation in connect a motor.	
E - 18	Terminal input error	Braking down of a wire for VI/II input signal. Terminal circuit board comes off and falls P24 overcurrent	Check VI/II input signal. Install the control terminal board to the inverter. Check P24 terminal short circuit to CC or CCA.	
E - 19	Abnormal CPU2 communication	An error arises during CPU2 communication.	Make a service call.	
E-20	V/f control error	 Output voltage / Output frequency ratio is too high compared to motor rating. It was run in vector control mode (P ೬ = ₹ , 3, 4, 7 or 8) without setting parameters (Auto-tuning) concerning the motor. Motor was in over-excitation state during deceleration. Motor constant 1 (Torque boost) F 4 10 is too large. Motor was started under the brake closed. 	 Set Base frequency voltage 1 u L u and Base frequency u L in accordance with motor rating. When operating a motor in V/f control mode selection P Ł = Z , Z , Y , T or B , follow section 6.22, and then set the parameters (Auto-tuning) concerning the motor. If the inverter is tripped during deceleration because of V/f control error (E - Z B) when F 3 B 5 (Over voltage limit operation) is set to 2 or 3, decrease the value for F 3 1 9 (Regenerative over-excitation upper limit). If the inverter is tripped during low frequency, decrease the value for F 4 1 B . If the inverter is tripped during braking, make the brake release timing early. 	
E-21	CPU1 fault	A software error occurs in the control CPU.	Make a service call.	
E-22	Abnormal logic input voltage	An abnormal voltage is applied to the control logic input terminal.	Check the signal given to the logic connected with the input terminal.	
E-23	Option 1 error	Option card 1 is defective. (Installed option at lower side) Option and 0 is defective.	Make a service call.	
E-24	Option 2 error	Option card 2 is defective. (Installed option at upper side)	Make a service call.	
E-25	Stop position retaining error	 A deviation error occurs during stop position retaining control. The stop position adjustment range specified with F 3 8 1 is too narrow. Creeping speed is too fast. 	-Check connection of encoderAdjust the proportional P gain F 3 6 2Increase F 3 8 1. -Lower the creeping speed.	
L		Crooping speed is 100 last.	Lower the dicepting specu.	

(Continued overleaf)

(Continue	ed)		
E - 26	Internal circuit	Motor control CPU is defective. The drive circuit board in the inverter was damaged. Power device is defective.	•Make a service call.
		•Using braking function in not P <u>L</u> = <u>Z</u> , <u>3</u> , <u>4</u> , <u>7</u> , <u>8</u> mode	•If the braking function is used, operate a motor in PE=2,3,4,7,8 mode
E-29	Control power backup undervoltage error	The control voltage between +SU and CC terminals is too low. Control power is not supplied through +SU and CC terminals. The parameter F & Y 7 is not set correctly.	•Check whether the voltage between +SU and CC terminals is DC20V or more. •Set F & Y 7 to 0 if a control power backup device is not connected to +SU and CC terminals. To reset the inverter that has been tripped because of this error, turn it off and then back on.
50UE	Step-out (for PM motors only)	The motor shaft is locked. One output phase is open. An impact load is applied.	Unlock the motor shaft. Check the interconnect cables between the inverter and the motor.

Note: Please contact us if you find any trips other than the above.

[Alarm] The following are messages only. No trip is developed.

Error	The following are messages only. No trip is developed.				
code	Problem	Possible causes	Remedies		
OFF	ST signal OFF	•ST terminal is in open-circuit.	Check SW1 select Close ST-CC circuit (Sink logic) Close ST-P24/PLC circuit (Source logic)		
COFF	Control power backup undervoltage	•The control voltage between +SU and CC terminals is too low. •Control power is not supplied through +SU and CC terminals. •The parameter F & 4 7 is not set correctly.	•Check whether the voltage between +SU and CC terminals is DC20V or more. •Set F & Y 7 to ① if a control power backup device is not connected to +SU and CC terminals. In the event of a € ① F F error, the inverter will not be reset automatically even if the control voltage between +SU and CC terminals returns to its normal level. To reset the inverter, turn it off and then back it on.		
поғғ	Undervoltage in main circuit	 The supply voltage between R, S and T is under voltage. Trouble of rush current restraint circuit or DC circuit fuse. 	Measure the main circuit supply voltage. If the voltage is at a normal level, the inverter requires repairing. Make a service call.		
rtry	Retry	•The inverter is in the process of retry. •A momentary stop occurred.	The inverter is normal if it restarts after several tens of seconds. The inverter restarts automatically. Be careful of the machine because it may suddenly restart.		
Errl	Point setting alarm	•The frequency setting signals at points 1 and 2 are set too close to each other.	•Set the frequency setting signals at points 1 and 2 apart from each other.		
E-17	Key failure alarm	•The same key is input continuously more than 20 seconds.	Check the operation panel.		
ELr	Clear enabling indication	This message is displayed when pressing the STOP key while an error code is displayed. Input terminal RES signal is ON during trip display.	Press the STOP key again to clear the trip. Turn off the input terminal RES signal.		
EOFF	Emergency stop enabling indication	•The operation panel is used to stop the operation in automatic control or remote control mode.	Press the STOP key for an emergency stop. To cancel the emergency stop, press any other key.		
H 1/L0	Setting error alarm An error code and data are displayed alternately twice each.	 An error is found in a setting when data is reading or writing. 	Check whether the setting is made correctly.		
dЬ	DC braking	•DC braking in process	•The message goes off in several tens of seconds if no problem occurs. [Note]		
dbOn	Shaft fixing in control	 Motor shaft fixing control is in process. 	•If the message disappears by stop command (ST-CC open), it is normal.		
E 3	Panel indication overflow	•The digit number of the item displayed, e.g., frequency, is in excess of the specified digit number. (Number of overflowing digits is indicated.)	*For indication of frequency, set multiplying rate (F 7 D 2) lower. (Parameter setting that results in overflow is of course valid.)		

(Continued overleaf)

(Continued)

(Continue	Continued)				
In It	Parameters in the process of initialization	Parameters are being initialized to default values.	Normal if the message disappears after a while (several seconds to several tens of seconds).		
REn	In auto-tuning 1	•Auto-tuning 1 in process.	Normal if it the message disappears after a few seconds.		
LSEP	because of F 2 5 6 is being performed.		•This function is deactivated when the command frequency becomes 0.2Hz or more higher than the lower-limit frequency (LL) or when a command for stopping operation is entered.		
Momentary •The deceleration stop function of •To restart		ປິບຸໂ (regenerative power ride-through control) is activated.	•To restart operation, reset the inverter or input an operation signal again.		
HERd/ End	Display of first/last data items	•First and last data in the RUH group.	•To exit from the group, press the MODE key.		
ŁUn	During learning	 Learning for brake sequence operation or light-load high-speed operation is currently in progress. 	•To cancel learning, suspend it and set learning parameters F 3 2 9 to 0.		
EUn I	Brake sequence learning error	*Braking operation is not performed normally. *The load is too heavy. *There are some operation errors.	Brake signal output (58, 59) is not assigned to the control output terminal. The brake function mode selection parameter (F3Y) is not set. Learning is performed while the load is lifted		
£Un2	Light-load high-speed learning operation error	•There are some errors in the operation for learning for light-load high-speed operation.	•Check whether the learning operation for light-load high-speed operation is performed correctly. ⇒ Refer to 6.16.		
եՍո∄	Light-load high-speed learning overload error	•Learning operation for light-load high-speed operation is performed while the load is lifted. •Motor constants (u L, u L u, F 4 0 5 to F 4 1 3) are not entered correctly.	Check the load. Check the motor constant setting.		
Undo	Key operation permitted temporarily	•This message appears if the ENTER key is pressed and held down for 5 seconds or more when key operation is prohibited by F 7 3 7.	•When this message is displayed, all the keys are operational. To prohibit key operation again, turn off the inverter and then turn it back on.		

Note: In the case of DC injection breaking ON/OFF function is selected for an input terminal; if "d b" disappears as a result of open-circuit between the terminal and CC, it is normal.

[Pre-alarm display]

li ie-aiaii	-aiaiii dispiayj				
Error code	Description	Possible causes	Remedies		
Ε	Overcurrent pre-alarm	Same as ££ (Overcurrent)	Same as ££ (Overcurrent)		
Ρ	Overvoltage pre-alarm Achieving PBR operation level	Same as IP (Overvoltage) P blink while PBR is operating is not an error.	Same as PP (Overvoltage) PP blink while PBR is operating is not an error.		
L	Overload pre-alarm	Same as £ 1 and £ £ (Overload)	Same as ££ / and ££ 2 (Overload)		
Н	Overheat pre-alarm	Same as ### (Overheat)	Same as ### (Overheat)		
Ŀ	Communication error	Various transmission errors occur when computer is linked up with inverter system. Various transmission errors occur in inverter to inverter communication (slave side). Time-out or trip in master side.	For measures to correct various kinds of data transmission errors, refer to the instruction manual for the communications device used specified in Section 6.42. Check the master inverter.		

If two or more problems arise simultaneously, one of the following alarms appears and blinks.

 $EP, PL, LH, EPL, \dots, EPLH$

The blinking alarms \mathcal{L} , \mathcal{P} , \mathcal{L} , \mathcal{H} , \mathcal{E} are displayed in this order from left to right.

13.2 Method of resetting causes of trip

Do not reset the inverter when tripped because of a failure or error before eliminating the cause. Resetting the tripped inverter before eliminating the problem causes it to trip again.

For recovering inverter from trip status,

- (1) By turning off the power (Keep the inverter off until the LED turns off.)
 - \Rightarrow Refer to Section 6.33.2 (inverter trip retention selection $F \in \mathcal{G} \supseteq P$) for details.
- (2) By means of an external signal (shorting RES and CC on control terminal board → release)
- (3) By operation panel operation
- (4) By means of a communication
 - ⇒ For details, refer to the instruction manual for the communications device used specified in section 6.41.

reset it in one of the following ways.

To reset the inverter by operation panel operation, follow these steps.

- Check whether the LED on the control panel indicates that tripping has occurred. If the occurrence of tripping is not indicated, press the MODE key to display it.
- 2. Press the STOP key and make sure that [] r is displayed.
- 3. Pressing the STOP key again will reset the inverter if the cause of the trip has already been eliminated.

When any overload function [#] 1: Inverter overload, ##L #: Motor overload, ##L #: Dynamic braking resistor overload] is active, the inverter cannot be reset by inputting a reset signal from an external device or by operation panel operation before the virtual cooling time has passed.

Standard virtual cooling time ... In case of \$\textit{GL}\$ 1: for about 30 seconds after trip
In case of \$\textit{GL}\$ 2: for about 120 seconds after trip
In case of \$\textit{GL}\$ r: for about 20 seconds after trip

Note: £L I or £L 2 can be reset during virtual cooling time if the CPU1 version is Ver.106 or successor. However, note that the inverter is in a state easy to trip during virtual cooling time.


If the inverter trips because of overheat (GH), reset it after a considerably long time enough for cooling it down completely, because overheat is detected based on its internal temperature.

- Caution -

For quickly recovering inverter from trip status, turn it off once and reset it. However, this measure is taken frequently, it may cause damage to the motor and other component units.

13.3 If the motor does not run while no trip message is displayed...

If the motor does not run while no trip message is displayed, follow these steps to track down the cause.



13.4 How to check other troubles

The following table provides a listing of other troubles, their possible causes and remedies.

The following table provides	a listing of other troubles, their possible causes and remedies.
Troubles	Causes and remedies
The motor runs in the wrong direction.	 Invert the phases of the output terminals U, V and W. Invert the forward/reverse run signal terminals of the external input device. ⇒ Refer to Section 7.2, Assignment of functions to control terminals.
The motor runs but its speed does not change normally.	 The load is too heavy. Reduce the load. Soft stall function is activated. Switch off soft stall function. ⇒ Refer to Section 5.14. The maximum frequency F H and the upper limit frequency UL are set too low. Increase the maximum frequency F H and the upper limit frequency UL. The frequency setting signal is too low. Check the signal set value, circuit, cables, etc. Check the setting characteristics (point 1 and point 2 settings) of the frequency setting signal parameters. ⇒ Refer to Section 7.3. The base frequency voltage 1 uLu is too low. If the motor runs at a low speed, check to see that the stall prevention function is activated because the torque boost amount (ub) and the acceleration time (R[[]). ⇒ Refer to Section 5.7 and 5.2.
The motor does not accelerate or decelerate smoothly.	•The acceleration time $(R \mathcal{E} \mathcal{E})$ or the deceleration time $(d \mathcal{E} \mathcal{E})$ is set too short. Increase the acceleration time $(R \mathcal{E})$ or the deceleration time $(d \mathcal{E})$.
A too large current flows into the motor.	•The load is too heavy. Reduce the load. •If the motor runs at a low speed, check whether the torque boost amount is too large. ⇒ Refer to Section 5.7.
The motor runs at a higher or lower speed than the specified one.	•The motor has improper voltage rating. Use a motor with a proper voltage rating. *The motor terminal voltage is too low. Check the setting of the base frequency voltage parameter (u L u). ⇒ Refer to Section 5.8. Change the cable for thicker one. •The reduction gear ratio, etc., is not set properly. Adjust the reduction gear ratio, etc. •The output frequency is not set correctly. Check the output frequency range. •Adjust the base frequency. ⇒ Refer to Section 5.8.
The motor speed varies during operation.	•The load is too heavy or too light. Reduce the load fluctuation. •The inverter or motor used does not have a rating large enough to drive the load. Use an inverter or motor with a rating large enough. •Check whether the frequency setting signal changes. •If the V/f control selection parameter P ₺ is set at ♂ or larger (5 and ₺ are removed.), check the vector control setting, operation conditions, etc. ⇒ Refer to Section 5.6.
Some or all of seven keys on operation panel don't work.	•Change panel operation prohibition parameter F 730~F 737. * Parameter is occasionally set for key operation prohibition mode. Cancel key
Access to parameter results in failure. Parameter settings cannot	To cancel the setting, press and hold down the ENTER key for 5 seconds or more.
be changed. Monitor (Display) is uncontrollable.	 (1)If parameter write protect selection parameter F 700 is set at 1 (prohibited), change the setting to 0 (allowed). (2)If there is an input terminal that is set for 110 (or 111) (parameter editing enabling) by input terminal function parameter, turn on the terminal.
anominaliane.	The chapming / by imput terminal function parameter, turn on the terminal.

How to cope with parameter setting-related problems

	3 1 1				
If you forget parameters	You can search for all reset parameters and change their settings.				
which have been reset	⇒ Refer to Section 5.21 for details.				
If you want to return all	You can return all parameters which have been reset to their default settings.				
reset parameters to their	⇒ Refer to Section 5.20 for details.				
respective default settings	Total to decition 3.20 for details.				

14. Inspection and maintenance

Warning



- The equipment must be inspected every day.
- If the equipment is not inspected and maintained, errors and malfunctions may not be discovered which could lead to accidents
- · Before inspection, perform the following steps.
 - (1) Shut off all input power to the inverter.
 - (2) Wait at least 15 minutes and check to make sure that the charge lamp is no longer lit.
 - (3) Use a tester that can measure DC voltages (800V DC or more), and check that the voltage to the DC main circuits (between PA/+ and PC/-) does not exceed 45V.

Performing an inspection without carrying out these steps first could lead to electric shock.

Be sure to inspect the inverter regularly and periodically to prevent it from breaking down because of the environment of use, such as temperature, humidity, dust and vibration, or deterioration of its components with aging.

14.1 Regular inspection

Electronic parts are easily affected by heat. Install the Inverter in a cool, well-ventilated, dust-free area for achieving the original performance for a prolonged amount of time in demonstrate its original performance for a long time. The purpose of regular inspections is to maintain the correct environment of use and to find any sign of failure or malfunction by comparing current operation data with past operation records.

Subject of	ln:	spection procedu	ıre	
inspection	Inspection item	Inspection cycle	Inspection method	Criteria for judgment
1.Indoor environment	Dust, temperature and gas Drooping of water and other liquid Room temperature	Occasionally Occasionally Occasionally	Visual check, check by means of a thermometer, smell check Visual check Check by means of a thermometer	Improve bad points. Check for any trace of water condensation. Max. temperature:60°C
2.Component parts and units	Vibration and noise	Occasionally	Tactile check of the cabinet	Is something unusual is found, open the door and check the transformer, reactors, contactors, relays, cooling fan, etc., inside. If necessary, stop the operation.
3.Operation data (output side)	Load current Voltage (*)	Occasionally Occasionally	Moving-iron type AC ammeter Rectifier type AC voltmeter	To be within the rated current, voltage and temperature. No significant difference from data collected in a normal state.

^{*:} The voltage measured may slightly vary from voltmeter to voltmeter. When measuring the voltage, always take readings from the same circuit tester or voltmeter.

■ Check points

- 1. Something unusual in the installation environment
- 2. Something unusual in the cooling system
- 3. Unusual vibration or noise
- 4. Overheating or discoloration
- 5. Unusual odor
- 6. Unusual motor vibration, noise or overheating
- 7. Adhesion or accumulation of foreign substances (conductive substances)

■ Cautions about cleaning

To clean the inverter, wipe dirt off only its surface with a soft cloth but do not try to remove dirt or stains from any other part. If stubborn stains persist, remove them by wiping gently with a cloth dampened with neutral detergent or ethanol.

Never use any of the chemicals in the table below; the use of any of them may damage or peel the coating away from molded parts (such as plastic covers and units) of the inverter.

Acetone	Ethylene chloride	Tetrachloroethane
Benzen	Ethyl acetate	Trichloroethylene
Chloroform	Glycerin	Xylene

Make a periodical inspection at intervals of 3 or 6 months depending on the operating conditions.

\triangle

Warning



· Before inspection, perform the following steps.

(1) Shut off all input power to the inverter.

(2) Wait at least 15 minutes and check to make sure that the charge lamp is no longer lit.
(3) Use a tester that can measure DC voltages (800VDC or more), and check that the voltage to the DC

main circuits (between PA/+ and PC/-) does not exceed 45V.

Performing an inspection without carrying out these steps first could lead to electric shock.




Never replace any part.

This could be a cause of electric shock, fire and bodily injury. To replace parts, call the local sales agency.

■ Check items

- Check to see if all screwed terminals are tightened firmly. If any screw is found loose, tighten it again with a screwdriver.
- Check to see if all caulked terminals are fixed properly. Check them visually to see that there is no trace of overheating around any of them.
- 3. Check all cables and wires for damage. Check them visually.
- 4. Clean up dust and soil. With a vacuum cleaner, remove dirt and dust. When cleaning, clean the vents and the printed circuit boards. Always keep them clean to prevent a damage due to dirt or dust.
- 5. If no power is supplied to the inverter for a long time, the performance of its large-capacity electrolytic capacitor declines. When leaving the inverter unused for a long time, supply it with electricity once every two years, for 5 hours or more each, to check the operation of the inverter. Supply electricity for at least 5 hours with the motor disconnected. It is advisable not to supply the commercial power directly to the inverter but to gradually increase the power supply voltage with a transformer.
- 6. If insulation test is needed, conduct it for the main circuit terminal board using a 500V insulation resistance tester only. Never conduct an insulation test on control terminals other than terminals on the printed circuit board or on control terminals. When testing the motor for insulation performance, separate it from the inverter in advance by disconnecting the cables from the inverter output terminals U, V and W. When conducting an insulation test on peripheral circuits other than the motor circuit, disconnect all cables from the inverter so that no voltage is applied to the inverter during the test.

Note: Before an insulation test, always disconnect all cables from the main circuit terminal board and test the inverter separately from other equipment.



- 7. Never test the inverter for pressure. A pressure test may cause damage to its components.
- 8. Voltage and temperature check

Recommended voltmeter

Input side ... Moving-iron type voltmeter (
Output side ... Rectifier type voltmeter (

It will be very helpful for detecting a defect if you always measure and record the ambient temperature before, during and after the operation.

14

■ Replacement of expendable parts


The inverter is composed of a large number of electronic parts including semiconductor devices. The following parts deteriorate with the passage of time because of their composition or physical properties. The use of aged or deteriorated parts leads to degradation in the performance or a breakdown of the inverter. To avoid such trouble, the inverter should be checked periodically.

Note: Generally, the life of a part depends on the ambient temperature and the conditions of use. The life spans listed below are applicable to parts when used under normal environmental conditions.

1) Cooling fan

The fan, which cools down heat-generating parts, has a service life of about 30,000 hours (about 7 years) (average ambient temperature: 40°C, operation time: 12 hours per day). The fan also needs to be replaced if it makes a noise or vibrates abnormally.

Remove the portion A and then portion B in the following figure to remove the cooling fan.



2) Smoothing capacitor

The smoothing aluminum electrolytic capacitor in the main circuit DC section degrades in performance because of ripple currents, etc. The smoothing aluminum electrolytic capacitor in the main circuit DC section degrades in performance because of ripple currents, etc. It becomes necessary to replace the capacitor after it is used for about 5 years under normal conditions (average ambient temperature: 40°C, load factor: not more than 80%, operation time: 12 hours per day). For the inverter that applicable motor output is 15kW (200V)-18.5kW (400V) or less, replace the capacitor together with the printed circuit board.

<Criteria for appearance check>

- · Absence of liquid leak
- · Safety valve in the depressed position
- Measurement of electrostatic capacitance and insulation resistance

Note: When it becomes necessary to replace expendable parts, contact your supplier. For safety's sake, never replace any part on your own.

By checking the cumulative operating time and the part replacement alarm information, you can get a rough idea of when each part should be replaced. For the replacement of parts, contact the service network or your supplier. (Operation hours can be known by alarm output, if it is set. For more details, refer to Section 6.33.12.)

■ Standard replacement cycles of principal parts

The table below provides a listing of the replacement cycles of parts when used under normal conditions (average ambient temperature: 40°C, load factor: not more than 80%, operation time: 12 hours per day). The replacement cycle of each part does not mean its service life but the number of years over which its failure rate does not increase significantly.

Part name		Standard replacement cycle	Replacement mode and others
	(200V/55kW models and 400V/90kW models or smaller)	5 years	Replacement with a new one
Cooling fan	(200V/75kW models and	5 years (Inside air cooling fan)	Replacement with a new one
	400V/110kW models or larger)	10 years (Outside air cooling fan)	
Smoothing capa	acitor	5 years	Replace with a new one (depending on the check results)
Circuit breaker and relays		-	Whether to replace or not depends on the check results
Aluminum capacitor on printed circuit board		5 years	Replace with a new circuit board (depending on the check results)

Note: The life of a part greatly varies depending on the environment of use. Do not install in any location where there are large amounts of dust, metallic fragments and oil mist.

14.3 Making a call for servicing

For the Toshiba service network, refer to the back cover of this instruction manual. If defective conditions are encountered, please contact the Toshiba service section in charge via your Toshiba dealer.

When making a call for servicing, please inform us of the contents of the rating label on the right panel of the inverter, the presence or absence of optional devices, etc., in addition to the details of the failure.

14.4 Keeping the inverter in storage

Take the following precautions when keeping the inverter in storage temporarily or for a long period of time.

- Store the inverter in a well-ventilated place away from heat, damp, dust and metal powder. (storage temperature:-25~+70°C)
- If no power is supplied to the inverter for a long time, the performance of its large-capacity electrolytic capacitor declines.

When leaving the inverter unused for a long time, supply it with electricity once every two years, for 5 hours or more each, to recover the performance of the large-capacity electrolytic capacitor. And also check the function of the inverter. It is advisable not to supply the commercial power directly to the inverter but to gradually increase the power supply voltage with a transformer, etc.

15. Warranty

Any part of the inverter that proves defective will be repaired and adjusted free of charge under the following conditions:

- 1. This warranty applies only to the inverter main unit.
- 2. Any part of the inverter which fails or is damaged under normal use within twelve months from the date of delivery shall be repaired free of charge.
- For the following kinds of failure or damage, the repair cost shall be borne by the customer even within the warranty period.
 - Failure or damage caused by improper or incorrect use or handling, or unauthorized repair or modification of the inverter
 - · Failure or damage caused by the inverter falling or an accident during transportation after the purchase
 - Failure or damage caused by fire, salty water or wind, corrosive gas, earthquake, storm or flood, lightning, abnormal voltage supply, or other natural disasters
 - Failure or damage caused by the use of the inverter for any purpose or application other than the intended one
- 4. All expenses incurred by Toshiba for on-site services shall be charged to the customer, unless a service contract is signed beforehand between the customer and Toshiba, in which case the service contract has priority over this warranty.

16. Disposal of the inverter



 For safety's sake, do not dispose of the disused inverter yourself but ask an industrial waste disposal agent (*).

If the collection, transport and disposal of industrial waste is done by someone who is not licensed for that job, it is a punishable violation of the law. (Laws in regard to cleaning and processing of waste materials)

(*) Persons who specialize in the processing of waste and known as "industrial waste product collectors and transporters" or "industrial waste disposal persons."

When disposing a used inverter, pay heed to the following points.

Blasting during incineration: There is a danger that electrolytic condensers used in the inverter may burst if it is

burnt in an incinerator, because electrolyte inside the condenser expands with heat.

Be careful of blasting of electrolytic condensers.

Plastics: Plastics used as covers of the inverter and so on generate poisonous gas when the inverter burnt. When burning the inverter, be careful of such poisonous gas.

Disposing manner: Be sure to dispose the inverter properly as an industrial waste.



TOSHIBA INTERNATIONAL CORPORATION

13131 West Little York RD., Houston, TX 77041, U.S.A

TEL: +1-713-466-0277 FAX: +1-713-896-5226

TOSHIBA ASIA PACIFIC PTE., LTD

152 Beach Rd., #16-00 Gateway East, Singapore 189721 TEL: +65-6297-0900 FAX: +65-6297-5510

TOSHIBA CHINA CO., LTD

23rd Floor, HSBC Tower, 101 Yin Cheng East Road, Pudong New Area, Shanghai 200120, The People's Republic of China TEL: +86-(0)21-6841-5666 FAX: +86-(0)21-6841-1161

TOSHIBA INTERNATIONAL CORPORATION PTY., LTD

2 Morton Street Parramatta, NSW2150, Australia TEL: +61-(0)2-9768-6600

FAX: +61-(0)2-9890-7542

TOSHIBA INFORMATION, INDUSTRIAL AND POWER SYSTEMS TAIWAN CORP.

6F, No66, Sec1 Shin Sheng N.RD, Taipei, Taiwan TEL: +886-(0)2-2581-3639 FAX: +886-(0)2-2581-3631



E6581301REV04

• For further information, please contact your nearest Toshiba Liaison Representative or International Operations - Producer Goods.

●The data given in this manual are subject to change without notice. 2008-12