



ABB DRIVES

UL Type 1 kit for ACS380, ACH480 and ACS480 drives frames R0 to R2

Installation guide



3AXD50000235254 Rev G EN 2023-02-22
Original instructions.



M4x10 Pozidriv, 2 pcs.

PT K40x8 Pozidriv, 2 pcs.

M3x14 Phillips/
Slot, 1 pc.

* = Also for ACS530, ACS560 or similar.

** = Insert plastic plugs into unused conduit plate holes. Plastic plugs are included in the delivery.

*** = Make two holes for the wall/base fastening (if not yet done). The fastening screws are user-defined. They are not included in the delivery.

1

ACS380

ACS380

ACS480/
ACH480*

ACS480/
ACH480*

2

3

ACS380


ACS380




ACS480/
ACH480*

ACS480/
ACH480*

ACS380 with
BAPO-01 (option +L534) or
BTAC-02 (option +L535) or
BREL-01 (option +L511)

ACS480 / ACH480* with
BAPO-01 (option +L534) or
BREL-01 (option +L511)



-  M4x10 Pozidriv, 2 pcs.
-  PT K40x8 Pozidriv, 2 pcs
-  M3x14 Phillips/
Slot, 1 pc.

* = Also for ACS530, ACS560 or similar.
** = Insert plastic plugs into unused conduit
plate holes. Plastic plugs are included in the de-
livery.
*** = Make two holes for the wall/base fastening
(if not yet done). The fastening screws are user-
defined. They are not included in the delivery.


© 2023 ABB. All Rights Reserved.




3AXD50000235254G

1


ACS380




ACS380




ACS480/
ACH480*





ACS480/
ACH480*





2
































3




ACS380



ACS380



ACS480/
ACH480*



ACS480/
ACH480*

