

131B3449

FC-102P18KT4E55H1XGXXXXSXXXXAXBXCXXXXDX

FC-102P18KT4E55H1XGXXXXSXXXXAXBXCXXXXDX

Frequency Converter
FC-102P18KT4E55H1XGXXXXSXXXXAXBXCXXXXDX
VLT® HVAC Drive FC-102
(P18K) 18.5 KW / 25 HP, Three phase
380 - 480 VAC, IP55 / Type 12
(H1) RFI Class A1/B (C1)
No brake chopper
Graphical Loc. Cont. Panel
Not coated PCB, No Mains Option
Latest release std. SW.
No A Option, No B Option
No C1 option, No D option
Frame: B1
Other options according to Model Code

Model code: FC-102P18KT4E55H1XGXXXXSXXXXAXBXCXXXXDX

Danfoss Drive is dedicated to ventilation, heating, and refrigeration applications. With a wide range of powerful standard and optional features, the Drive provides the lowest overall cost of ownership.

View Efficiency Data

PRODUCT DETAILS

Gross weight		22.39 kg
Net weight		21.44 kg
Volume		144.67 l
EAN		5702427174931
Sales restriction control		
Matr grp for sales restriction	0001	No grouping
VLT® HVAC DRIVE FC 100 SERIES		
Product View (Switch)	GLBL	Global (Standard)
Product Group	FC-	VLT® HVAC Drive FC-
Series	102	102
Power Rating	P18K	(P18K) 18.5 KW / 25 HP
Phase	T	Three phase
Mains Voltage	4	380 - 480 VAC
Enclosure	E55	IP55 / Type 12
RFI Filter	H1	(H1) RFI Class A1/B (C1)
Brake - Safe Stop	X	No brake chopper
LCP	G	Graphical Loc. Cont. Panel
Coating PCB	X	Not coated PCB
Mains Option	X	No Mains Option
Adaptation A	X	Standard Cable Entries
Adaptation B	X	No adaptation
Software Release	SXXX	Latest release std. SW.
Software Language Pack	X	Standard Language Pack

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

PRODUCT DETAILS

A Option	AX	No A Option
B Option	BX	No B Option
C0 Option MCO	CX	No C0 option
C1 Option	X	No C1 option
C Option Software	XX	No software option
D Option	DX	No D option
Frame Size	B1	B1
Product Catalog	NO_VIEW	NO VIEW
Typecode Part 1		FC-102P18KT4E55H1XGX
Typecode Part 2		XXXSXXXXAXBXCXXXXDX
Power 110% (NO) [KW]		18.5
Height [mm]		480,0
Width w/ no C options [mm]		242,0
Depth [mm]		260,0
Depth with Option A/B [mm]		260,0
kVA		26
Power Loss NO [W]		465
Power Loss NO [W]		465
Continuous Current (NO) [A]		37.5
Intermittent Current (NO) [A]		41.2
Continuous Current (NO) [A]		34
Intermittent Current (NO) [A]		37.4
Calculated Gross Weight [kg]		22.4
Calculated Net Weight [kg]		22.1
Material Gross Weight		22.39
Material Net Weight		21.44
Vendor	ERR01	Cannot Determine Vendor
Recommended Factory	ERR01	Cannot Determine Vendor
Modelcode01		FC-102P18KT4E55H1XGX
Modelcode02		XXXSXXXXAXBXCXXXXDX

For Documents, Software, Visuals and more information, please use this link to visit the product page on Danfoss Product Store

Accessories



130B3383

Back plate IP21/Type 1, IP55/Type 12, B1

FC 300 back cover for the devices in IP21 / 55 Housing size B1



130B4598

Weather shield f. outdoor instl A4 to B2

Weather shield for enclosure sizes A4, A5, B1, B2

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



130B7533

Mounting Kit C Option, B/C/D/E/F(not B3)

MCF105 C Option, Mounting Kit A2 and A3



130B5436

Side Fixture Mounting Kit

Side Fixture Mounting Kit for enclosure size A5 / B1 / B2 / C1 / C2
To be used when retrofitting the following MCA options:
MCA 120 Profinet
MCA 121 EtherNet
MCA 122 Modbus TCP
MCA 123 POWERLINK
MCA 124 EtherCAT
Product group: R1



130B5435

DIN Rail Mounting Kit



130B1170

LCP Panel Mounting Kit

The kit includes fasteners and gasket. No LCP and no cable included.



130B1387

5xMCB107 24VDC no coat w.out mount brack



130B1385

VLT® Profibus DP V1 MCA101, unctd 5pcs



130B1006

VLT® Motion Ctrl Tool MCT 10>100 lic.

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



130B1005

VLT® Motion Ctrl Tool MCT 10,100 lic.

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.



130B1004

VLT® Motion Ctrl Tool MCT 10,50 lic.

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.



130B1003

VLT® Motion Ctrl Tool MCT 10,25 lic.

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.



130B1002

VLT® Motion Ctrl Tool MCT 10,10 lic.

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.



130B1001

VLT® Motion Ctrl Tool MCT 10,5 lic.

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



130B1000

VLT® Motion Ctrl Tool MCT 10,1 lic.

An interactive tool for quick and easy online/offline configuration of a VLT® drive or soft starter using a PC. Configure communication networks and back up relevant parameter settings. Control and configure systems simultaneously and monitor entire system more effectively for faster monitoring, diagnosis, troubleshooting (alarms/warnings) and better preventive maintenance.



130B1135

VLT® PROFINET MCA 120, UNCOATED

MCA 120 PROFINET interface
-Supports operation on PROFINET network with extensive properties
-DCP support for easy setting u. Communication parameters via the PLC
- On Board web-Page with Drive Status
- Parameterization with the MCT10 software
- 2 port version, reduced external hardware



130B1125

VLT® General Purpose I/O MCB 101,unctd

MCB 101 - Advanced I / O option
Expands the number of freely programmable Control inputs and outputs around the following I / Os:
- 3 digital inputs opto-decoupled 0 - 24 V.
- 2 analog inputs 0 - 10 V.
- 2 digital outputs NPN / PNP switchable 24 V
- 1 analog output 0/4 - 20 mA



130B1124

VLT® Control Panel LCP 101, numeric

Numerical control unit for FC 100 and FC 300. Allows access to all device parameters.
Quick menu for brief commissioning. Manual / auto switchover and alarm acknowledgment.



130B1117

LCP Mounting Kit, w/ no LCP

The kit includes fasteners, 3m cable and gasket - There is no LCP included.



130B1110

VLT® Relay Option MCB 105, uncoated

Relay extension for FC 100 and FC 300. Extension with 3 additional load relays (changeover contacts), easy to retrofit thanks to modular technology.
Max. Load 240V AC (resistive): 2 A
Max. Load 240V AC (Cos Phi 0.4): 0.2 A
Max. Load 24V DC (ohmic): 1 A
Max. Load 24V DC (inductive): 0.1 A

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



130B1155

USB extension Cable, 350mm

USB extension kit for FC 300 cable length: 350mm for the housing size:
B2, C1 and C2 screw connection M 25



130B1143

VLT® Analog I/O Option MCB 109, unctd

I / O expansion for FC 100, through modular technology easy to retrofit. Analog inputs/outputs galvanically isolated.
Expands the analog inputs / outputs by:
3 analog inputs: 0 ... 10V / Pt1000 / Ni1000
3 analog outputs: 0 ... 10V
Time switch (RTC backup): lithium cell for 10 years



130B1081

Mounting Brackets, B1

Mounting brackets for enclosure size B1



130B1077

Blindcover, w/ Danfoss logo, IP55/66

LCP Blindcover IP66



130B1071

6 Pole Connector, FC series,10 pcs

6-pole spring cage connectors 10 pcs



130B1070

RS485 plug, FC series,10 pcs

10pcs RS485 connectors for FC-series.
Product group: R



130B1108

VLT® 24V DC Supply MCB 107, uncoated

Connect an external DC supply to keep the control section and any installed option alive during power failure. Enables full operation of the LCP (including the parameter setting) and all installed options without connection to mains.



130B1102

VLT® DeviceNet MCA 104, uncoated

Robust, efficient data handling thanks to advanced Producer/Consumer technology. ODVA's strong conformance testing policies ensure products are interoperable, and the AC-drive profile, supported using I/O instance 20/70.21/71, secures compatibility to existing systems.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



130B1100

VLT® Profibus DP V1 MCA 101

Provides wide compatibility, a high level of availability, support for all major PLC vendors and compatibility with future versions. Fast, efficient communication, transparent installation, advanced diagnosis and parameterization and auto-configuration of process data using GSD-file. Acyclic parameterization using PROFIBUS DP-V1, ¬PROFIdrive or Danfoss FC profile state machines, PROFIBUS DP-V1, Master Class 1 and 2.



175Z0929

LCP Cable, 3m

Cable for control panel (LCP), 3 meters
Works with the following LCP:
Alphanumeric control panel LCP3 - 175N0131
VLT® LCP 102 Graphic Display - 130B1107
VLT® LCP 101 Numeric Display - 130B1124
VLT® LCP 102 Graphic display IP66 - 130B1078
Product group: F1

Image coming soon

175U0009

Mounting bracket Kit, 216 x 30 x 18mm

Mounting angle for flatpack resistor 200W



175N2584

VLT® EtherNet/IP Modbus TCP gateway

Image coming soon

134B6302

VLT MCT 10 Software Customizer, 1 key

the commissioning experience of the VLT® to best fit your needs. It is a strong tool that enables you to quickly create your setup and test it first to MCT 10 using the simulator before uploading it to a real drive. local Danfoss Drives representative to order the required license(s).
Customize your commissioning experience
As the name suggests, VLT® Software Customizer allows you to customize
Note that the Advanced MCT 10 license is needed, please contact the

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



134B5925

Pressure Transmitter

VLT PTU 025 pressure transmitter unit
for external attachment to frequency converters
VLT HVAC Drive FC-102 IP55 / IP66 on one
the cable entries suitable for M25
- with four pressure sensors 2x 0-500 Pa;
1x 0-1000 Pa; 1x 0-2500 Pa
- eight hose connections D 5mm
- Can be positioned 360 ° around the longitudinal axis
Software version of the frequency converter FC-102
at least 5.20 am required
Mounting thread: M25
Dimensions LxW: 155mm x 38mm
(Length with hose support rail 260.5mm)
Degree of protection: IP66

Image coming soon

134B5225

Remote LCP unit, 10m

Remote mounting kit for LCP with cover for outdoor mounting with 10 m (33 ft) cable

Image coming soon

134B5224

Remote LCP unit, 5m

Remote mounting kit for LCP with cover for outdoor mounting with 5 m (16 ft) cable



134B5223

Remote LCP unit, 3m

Remote mounting kit for LCP with cover for outdoor mounting with 3 m (10 ft) cable

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories



134B0460

LCP 103 Wireless Communication Panel

With VLT® Wireless Communication Panel LCP 103 you can communicate with MyDrive® Connect - an app that can be downloaded for iOS and Android based smartphones. MyDrive® Connect makes commissioning easy, monitor and maintain tasks on your frequency converter. VLT® Wireless Communication Panel LCP 103 shows the current status of the drive (On, Warning, Alarm, Wifi connection) via built-in LED. Detailed information is also available using MyDrive® Connect. Here do you have access to i.a. status, menu and alerts. You can also see graphs over the latest available data.
The new VLT® Wireless Communication Panel LCP 103 allows you to wireless communication to the following drives:
- VLT® HVAC Drive FC 102
- VLT® Refrigeration Drive FC 103
- VLT® AQUA Drive FC 202
- VLT® AutomationDrive FC 302
[!] Note!
LCP 103 only works on frequency converters produced in 2018 (White USB stik).
Product group: R1

Image coming soon

134B1992

Control Terminals w/ screw connections



130B1106

VLT® LonWorks MCA 108, uncoated

Developed for building automation, it enables communication between individual units in the same system (peer-to-peer) and supports decentralizing of control. No need for main station (master-follower). Units receive signals directly. Supports Echelon free-topology interface (flexible cabling and installation) and embedded I/Os and I/O options (easy implementation of decentral I/Os). Sensor signals can quickly be moved to another controller using bus cables. Certified as compliant with LonMark ver. 3.4 specifications.



130B1144

VLT® BACnet MCA 109, uncoated

Open communication protocol dedicated to building automation
- Efficient integration of all parts of building automation equipment
- BACnet: standard for building automation worldwide
- International standard ISO 16484-5
- can be used in all sizes of building automation systems
- the Drive communicates easily with construction management systems running the BACnet protocol
- can be easily integrated into the network of existing control equipment
Product group: R1

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

Image coming soon

134B7093
VLT C-option Adapter MCF 107



130B0295
Accessory bag with control card plugs

Image coming soon

134B1985
Accessory bag for smooth cable entry B1



134B1586
VLT® BACNET/IP MCA125
The VLT® BACnet/IP MCA 125 option is a plug-and-play solution that optimizes the use of VLT® HVAC Drive together with building management systems using the BACnet/IP protocol or running BACnet on Ethernet. The embedded three-port managed switch of the VLT® BACnet/IP MCA 125 option comprises two external and one internal Ethernet port. This switch allows the use of line structure for the Ethernet cabling. In modern installation this is becoming increasingly attractive

Image coming soon

130B4847
extension cable for lcp+communication



134B8492
Transducer 0-10g, 4-20mA; HS-22B50



134B8493
CBM Transducer 0-25mm/s RMS 4-20mA
CBM Transducer 0-25mm/s RMS 4-20mA



134B8494
Transducer w, temp 0-25mm/s RMS 4-20mA



134B8496
Cable assy 10m, straight socket connetc.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Accessories

Image coming soon

134B8497
Cable assy, M12 female connec.10m screen

Spare Parts

Image coming soon

612Z1182
fuse,4a,3 x 32mm,super fast



130B3377
RFI unit 200/500V adv. A1/B for frame B1
RFI unit 200/500V adv. A1/B for frame B1



130B9001
multiple 2 pole power combicon, 24V plug



130B0264
Cradle for A5,B1,B2,C1,C2,D2h enclosure
cradle for LCP cradle for a5, b1,b2,c1,



130B0295
Accessory bag with control card plugs



130B1077
Blindcover, w/ Danfoss logo, IP55/66
LCP Blindcover IP66



130B1069
Multiple relay 1 plug
spare, 3 pole connector, relay 1, fc300



130B1068
Multiple relay 2 plug
spare, 3 pole connector, relay 2, fc300

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts



130B1061

DCcoil 18,5kW T4/6/7 for frame B1 and B2



130B1107

VLT® Control Panel LCP 102

Graphic operating unit LCP102 Illuminated graphic display with plain text. Supports all languages and characters. Quick menu for brief commissioning.Saving and copying parameter sets.Online help for each function



130B1822

Power Card 18kW 400V



134B1730

Control Card w/o safe stop for FC-102

Note: The MKII control cards are backward compatible to the old cards but will only work with SW equal or higher than 5.21. If your drive has a customer specific software or a brand labeled software version please order the old control card MKI PN: 130B1151.

Image coming soon

134B1986

Accessory bag for smooth cable entry B2

Accessory bag for smooth cable entry B2

Image coming soon

134B1985

Accessory bag for smooth cable entry B1



134B5920

cable jumper 20 pole for frame size B1



134B7130

Gasket for cable entry, frame B1 and B2

Image coming soon

134B7132

External fan for frame size B1

Note: Old material number 130B3407

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts

Image coming soon

134B7134
Coated internal fan frame size B1 & B2
Note: Old material number 130B3441



134B7135
Busbar insulation foil for frame size B1

134B7139
mylarfolie to dc-link card
mylarfolie to dc-link card



134B7173
Busbar assembly for frame size B1



134B7172
Gasket for local control panel IP55/66



134B7194
3-pole Terminal Block



134B7178
24 pole 3 connector jumper for C option
24 pole 3 connector jumper for C option

Image coming soon

134B7057
Screws 12 pcs 640f0774 cover B1 B2 C1 C2



134B5475
cable jumper 44 pole for frame size B1
cable jumper 44 pole for frame size B1

Image coming soon

134B5998
24 pole jumper/2 connector jumper

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Spare Parts



134B7346

Plastic front cover assembly B1



134B7466

Option A Ethernet Package

Services



131F3243

FC-102P18KT4E55H1UGCXXXSXXXXAXBXCXXXXDX

Frequency Converter
FC-102P18KT4E55H1UGCXXXSXXXXAXBXCXXXXDX
VLT® HVAC Drive FC-102
(P18K) 18.5 KW / 25 HP, Three phase
380 - 480 VAC, IP55 / Type 12
(H1) RFI Class A1/B (C1)
Brake chopper + Safe stop
Graphical Loc. Cont. Panel
Coated PCB, No Mains Option
Latest release std. SW.
No A Option, No B Option
No C1 option, No D option
Frame: B1
Other options according to Model Code

Model code: FC-102P18KT4E55H1UGCXXXSXXXXAXBXCXXXXDX

Danfoss Drive is dedicated to ventilation, heating, and refrigeration applications. With a wide range of powerful standard and optional features, the Drive provides the lowest overall cost of ownership.



130R1131

DrivePro ExWarr Work Shop PG04 30 months

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services



130R1134

DrivePro ExWarr Work Shop PG04 48 months

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1135

DrivePro ExWarr Work Shop PG04 54 months

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1137

DrivePro ExWarr Work Shop PG04 66 months

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1138

DrivePro ExWarr Work Shop PG04 72 months

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1136

DrivePro ExWarr Work Shop PG04 60 months

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1130

DrivePro ExWarr Work Shop PG04 24 months

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services



130R1132

DrivePro ExWarr Work Shop PG04 36 months

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1133

DrivePro ExWarr Work Shop PG04 42 months

DrivePro® Standard Extended Warranty provides repair at a Danfoss Drives workshop, or shipment of a replacement product to the site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1034

DrivePro ExWarr Onsite PG04 48 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1031

DrivePro ExWarr Onsite PG04 30 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1032

DrivePro ExWarr Onsite PG04 36 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1035

DrivePro ExWarr Onsite PG04 54 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services



130R1033

DrivePro ExWarr Onsite PG04 42 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1030

DrivePro ExWarr Onsite PG04 24 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1038

DrivePro ExWarr Onsite PG04 72 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1036

DrivePro ExWarr Onsite PG04 60 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.



130R1037

DrivePro ExWarr Onsite PG04 66 months

DrivePro® On-site Extended Warranty provides repair at the customer site, or replacement at the customer site.
You can only order DrivePro® Extended Warranty when purchased with a new drive. For drives previously shipped or purchased; contact your local Danfoss Drives sales office for extended warranty contract options.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services



130R1303

DrivePro Start-Up unit pre-order small

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.
The following benefits can be gained:
• Installation is checked to ensure it complies to Danfoss guide lines.
• The AC drive is fine-tuned specific to the application, ensuring optimal performance.
• Maximum energy savings to the Customer.
• Extend the AC drive's lifespan.
• Report detailing findings.
Before DrivePro® Start-up can be implemented, the AC drive must be installed and
ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.



130R1324

DrivePro SU + ctr interface test A,B & C

DrivePro Start-Up Control interface testing small frame unit



130R1321

DrivePro SU + spec. applications A,B & C

DrivePro Start-Up special applications small frame unit



130R1313

DrivePro Start-Up 1 day on-demand small

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.
The following benefits can be gained:
• Installation is checked to ensure it complies to Danfoss guide lines.
• The AC drive is fine-tuned specific to the application, ensuring optimal performance.
• Maximum energy savings to the Customer.
• Extend the AC drive's lifespan.
• Report detailing findings.
Before DrivePro® Start-up can be implemented, the AC drive must be installed and
ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services



130R1312

DrivePro Start-Up 1 Day Pre-order small

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.
The following benefits can be gained:
• Installation is checked to ensure it complies to Danfoss guide lines.
• The AC drive is fine-tuned specific to the application, ensuring optimal performance.
• Maximum energy savings to the Customer.
• Extend the AC drive's lifespan.
• Report detailing findings.
Before DrivePro® Start-up can be implemented, the AC drive must be installed and
ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.



130R1304

DrivePro Start-Up unit on-demand small

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.
The following benefits can be gained:
• Installation is checked to ensure it complies to Danfoss guide lines.
• The AC drive is fine-tuned specific to the application, ensuring optimal performance.
• Maximum energy savings to the Customer.
• Extend the AC drive's lifespan.
• Report detailing findings.
Before DrivePro® Start-up can be implemented, the AC drive must be installed and
ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.

Services

Image coming soon

130R1380

DrivePro Start-Up ½ day pre-order small

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.
The following benefits can be gained:
• Installation is checked to ensure it complies to Danfoss guide lines.
• The AC drive is fine-tuned specific to the application, ensuring optimal performance.
• Maximum energy savings to the Customer.
• Extend the AC drive's lifespan.
• Report detailing findings.
Before DrivePro® Start-up can be implemented, the AC drive must be installed and
ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.
General Terms and Conditions of Delivery and Warranty apply.

Image coming soon

130R1381

DrivePro Start-up ½ day on-demand small

DrivePro® Start-up gives the Customer a full range of checks and adjustments during commissioning of the drive, ensuring their system is tuned for optimal performance right from day one.
The following benefits can be gained:
• Installation is checked to ensure it complies to Danfoss guide lines.
• The AC drive is fine-tuned specific to the application, ensuring optimal performance.
• Maximum energy savings to the Customer.
• Extend the AC drive's lifespan.
• Report detailing findings.
Before DrivePro® Start-up can be implemented, the AC drive must be installed and
ready for operation. The entire system must be fully operational under normal operation conditions. Installation of the drive is not included in this package. Commissioning needs to take place during the standard working hours.
General Terms and Conditions of Delivery and Warranty apply.

For more information, please use this link to visit the product page on Danfoss Product Store

Danfoss can accept no responsibility for possible errors in catalogs, brochures and other printed material. Danfoss reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub-sequential changes being necessary in specifications already agreed. All trademarks in this material are property of the respective companies. Danfoss and the Danfoss logotype are trademarks of Danfoss A/S. All rights reserved.