


RHMIF-02

English / Español / Português
Document: 10001126166 / 00



(*) HMI not included
HMI no incluido
HMI não incluída






NOTE! / ¡NOTA! / NOTA!

The 2 M3 x 5.8 spacers for securing the cable to the HMI are supplied with the inverter (included in control cable shielding kit).

Los 2 espaciadores M3 x 5.8 para la fijación del cable en la IHM son suministrados con el convertidor de frecuencia (incluido en el kit de puesta a tierra de los cables de control).

Os 2 espaçadores M3 x 5.8 para a fixação do cabo na HMI são fornecidos com o inversor (incluídos no kit de aterramento dos cabos de controle).



Dimensions/Dimensiones/Dimensões mm [in]